




PT-50DC

User's Guide


Read this manual carefully before starting and keep the manual in a handy place for future reference.

Printer Parts


Front





Profile




Rear



Confirm the Packing List



Display Status



Wireless Communication/Bluetooth

Sign of connected through bluetooth.

USB Mode

Sign of connected through USB.

Setting Mode

Indicates the printer is in setting mode.

Unlock State

Indicates the print head is unlocked.

Out of Paper State

Out of Paper Error. When paper is run out or loaded incorrectly, this sign will be indicated.

External Power Supply Indicator

Indicates an external power supply is connected. When inserting the external power supply, it appears. By taking out the external power supply, it disappears.

Battery Level

While charging this sign flashes. Please charge up at low battery.


Text Area

The area shows some text information.

Before Using

Note

Make sure you fully charge the battery before you first using PT-50DC. In order to ensure the best effect of the battery, please charge it fully when it is not in use for long.



Battery

Steps before using, including ribbon loading, battery charging and paper placing.




Label paper

Battery Charging

Insert the AC adapter plug into the electrical outlet, while inserting the DC adapter plug into the DC connector of the printer.

AC:100V~240V(50-60HZ)

220V power supply




Warning

Please use the original adapter only, otherwise it may damage the printer.

Attention

The printer still works during charging. Don't remove the battery during charging.



Charging: The power indicator icon flashes

End of charge: The power indicator icon is full and stops flashing.


Label Roll Loading



PT-50DC label printer material:
width:12-52mm
the maximum diameter:50mm

Note

1.Use only PUTY tapes with this machine. Don't use tapes without PUTY mark.




- 2.Adjust the catch according to the label width and push the ribbon lock to the locked position.
- 3.Please close the cassette cover after installing the label.

■ Insert the label roll as shown (with the side to be printed on facing down)

Basic Functions

Turn On

Press and hold POWER button for 2 seconds to turn on the printer



Power Off

Press the POWER button for 2 seconds, to turn off the printer

Feed Paper

Press the FEED button, take a piece of paper.

Auto Power Off

The printer will turn off automatically after a standby period.

Setting

Initial Settings

You will enter the user's setting interface when the printer turns on.

POWER button:

Toggle Option Language



Language: English/中文

Press the FEED button to set the language of the operation interface

Toggle Option Shutdown Mode



Shutdown Mode

Press the FEED button to adjust the mode of shutdown: 10 minutes/20 minutes/30 minutes/never

Toggle Option Paper Type



Paper Type

Label Normal

Black Mark

Press the FEED button to adjust paper type. Black Mark and Label with re-calibration function

Toggle Option Automatic Calibration



Automatic calibration

Press the FEED button to automatically calibrate Black Mark and Label only

Toggle Option MAC Address



MAC address

Press the POWER button to show the MAC address of this printer

Toggle Option Print SelfTest



Print SelfTest

Press the FEED button to show the printer's information and the print test

Toggle Option Factory Settings



Restore factory settings

Press the FEED button to restore factory settings

Attention:

You can adjust the printer when you see this icon on the upper left screen.




1 POWER button: Short press to enter the setting interface after turning on.

2 FEED button: Press it to check that paper can be printed correctly by the printer. If not, make sure that it snaps into place.

Connecting Method


PT-50DC Bluetooth Connecting



NFC Transmission Connecting (Non-touch identification and interlinked technology)

If you use a smart phone equipped with NFC function, it will pair, match and connect automatically when approaching to the printer. The phone will load its special label APP automatically to prepare all the work before printing (it will pop up the app for downloading at the first time).

PC Connecting



Specification

Printing	
Print method	Thermal printing
output mode	Black and white
Print resolution	203dpi
Dots per line	384dot/line
Print speed	40mm/s
Standby time	500h
Connection mode	USB/Bluetooth/NFC
Positioning mode	Penetration
Printing instruction	LPAPI/Label
Printing contents	Text/Image/Line(JPG, BMP, TIF, JPEG and other types are available)
Barcode printing	1D/2D Barcode
Connection mode	Standard USB, Bluetooth (Android, IOS) , NFC
Printer	
Weight	300g(with battery)
Dimension	130 × 84 × 61(mm)
Temperature	-10 °C ~ 50 °C
Battery	
Type	Li-polymer
Voltage	7.4V
Electricity	1350mAh
Charger	
Input	AC 100-240V 50/60Hz 0.35A
Output	DC 9V/1A
Charge mode	Charging via USB to computer system or power adapter
Consumables	
Type	Continuous length/Die-cut length
Form	Roll
Specification	Max 52mm×50mm(width × diameter)
Thickness	0.05mm ~ 0.25mm

APP Printing

1. Download the APP: Scan the QR code to download the APP. Or use the smart phone equipped with NFC function to open its APP automatically when approaching to the NFC area of the printer




2.The Smart phone equipped with NFC function will open its APP automatically when approaching to the NFC area of the printer


3. When you open this APP and enter the user's interface, the Bluetooth will be connected automatically (you can also pair it manually)




4.Create a new label or load a template



5.Editing



6.Settings




Maintenance and Repair

Maintenance Instruction

1. While dusting the outside and paper compartment of the printer: Please wring out the wet cloth and wipe them gently.

2. While cleaning the print head: Please clean it occasionally which will help keep foreign matter from getting inside the printer.

You can easily clean it using the following methods:



3. If the printer gets soaked in water, please turn it off and remove the battery soon, leaving it in open air.

4. If the printer won't be used for a long time, please remove the battery and store it separately.

Usage and Storage of Printer Consumables

1. The unopened products should be stored in room temperature.
2. Please clean the surface of posted item, when sticking the printer consumables.

Problem	Possible causes	Remedy
When you hear the sound "DING" two times during a short break.	The battery may be weak.	Please charge it in time.
When the printer prints without data.	Install the wrong side.	Please insert it correctly.
	The printer has not been cleaned for a long time that the print head was polluted.	Please clean the print head.
	Poor printer consumables.	Please try to adjust the print density and the print quality. Please use PUTY original consumables.
When you hear the sound DING three times.	The print head is not locked tightly when printing.	Please lock the print head tightly.
The labels become faint even for few weeks.	Poor quality consumables.	Please use the original high quality labels and ribbons.
The power turns off when you try to print.	The battery has run out.	Please charge it soon.

Note: Do not use poor quality labels, otherwise it may cause damages to the print head.

Other Precautions

Installation and Handling of the Label Printer



- Avoid pressing backwards when the paper cover is opened to the maximum position.
- Insert the label roll under instructions and pass through the paper guide slot.
- Make sure the print head is in locked status before feeding and printing.
- The print head is a precise and vulnerable part. Please do not touch it with hands or sharp objects directly.
- Please use original power adapter only.

Cautions of the Print Head

- Be sure to disconnect the power of the printer before cleaning it.
- Please disconnect the power of the printer and wait for about 2 to 3 minutes before cleaning the print head.
- Do not touch the heating section of the print head while cleaning it, otherwise static electricity may damage it.
- Attention: Protect your print head from scratches and other damages.

3C Certification Standards

- The 3C Certificate, is China's mandatory product certification system. "CCC" is the abbreviation of "China Compulsory Certification", which is in PRC more commonly known as "3C Certification". In view of protecting the consumers and country and strengthening product's quality, the government of PRC applies this product quality standardization.
- This label printer and power adapter has been certified by PRC of China CCC.
- The User's Guide aims to help the user to use and maintain PT-50DC Label Printer. Some other products or company titles mentioned may be trademarks or registered trademarks of other companies, which we have applied here only for explanation, not involved in tort. All information in this Guide are prohibited to be used, copied or transferred by any company or individual without the formal written authorization of PUTY Technology.

Battery Recycling:

- This product uses rechargeable lithium battery. In order to protect the environment, please do not arbitrarily deal with used batteries.
- Be sure to dispose of used battery in accordance with the relevant regulations.



FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.