




Before using this product, carefully read and properly keep this manual.

YESOUL Bike

Model: YS-001
FCC ID: 2A3YB-YS-001
IC:30451-YS001



Please scan the QR code to watch the installation guide video.
Product model: YS-001
Item NO.: G1MMAX

YESOUL Smart Cycling Bike Product Manual

Installation Guide - List of Parts

NO.	Name	Quantity	Picture
⑫	Head tube	1	
⑬	Screen fixing part	1	
⑭	Bottle holder	1	
⑮	C to C data cable	1	
⑯	C to Lightning data cable	1	
⑰	One-piece hood	1	
⑱	Cross pan head screw with washer M4 × 10	8	
⑲	Cross recessed pan head screw M5 × 8	1	
⑳	Speaker holder	1	
㉑	Rear speaker connector	1	
㉒	Instructions	1	
㉓	Spare parts	1	


Installation Guide

3. After correctly aligning the hole position, use L-shaped hex wrench 5# (A) to screw the hexagonal socket head screw M6×12⑩⑪-4 and the hexagonal socket head screw (M6×35)⑪ into the holes and lock them. Next, tighten the hexagonal socket head screw (M6×12)⑪-2;
4. Finally, insert the monitor bracket ⑯ into the handle in the direction of the arrow (as shown in the picture).



STEP 5: Installation of one piece hood

1. Gently snap the one piece hood ⑰ onto the handlebar assembly ⑯;
2. Use L-type cross head hex wrench 6# (B) to screw the cross recessed pan head screw (M5×8) ⑯ into the cross recess.



Product Parameters

Screen size	21.5 inches (1920*1080 pixels)
Supporting software version	iOS 12.0 or higher, Android 5.1 or higher (inclusive)
Resistance system	Magnetron resistance system
Drive mode	Belt drive
Power supply input	24V= 3A
Wireless connection method	WiFi2.4GHz/BT/BLE
Bluetooth	Bike: V4.2, Speaker: V5.3 (Optional)
Height limit	140 ~ 195cm
Rated maximum load	120kg
Net weight	35kg
Gross weight	40.5kg
Overall dimensions	(Length) 1374mm × (Width) 528mm × (Height) 1429mm

Routine Maintenance

1. Keep the cycling bike on a dry, ventilated and flat floor. If not used in a long time, the bike should be covered to keep its body clean and tidy.
2. Wipe off sweat on the frame with cloth after exercise. Do not wipe the bike with wet cloth, in order to avoid rusting.
3. Adjust or replace the belt timely if the belt pulley is cracked and deviated. Regularly clean the belt groove to prevent the belt from jumping out of the groove.
4. Regularly check the screws of all body parts for loosening or falling, and tighten or replace them in time.
5. Regularly Check the resistance knob for looseness or dislodgement and reasonable resistance values so that the resistance value can be calibrated in time.
6. Regularly check if the screws between the pedals and the crank are loose. Tighten them promptly if necessary.
7. Regularly check if the saddle is loose. Tighten it promptly if necessary. Use a cotton cloth to wipe the saddle and keep it dry.
8. Regularly inspect the power cord for any cracks or damage, and replace it promptly if needed.

Monitor Parameters

Panel type	VA
Curvature	Flat screen
Proportion	16:9
Size	21.5 inches
Backlight type	LED
Display size (H*V)	476mm*268mm
Resolution	1920*1080
Refresh rate	Max:60Hz
Interface version	1*USB+Type-c+TTL+Audio out+DC IN
Indicator mode (power on, standby)	Blue light indicates power on, light turns off when power is off, and blinks every 0.5 seconds in standby mode.
Storage temperature	-20°C~60°C
Operating temperature	0°C~40°C
Operating humidity	10~90%RH
Storage humidity	10~90%RH
Control method	Five-way joystick buttons

Front Speaker Parameters (Optional)

Product Size	Front speaker: 498*72*82mm
Product weight	1080g

Note: After the speaker is installed and turned on for the first time, you need to double-click the button to pair.

Important Safety Instructions

Please read them carefully. Improper use may result in personal injury or death!

1. This product is for household use (Class H) and not medical fitness equipment.
2. This product must not be used for medical rehabilitation.
3. Keep children and pets away from this product. This product is for those over 16 years old only.
4. Do not place the equipment in damp or wet environments.
5. Never use this product with inappropriate shoes or barefoot.
6. Use this product on a flat and clean ground.
7. Lift the rear tube and the roller on the front tube can move the product freely or be placed in a suitable position.
8. If the product fails, immediately stop using it.
9. Check whether the bike for loosening or damage before each use.
10. Never stretch any object or body part into the openings of the bike.
11. When using the screen holder, ensure the device is centered to prevent it from falling off.
12. Never refit this bike or use non-original accessories without permission. The casing must be opened by professionals, in order to avoid damage.
13. Ensure all screws and bolts are securely tightened before use.
14. When not in use, turn the knob to the right end to lock the corresponding component.
15. Instructions for using the emergency brake: When you want to stop movement, press down on the emergency brake until it stops.
16. Never turn pedals by hand, or touch any rotating mechanical part, otherwise personal injury may be caused.
17. Get off the bike until flywheel/inertial wheel and pedals stop rotating. Otherwise, severe injuries may be caused due to control failure.
18. Wear professional cycling clothes or tight-fitting sportswear and sports shoes, and tighten foot straps to avoid injury caused by pulling or entanglement by this product.
19. The product should have at least 0.6 meters of free space all around it.
20. Incorrect or excessive training may cause injury.
21. Use this product according to the instructions in this manual. Warm up fully before exercise.
22. Keep the body hydrated as needed during riding.
23. Without the preliminary determination of baseline fitness level and medical certificate signed by a doctor, never be engaged in high-speed or high-intensity sports. Before attempting any high-intensity short sprints, pay attention to the body state and posture, and apply a controllable speed.
24. If you experience any discomfort while using the equipment, stop immediately and consult a doctor.
25. Those pregnant or with high blood pressure, heart disease, lumbar spondylosis or reduced mobility must not use this product without the permission of doctors.
26. The weight of the user must not exceed the maximum load.
27. Carry out preventive maintenance regularly.
28. Please use the standard power adapter. Replacement of the power adapter without authorization may cause serious consequences.

Installation Guide - List of Parts


STEP1: Check of parts

NO.	Name	Quantity	Picture
①	Frame	1	
②	Front tube	1	
③	Rear tube	1	
④	Pedal set left/right	1	
⑤	Handlebar assembly	1	
⑥	Monitor stand	1	
⑦	Front speaker	1	
⑧	Display screen	1	
⑨	24V=3A power adapter	1	
⑩	Hexagon socket head screw M6×35	1	
⑪	Hexagon socket head screw M6×12	4	


Installation Guide

STEP 4: Installation of handlebar assembly

1. Align the holes on the handlebar assembly ⑤ with the holes on the head tube ⑫. Take out the hexagon socket head screw (M6×12) ⑪-1-2. As shown in the figure, hand-tighten the screws 1-2 clockwise (do not fully tighten them yet) to temporarily hold them in place;



2. Insert the monitor stand ⑥ into the handlebar following the direction of the arrow.



Installation Guide - List of Parts


NO.	Name	Quantity	Picture
⑫	Accessories list (Tools list)	1	
A	L-shaped head six corner wrench 5#	1	
B	L-type cross head hex wrench 6#	1	
C	L-shaped head six corner wrench 5#	1	
D	Multi-function wrench	1	

*Some fixing screws are pre-locked on the corresponding parts at the factory. Please remove them before installing the corresponding parts during assembly. Spare parts are subject to actual conditions.


Installation Guide

STEP 2: Installation of bottom tube

1. Take L-type cross head hex wrench 6# (B) out of the ziplock bag; 2. Remove 4 hexagon socket button head screws (M8×45) and washers of the front tube ② and rear tube ③ via the L-type cross head hex wrench 6# (B);




3. Align the holes of the front tube ② and rear tube ③ with the holes at the bottom of the frame ①. Hand-thread the washers and hexagon socket pan head screws (M8×45) in sequence. Then, use the L-type cross head hex wrench 6# (B) to fully tighten them.




Installation Guide

3. Align the speaker assembly with the slot of the screen assembly and insert the buckle connection;



4. Loosen the hexagonal socket head screw (M8×16) pre-installed on the monitor stand ⑥ with an L-type cross head hex wrench 6#(B), and then remove the upper connecting seat;


5. Insert the screen and speaker components assembled in the previous step into the monitor stand ⑥, then put in the upper connecting seat and hexagonal socket head screw (M8×16) in sequence, and use an L-type cross head hex wrench 6#(B) lock until secure.




Installation Guide

STEP 3: Installation of head tube

1. Screw out the adjustment knob as indicated by the arrow, and connect the screen connection cable in the head tube ⑫ to the cable in the bike ① (as shown in the figure). After the screen connection cable is connected, align the head tube ⑫ to the mounting hole of the frame ① (Note: Place the surface with a hole in the head tube ⑫ outwards. Do not press the cable);




2. Insert the head tube ⑫ into the frame ①, and keep the scale parallel to the top surface of the tube. Align the hole on the head tube ⑫ with the hole on the frame ①. Then, tighten the adjustment knob as indicated by the arrow.



Installation Guide

STEP 7: Installation of bottle holder

As shown in the figure, remove the 2 hexagon socket head screw M6 pre-installed in the monitor stand ⑥, and align the bottle holder ⑯ with the slot in the monitor stand ⑥, and push it in along the direction shown in the figure. Then, use the L-shaped head six corner wrench 5#(A) to align 2 hexagon socket head screw M6 with the holes, and lock the bottle holder.



Installation Guide

STEP 5: Installation of one piece hood

1. After correctly aligning the hole position, use L-shaped hex wrench 5# (A) to screw the hexagonal socket head screw M6×12⑩⑪-3-4 and the hexagonal socket head screw (M6×35)⑪ into the holes and lock them. Next, tighten the hexagonal socket head screw (M6×12)⑪-2;

4. Finally, insert the monitor bracket ⑯ into the handle in the direction of the arrow (as shown in the picture).




STEP 6: Installation of one piece hood

1. Gently snap the one piece hood ⑰ onto the handlebar assembly

Installation Guide


STEP8: Installation of pedal

- Take the pedals out of the package;
- Distinguish between the left and right pedals. The right pedal is marked with a blue "R" and the left pedal is marked with a red "L". (Pay attention to distinguishing the left and right pedals. If they are installed incorrectly, the crank threads will be damaged!);
- Stand behind the seat and face the handlebar. Remove the nut pre-installed on the right pedal and install the right pedal to the right hand side on the crank, the foot pedal should be perpendicular to the crank installation opening. Use a multi-function wrench (D) to lock it by turning it towards the front of the bike. Then align the removed nut with the thread and use a multi-function wrench (D) to lock it towards the tail direction;
- Remove the nut pre-installed on the left pedal and install the left pedal to the left hand side on the crank, the foot pedal should be perpendicular to the crank installation opening. Use a multi-function wrench (D) to lock it by turning it towards the front of the bike. Then align the removed nut with the thread and use a multi-function wrench (D) to lock it towards the tail direction.
- Note: During installation, correspond the red mark on the crank to the blue mark on the pedal, and the blue mark on the crank to the blue mark on the pedal.



Multi-function wrench (D) (in the ziplock bag)


Note: Check whether the pedal straps are tightened before riding. Tighten them by pulling them down.



Safety tips:
Reverse riding is not recommended, as it is likely to loosen pedals. After reverse riding, check whether the pedals are locked, in order to avoid safety issues arising from loose pedals.

How to adjust the speakers -Optional

Audio function operation




	Project	Pre-Condition	Operation steps	Effect	Tone	LED
On/Off	Power On	/	Short press the power switch	Power On	Power sleep sound effect	Red LED always on
	Power Off	/	Press and hold the knob button for 3 seconds	Power off	Shutdown tone (Power off)	Red LED goes out
Sleep state	Power On	/	The speaker has no AUX signal or Bluetooth signal input for more than 10 mins	The speaker goes to sleep	/	Red LED goes out
Wake-up function	Sleep state	Sleep state	When clicking the knob button (power switch not switch mode), inputting audio signals, adjusting the volume, or connecting Bluetooth can wake up	Enter pre-wake state	/	Red LED always on
Control Function	Volume up	/	Turn the switch clockwise	The volume increases gradually as your rotation	Volume up to maximum with a tone (Tone)	/
	Volume down	/	Turn the switch anticlockwise	The volume decreases gradually as your rotation	/	/
Mode Switch	Power on	Short press the rotary switch	Switch AUX mode and Bluetooth mode	Switch to Bluetooth mode (Bluetooth pairing on)	Bluetooth mode red light	/
	Power on	Double click the knob button of the front and rear speakers to pair	Front and rear speakers combined to play music simultaneously	Front and rear speakers combined to play music simultaneously	Bluetooth mode	Red LED
TWS pairing	Front and rear speakers powered on	Double click the knob button of the front and rear speakers to pair	Front and rear speakers combined to play music simultaneously	Front and rear speakers combined to play music simultaneously	Bluetooth mode	Red LED
	Power on	Click the knob button to switch the mode to Bluetooth mode	Bluetooth device searches for "YESOUL Speaker" and connects, successful pairing	Bluetooth device searches for "YESOUL Speaker" and connects, successful pairing	Bluetooth mode	Red LED
Pairing function	Power on	Open the Bluetooth and Search on the other device	Close your device pairing function	1. Announcement tone (Disconnected)	Red LED	Red LED
	Power on	Cancel the pairing by the device	Cancel the pairing by the device	2. Speaker enter the pairing mode	Red LED	Red LED
Disconnected	Connected	Disconnect the Bluetooth connection by Device	1. Announcement tone (Disconnected)	Disconnect tone (Disconnected)	Red LED	Red LED
	Connected	Close your device pairing function	Close your device pairing function	2. Speaker enter the pairing mode	Red LED	Red LED
Reconnected	Disconnected	1. Connected with device. No device pairing successful after move the device out of the BT range	1. After move-distance disconnection, the speaker enters the pairing state and the device pairing successful	1. After move-distance disconnection, the speaker enters the pairing state and the device pairing successful	Red LED	Red LED
	Disconnected	2. After 10 mins, no device is connected and the speaker enters sleep state	2. After 10 mins, no device is connected and the speaker enters sleep state	2. After 10 mins, no device is connected and the speaker enters sleep state	Red LED	Red LED
Reconnected	Bluetooth mode (paired with device before)	Switch to bluetooth mode, speaker try to reconnect with the last device	If unable to reconnect within 10mins, enter sleep state	Reconnected successful with device	Red LED	Red LED
	Bluetooth mode (paired with device before)	1. Restore to the default boot state	1. AUX mode or Bluetooth mode, speaker try to reconnect with the last device	Recovery success tone (Connected)	Red LED	Red LED
Factory Reset (In AUX mode and Bluetooth mode)	Power On	1. AUX mode or Bluetooth mode, speaker try to reconnect with the last device	2. Clear Bluetooth connection records and pairing records, speaker try to reconnect with the last device	Recovery success tone (Connected)	Red LED	Red LED
	Power On	3. Enter the pairing state	Pairing record, volume restored to default value (maximum volume 50%)	Recovery success tone (Connected)	Red LED	Red LED
Factory Reset (In AUX mode and Bluetooth mode)	Power On	4. The rear camera enters the pairing state	4. The rear camera enters the pairing state	Recovery success tone (Connected)	Red LED	Red LED

Note: When your phone is connected to the speaker via Bluetooth and connected to wired screen projection, please switch the speaker to AUX mode.

About display interface

Display interface description:




Member screen mirroring connection

Installation Guide

STEP 9 : Installation of connection cable

- We recommend first insert the signal port (c) and power port (d) of the speaker into the jack at the bottom of the back of the monitor, then plug the power port (a) and signal port (b) of the monitor into the jack at the bottom of the back of the monitor. Be sure to plug them in tightly (Matching the colors and specifications of the sockets. Ensure that the power cord is properly inserted and securely fastened);
- Select the appropriate full-featured C to C data cable (which supports DisplayPort (DP) signal output) and insert it into the Type C jack under the monitor (Secure any excess wire with velcro);
- Connect the power adapter ⑨ to the power jack at the rear under the frame ①. The indicator light is always on (Please use the standard power adapter, unauthorized replacement of the power adapter may cause serious consequences).

Safety tips:
Reverse riding is not recommended, as it is likely to loosen pedals. After reverse riding, check whether the pedals are locked, in order to avoid safety issues arising from loose pedals.



Note: Check whether the pedal straps are tightened before riding. Tighten them by pulling them down.



Safety tips:
Reverse riding is not recommended, as it is likely to loosen pedals. After reverse riding, check whether the pedals are locked, in order to avoid safety issues arising from loose pedals.

Note: Do not plug or unplug the monitor's interface without cutting off the power supply. Please unplug the power when not in use.

Installation Guide (for reference only, subject to the actual product)

⚠ Safety tips:
Please adjust the back according to your physical condition before use; and tighten the body fastening knob.

Before the first use, please turn the resistance adjustment knob counterclockwise to loosen it; otherwise, you cannot ride the bike!

Resistance knob
(Please adjust the resistance appropriately according to your exercising needs. Press the knob to brake in an emergency.)

360 degrees of rotation angles of the screen, rotate 180 degrees clockwise/counter-clockwise (Here, the L-type cross head hex wrench 6# (B) can be used to tighten/loose).

Saddle tightening knob (Adjust the saddle position front to back)

Rear column tightening knob (Adjust the saddle height)


Front tightening knob (Adjust the head height)

Movable pulley

Precautions

Check screen

After the installation is complete, please check whether the screen will fall down when flipped up and down. If this happens, use an L-shaped head six corner wrench 8#(C) and an multi-function wrench (D) to tighten them as shown in the picture. (If there is any looseness during use or adjustments needed for the joints, you can adjust them according to this operation)



Statement:

This manual contains the functional introduction and operating instructions as much as possible when printed. With the continuous improvement of hardware and software and optimization of design, this manual may be inconsistent with the purchased product.

In case of any discrepancy in appearance, interface and color, the actual product shall prevail.


How to adjust the screen

Screen Adjustment:

- Press and hold the "OK key" button for 6 seconds to power off the phone, and for 1-2 seconds to power it on.
- The monitor is turned on, and when there is a screen projection signal, press the "OK key" button to activate the main menu.
- Use the Arrow key to navigate the main menu and select the desired item for adjustment. After selecting the item, press the "OK key" to adjust it. Press the "OK key" again to save changes and return to the upper-level menu.
- Press and hold the left shortcut key for 10 seconds to display the version number.
- After confirming the adjustment, move the joystick to the left to exit the current option.

Operations to close the data window during screen projection:


- Connect the screen projector and start projecting.
- Press the "OK key" button to enter the main menu.
- Scroll down using the remote to select "Settings," and then scroll right to enter the setting options.
- Scroll down using the remote to select "BikeOsd," and then scroll right to enter the "BikeOsd" setting interface.
- Select "OFF," and press the "OK key" button to confirm the option.
- Continuously scroll left three times using the remote to exit the main menu.



APP usage instructions

APP installation registration


You can scan the QR code below to download the APP and register an APP account.



1. Scan the QR code and download the APP 2. Enter the APP login page 3. Register an APP account

Connect devices

When using for the first time, click the '+' in the upper right corner of the 'Home' or enter the course and connect the device according to the interface prompts.



4. Enter the APP homepage

For subsequent use, just step on the device and open the sports mode or course of the APP to automatically connect.

The device does not support simultaneous connection of multiple mobile phones. Please confirm that no other users are connected to the device at this time before use.

After shutting down, Bluetooth will be automatically disconnected.

In addition to connecting with YESOUL FITNESS APP, Bluetooth can also be connected with Kinomap and Zwift software.



About wired projection screen

Installation instructions for wired screen projection:

1. Take out the data cable.


Note: There are two data cables for Android and iOS included in the package.

Please use the appropriate one according to your phone model;

2. Connect the Type-C interface of the data cable to the screen;

3. Connect the Type-C or Lightning interface of the data cable to the phone.


Note: Android phones need to support DisplayPort (DP) signal output in order to use the wired screen projection function normally.



IOS:



Android:



Screen casting permissions (Membership):

1. After completing the above steps, connecting the bike will activate screen casting permissions, allowing you to use the screen casting function.

2. Once the bike has activated screen casting function permissions, it can share the function with up to 4 other non-member accounts (a total of 5 shared accounts).

Note: (1) Among the 5 most recently paired accounts with the bike, at least 1 must be a member; otherwise, the screen casting function will be disabled.

(2) Member accounts can only activate the bike they are initially paired with.


For any changes, please contact customer service.



How to Adjust Bike

1. Handlebar height adjustment:

Loosen the handle under the saddle, slide the saddle back and forth to the desired position, and tighten the knob as much as possible.



Note: Before locking, please make sure to align the holes and do not exceed the MAX line.

The head tube must not exceed the MAX mark during handlebar adjustment.

Tight (Right) Loose (Left)

Pull

Note: Before locking, please make sure to align the holes and do not exceed the MAX line.

The saddle must not exceed the MAX mark during saddle adjustment.

Tight (Right) Loose (Left)

Pull

Note: Before locking, please make sure to align the holes and do not exceed the MAX line.

The saddle must not exceed the MAX