



OWNER'S MANUAL

CT412 DAB INITINAL

Safety Information

Thank you for purchasing this product, please read the manual carefully before operating, and reserve it for future reference.

PRECAUTIONS

- Only in a 12-volt DC negative-ground electrical system.
- Disconnect the vehicle's negative battery terminal while mounting and connecting the unit.
- When replacing the fuse, be sure to use one with an identical amperage rating. Using a fuse with a higher amperage rating may cause serious damage to the unit.
- Make sure that pins or other foreign objects do not get inside the unit, they may cause malfunctions, or create safety hazards such as electrical shock.
- If you have parked the car for a long time in hot or cold weather, wait until the temperature in the car becomes normal before operating the unit.
- Keep the volume at a level at which you can hear outside warning sounds (horns sirens, etc.).

CAUTION

- DO NOT open covers and do not repair by yourself. Ask the dealer or an experienced technician for help.

Specifications

General

Power supply:	10.8V~16V DC
Maximum power output:	4x 40W
Suitable speaker impedance:	4ohm
Fuse spec:	10A
Weight:	0.68kg
Dimensions (WxDxH):	188*118*58.5mm

FM Tuner(Europe)

Frequency range:	87.50 ~ 108.00MHz
Step:	0.05MHz

AM Tuner(Europe)

Frequency range:	522 ~ 1620kHz
Step:	9KHz

LW Tuner

Frequency range:	144.00 ~ 288.00KHz
Step:	3kHz

DAB

Frequency range:	174.928~239.200MHz
------------------	--------------------

Contents

Safety Information	1
Specifications.....	1
Panel Controls.....	2
Button Tips.....	3
Bluetooth Functions.....	5
TUNER OPERATION.....	5
DAB function	6
Wiring Diagram.....	7
Troubleshooting.....	8


BEFORE OPERATION

- Do not raise the volume level too much, as this will block outside sounds, making driving dangerous.
- Stop the car before performing any complicated operation.

Note:

- 1 According to models with different wiring harness to connect the definition of the specific content, please refer to the model label.
- 2 Specifications and the design are subject to change without notice due to improvements in technology.

Panel Controls



(1). - Microphone

(2). - Power on/off,
- Mute,
When on, hold it more than 2 seconds to power off.
- Rotate the VOL knob to adjust volume.

(3). - Switch source:DAB1/BT AUDIO/FM1/
LW/MW (short press)
- Radio mode
Setting FM1/FM2/FM3/FM4 (long press)
- DAB mode
Setting DAB1/DAB2/DAB3/DAB4 (long press)

(4). - Radio mode
Automatic search the station from high to low. (short press)
Browse preset station. (long press)

- BT music mode
Select the previous track

(5). - Radio mode
Automatic search the station from low to high. (short press)
Scan mode (long press)
- BT music mode
Select the next track

(6). - Enter EQ/DISP menu (short press)
- Enter Setup menu (long press)

(7). - Play/pause (BT music mode)

(8). - Answer/Dial/Call transfer/Hang on

(9). - Hang off/Reject a call (short press)
- Disconnect the Bluetooth device (long press)

(7-12).
- 1-6 radio preset
Press to tune in a preset station.
Hold for more than 2 seconds to store current station.

Button Tips

Power On/Off Button

Press the [] button to turn the unit on when the vehicle ignition switch is on. Press and hold the button to turn the unit off.

Adjust Volume level

Rotate the knob to adjust volume level. Rotate it clockwise to increase and anticlockwise to decrease the volume.

Audio Mute

Press the [] button to mute the volume from the system. "MUTE" will appear on the display panel and the volume will be muted. Press the [] button again, or rotate [] button to return the volume level to the setting in use before the Mute function was activated.

Mode Button (SRC)

Press the [**SRC**] button to change between DAB1/BT AUDIO/FM1/LW/MW.

System setting

On the non time display menu:
Hold it [**MENU**] and press [ / ] button to enter the system setup menu.
LW → MW → TIMER → BEEP → 12/24H →
CLK DISP → CLOCK → CLK SYNC → PWD →
PWDSET → VOL LAST → SWRC SET → SWRC
TYPE → DIMMING → ST/MONO → RUR/
URB → AREA SEL
Wait for 1s and rotate the knob to adjust.

Timer ON/OFF

Timer ON: when ignition of the machine is off, you can turn the unit on by pressing POWER button, and it can work for about 2 hours

Timer OFF: when ignition of the machine is off, the unit can't work anymore.

BEEP

Rotate the knob to select button beep sound on or off.

12/24H

To select 12 / 24 h Clock format

Clock

To adjust hours and minutes

SWRC SET

Activate or deactivate the steering wheel controls

SWRC TYPE

Allows you to select the signal mode of the steering wheel controls:

> RESIST: chain of resistors

> PWM: frequency - 100 Hz at 12 Volts

AREA SETTING

Rotate the knob to select EUROPE,USA, JAPAN,AUSTRA, LATINR.

VOL LAST/ADJ mode

Rotate the knob to select VOL LAST or ADJ mode.

DISPLAY

1. Press the [**MENU**] button and press [ / ] button to enter DISP SET mode.
2. Rotate the knob to set DIM/CLOCK/PTY/RT mode.

Button Tips

Password entered

Rotate the knob to select the digits, press the knob to confirm.

If the password is incorrect, "ERROR" appears on the display. Please enter the password again. If the user code is lost, contact the After Sales Service.

PWD OFF/ON: Activating/ Deactivating the security code.

When the unit is switched on, Press [MENU] button more than 2 seconds and press [◀◀▶▶] button show "PWD". Turn the knob to select "ON" or "OFF": the password is activated or deactivated.

When set to "ON", the radio code will be requested, you will have to enter the password after each time you turn the ignition from ACC OFF to ACC ON, or the battery is disconnected (the default password is "1111"). If you only turn off the ignition (+15/30), the code will not be requested.

PWD NEW: Create a new password

You can set a new password for the unit:

Press [MENU]button more than 2 seconds and press [◀◀▶▶] button show "PWD SET", Press the knob to enter your old password. If the old password is incorrect, "ERROR" appears on the display, please enter the password again.

If the old password is correctly entered, "NEW" is displayed, enter your new password. When "AGN" is displayed, enter your new password again. If "SET OK" is displayed, the code has been updated.

SOUND SETTING

Press the [MENU] button and press [◀◀▶▶] button to select sound mode, press the knob to confirm. First press shows current EQ. Press [◀◀] or [▶▶] button to select options, rotate the knob to adjust.

EQ OFF -> BALANCE -> FADER-> LOUD

BALANCE:LEFT 1-7->CENTER->RIGHT 1-7
FADER:FRONT 1-7->CENTER->REAR 1-7
LOUD: ON/OFF

Pairing

Use this function to establish a connection between the unit and your mobile phone.

1. Turn on the unit.
2. Turn on Bluetooth function of your mobile phone, keep phone within 3 meters to the unit and start to search for Bluetooth devices.
3. After the name of the Bluetooth module “CT412 INI” appears on the pairing list of your mobile phone, select it. At this time, a pairing code is required. Enter the pairing code “1234”, and the Bluetooth pairing will process automatically.

After pairing successfully, BT icons will light up.

BT mode selecting

Press [SRC] button to choose BT/AUDIO mode.

Receive

1. After pair successfully, if there is a call incoming, the unit switch to BT mode automatically.
2. Press [5] button to receive.
3. Press [6] button to hang up.

Dialing

1. Phone dialing

Mobile phone dialing, LCD screen displays dialing information.

Call Transfer

During talking, press [5] button to transfer audio from the unit to your mobile phone.

Note:

Some mobile phones will transfer audio from the unit to themselves once the incoming call is answered.

Music Mode

A2DP

A2DP is short for Advanced Audio Distribution Profile. The mobile phones supporting this function can transmit stereo audio, whereas the ones not supporting this function can transmit mono audio only.

On A2DP music playing mode, press [1] button to choose pause/play mode.

Press [/] button to previous or next track.

Band

During radio play, press the [SRC] button to choose between FM1, LW, MW bands.

During radio play, long press the [SRC] button and then rotate the knob to choose FM1,FM2,FM3,FM4.

Up Tuning

Press the seek [] button to the next available station.

Down Tuning

Press the seek down [] button to the previous available station.

DAB function

DAB Radio Selection

DAB/DAB+ Provides radio programs in digital sound quality. To access Digital Audio Broadcast (DAB) press the [SRC] button and select DAB

DAB Service SCAN "Synchronising"

If the antenna is not connected, ""No signal"" will be displayed. If the tuner has never been used, ""No service"" will be displayed.

Automatic scan:

The radio will initiate an automatic scan of the DAB transmitters for the first operation, or if the DAB transmitters is lost.

Manual scan:

In DAB mode, if you want to launch a scan, hold down the ""SCAN"" button for 2 second. The screen will display the message ""SCAN OK"" and will display the numbers 1 to 100K one after the other (DAB block). At the end of the scan, the screen will display the number of stations received (e.g. FOUND 39 = 39 stations found) and will broadcast the first station.

Select DAB group

Hold the [SRC] Button to select one of the available DAB groups:
DAB1 > DAB2 > DAB3 >DAB4 . They allow the storage of 6 stations each.

Tuning a DAB Service

To tune a DAB service push [◀▶▶] to select the next/previous DAB service.

“Tuning” is shown on the Display, Then the station is automatically broadcast

Recall Stored Favourites

To recall a preset station, briefly press the desired button (1 to 6)

Rural / Urban

Hold [MENU] and Press the [◀▶▶] button several times to select RURAL / URBAN. Turn the [volume] button to select the appropriate tuner mode:

RURAL (poor reception) or URBAN (locations near emitters).

BT VOL

Adjusts the level of the AD2P-BT relative to other sources (from 0 to +7).

This radio allows manual or automatic dimming of the display and key buttons.

Select ""DIMMING"" from the setup menu and select one of the following:

- > Select ""OFF"" to deactivate dimming
- > Select the ""MANUAL"" attenuation when the radio is not connected to the vehicle ignition pin . The change between day and night mode is done by selecting Settings menu ""DIMDAY"" or ""DIMNIGHT""
- > Select the ""AUTO"" attenuation when the radio is correctly connected to the vehicle ignition pin (A6, +12 V lantern or pilot lights), the lighting will change when the parking light is switched on.

Select Manual dimming to adjust Brightness of display and Buttons". Select DIM MAN and change between day mode and night mode

by selecting "DIMDAY" or "DIMNIGHT"

> To adjust Night Brightness of the display and buttons select "DIMNIGHT"

> To adjust Day Brightness of the display and buttons select "DIMDAY"

MW (ON/OFF)

To enable/disable MW Reception

LW (ON/OFF)

To enable/disable LW Reception

DAB FMLK

Switching automatic between DAB and FM (DAB FMLNK). When the DAB signal quality drops significantly, it is preferred to switch and listen to the service via FM.


Switching between DAB and FM (DAB FMLNK) can be disabled via the system settings menu.

Note: If the AF indicator is not displayed, the radio has not found the corresponding station in FM and can not switch from DAB to FM and vice versa

DAB ANT

Selection of Active or Passive antenna

Wiring Diagram



NO.	NOTE	NO.	NOTE
A1		B1	RR+
A2	Mute	B2	RR-
A3		B3	FR+
A4	BATTERY +	B4	FR -
A5	ANTENNAREMOTE	B5	FL +
A6	ILLUMINATION	B6	FL -
A7	IGNITION/ACC	B7	RL +
A8	POWERGROUND	B8	RL -
C5	SWRC+	D1	MIC -
C6	SWRC GND	D4	MIC +

TROUBLESHOOTING

The following checklist can help you solve some problems which you may encounter when using the unit. Before consulting it, check the connections and follow the instructions in the user manual. Do not use the unit in abnormal condition, for example without sound, or with smoke or foul smell can cause fire or electric shock, immediately stop using it and call the store where you purchased it.

Problem	Possible cause	Solution
General		
The unit will not switch on.	Car ignition is not on. Cable is not properly connected. Fuse is burnt.	Turn your car key in the ignition. Check cable connection. Replace fuse with a new fuse of the same capacity.
No sound	Volume is set at minimum or the mute function is on.	Check the volume or switch the mute function off.
The unit or screen does not work normally.	The unit system is unstable.	Press the RESET button.
Mode TUNER		
Unable to receive stations.	The antenna is not connected properly.	Connect the antenna properly.
Poor quality reception of radio station.	The antenna is not fully extended or it is broken.	Fully extend the antenna and if broken, replace it with a new one.
Preset stations are lost.	The battery cable is not properly connected.	Connect the permanent live on the unit to the permanent live on the vehicle.

FCC

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

Hereby, AMS-Diffusion declares that the radio equipment type CT412 DAB INITINAL is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:



ZA du Chevalement - Rue des Galeries 59286 ROOST WARENDIN - FRANCE

Phone : +33 (0)3 27 94 44 44 Fax : +33 (0)3 27 94 44 45

Web : www.ams-diffusion.com

P/N:12707500XXXX