




2.0 Channel Bluetooth Sound Bar KY-2023, KY-8000

support@assistrust.net

Install the soundbars to the base

Base installation method:
Connect the two sound bars with the base installed with the connecting wire of the base to complete the vertical assembly.



After getting the package

1. Open the box
Check all the cables/base/power adapter/remote, if anything wrong, please contact support@assistrust.net

2. Install the 2 small soundbars

When you get the package, the soundbars are separate like 2 small soundbars. You can choose to assemble them into a large horizontal speaker, or attach them to the base and use them independently.


3. Power On and Connect the soundbar with your TV

Keep reading the next page to power on and connect.

— 6 —

Step 1. Check parts and know their function

Page 1/2 will briefly describe the functions of buttons and cables.




Body button description




- Short press to turn on, long press for 2 seconds to turn off. Short press to switch modes. (BT+HDMI+OPT+BT)
- In Bluetooth mode, short press to play/stop songs in turn.
- Short press to increase the volume step by step, long press the previous song. (In the Bluetooth mode, the volume is increased to the maximum and the indicator light flashes quickly)
- Short press to decrease the volume step by step, long press to switch to the next song

— 1 —

User code: 8019



Without battery



1. Make sure you have removed the protective cap from both ends of the cable. 2. Inserting the plug in the wrong orientation can damage the plug and the connector.

— 2 —

Step 2. Assemble 2 soundbars

When you just open the outer box, you will find 2 separate small soundbars and 1 base. You can choose 2 usage (usage A and B) to use it.

A: assemble 2 separate small soundbars together to be a long soundbar.

B: assemble 2 separate small soundbars on the base to be a tower soundbar.

Combined installation method:

- ① Align one section of the sound bar with the other section as shown in Figure 1.
- ② Align the two sound bars and press $\Delta \rightarrow \Delta$ to lock and unlock.
- ③ Press $\Delta \rightarrow \Delta$ to lock the two sound bars to complete the combination.

— 3 —


Install the soundbars to the base

Base installation method:

① Align the sound bar with the base as shown in Figure 1.

② Lock and unlock the sound bar and the base according to the $\Delta \rightarrow \Delta$ method.

③ Lock the sound bar and the base according to the $\Delta \rightarrow \Delta$ method, and the installation is complete.



— 4 —


Install the soundbars to the base

Base installation method:

① Align the sound bar with the base as shown in Figure 1.

② Lock and unlock the sound bar and the base according to the $\Delta \rightarrow \Delta$ method.

③ Lock the sound bar and the base according to the $\Delta \rightarrow \Delta$ method, and the installation is complete.



— 5 —


4. TV Settings (Different TV has different paths)

Depending on the method of external audio, go to your TV's sound settings

The most commonly set paths for different TVs:


Path 1 Smart/Home > Settings > Sound Out > External Speaker/External Audio

Path 2 Settings > Sound > Sound Output > Audio Out > HDMI/ARC > Digital Output




Tips: Some TVs require further setup, please try path 3.

Path 3 Smart/Home > Settings > Audio Output > ARC (HDMI) > Digital Output Format > PCM



Some TVs require further setup. If there is no sound after connecting, enable HDMI-CEC

Path 4 Settings > Display and Sounds > HDMI-CEC Device Control > On




Notes: Allow your TV to control connected CEC-capable HDMI devices using your TV's remote.

Playback, navigation, and other functions can be controlled using the remote.

— 11 —

Step 3. Power on

1. First, Connect the power cord to the DC IN port on the back of the soundbar.
2. Next, Plug the other end of the power cord into an AC (mains) power outlet.



Tips:

1. Connect the soundbar.
2. Note: The soundbar needs to be connected to be used as a soundbar or dual tower speaker.

3. Plug the soundbar into a power source. Once it's connected, the soundbar LED indicator will turn RED.

Note: The RED light doesn't represent standby mode, but signals there's an active power source

3. To turn it on, hold down the power button for 2 seconds or press the power button on the soundbar's remote. The LED will flash blue and you'll hear a beep (in default mode - Bluetooth mode).

4. To change the connection mode, press HDMI/AUX/OPT button on soundbar remote or quick press the power button.

For VIP Tech Support or free Lifetime warranty for soundbar and remote. Please contact us at: support@assistrust.net

Power Off (For Your Information)

When you need to turn off the soundbar after using, you can refer to here.

1. First, Turn off the soundbar by pressing the power button on the remote or the power button on soundbar.

2. Next, Turn off the TV.


Because many TVs will generate a large audio impact signal when they are turned off, this signal will be transmitted to Soundbar, which will cause a large noise and affect your hearing. It's suggested that the soundbar should be turned off first.

— 7 —

Step 4. Turn on

Press power button on the soundbar remote to turn it on, LED will flash BLUE and hear a beep (in default mode - Bluetooth mode).

Remote control key description you may want to know:



HDMI: Before plug the HDMI cable, please press this button to set the soundbar into HDMI mode. You can check the LED color (orange) to know if the mode is set.

OPT: Before plug the OPT cable, please press this button to set the soundbar into OPT mode. You can check the LED color (green) to know if the mode is set.

AUX: Before plug the AUX cable, please press this button to set the soundbar into AUX mode. You can check the LED color (white) to know if the mode is set.


BT: Press this button to set the BT mode, you can check the mode below to know the status.

Mode	Status
AUX Mode	LED: stay white
Bluetooth Mode	BT mode LED: flash blue BT connected LED: stay blue BT disconnected LED: flash blue
OPT Mode	LED: stay green
HDMI Mode	LED: stay orange


— 8 —

INSTALL THE REMOTE BATTERIES

1. Open the battery compartment cover on the back of the remote.



2. Insert the two AAA 1.5V batteries. Match the H and Z symbols on the batteries with the + and - markings inside the compartment.



3. Put the battery compartment cover back into place.

“According to local transportation rules, batteries are not allowed in the package. Please prepare 2 AAA batteries for the remote control. Thank you for understanding.”

— 9 —

Step 5. Connect soundbar with TV

1. choose 1 connection according to your TV's slots, such as Bluetooth/HDMI/ARC/OPT/AUX. You can find the specific page about connection steps for: HDMI/OPT/AUX/Bluetooth.

You can find the specific page according to the title of each page and follow the steps of specific connection.

3. for wired connection: insert 1 cable to both of all cables.

Option 1 (preferred): HDMI eARC or ARC

If you want to use HDMI connection please keep reading if you want to use other connections, please refer to other pages.


1. Insert one end of the HDMI cable into your TV's HDMI eARC port or ARC port.

2. Insert the other end of the cable into the HDMI (ARC) port on the soundbar.

3. Press the “ARC” button on the soundbar's remote to switch modes until LED shows orange. If LED shows other color, please press ARC button again until it shows orange.

1. Insert one end of the HDMI cable into your TV's HDMI ARC port, not a standard HDMI port. If your TV doesn't have an HDMI ARC port, it means you can't use HDMI connection/need to try other connections because your TV doesn't support HDMI (ARC).

3. Some TV has 2 HDMI jacks and modes, choose “HDMI ARC” ONLY.



Note: Be sure you insert the HDMI cable into an HDMI ARC port on your TV, not a standard HDMI port. NOT HDMI (ARC) port. NOT HDMI (ARC) port.

— 10 —

Troubleshooting

Problem

Solution

No Sound	<ul style="list-style-type: none"> - Check the power adapter is properly connected to an electrical outlet. - Make sure the DC plug is properly connected to the DC IN socket. - Unplug the power adapter for at least one minute and reconnect.
No HDMI eARC port or ARC port on your TV	<ul style="list-style-type: none"> - Use the optical cable to connect the soundbar to your TV.
No HDMI eARC, ARC, or optical port on your TV	<ul style="list-style-type: none"> - Please connect the TV using Bluetooth, 3.5 audio cable or RCA
Soundbar doesn't power off	<ul style="list-style-type: none"> - The soundbar may be in standby mode. On the remote, press the Power button Δ to wake the soundbar. Press Δ again to power off the soundbar.
Intermittent or no audio from soundbar	<ul style="list-style-type: none"> - Play audio from a different application or music service.
Sound from TV speaker	<ul style="list-style-type: none"> - Press the Power button on the sound bar or remote control to turn on the sound bar. The power indicator lights up green. - Press MUTE button on the remote control to restore sound. - Ensure that the source device has correct volume settings and is playing a track. - Ensure the correct source device is selected. - Plug the audio cable into a connector on your TV labeled Line OUT or AUDIO OUT. - Disconnect the power cord for the soundbar, wait 30 seconds, and plug them firmly into the AC (main) outlet. - Unplug the power cords for the soundbar, wait 30 seconds, and firmly plug them into the AC (main) outlet. - Turn off your TV speakers. Refer to your TV owner's guide. - Disconnect the power cord for the soundbar, wait 30 seconds, and firmly plug them into the AC (main) outlet. - If the soundbar is connected to your TV's HDMI eARC (or ARC) port, make sure that Consumer Electronics Control (CEC) is enabled in your TV system menu. Your TV may refer to CEC by a different name. Refer to your TV owner's guide.
Poor audio quality	<ul style="list-style-type: none"> - Make sure that the soundbar's HDMI cable is inserted into a port on your TV labeled HDMI eARC (Enhanced Audio Return Channel), not a standard HDMI port. If your TV doesn't have an HDMI eARC port, connect the soundbar using the optical cable. - Make sure the CEC code (HDMI eARC or CEC) is enabled in your TV system menu. Your TV may refer to CEC by a different name. Refer to your TV owner's guide. - Disconnect the power cord for the soundbar, wait 30 seconds, and firmly plug them into the AC (main) outlet. - Turn off your TV speakers. Refer to your TV owner's guide. - Disconnect the power cord for the soundbar, wait 30 seconds, and firmly plug them into the AC (main) outlet. - If the soundbar is connected to your TV's HDMI eARC (or ARC) port and power is off, turn on the soundbar, wait 30 seconds, and firmly plug them into the AC (main) outlet. - Press the volume, music or never button on the remote control to select a suitable sound mode. - Set the volume of the sound bar to 75 percent (maximum). (Note: the maximum volume drop 3 levels is 75 percent.) - Select a suitable connection for the soundbar and TV (or other connected sources). - Turn on the TV speakers. Refer to your TV's user manual for more information.

— 16 —

Safety Instructions

1. Do not pull the plug out of the socket by the power cord, and do not wrap the power cord around the appliance.

<tbl_r