

V2 Describes the operations

Installation instructions

1. Connect one end of the USB data cable to the V2 device, and the other end to the computer port, so that the machine will light up
2. Prototype coil is low frequency card operation area, square coil is high frequency card operation area.
3. Install hf interface LF corresponding to HF interface LF corresponding to low frequency antenna

RdV2 card reader IC card operation area and ID card operation area

High-frequency card operation:

1. Place the IC card to be cracked in the high frequency reading area of the machine
2. On the IC card operation interface of the software, read the IC card type and resolve the password with one click
3. The card reading success message is displayed, indicating that the card reading is complete. Data in sectors 0 to 15 is displayed on the right
4. Put the IC card on the machine and click write UID card.

Low frequency operation:

1. Place the ID card in the low-frequency area of the machine
2. The software reads the card number
3. Remove the original card and put the 5577 white card
4. Clone the ID card

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction