# **MONSTER®**



Monster Airmars XKO01 FCC ID:2A8PV-QSMXKO01

BLUETOOTH WIRELESS HEADPHONES
INSTRUCTIONS MANUAL

# Product parameters

- Bluetooth version ----- V5.3

- Sensitivity ----- 106±3dB
- Battery capacity(Charging case) ----- 400mAh 3.7V
- Battery capacity(Headphone) ----- 50mAh 3.7V
- Charging time(Charging case) ----- ≈1.5 hours
- Music playtime(Headphone) -----  $\approx$ 7 hours
- Music playtime with charging case ---- ≈28 hours

# Product Schematic Description



Headphone\*2



Charging case\*1



Instructions Manual\*1




Type-C Charging Cable\*1

# Product Schematic Description



Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.



Rated input: 5V==40mA(Headphone)

Rated input: 5V==320mA(Charging case)

Tips: When the cover of the charging box is closed, the blue LED on the left side of the charging box flashes 5 times continuously, then goes out. Please charge the charging box.

### (Indicator guide)

Mode	Describe	Sound prompt
Power On	Power On         The headphones LED indicator flash in ice blue light for one second.           Power Off         The indicator LED of headphones show blue and quickly flash 3 times           Pairing         Two headphones are flash blue slowly	
Power Off		
Pairing		
Connected	The headphones LED indicator is off.	"Connected"

Mode	Describe	Sound prompt	
Disconnected	The headphones LED indicator flash in ice blue quickly.	"Disconnected"	
Low Battery	_	"Battery low"	
Headphones placed in charging case	The indicator LED of headphones stay on blue when fully charged it goes out.	_	
Charging case low power	The left blue LED flashes 5 times continuously , then turns off. $% \label{eq:left}$	_	
Charging case charged			
Charging case fully charged Three blue lights are always on.		_	

### Wearing Guide



### Step one

Open the upper cover of the charging box and take the headphones / out of the charging box



### Step two

Use the illustration to hold the main body of the headphone with your thumb and forefinger respectively, and use your middle finger to push the hook, also keep it is in this state.



Keep the second step and slowly rotate the headphone along the inner side of the ear until it fits the ear.



### Step four

Wear headphones and enjoy music

# Product operating instructions

### 1. Power on

Method 1: Open the charging case, the headphones will turn on automatically. Method 2: Long touch the MF button of the headphones for 3s to turn on the headphones

### 2. Power off


Method 1: Put the headphones into the charging case and close the cover. Method 2: When the headphones is not connected to the Bluetooth device long touch the MF button of the headphones for 5s to turn off the headphones. Method 3: After disconnected from the Bluetooth device for 3 minutes.

### 3. Pairing

Step one: Open the charging case, the headphones will start pairging automatically.

Step two: Search and click for "Monster Airmars XKOO1" on the Bluetooth list of the smart device, and when connection is successful, "Connected" will be heard.

\* Headphones will try reconnecting to the device within 3 minutes when connection is lost



### NOTE:

\* Fully charge the headphones and power off before an intended not-in-use period.

\* Unplug the charging cable after charging

### Operation


Normal



# Music playback



# Phone



# Game/music switching : device connected



# Restore factory settings

When you turn on the headphone, make sure it does not connect to any Bluetooth device, and click the MF button 5 times to clear the pairing record, then turn off the headphone.

### Precautions

- Headphones will turn on automatically (needless to press any button) pair and connect the device when the charging case is opened. After placing the headphones in the charging case, they will turn off and automatic charging will start when the cover is closed.
- 2.Charging every 15 days will extend battery life when not in use often. Cleaning off dirt on the charging contacts by cotton swabs with alcohol will maintain a good contact for charging.
- Keep battery(battery pack)away from inflammables or excessive heat such as direct sunlight.
- Intermittent is normal during playback for wireless products due to environmental factors, device brand, users' behavior, etc.

### Warnings

- 1. Do not use headphones at high volume for an extended perios of time.
- 2. Keep the headphones away from dust and water.
- 3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.
- Keep headphones away from any impact or vibration.
- 5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	0	0	0	0	0	0
Loudspeakers	0	0	0	0	0	0
PCBA	Х	0	0	0	0	0
Accessories	Х	0	0	0	0	0

This table is compliled according to SJ/T 11364

- O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
- X: Indicates that this hazardous subatance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

### **FCC** Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
  - -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- -- Consult the dealer or an experienced radio/TV technician for help. This device complies with nart 15 of the ECC Rules

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CMIIT ID:2023DP3136





This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical produsts will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

# Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info		
User name	Email	
Contact number	Postal code	

# Product information

Mailing address

. reaset in emailed				
Product name		Produc	t number	
Product barcode	/ Serial number / Batch num	ber		

# Vendor information Name Address Contact number Postal code Sales date Invoice number Remark

