


# USER MANUAL



## CAR REFRIGERATOR

Model: BCD35AW,BCD35,BCD35W,BCD35A,  
BCD25AW,BCD25,BCD25W,BCD25A  
DC 12V/24V AC100-240V

Foshan Alpicool Electric Appliance Co., LTD.  
Address: 13A ,Xinlong Road, ShilongJiyue Industrial Zone,  
Xintang Village, Lunjiao Town ,Shunde District, Foshan City,  
Guangdong,China

Please read this operating manual carefully before starting the device.  
Keep it in a safe place for future reference.

**CONTENTS**

1.SAFETY INSTRUCTIONS ----- Page1

2.PRODUCT FEATURES ----- Page3

3.PRODUCT STRUCTURE ----- Page3

4.FUNCTION AND OPERATION ----- Page4

5.CARE AND MAINTENANCE ----- Page5

6.SMART CONTROL - FRIDGE APP INSTRUCTIONS ----- Page6

7.TROUBLESHOOTING ----- Page7

## 1.SAFETY INSTRUCTIONS

### **WARNING!**

- Do not operate the appliance if it is visibly damaged.
- Do not block the gaps of the fridge with things like pin, wire, etc.
- Do not expose the appliance to rain or soak it in water.
- Do not place the appliance near naked flames or other heat sources (heaters, direct sunlight, gas ovens etc.)
- Do not store any explosive substances like spray cans with a flammable propellant.
- Ensure the supply cord is dry and not trapped or damaged. Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- Check the voltage specification on the type plate corresponds to that of the energy supply. The appliance is only to be used with the power supply unit provided with the appliance.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Once unpacked and before turning on, the appliance must be placed on a level surface for more than 6 hours.
- Make sure that the appliance stays horizontally when it is running. The tilt angle must be less than 5° for long time running and be less than 45° for short time running.
- Keep the ventilation openings in the unit casing or in the built-in structure free of obstacles.
- Keep the appliance stable on the ground or in the car; Do not drain upside down.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **CAUTION!**

- Repairs may only be carried out by qualified personnel. Incorrect repair may cause danger. The lamp and supply cord must be replaced by the manufacturer or qualified persons.
- The installation of DC power in the boat must be handled by qualified electricians.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they've been given supervision or instruction concerning use of the device in a safe way and understand the hazards.

### **NOTICE!**

- Disconnect the power supply before each cleaning and maintenance and after every use.
- Do not use sharp tools to defrost; Do not damage the refrigerant circuit.
- Risk of child entrapment. Before you throw away your old refrigerator or freezer: take off the doors: leave the shelves in place so that children may not easily climb inside.
- Check if the cooling capacity of the appliance is suitable for storing the food or medicine. Food may only be stored in its original packaging or in suitable containers.
- If the appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.

- The appliance is intended to be used in household and similar applications such as:
  - Staff kitchen areas in shops, offices and other working environments;
  - Camping, Farm houses and by clients in hotels, motels and other residential environments;
  - Bed and breakfast type environments;
  - Catering and similar non-retail applications.

 Please according to local regulations regarding disposal of the appliance for its flammable refrigerant and blowing gas.

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).


**FCC NOTE:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## 2.PRODUCT FEATURES

- High-efficiency compressor and conversion module.
- CFC free and great heat insulation.
- Lowest cooling to -20°C /-4°F (based on 25°C/77°F room temperature).
- Intelligent battery protection system prevents your vehicle from running out of battery.
- Touch screen control panel for temperature setting.
- Dual fridge and freezer zone.
- Optional car/home use.
- Detailed design: interior light, shelf, handle.

## 3.PRODUCT STRUCTURE



① Handle

② Freezer Compartment

③ Fridge Compartment

④ Shelf

⑤ Machine compartment

4.FUNCTION AND OPERATION

BCD35A/  
BCD35AW



DC12/24V



100-240V , 50/60Hz

- **Power Supply:** connected to DC 12/24V or AC100~240V(using the adapter).
- **Power On/Off:** press to switch ON, **long press** for three seconds to switch OFF.
- **Temperature Setting:** under running, press to switch refrigerator or freezer temperature setting. Press **+** or **-** to adjust temperature. The setting will be saved automatically after stopping operating for 4 seconds(Note: the temperature displayed is the current temperature of the compartment, it'll take a while to reach the set temperature.)  
Temperature setting range: Fridge(rE):0~8°C/32°F~46.4°F; Freezer(Fr):-12~-20°C/10.4~-4°F.
- **Battery Protection Mode (for car use type):** under running, long press for three seconds until the display screen flashes, then select three battery protection modes H(High), M(Medium) and L(Low) by clicking again. \* Factory setting is High battery protection mode.



From left to right: Low/Mediem/High.

| INPUT<br>MODE | DC 12V  |        | DC 24V  |        |
|---------------|---------|--------|---------|--------|
|               | CUT OUT | CUT IN | CUT OUT | CUT IN |
| L             | 8.5V    | 10.9V  | 21.3V   | 22.7V  |
| M             | 10.1V   | 11.4V  | 22.3V   | 23.7V  |
| H             | 11.1V   | 12.4V  | 24.3V   | 25.7V  |

\* the voltage is theoretical value, there may be a deviation in different sceneries.

\* H should be set when the product is connected to car power, and M or L should be set when it is connected to a portable battery or other back-up battery.

- **Temperature Unit Setting:** Switch off the fridge then long press  until displays E1, keep pressing  until displays E5, then press **+** or **-** to select Celsius or Fahrenheit.
- **Reset:** switch off the fridge, press  until E1 displays, then press button **+** and **-** at the same time to reset.
- **Recommended temperature for common food:**

|                                                                                  |                                                                                   |                                                                                   |                                                                                   |                                                                                   |                                                                                   |                                                                                   |
|----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
|  |  |  |  |  |  |  |
| Drinks                                                                           | Fruits                                                                            | Vegetable                                                                         | Delicatessen                                                                      | Wine                                                                              | Ice cream                                                                         | Meat                                                                              |
| 5°C/41°F                                                                         | 5~8°C/41~46°F                                                                     | 3~10°C/37~50°F                                                                    | 4°C/39°F                                                                          | 10°C/50°F                                                                         | -10°C/14°F                                                                        | -18°C/0°F                                                                         |

5.CARE AND MAINTENANCE

### ■Cleaning:

- Unplug the fridge first to avoid electric shock.
- Do not soak the fridge in water and do not wash it directly.
- Do not use abrasive cleaning agents during cleaning as these can damage the fridge.
- Use wet cloth to clean the fridge and dry it.

### ■Storage:

If the device will not be in use for a long time, please follow the instruction:

- Turn off the power and remove the plug.
- Remove the items stored in the refrigerator.
- Wipe off excess water from the fridge with a rag.
- Put the fridge in a cool and dry place.

### ■Defrosting:

Humidity can form frost in the interior of the cooling device or on the evaporator. This reduces the cooling capacity. Defrost the device in good time to avoid this.


- Switch off the device
- Take out all the contents of the device.
- Keep the door open.
- Wipe off the defrosted water.

 **Never use hard or pointed tools to remove ice or to loosen objects which have frozen in place.**

## 6.SMART CONTROL - FRIDGE APP INSTRUCTIONS

**First Step:** Turn on the Bluetooth on your smart device; start the APP and click "Search" to find nearby fridges.

**Second Step:** Click fridge icon for Bluetooth pairing (the APP will prompt you to pair the fridge by pressing the set button  on the fridge's control panel when connecting the fridge for the first time). After pairing, the APP will switch to the main interface allowing you to control the fridge.



- ① MENU
- ② Current temperature
- ③ Current voltage
- ④ Target temperature
- ⑤ Switch Left/Right compartment
- ⑥ SET
- ⑦ ON/OFF
- ⑧ ⑨ Temperature control
- ⑩ ECO(Energy-saving) / MAX(Fast-cooling)
- ⑪ Lock / Unlock
- ⑫ Celsius / Fahrenheit
- ⑬ Unpairing the device and return to search
- ⑭ Battery protection mode: High/Medium/Low

### Note:

\*Click the lock icon  on the APP to lock/unlock the control panel on the fridge, if locked, the fridge can only be controlled by the APP.

## Downloading the "CAR FRIDGE FREEZER" Application



IOS



Android

Scan the QR code on the left or search for the "CAR FRIDGE FREEZER" APP in the APP Store (for Apple devices) or Google Store (for Android devices).

## 7.TROUBLESHOOTING

| Issues                                                                 | Cause/Suggestions                                                                                                                                                                                                                                                                                                                      |
|------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Refrigerator does not work</b>                                      | <ul style="list-style-type: none"> <li>• Check if the switch is on.</li> <li>• Check if the plug and socket are connected well.</li> <li>• Check if the fuse has been burnt.</li> <li>• Check if the power supply is malfunctioned.</li> <li>• Switch on/off the fridge frequently may cause start delay of the compressor.</li> </ul> |
| <b>Refrigerator compartments are too warm</b>                          | <ul style="list-style-type: none"> <li>• The door is opened frequently.</li> <li>• A large amount of warm or hot food was stored recently.</li> <li>• The refrigerator has been disconnected for a long time.</li> </ul>                                                                                                               |
| <b>Food is frozen</b>                                                  | <ul style="list-style-type: none"> <li>• The temperature was set too low.</li> </ul>                                                                                                                                                                                                                                                   |
| <b>There is "water flow" noise from inside the refrigerator</b>        | <ul style="list-style-type: none"> <li>• It's a normal phenomenon, caused by the flow of refrigerant.</li> </ul>                                                                                                                                                                                                                       |
| <b>There are waterdrops around the refrigerator casing or door gap</b> | <ul style="list-style-type: none"> <li>• It's a normal phenomenon, the moisture will condense to water when it touches a cold surface of the refrigerator.</li> </ul>                                                                                                                                                                  |
| <b>The compressor is slightly noisy when starting</b>                  | <ul style="list-style-type: none"> <li>• It's a normal phenomenon, the noise will be reduced after the compressor works stably.</li> </ul>                                                                                                                                                                                             |
| <b>Code F1 displayed</b>                                               | <ul style="list-style-type: none"> <li>• Possible cause: low voltage to fridge.<br/>Adjust the battery protection from High to Medium or from Medium to Low.</li> </ul>                                                                                                                                                                |
| <b>Code F2 displayed</b>                                               | <ul style="list-style-type: none"> <li>• Possible cause: condenser fan is overloaded.<br/>Disconnect power to fridge for 5 minutes &amp; re-start.<br/>If the code shows again, contact manufacturer for service.</li> </ul>                                                                                                           |
| <b>Code F3 displayed</b>                                               | <ul style="list-style-type: none"> <li>• Possible cause: the compressor starts too frequently.<br/>Disconnect power to fridge for 5 minutes &amp; re-start.<br/>If the code shows again, contact manufacturer for service.</li> </ul>                                                                                                  |
| <b>Code F4 displayed</b>                                               | <ul style="list-style-type: none"> <li>• Possible cause: compressor not kicking in.<br/>Disconnect power to fridge for 5 minutes &amp; re-start.<br/>If the code shows again, contact manufacturer for service.</li> </ul>                                                                                                             |
| <b>Code F5 displayed</b>                                               | <ul style="list-style-type: none"> <li>• Possible cause: overheating of the compressor &amp; electronics.<br/>Disconnect power to fridge for 5 minutes &amp; re-start.<br/>If the code shows again, contact manufacturer for service.</li> </ul>                                                                                       |
| <b>Code F6 displayed</b>                                               | <ul style="list-style-type: none"> <li>• Possible cause: no parameter can be detected by the controller.<br/>Disconnect power to fridge for 5 minutes &amp; re-start.<br/>If the code shows again, contact manufacturer for service.</li> </ul>                                                                                        |
| <b>Code F7 or F8 displayed</b>                                         | <ul style="list-style-type: none"> <li>• Possible cause: temperature sensor is faulty.<br/>Contact manufacturer for service.</li> </ul>                                                                                                                                                                                                |