



Wireless Headset SkyBuds Lucid



Thank You

for choosing a quality product from 4smarts

1 Safety Instructions

1.1 General precautions

- Do not drop the product or subject it to violent shocks.
- Have the product repaired by qualified personnel only.

1.2 Precautions for electrical products

- Protect the unit from dirt, moisture, overheating, extreme temperatures and use it only in dry rooms.
- Do not open the unit or operate it if it is damaged.
- Never use force when plugging in the unit or any adapters.
- Do not operate the unit outside the power limits specified in the technical data

1.3 Battery precautions

- Avoid storage, charging and use in extreme temperatures.
- Recharge the battery regularly (at least quarterly) if stored for a long time.
- Never open, damage, swallow or allow batteries to enter the environment as they contain toxic and environmentally harmful heavy metals.
- In the event of a leaking battery, do not allow the liquid to come into contact with the skin or eyes. In case of contact, rinse with plenty of water and consult a doctor.

2 Technical Data

Bluetooth version: 5.3

Range: Approx 15m

Bluetooth transmission power: 8dBm, 6.5mW max.

Battery: Lithium polymer

Battery capacity per headphone: 25mAh, 0.09Wh

Battery capacity of charging case: 250mAh, 0.92Wh

Charging port: USB-C

Charging port voltage / current: DC 5V/0.5A

Charging port power: 2.5W max.

Output power per headphone: 4mW

Headphone charging time: Approx. 1.5 hours

Charging time: Approx. 3 hours

Playback time headphones without charging cradle: 5 hours

Playback time headphones with charging cradle: 20 hours

3 First Steps

3.1 Charging

Fully charge the product before using it for the first time. Connect the plug of the supplied cable to the USB-C charging port of the charging cradle. Connect the other side of the cable to a suitable charger. Always pay attention to the voltage and power specifications of your device. Wait until the product is fully charged before continuing. Disconnect the cable when charging is complete to conserve battery life.

Charging the charging case

While the charging case is charging using the USB cable, its LED status indicator flashes red. As soon as the battery of the box is fully charged, the LED goes out.

Charging the headphones

The headphones automatically switch to charging mode when you place them back in the charging cradle, the charging case LED status indicator flashes green. However, the charging cradle must have sufficient power for this.

Earphones LED effect

Charging completed: Red and blue lights out.
Turn on: Red and blue lights flash.
Turn off: The red light blinks three times.
Battery low: Blink red for 5 seconds.
Connected successfully: Red and blue lights off.
Connection failure: The red and blue lights flash quickly, and the right lights are off.
Connection interrupted: The red and blue light on the left flash rapidly and the right light is off.

3.2 Bluetooth connection

Open the charging cradle and take out the headphones. Go to the Bluetooth settings of your smartphone and search for '4smarts SkyBuds Lucid'.

4 Function notes

Function:	Touch Control:
Switch on / off	Automatically
Play/Pause/Accept call/Hang Up	2x no matter which side
Skip one song forward	3x right
Skip one song back	3x left
Increase volume	Long tap right
Decrease volume	Long tap left
Voice assistant	Tap the touch area for a long time until the voice assistant responds

5 Trouble Shooting

The connection does not work:

Make sure that the product:

- Is fully charged.
- Is within range of the device.
- Is not already connected to other devices (deactivate Bluetooth on other devices if necessary).

Make sure that your device:

- Is compatible with the Bluetooth version specified in the technical specifications.
- Has an active Bluetooth connection and is in pairing mode.

Play/Pause:

While listening to music, twice touch the touch area to pause or resume playback.

Forward/Reverse:

To skip forward one track, triple-tap the right earpiece. Tap the left earpiece three times to skip to the previous track.

Volume control:

Long tap the right earpiece to increase the volume, long tap the left earpiece to decrease the volume. Repeat this process until the desired volume is reached.

Answering/ending calls:

Tap the touch sensor twice to answer an incoming call. Tap twice again to end the call.

Voice assistant:

Tap the touch area for a long time until the voice assistant of your smartphone responds.

6 Disposal notification

Electrical and electronic devices as well as batteries must not be disposed of with household waste. The consumer is legally obliged to return electrical and electronic equipment as well as batteries at the end of their service life to the public collection points set up for this purpose.

9 Service and Support

If this product is defective or in case of problems during installation, please consult your dealer or the 4smarts product consulting via: <https://4smarts.com/contact>

Service Hotline

Monday – Friday: 9am-5pm +49 (0)821 20708444

Email: customer-service@4smarts.com

10 Attestation of conformity

Hereby, 4smarts GmbH, declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at www.4smarts.com.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.