How to connect/disconnect the device with/from the computer

On main desktop, connect the device with the PC, touch right side of the status bar on the bottom of desktop





Press "USB connected", select "Turn on USB storage". The device is recognized at Explorer of the computer. Now you can use it as an external storage



After finishing your work, Press"Turn off USB storage"to unmount it.

This manual contains important safety precautions and information of correct use. Please be sure to read this manual carefully before use so as to avoid any accidents.

Do not place the product in hot, wet or dusty environment, especially in summer: do not

leave the product inside a car with all windows closed.

Avoid dropping, impacting or shaking the product violently; otherwise it may cause damages or

malfunctions. Select a proper volume to avoid ear problem when using earphones.

Do not cross the road or drive vehicles, using headphones to avoid traffic accidents.

Be sure to use the provided chargers and accessories in the package. Be sure to charge the product when the following situations take place.

-The battery icon shows lower or empty.

System automatically shut down and it turns off soon after restart.

-Operation keys do not respond properly. The device shows on the top right corner.



Warning: this mark is a warning sign alerting you of dangerous voltage in side the product. Caution: this mark is a warning sign alerting you of important operation and



maintenanct instructions accompanying the producgt. "The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus"

- "The main plug is used as the disconnect device the disconnect device shall
- emain readily operable."
- The design and manufacture of the appliance have filly considerted the safety of human body. However, inappropriate handling of it may cause such accidents as electric shock and fire. So, the following safety instruction should be fully observed.

Notice: the appliance cannot be handled with wet hand. It should be kept at dry place with proper ventilation.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.