

CONTENTS: 2 Walkie Talkies. 1 Instruction Guide

HOW TO OPERATE YOUR WAI KIE TAI KIE

- 1. Turn the units ON by pushing the Power/ Channel Switch to one of 3 channels A/B/C being sure both units are set on the same channel. The LED Power Indicator will turn on then off. Once you press the PTT talk button, the LED will turn on.
- When the units are on and not being used for speech, they are always in the receiving mode. Pressing the PTT Button changes the mode to sending.
- 3. Push the Power/Channel Switch to the O position to turn the unit off. The LED Power Indicator will turn off.
- IMPORTANT: Only one Walkie Talkie can transmit at a time

CALLING ANOTHER UNIT

Set both units to the same channel. Press the PTT Button twice to call.

TIPS

- When you are finished speaking, say "OVER" so the other spy knows it is his turn to talk.
 When the conversation is complete, say "OVER AND OUT."

- HOW TO INSTALL BATTERIES 1. Open the battery door with a screwdriver.
- 2. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery. DO NOT remove or install batteries using sharp or metal tools.
- 3. Install new batteries as shown in the polarity diagram (+/-) inside the battery compartment.

 4. Replace battery door securely.
- 5. Check disposal. . Check your local laws and regulations for correct recycling and/or battery

NOTE: If normal function of the product is disturbed or interrupted, strong electro-magnetic cinterference may be causing the issue. To reset product, turn it completely off, then turn it be on. If normal operation does not resume, move the product to another location and try again. To ensure normal performance, change the batteries, as low batteries may not allow full function.

Special Note to Adults: Parental guidance is recommended when installing or replacing batteries. Regularly examine the toy for damage. In the event of any damage, the toy must not be used until the damage has been repaired. This toy is not intended for children under 6 years old.


BATTERY SAFETY INFORMATION: Requires 3 x 1.5 V AAA/LR03 alkaline batteries (not included). Batteries are small objects. - Replacement of batteries must be done by adults. - Follow the polarity (+/-) diagram in the battery compartment. - Promptly remove dead batteries from the toy. - Dispose of used batteries properly. - Remove batteries for prolonged storage. - Only batteries of the same or equivalent


Datacles properly. - Remove batteries in protoriged storage. - Only batteries of the same or equivalent type as recommended are to be used. - DO NOT dispose of this product in fire, as batteries inside may explode or leak. - DO NOT dispose of batteries in fire, as batteries may explode or leak. - DO NOT mix old and new batteries or types of batteries (ie. alkaline/standard). - DO NOT use rechargeable batteries - DO NOT recharge non-rechargeable batteries. - DO NOT short-circuit the supply terminals.

WARNING: Any adjustment to this equipment is recommended to be performed by or under the immediate supervision and responsibility of a person certified as technically qualified to perform transmitter maintaineance and repair dubles in the private land mobile services and fixed services by an organization or committee representative of users of those services.

SAFETY INFORMATION

Your wireless hand-held portable transceiver contains a low power transmitter. When the Push-to-Talk (PTT) button is pushed it sends out radio frequency (RF) signals. The device is authorized to operate at a duty factor not to exceed 50%. In August 1996, the Federal Communications Commissions (FCC) adopted







Care and Maintenance: Always remove batteries from the toy when it is not being used for a long period of time. Wipe the toy gently with a clean damp cloth. Keep the toy away from direct heat. Do not submerge the toy in water. This can damage the electronic assemblies.

FCC Statement: This device complies with Part 15 of the FCC rules. Operation is subject to the following FCC Statement: This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesirable operation. This equipment has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this toy does cause interference to radio or relevision reception (you can check this by turning the toy of and on while listening for the interference), one rome of the following measures may be useful: Reorient or relocate the receiving antenna · Increase the separation between the toy and the radio or the TV · Consult the dealer or an experienced TV-radio technician for help. NOTE: Changes, adjustments or modifications to this unit, including but not limited to, replacement of any transmitter component (crystal, semiconductor, etc.) could result in a violation of FCC rules under part 15 and/or 95 and must be expressly approved by Acctorn Co. Ltd. or they could work the user's authority to operate the equipment. approved by Acctron Co., Ltd. or they could void the user's authority to operate the equipment.

RF exposure guidelines with safety levels for hand-held wireless devices.

CAUTION: To maintain compliance with the FCC's RF exposure guidelines hold the transmitter and antenna at least 1 inch (2.5 centimeters) from your face and speak in a normal voice, with the antenna pointed up and away from the face, use only the supplied belt clip for this product and when transmitting, use of other accessories may not ensure compliance with FCC RF exposure guidelines. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

Use only the supplied antenna. Unauthorized antennas, modifications, or attachments could damage the transmitter and may violate FCC regulations.



