# **Anker Portable Bluetooth Speaker**

Model No: 99ANSP9901 Code NO.: MP141

# **Instruction Manual**

### **Package Contents**

Anker Portable Bluetooth Speaker Micro USB cable 3.5mm audio cable Travel pouch Instruction manual

#### **Product Features**


- Huge 1800mAh capacity delivers 15-20 hours of play time, outlasting even your iPhone 5s.
- Powerful 4W acoustic driver pumps out clear, room-filling sound.
- Latest Bluetooth 4.0 standards enables high definition audio, backward compatible with all Bluetooth versions.
- Built-in high-sensitivity microphone with advanced CVC (Clear Voice Capture) technology captures clear sound within a 2-foot (60cm) radius, perfect for use as a speaker phone.
- 3.5mm line-in port for connecting to your non-Bluetooth devices.
- Automatically turns off after 10 minutes when no device is connected.
- Automatically connects to the last-connected device when turned on (both device's Bluetooth functions need to be enabled).

## **Specifications**

Bluetooth Standard	4.0, backward compatible with all standards.
Product Weight	$280 \pm 10 \text{ g} / 9.9 \pm 0.4\text{oz}$
Product Size	$80 \times 80 \times 60$ mm / $3.1 \times 3.1 \times 2.7$ in
Lithium Battery Capacity	1800mAh
Play Time	15 - 20 hours
Charge Time	5 hours
Operating Range	10m / 33ft
Speaker Output Power	4W × 1

Audio Cable Type	3.5mm audio cable
Supported Bluetooth Profiles	HSP, HFP, A2DP and AVRCP

# **Product Overview**



- 1. Volume Down
- 2. Volume Up
- 3. Play/Pause
- 4. Micro USB Input
- 5. Audio Input
- 6. Power Switch
- 7. Status Indicator
- 8. Battery Indicator

# **How to Pair with Your Device**

1. Turn the Power Switch on. The Status Indicator will light up. The speaker will enter pairing mode automatically within 3 seconds, and the Status Indicator will begin to flash.

- 2. Activate your device's Bluetooth function and search for the device.
- 3. Once the Bluetooth speaker has been detected, select the product name "Anker MP141" to connect. (For devices with Bluetooth versions below 3.0, press "Yes" to confirm pairing. Enter a passkey or PIN code "0000" (4 zeros), then press the "Yes" or "OK" key to finish pairing.)
- 4. When the Bluetooth speaker and your device are successfully paired, the Status Indicator will go on and remain on while connected.

Note: The speaker will automatically connect to the last-connected device once Bluetooth function is enabled. When pairing with an additional device, disable the Bluetooth function on the previous device and shut off the speaker, or simply delete the pairing record. Then, repeat the pairing process.

#### How to Use

### Turning the speaker on/off

Slide the switch to the "on" or "off" position to turn the speaker on or off.

### Music play/pause

First, make sure your device is connected to the speaker successfully. Open your music software to play your music from the speaker. Press the "Play/Pause" button to pause music.

#### Adjusting volume

Press the "Volume Up" or "Volume Down" button to increase or decrease the volume.

#### Voice dialing

Please ensure your mobile phone supports voice dialing and voice tag recognition to use this feature. Press the "Play/Pause" button for 2 seconds, then give your voice command. Your device should then repeat the name to confirm before calling. (On iPhone, this will activate Siri.)

### Answering a call

Press the "Play/Pause" button to answer a call, or answer directly from the phone.

### **Ending a call**

Press the "Play/Pause" button to end a call, or end directly from the phone.

### Rejecting an incoming call

Press the "Play/Pause" button for 2 seconds to reject an incoming call.

### Microphone

Use the microphone directly on the speaker to talk after answering a call. The distance between your mouth and the speaker should not exceed 2ft/60cm.

## **Deleting pairing records**

When the speaker is in standby mode, press the "Volume Down" and "Volume Up" buttons for 2 seconds to delete pairing records.

**Note:** Basic functions may be restricted depending on Bluetooth software compatibility or setting limitations of your device.

# **How to Recharge**

When the speaker's battery is low, the speaker will announce, "Battery low", and the Battery Indicator will flash 10 times every 5 minutes to remind you.

- 1. Plug the micro USB cable into the input port of the speaker.
- 2. Insert the remaining end of the USB power wire into (a) a USB AC adapter (not included) connected to a wall socket, or (b) a charging computer USB port. A steady red Battery Indicator will show that it is charging.
- 3. The red Battery Indicator will go off when the speaker is fully charged.

#### **LED Indicator Instructions**

LED indicator	Meaning
Blue Status Indicator rapidly flashing	Pairing mode
Steady Blue Status Indicator	Connected to a device
Red Battery Indicator flashing 10 times every 5 minutes	Low Battery
Steady Red Battery Indicator	Charging
Red Battery Indicator goes off	Fully charged

# **Usage Tips**

- 1. Power off the speaker when not in use and before storing.
- 2. The operational range of the speakers may be influenced by obstructions, such as walls, pillars, etc. To ensure a stable connection, we recommend avoiding such obstructions whenever possible and/or shortening the distance during use.
- 3. To protect the long-term performance of the battery, please do not place the speaker in high temperatures above  $140^{\circ}\text{F/}60^{\circ}\text{C}$ , such as in a hot vehicle or under direct sunlight.
- 4. Do not expose the speaker or any of its supplied parts to rain or other liquids.

## FAQ

- 1. Why can't the speaker connect to my device?
- a. Check to ensure your device's Bluetooth function is enabled.
- b. Make sure your device is within 3ft/1m of the speaker.
- c. Delete the pairing record(s) on the speaker or your device.
- 2. Can I use the speaker to play music while charging?

No. Concurrently charging and using the speaker will cause damage to the speaker's circuit and affect the long-term performance of the battery.

3. Can I Skype using this speaker?

Skype is only available when using iOS 6. It cannot currently be used under other operating systems (Android, iOS versions excluding iOS 6).

#### **FCC STATEMENT:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

## **RF** warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.