Introduction

Thank you for purchasing GameStick. Before starting, please take a couple of minutes to read this guide to setting up and using GameStick.

What's in the box

- 1 x GameStick (A)
- 1 x Controller (B)
- 1 x Mains Power Supply Unit (region specific) (C)
- 1 x 1m USB to Micro USB Power Cable (for controller) (D)
- 1 x 30cm Y Cable from Micro USB to Regular USB (type A) (For Stick) (E)
- 1 x HDMI Extender Cable (F)

You will need

- Wireless internet connection
- TV with HDMI port
- Access to a device with an internet browser for one-time registration

Controller Map

Shoulder buttons BT Pairing Power button

D Pad Charge points
Home button LED Indicator Strip
Reset Micro USB port

Charge your Controller

We recommend that you fully charge the controller before using for the first time. To do this:

- Plug cable (D) into the Micro USB port (N) on the front of the controller.
- Plug the other end of cable (D) into any powered USB port e.g. on TV, PC or Y cable (E) as per figure 3.
- All 4 LED lights will flash at once whilst the controller is charging.
- When all four lights remain on, the controller is fully charged.

Set up your GameStick

- Power GameStick using the included Y Cable (E) & Power Supply (C) per Figure 3. A white light from within the stick indicates power.
- Plug GameStick into TV's HDMI port (use the extender cable (F) provided if required).
- Switch on controller by pressing and holding the power button (O) for 3 seconds and follow Controller Pairing instructions below.
- Once the controller is paired, follow the one-time on-screen device and account setup instructions.

Controller Pairing

When you turn on your controller, it will automatically enter pairing mode then connect. Pairing mode is indicated by a flashing light on LED Indicator Strip (M). When paired, the light will stop flashing and remain solid.

GameStick supports up to four controllers simultaneously. Successfully connected controllers are represented by additional solid lights on LED Indicator Strip (M).

If pairing your controller for the first time, GameStick will scan for available controllers. Once it has detected your controller, you will be prompted to press button A to pair that device. This process should take approximately 30 seconds.

Troubleshooting - If your controller fails to pair, first try rebooting your GameStick by disconnecting then reconnecting power and trying again. If this is unsuccessful you will need to reset your controller. To do this, press the

recessed Reset button (J) on the back of the controller which will turn the device off. Turn the controller back on and wait for GameStick to scan and find the controller, you will then be prompted to press button A to pair that device.

Need more help?

For more information and further support go to www.gamestick.tv/support.

Looking after GameStick

Whilst every precaution has been taken to ensure your safety, every electrical device should be handled with care at all times. Please follow these guidelines;



Observe ALL warnings, precautions and instructions

 $ilde{m{igwedge}}$ Always unplug your GameStick from your TV and switch off power supply when not in use. Store it in a cool, dust free area, out of direct sunlight.

Do not expose to extreme temperatures or direct sunlight for any length of time. If the GameStick or Controller becomes too hot to touch, unplug it (including all cables) immediately and stop use

Do not get the device, Controller or any cables wet. If you wish to clean the Controller, please do so using a dry cloth. Do not expose to liquids, chemicals or fluids as these may damage your device.



 $ilde{oldsymbol{ol}}}}}}}}}}}}}}}}}}}}}}$

If you have an epileptic condition or have had any seizure in the past, please consult your doctor before playing. We recommend that parents observe their children while they play video games. If you or your child experience any of the following symptoms: dizziness, altered vision, eye or muscle twitching, involuntary movements, loss of awareness, disorientation, or convulsions, DISCONTINUE USE IMMEDIATELY and consult your doctor.



🔼 Play Safe;

- Children should be supervised whilst playing games.
- All users should take regular breaks
- Don't sit or stand too close to the screen
- Play in a well-lit room
- Stop playing if you feel drowsy, fatigued or in any way unwell

Legal Notices:

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

INDUSTRY CANADA NOTICES (IC):

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device

Avis d'Industrie Canada (IC):

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must be co-located for operating in conjunction with any other antenna or transmitter.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's a uthority to operate the equipment.

For warranty information please visit www.gamestick.tv/warranty

Android is a trademark of Google inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. Portions of this package are reproduced from work created and shared under the Creative Commons 3.0 Attribution licence. The Bluetooth word, mark and logos are all owned by Bluetooth SIG, Inc. HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing, LLC. © PlayJam Ltd. All rights reserved.

License Agreement

GameStick and third-party software license terms can be found at www.gamestick.tv Use of GameStick constitutes acceptance of as well as agreement to those license terms

Information in this document, including URL and other internet web site references, is subject to change without notice.