## **User Manual**

# Mobile phone

Trade: SDEALS

Model Name: SD100

Company: SotoDeals

Address: 2061 NW 112th AveNUE #147, Miami, Florida, 33172, United States

### Contents

1.		Preface	.39
2.		Quick Start Guide	
	2.1	Insert SIM card and battery	
	2.2	Insert memory card	. 40
	2.3	Battery charging	. 40
3.		Call	.41
	3.1 Di	alpad	. 41
		aking an overseas call	
		aling via Contacts	
		Illing an extension number	
		aking an emergency phone	
		swer or reject incoming calls	
	3.7 M	enu during a call	
4.		Call Log	
5.		Contacts	
	5.1	Browsing contacts	
	5.2	Quick search	
_	5.3	Creating contacts	
6.		Message Service	
	6.1	SMS	
_	6.2	MMS	
7.		Browser	
	7.1	Open	
_	7.2	Browser	
8.	0.1	Multimedia	
	8.1	Audio Player	
	8.2	Video Player	
	8.3 8.4	FM Radio.	
9.	8.4	Application	
9.	9.1	Clock	
	9.1	Calendar	
		an create new events prompt appears on the phone to remind.	
	9.3	Calculator	
	9.4	Recorder	
	9.5	SIM Toolkit	
10		Setting	
	10.1	Dual SIM settings	
	10.2	Connection Management	
	10.3	Call settings	
	10.4	Phone profile	
	10.5	Display	
	10.6	Security	. 50
		tenance of Mobile Phonetenance of Mobile Phone	
12	Trou	pleshooting for Simple Troubles	.40
13	Safe	ty Information	1

### 1. Preface

#### Thank you for choosing this Spreadtrum Platform Cellphone.

This device will offer you an unprecedented surprise for it can support two GSM cards with double standby. Meanwhile, this cellphone is equipped with a 3 m egapixel HD digital cam era, a M P3 music player and a MP4 video player. Enjoy yourself!

#### **Safety**

Please go through, and comply with, the following considerations before using this cellphone.

**|+**|

sos

◆ Please take earph one if m aking or answering a call while driving or after 
 you car is parked.

performance.

- Any cellp hone may be susceptible to interference, which could af fect
- Please us et he ori ginal battery and accessories in order to ha ve opt imal performance an d pre vent phone damage. Plea se do n't use unmatched products.
  - ◆ To av oid int erference with blas ting work, please turn off the cellphone on the site or w here two-way radio m ust be switched of f. Please observe the local rules.
- ◆ If yo ur cell phone needs t o be connected wi th other de vice, pleas e read the User Guide of the latter.
- Please copy or keep a w ritten copy of the v ital information s tored in y our cellphone.

- The cellphone may interfere with aircraft telecommunication. So please turn off or switch to flight mode during the flight.
- Please turn of f your cell phone near the medical e quipment or in the m edical facility where any cellphone must be out of service.
- Please turn off your cellphone in the gas
   station or near fue 1 or chemicals t o prevent explosion.
- ◆ Burning or disposing of cellphone battery as usu al is prohibited, or it may cause life risk or environ mental pollution. Ple ase dispose of and recycle it in compliance with the local environmental regulations.
- Some sm all components (e.g. m emory card, e tc.) s hall be out of chi ldren's reach; otherwise it may be swallowed or cause other hazards.
  - Ensure the cellphone is turned on an d within the service area. Enter the emergency number, press the talking key to tell your location. Please don't end the call without permission.

### 2. Quick Start Guide

### 2.1 Insert SIM card and battery

- > Press turn it off;
- Slide the cover downwards and remove it;

Remove the battery. Insert SIM Card 1 (per the m ark "**SIM1**" on the card slot. The contactor sh all face down (note the notch on the SIM card is in line with the slot). Push the SIM card inwards from the card slot until it absolutely fits the slot. Insert SIM Card 2 in the same manner.

Insert the b attery with m etallic contact aligned to the cellphone battery contact and replace the cover.

## 2.2 Insert memory card

This cellphone supports the T-Flash memory card. After it is inserted, you can browse or copy, etc. the files stored in the memory card. Also, the memory space of this device can be expanded.

- Remove the cover and battery and turn over the cover of the memory card in the direction as shown thereon;
- Let the side of the memory card bearing metallic contact face down, insert the narrower end into the card slot until absolutely fitted by it, and replace the back cover.

### 2.3 Battery charging

#### The cellphone battery may be charged with travel charger.

- Insert the battery in the device correctly;
- Let the charger arrow towards the screen, insert the charger plug into the interface, and connect the charger to the standard power supply socket.
- After charging is over, cut off the connection between the charger and the standard power supply socket.

## 3. Call

### 3.1 Dialpad

Press the physical keyboard to enter the dialpad

Press "Call", escape the SIM card select screen. Select SIM1 to dial with SIM1; select SIM2 to dial with SIM2

Press "IP" button to carry out IP dial;

### 3.2 Making an overseas call.

Enter the country code (in this case, "+" shall be entered by pressing \* twice continuously);

Enter the area code (without "0" prefixed to that as usual) and the phone number;

Press "Call", escape the SIM card option screen. Select SIM1 to dial with SIM1; select SIM2 to dial with SIM2

### 3.3 Dialing via Contacts

Enter the Contacts and search for the phone number you need;

Press Record for a long time to select Call in the option menu.

### 3.4 Calling an extension number

Enter the switchboard number;

Press [Add call] and then input the extension number;

Press "call", escape the SIM card select screen. Select SIM1 to dial with SIM1; select SIM2 to dial with SIM2

### 3.5 Making an emergency phone

Enter the emergency phone number;

Press "Call", escape the SIM card select screen. Select SIM1 to dial with SIM1; select SIM2 to dial with SIM2

### 3.6 Answer or reject incoming calls

If there is an incoming call, press "Answer" to answer it;

If there is an incoming call, press "Reject" to reject it;

### 3.7 Menu during a call

During a call, you can:

**Hold:** Press [Hold] to hold current call.

**Contacts:** Enter into the interface of contact list.

**Keypad:** Enter into the dial interface.

**Record**: Record the call details, and the document will be kept in the file manager automatically.



Note:

It is illegal to record any call in some countries. So please do so with the speaker's prior consent.

**Mute:** Turn off the microphone during the call. In the mute mode, you can hear the speaker but the speaker can't hear you.

Hands-free: Start or cancel a handsfree call.

Adjust volume: You can volume the receiver by down key during a call

End a call: Press "Hang up" to end a call.

## 4. Call Log

Roll to any number and press the dial button reply the call, and can press [Menu] to select other operations.

#### **Commonly Used Functions:**

Press the single record for a long time, and open the option menu.

Call: call again.

Edit number before call: Edit the current number before call

Write message: Send message to the current number.

Add to blacklist: Set the phone number as a rejected call

Add to contacts: Store the number to this phone.

**Remove from call log:** Remove the current number.

.

## 5. Contacts

### 5.1 Browsing contacts

When this device standby, select [Contacts] and open the namelist.

The contacts are listed in the order of unnamed, special symbol, digit and English letter respectively (for Chinese names, the English letter corresponding to their pinyin prevails).

### 5.2 Quick search

When this device stands by, select [Contacts] and open the namelist.

Press the [A **rrow keys**] to m ove to the [Search box]. You may search via the physical keyboard 0~9 keys on the lower part of the screen or the keys on the keyboard (vague search is allowed).

### **5.3** Creating contacts

**SIM1:** The input is added to SIM1 with only one number stored under a name.

**SIM2:** The input is added to SIM2 with only one number stored under a name.

**Phnone:** All records other than in SIM1 and SIM2 are s tored in the memory of this device. Can be added to the group: Famoly, Friends, Business, Classmates.

Note: Name may be empty, but phone number shall not be so for any new record.

On the contacts list interface, press one record for a long time to operate the following functions:

**View contact:** View the contact.

**Call:** ring the contact.

**Send message:** send one message to the contacts.

**Delete contat:** Delete the person information.

**Edit contact:** Edit the contact.

**Send contact:** send the contact in vCard.

## 6. Message Service

Message service is actually a ne twork service. This menu works soundly depending on the type of your SIM card and the service prov ided by the network operator. Therefore, please check it before applying such function.

### Messaging

Please have the service center number from the network operator before applying this function. The storage capacity of SIM card depends on its type.

#### **6.1** SMS

This device supports multi-m essaging. Five comm on messages are editable at m ost with each containing 268 Chinese characters or 612 English ones.

When this device stands by, open the function m enu, select [Message New Messag] to open the editing screen and write a message.

#### **6.2** MMS

Short for multi-m edia service, MM S is just a multi-m edia m essage, which supports GIF , JPEG, WBMP or BMP display.

Select [Message→New Messag] to open the edit screen and edit a message.

## 7. Browser

Internet is an application platform integrating wireless communication and Internet technology, which makes it possible for you to access to rich Internet inform ation source and e-commerce application etc.

### **7.1** Open

Input webpage address you are to browse or link to the pre-set or default main page.

The lar gest free wireless portal website m akes it possible for you to have access to g lobal information without even stepping out of your house.

#### 7.2 Browser

Open the starting page of the brower, users can enter into input URL, search, bookmarks, history and stored pages through the interfaces.

### **Current Page:**

New window: Open the new page of the brower.

**Bookmarks:** Open the list of the stored bookmark.

Refresh: Refresh current WAP page.

**Send connection**: Send this link to a text message

More: Find on page, Select text, Page info, Settings, Exit

### 8. Multimedia

### 8.1 Audio Player

The cellphone is able to play music files saved in cellphone and the downloaded music and support background play of MP3 file.

#### **Background Play of Audio File**

In audio player m ode, press key to exit the audio player mode and e nter background play mode, at the same time, the idle mode will display name of the playing music.

### 8.2 Video Player

The video player supports 3gp and mp4 documents.

#### 8.3 Camera

Enter main menu, select [Camera] to enter Capture / record video pre-view mode.

### 8.4 FM Radio

In idle m ode, select **[FM Radio]**. To listen to broadcasting program , connect your compatible headset to the radio, and open it. Select the medium volume to listen to music.

## 9. Application

#### 9.1 Clock

You can use the Clock app's Alarms screen to set up one or more wake-up alarms.

### 9.2 Calendar

You can create new events prompt appears on the phone to remind.

### 9.3 Calculator

Enter the function list and select [Calculator].

Input the data by physical keyboard and you can choose add, subtract, multiply and divide.

### 9.4 Recorder

Don't just think out loud. Use Voice Recorder to quickly capture your thoughts. You can also record your voice and set it as a ringtone.

### 9.5 SIM Toolkit

In standby mode, press middle key to enter the function list and select [SIM Toolkit].

Entering the STK sub-menu, you can use the value added service offered by network operator.

This mobile supports STK function but this service is offered by network operator. If your SIM card and network operator don't support this service then you cannot use it. Please contact your network operator for more information.

## 10. Setting

### 10.1 Dual SIM settings

Data connection Setting

Standby SIM card Setting

♦ Standby SIM card Setting: When setting the SIM card (in standby) mode, you can choose either one SIM card card or two SI M card cards SIM cardu ltaneously to be in standby. You can custom ize Flight mode as the standby mode (Flight mode can not be switched continuously and 10 seconds is needed to turn of f it after it is activated) and customize Power-on options.

### **10.2 Connection Management**

The items are:

**Data connection settings:** Select to connect as needed or all the time.

**Network selection:** Select to automatically or manually connect.

### 10.3 Call settings

Set up call services such as call divert, call barring, call waiting, hide ID and Others.

### 10.4 Phone profile

The preset modes are General mode, Mute mode, Conference mode, Indoor mode, Outdoor mode, Headset mode. It support custom profiles, define at most 5 profiles, and users can set the parameters of the profiles.

Instruction: The preset profiles do not support delete, while the custom profiles support delete.

### 10.5 Display

Set up display settings such as automatic screen orientation, brightness, screen timeout, and more.

### 10.6 Security

### Including:

**PIN code:** Start and close of PIN code and the modification of PIN.



## **Warning**

Please use this function cautiously. If you for get the PUK code, please get it from the service provider. Ten consective incorrect PUK code entries will make the SIM card card unserviceable.

Modify PIN2 code: Modification of PIN2 code.



## Warning:

Be cautious to use this function, if wrong PUK2 code is entered for 10 times, SIM card can not be used.

Phone Lock: Open or close the phone lock.

**Change Phone Password:** Change the phone password.

**Privacy Protection:** Set the privacy protection

## 11 Maintenance of Mobile Phone

Mobile phone is a high-precision electronic product, so please take good care of it. The following suggestions can help you preserve it and lengthen its useful life:

- Put mobile phone and its accessories to the place where children are out of reach.
- ➤ Keep mobile phone dry. Rain, moisture or water may erode c ircuit board. If mobile phone falls into water carelessly, take battery out in time and send it to local authorized service center immediately.
- Please do not put mobile phone at dust-covered place or its normal usage will be affected.
- Liquid crystal display is an easily vulnerable part of m obile phone, try to preve nt it from falling down or violently shaken; it is forbidden to use sharp item to touch the screen.
- Please do not put mobile phone on the place where temperature is too high. High temperature will shorten the life of electric equipment, damage the battery, deform or melt its plastic cover.
- Please do not put mobile phone on the place where temperature is too low, or moisture will come out when its temperature increases to normal temperature, it will damage the circuit *board* of mobile phone.
- Please do not throw, knock or forcefully shake mobile phone to a void its inner circuit *board* and precise structure are damaged.
- Please do not clean mobile or with chemical agent, cleaning solvent or powerful detergent, instead, clean it lightly with soft cloth with soap water.
- Please do not draw mobile phone with painting material to prevent its removable parts from being stuck, which will affect its normal operation.
- Please use cleaning soft cloth to clean lens, such as camera's lens.
- When a ntenna is rep laced, use only supporting or designated antenna. Using unauthorized a ntenna, accessories or reshaping mobile phone may damage it or violated relevant wireless electric equipments.

# **12Troubleshooting for Simple Troubles**

In the cours e of using mobile phone, if abnorm al condition comes out, please refer to following instruction to rule out malfunctions. If it can't work, please contact designated maintenance center.

Mobile phone can't be turned on

Possible causes of trouble	Troubleshooting
The time pressing end key is too short.	Please keep pressing hanging mobile phone for more than three seconds.
Electricity of battery is exhausted.	Please charge the battery.
Battery is misinstalled.	Please install battery correctly.
Mobile phone can't be turned on because of illegal usage.	Please input correct anti-robbery password.

Mobile phone turns off automatically

Possible causes of trouble	Troubleshooting
If the function of turning of fm obile phone at set time is on	If you do n't nee d the function of tur ning off mobile phone at set time, please cancel it.
The electricity of battery isn't sufficient.	Please charge the battery.
The battery is loose.	Please i nstall batt ery correctly ac cording t o installation method of battery on the instruction book.
Mobile phone is turned off automatically because of illegal usage.	Please input correct anti-robbery password.

#### PIN/PUK code lock

Possible causes of trouble	Troubleshooting
Wrong PIN number (Personal	Please input correct password.
Identification Number) / PUK number	
(Personal Unlock Key number) is	
imputed.	



#### Note:

- 1. If PIN number is inputed wrong for 3 times successively, many functions of SIM card and mobile phone are locked, please read details in "safety settings" in P59.
- 2. Correct PIN number and PUK number can't be guaranteed, please contact operator or retailer.

Poor quality of conversation

Possible causes of trouble	Troubleshooting
Current signal strength changes sharply.	Maybe you are in a status of moving at high speed (in a train or motor, ect.), judge by signal strength indicator and choose a place with strong signal strength to communicate in order to assure conversation quality.
You are in the location where signal is badly received	Please go to the open place

Inability to answer mobile phone

Possible causes of trouble	Troubleshooting
Call forwarding is set.	Please cancel call forwarding according to your demand.
Call barred is set.	Please canncel relevant bar red function of Call barred according to your demand.

Inability to dial mobile phone

Possible causes of trouble	Troubleshooting
Mobile phone is power off.	Please turn on your mobile phone.
Mobile phone is out of network service area	Please confirm network is in normal service status.
Proper SIM card isn't correctly inserted.	Please confirm if your SIM card can be normally used.
Call barred is set.	Please cancel re levant barre d fu nction of Call barredaccording to your demand.
Keyboard is locked automatically.	Please select left soft key+# key, unlock keyboard

### Low conversation volume

Possible causes of trouble	Troubleshooting
The conversation volume is set too low.	Please increase conversation volume.

The counterpart can't hear you

Possible causes of trouble	Troubleshooting
Your microphone is too far away from voice.	Put the microphone close to your mouth.

### No ringtone for incoming call

Possible causes of trouble	Troubleshooting
The a lerting signal of incoming call is set in mute mode.	Please reset alerting signal of incoming call in ringtone
The volume of ringtone is set too low.	Please increase volume.
Call forwarding is set.	Please cancel Call divert

### Battery can't be charged

Possible causes of trouble	Troubleshooting
The battery is exhausted and placed for too long.	Please charge batt ery in tim e after mobile phone signalizes insufficient power.
Battery is in bad co ntact with m obile phone.	Please make sure battery is correctly placed.
Charger is in bad contact with mobile phone.	Please link well charger and port of mobile phone, now the screen displays charging indicator
Battery or charger is damaged.	Please contact m aintenance sta tion des ignated by the company
The surrounding temperature is too low or too high.	Please charge mobile phone under normal temperature.

### No network displayed

Possible causes of trouble	Troubleshooting
SIM card is wrongly placed.	Please place SIM ca rd correctly ac cording to its installation method on the instruction book.
There are im purities between SIM car d and contacts of mobile phone.	Please keep clean between SIM card and the contacts of mobile phone.
SIM card is ineffective.	Please check if SIM card is expired.
Network en vironment is in w eak field strength area.	Please move to the place with good signal strength of network for using mobile phone.

### Memory card can't be found in mobile phone

Possible causes of trouble	Troubleshooting
Memory card is wrongly inserted.	Please use m emory car d correct ly acc ording to its inserting method on instruction book.
Memory card is damaged.	Please change memory card.

### Insufficient space

Possible causes of trouble	Troubleshooting
MMS or SMS h ave occupi ed too m uch storing space.	Please Clear unnecessary MMS or SM S to free up space.
History recor ding s aved in brow ser has occupied too much storing space.	Please select <b>Communication</b> → <b>Browser</b> → <b>WAP settings</b> → <b>Browser settings</b> → <b>Clear cache</b> ] to free up space.

### Menu options what PC Camera of mobile phone can't realize

Possible causes of error	Troubleshooting
After mobile phone is linked to computer, no menu of "PC Camera" is displayed on mobile phone.	<ol> <li>Please check if USB port of computer is complete.</li> <li>Please check if you have correctly used linking line provided by retailer.</li> </ol>

## 13 Safety Information

#### **Usage Environment**

To assure you use mobile phone reasonably and avoid its affect on you and environment, please keep in mind relevant regulations and provisions which shall be complied with at any place when you use mobile phone.

In the places which may give rise to bomb such as gas station, fuel reservoir, chemical factory, or bom bing work, please turn off your mobile phone and abide by all safety marks and instruction there. Any violation against relevant regulations may give rise to bomb and cause casualty.

Using mobile phone in plane may disturb plane's operation and give rise to danger. Therefore, please do turn off your mobile phone before boarding and make sure it is power off in the whole course of flight.

When your drive, please place mobile phone on a special stand, do not place it on seat or any place where it may slide when it comes to collision or sudden braking. In the course of driving, please do not use mobile phone to assure a safe drive and avoid traffic accident. If you must use mobile phone, please stop first before using it.

Please keep your mobile phone away from high-temperature environment to avoid bomb rising from increased temperature of battery.

#### **Medical Equipments**

It is expressly stipulated in writing that you shall turn off mobile phone nearby electric medical equipments (like c ardiac pa cer m aker an d hearing a ids). M ost m edical e quipments ha ve f unction of b locking radio-frequency signal given off by mobile phone, but some electronic equipment don't. if you have any doubt or uncertainty about if m edical equipment have function of blocking radio-frequency signal, please consult doctors or manufacturer of medial equipments.

#### Pace Maker

Manufacturer of pace maker suggests you keep a di stance of about 6 f oot (15.3 cm) at le ast between your mobile phone and pace maker, in order to prevent mobile phone from causing disturbance to pace maker.

#### **Staff wearing pace maker:**

When your mobile phone is power on, make sure the distance between your mobile phone and pace maker is about 6 foot (15.3 cm) at least.

Please do not put mobile phone into the pocket in front of chest.

Please receive the call with the ear at the side different from pace maker.



#### Note:

If you suspect any disturbance, please turn off mobile at once and consult medical staff in time.

#### **Hearing Aids**

Mobile phone m ay disturb som e hearing aids , if disturbance is m ade, please contact

manufacturer of hearing aids at once.

#### **Emergency Call**

The sam e as o ther mobile p hones, this k indo f mobile phone uses rad io signal, wi reless and ground communication network and personal setting function, it can't guarantee it can get linked successfully under any situations. Please don't reply on only mobile phone for sending important communication (such as medical emergency)

#### Dial emergerncy call

If your mobile phone is power off, please turn it on and check if network signal is strong enough.

- Input correct local emergency number (like 120 emergency center), the number differs from one district to another.
- Please call by pressing talking key.



In case of em ergency call, please try to provide all important informtions. The mobile phone may be at t he accident site. It is the only conversation tool, please do not end conversation without approval.

#### Password Access

The mobile phone and SIM card can be protected by password to prevent them from illegal usage.

#### **Power-on Password**

To prevent your mobile phone from being used by others without your approval, you can set password when you use the function for the first time. After you use mobile phone, please change power-on password as soon as possible and keep it secret.

#### **PIN Code**

It is p ersonal identification number to p rotect SIM card from being used by others without your approval. Usually PIN code and SIM card are provided together. When you use using power-on PIN code, every time when you turn on mobile phone, you have to input password before starting the normal phone function.



#### Note:

If PIN code is imputed wrong for three times successively, SIM card will be locked. You need to input PUK code to unlock it. (If no P UK code is available, please cont act your network operator or SI M card retailer asking for PUK code. Please don't input any character.)

#### PIN2 Code

PIN2 is password to realize special function of SIM card. If the network operation company provides this z

Unlock K ey PIN code. U sually PU K co de and SIM card are provided together. If y ou don't have, please contact your network operator or SIM card retailer. If you imput wrong PUK c ode for ten times successively, SIM card can't be used any more. Then please apply to your network operator for a new card. Do not change PUK code.

#### **PUK2 Code**

Unlock PIN 2 code. U sually PUK2 code and SIM card are provided together, PUK2 code can alter locked PIN2code. If PUK2 num ber is imputed wrong for ten times successively, some functions can't be used any more. Then please apply to your network operator for a new card. Do not change PUK2 code. If it is lost, please contact service provider.

#### **Attentions on Charging of Battery**

This kind of mobile phone provides energy by lithium ion battery, system environment, mobile phone settings and others will affect waiting and conversation time of mobile phone.

Please us e the standard battery and c harger provided by the c ompany, or the com pany isn't responsible for damage caused by battery or charger unauthorized by the company.

When the mobile phone is power on, the *batty* starts to roll on the battery indicator on the screen.



#### Note:

- 1. If the battery doesn't have power at all, the battery indicator will show up after it is charged for 2 to 3 minutes. Generally according to current status of mobile phone (if it is power on, with conversation, etc), the charging time is 2 to 5 hours.
- 2. To make new battery reach perfect performance, please finish two to three charging and discharging cycles. A new battery shall be charged continuously for above 10 hours for the first time.

In the course of charging mobile phone, please do not contact its battery or charger with wet hand in order to avoid danger.

When mobile phone is charged, please do not to use it as possible as you can.

After the battery is charged full, the electricity indicator stops rolling, then take mobile phone out from the port of its adaptor.

#### **Attentions on Use of Battery**

The usage of battery is determined by network, settings of mobile phone, usage of mobile phone, take lithium ion battery with capacity of 1200 MA, for example, its conversation time is about 6 to 8 hours and standby *time* is 150 to 240 hours.

Please do not use damaged charged battery.

When mobile phone is used nearby network base, battery consumes little electricity. Therefore, conversation and standby *time*, to great extent, are affected by signal strength of cellular network and parameter set by network operator.

Time of char ging battery depends on residual capacity, type of battery and electronic equipment type. When usage time of battery is obviously shortened, you have better change battery to guarantee the performance of

mobile phone.

Please use standard battery and charger provided by Amoi Company, or it may give rise to bomb. When you don't need charger, please cut off electricity source. Do not keep battery linked with charger for over one week, overcharge will shorten useful life of battery.

Please do not place battery by mistaking its cathode and anode.

Please do not place battery at place where it is too high or too low, or it will decrease battery's capacity and life. Please use battery at domestic temperature as possible as you can.

Do not make battery short-circuit, or it will damage battery core or protective circuit inside battery. When you put un used b attery in po cket or bag, medal items (coin, pi n or pen, etc.) may link two ends of b attery immediately and make battery short-circuit, so please place battery singly and safety.

Please do not burn battery of mobile phone or do wit h it as common rubbish. To avoid potential life hazards and harm to environment, please comply with environment-friendly policy stipulated by local government, treat and recycle battery in time.

If your mobile phone, battery or other charging equipment fall into water carelessly, please do not dry it in any heating equipment (such as drier, microwaver). Mobile phone or other products may give rise to malfunction, and mobile phone, battery or other charger may burn, expand bomb.

Please do with abandoned used battery according to relevant stipulation.

Amoi Company isn't responsible for any direct or indirect loss caused by above-mentioned wrong operation.

#### **Attention on Use of Accessories**

Please put all accessories (such as SIM card, memory card, battery) in the place where children are out of reach, to avoid danger.

Before taking out battery of mobile phone, please make sure mobile phone is power off and cut off linkage between mobile phone and charger.

Accessories of mobile phone don't have waterproof performance, please keep all accessories dry.

When cutting off electricity from any accessory, take out plug correctly, do not draw power cable.

If mobile p hone, b attery and charger don't function normally, please contact the nearest and qualifying maintenance department.

#### **Other Safety Information**

When mobile phone is not used, you'd better turn off mobile phone and take out battery in order to save energy and eliminate radiation of mobile phone.

When mobile phone is used, please do not adjust its volume too high or it will do harm to hearing

Non-professional shall not take out terminal and battery of mobile phone by himself or herself.

You'd better not use leather case with magnetic button as possible as you can to avoid magnet what may cause disturbance to signal of powering on or off the mobile phone, and its hard iron button may damage fluid crystal

display; plastic case may cause unsmooth evaporation to steam, eroding components inside mobile phone and oxidizing and discoloring its cover.

This device complies with part 15 of the FCC Rules.

Operation is subject to the condition that this device does not cause harmful interference Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

#### Specific Absorption Rate (SAR) information:

This Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: SD100 (FCC ID: **2AC55SD100**) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 3.243W/kg and when properly worn on the body is 1.393W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not

comply with FCC RF exposure requirements, and should be avoided.

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.