#### **WARRANTY TERMS**

This warranty does not cover any defect for bad use or natural wear, or even IF it is not used according to our guidelines.

This warranty does not cover any defect caused by use of non original or non compatible peripherals and third party software installation.

In case this product has a factory defect, since you can prove it, Multilaser is compromises to fix it or replace your product.

The below cases are not covered by this warranty:

- . Natural use
- . Damages caused by liquids, high temperature (Hot or cold)
- . Oxidation or fungus
- . Shocks
- . Impacts
- . Damages caused t LCD because of bad use, pressing, shock or humidity

This product is warranty covered for the period of 12 months and the accessories that are included in this kit are covered for 3 months from the acquisition day on.

This certified is only valid under the presentation of the purchase receipt.

### 1. Usage Tips

For your safety and better conservation of the product, do not let your device take rain, humidity, sunlight, excessive heat. Do not disassemble the device, it will result in loss of warranty and can also affect your safety.

## 2. Cleaning your product

In order to clean the screen or other parts, always use soft cloth, avoid the use of gauze or rough cloth and other rough papers, this can scratch your device.

## 3. Turning your Tablet

In order to power on your tablet, press the POWER button for 3 Seconds.

To turn it off, press the POWER button for 3 seconds, select OK in the screen that appears next...

## 4. Starting to use

As soon as you power on the device, the screen below will be displayed. This is the home screen lock,

to unlock, tap and drag the center of the circle to the corner where the icon is \textstyle \textst



#### 5. Touch Screen

In order to select any object on the screen, tap the screen softly.

Pressing and holding the objects on screen enables them to be moved, create shortcuts and delete the desired application.

#### **6. Data Transfer**

You can transfer files, music, videos, photos and applications from your PC to your tablet, or vice versa. This can be done by using an USB cable. Plug the cable into the tablet and the computer, click on the status bar at the right bottom of the screen of the tablet, click on "Turn on USB storage", as shown below, then you can navigate between folders of files.



#### 7. Micro SD Card

This device is compatible with Micro SD card to store music, files, videos, photos and applications. You can use it as an extension of internal memory.

To have access to the contents in the card, insert it into the card input, identified on your tablet, go to the app menu and select the "Explorer" or "File Manager", on the next screen, select the "SD Card" option

In order to remove the SD card, tap the icon Storage > Dismount SD card.



## 8. Charging battery

Battery model: 326210

Prefer to use only the adaptor included in the kit, other adaptors voltages maybe be different and this can damage your tablet.

In order to charge it, connect the Adaptor and the tablet and plug it into a socket.

indicates that the battary is being recharged, and the icon battery is fully charged.

To preserve the battery life, use the device at least once a week, and regularly gives a full charge to the battery. When using your device for the first time, make sure the battery is fully charged. If you need to recharge it, connect the adapter included in the kit and plug into a 110V or 220V socket. Let it recharge for about 4 hours or until the device indicates that the battery is fully charged.

If the device is not working at all, connect the charger, plug it into the socket and restart your Tablet using the RESET button.

The device can be up to 3 hours without showing any signs on the screen or even a noise, after that period, it should be ready to be powered on.

## 9. Wi-Fi Settings



Tap the icon > select Wi-Fi option on the left side bar on the screen.

The available networks Will appear on the right side of the screen, Select the desired network.



In case the network has the symbol , ,you Will need to have a network password to have access.

To return to desktop, tap the button on the right bottom side of the screen.

## 10. Desktop



- 1 Search
- 2 Voice search function
- 3 Aplication menu
- 4 Back
- **5** Home
- 6 Running applications

- Volume control -
- 8 Volume control +
- 9 Notification bar
- **10** Wi-Fi status
- 11 Battery status

# 11. Installing Applications

Go to the apps menu and tap the icon



As soon as the app is open, you need to login with a Google account, that can be created on Google

website or even through the application.

Follow the instructions on screen to proceed. When you finish the operation, you Will have Access to all the available application for your device on Play Store, you can download free and paid applications. For the paid applications you will need to insert a credit card number on account settings.

## 12. Uninstalling Applications

The applications can be removed from your tablet in two different ways:

- 1. Touch and hold the application, then slide it and release on the "X" that Will appear on the upper central side of the screen.
- 2. Go to the Settings menu > Apps > Select the application > Uninstall > Ok.

#### 13. Sound Record





#### 14. Camera

Go to the application's menu and tap the icon lacksquare, you will can be able to make photos and videos.

to take the photos. The photos Will appear on the upper right side of the sreen, touch the photo for a preview nas then touch to return to camera function.



The button starts and the button stop the record.

The icon on top right corner of screen access the settings camera's menu for adjust the light's mode, brightness and storage's place.

The camera's zoom can be done with a motion of tweezers over the screen, using only two fingers for increase or decrease the zoom.

#### **15. E-mail**

In order to start, make sure that the tablet is connected to a Wi-Fi network.

Please contact your email provider to confirm if the server is compatible with (POP) and (SMTP).

Select > Enter an e-mail address and Password> Next> Manual Setup (optional): server settings can be made on the email provider (EX: gmail.com) according to your e-mail. If you need to make a review, click "manual setup" to make changes.

Click Next Step> Enter the Account name> Finish.

#### 16. Music

Tap on Source or in a Micro SD card, reproduction can be selected by Artist, Album, Track or favorite folder.

## 17. Wallpaper

Go to Desktop, touch and hold the screen for few seconds until the below options appear:

You can choose one of the options



Select a wallpaper from gallery.



Select an Android preloaded wallpaper.

#### **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.