


# American Standard

---



**American Standard is devoted to making life,  
in the heart of your home, better every day...**

...so, thank you for inviting us in! With the very best in kitchen and bathroom products, we are here to help make your life happier, healthier and simpler. Our commitment to quality, innovation and performance has made us part of your everyday routine for nearly 150 years, and we look forward to being a part of your life for many years to come.

**Learn more at [www.AmericanStandard.com](http://www.AmericanStandard.com)**

## **REGISTER YOUR WARRANTY**

Try the easy-scan **QR code** to quickly enter your information or find your product's detailed warranty here:

**[www.AmericanStandard.com/warranty](http://www.AmericanStandard.com/warranty)**



Registering allows you to keep your product information safe, and us the ability to contact you in the event of a product recall or *any* news about your purchase.

**And if ever you have a question or need help...?**

Call us at 1-855-815-0004

M985146 EN (7/23)

607B121/607B051/607B013/6078013/6078051


*American Standard*  
DetectLnk

# OWNERS MANUAL




## IoT DetectLnk™ Exposed Urinal Flush Valve

607B121 / 607B051 / 607B013 /  
6078013 / 6078051

Image shown may vary from product purchased.




### INSIDE THE BOX (BATTERY VERSION)






60780XX FOR BATTERY VERSIONS

POWER KITS SOLD SEPARATELY




### INSIDE THE BOX (AC VERSION)




607BXXX/607B0XX FOR AC VERSIONS

POWER KITS SOLD SEPARATELY

Hard-Wired AC  
Power Kit  
PK00.HAC / PK00.BBU



Hard-Wired AC &  
Multi-AC Power Kit  
PK00.MAC / PK00.HAC  
PK00.BBU



**NOTE TO INSTALLER: Please give this manual to the customer after installation.**

To learn more about American Standard Selectronic® Products visit our website at:  
[www.americanstandard-us.com](http://www.americanstandard-us.com) or e-mail us at: [ASdetectlnk@lifixil.com](mailto:ASdetectlnk@lifixil.com)

**For Parts, Service, Warranty or other Assistance,**  
**please call (844) CRT-TEAM / (844) 278-8326**  
**(In Toronto Area only: 1-905-306-1093)**



## PRIOR TO INSTALLATION

**Note:** Prior to installing the DetectLnk™ Flush Valve the following items must be installed.

1. Urinal/Toilet
2. Drain line
3. Water supply line

### IMPORTANT:

- **All plumbing and electrical wiring should be installed in accordance with applicable codes and regulations.**
- The use of water hammer arrestors is strongly recommended for commercial applications. All piping behind the walls should be properly secured and fastened.
- Water supply lines must be sized to provide an adequate volume of water for each fixture.
- Flush all water lines prior to operation. Dirt and debris can cause flush valve to run continuously.
- **With the exception of Stop Valve Inlet, DO NOT use pipe sealant or plumbing grease on any valve component or coupling!**
- Protect the chrome or special finish on the Flushometer. DO NOT USE toothed tools on finished surfaces to install or service these valves. Also see "Care and Cleaning" section of this manual.
- This product contains mechanical and/or electrical components that are subject to normal wear. These components should be checked on a regular basis and replaced as needed to maintain the valve's performance.

## RECOMMENDED TOOLS

Installation steps will indicate which tools should be used with associated letter



Teflon Tape

**A**




Flat Blade  
Screwdriver

**B**



Adjustable  
Wrench

**C**




Hacksaw

**D**



Tape Measure

**E**



Tubing Cutter

**F**




File

**G**



2.5 & 1.5 mm  
Hex Wrench

**H**



Solder & Torch

**I**

**Consult fixture manufacturer for minimum pressure requirements. Most High Efficiency water closets require a minimum flowing pressure of 25 psi (172 kPa). Many building codes and the ASME A112.19.2 fixture standard list Maximum static water pressure as 80 PSI (552 kPa).**

# FLUSH VALVE INSTALLATION

1


## INSTALL SWEAT ADAPTER



**Turn off hot and cold water supplies before beginning.**

**Note: Install Optional Sweat Adapter (Supplied) for copper pipe supply line.**

1. Measure the distance (A) from the finished wall to the center of the inlet spud on the fixture.
2. Cut the supply pipe 1-1/4" (A-B=C) shorter than the measurement taken in Step 1. File any rough edges off the end of the supply pipe.
3. Clean the end of the supply pipe. Push the threaded Adapter until it is seated against the internal stop. Sweat the Adapter to the pipe.



**F G I D E**

2


## INSTALL COVER TUBE, WALL ESCUTCHEON AND STOP VALVE

1. Measure from finished wall to first thread of Adapter or threaded supply pipe (dimension "X"). Cut COVER TUBE (1) to length (X). Apply Teflon Tape to the threaded end of the Adapter or supply pipe.
2. Push WALL ESCUTCHEON (2) onto the COVER TUBE (1). Slide both onto the SUPPLY PIPE (3).
3. Push the COVER TUBE (1) in to expose the threads of the supply pipe. With a wrench thread the STOP VALVE (4) onto the SUPPLY PIPE (3). Align and tighten.
4. Pull COVER TUBE (1) against STOP VALVE (4) and push WALL ESCUTCHEON (2) against finished wall.

Fig. 4a

Fig. 4b

Fig. 4c




**A C D F**

### 3

#### FLUSH OUT SUPPLY LINES

1. Remove STOP VALVE COVER (1) from STOP VALVE (2).
2. Open STOP VALVE (2) with a flat blade screwdriver.
3. Turn on water supply to flush line of any debris or sediment.
4. Close STOP VALVE (2) and replace STOP VALVE COVER (1).



B


### 4a

#### INSTALL VACUUM BREAKER TUBE: APPLICABLE FOR STANDARD CERAMICS

**Note:** Step 4a is only applicable if using standard ceramics. If using IoT Ceramics, skip to step 4b.

1. Insert VACUUM BREAKER TUBE (1) through HEX NUT (4), FLUSH VALVE BOTTOM COVER (2), and SPUD COVER (3).
2. Thread SPUD COVER (3) on to the toilet base.

**Note:** Ensure that the O-ring is properly seated in the base of HEX NUT (4).



C

## 4b

### INSTALL VACUUM BREAKER TUBE: APPLICABLE WITH ASA IoT CERAMICS

**Note:** Step 4b is only applicable if using ASA IoT Ceramics or the hard-wired power option. Otherwise, refer to step 4a.


1. Separate HEX NUT (4) from SPUD COVER (7).
2. Thread WIRE (5) through FLUSH VALVE BOTTOM COVER (2) and SPUD COVER (3).
3. Insert VACUUM BREAKER TUBE (1) through the FLUSH VALVE BOTTOM COVER (2), SPUD COVER (3), HEX NUT (6), AND HEX NUT (4).
4. Thread HEX NUT (4) on to the Toilet Base.

**Note:** Ensure that the O-ring is properly seated in the base of HEX NUT (4).


**Note:** Vacuum breaker tube can be shortened by up to 1-1/2" if desired.

**Note:** Wire (5) may be one or two wires. ASA IoT Ceramics has a wire here as well as the Hard-Wired AC power option (27" extension cable).

**Note:** Spud Cover (3) and Wire Cover and Vacuum Breaker Tube (1) are available in the IoT Ceramics Packaging.




**C D**




1. Slide SPUD COVER (1) over HEX NUT (2).
2. Secure SPUD COVER (1) by tightening SET SCREW (3).

**H**



1. Thread WIRE (1) through the back of FLUSH VALVE BODY (2).

**Note:** There is a small hole on the top back of the brass body for the wire head to fit through.




5

## CONNECT VALVE BODY TO STOP VALVE

1. Push VALVE BODY (1) in to STOP VALVE (2) allowing the O-ring to seal the connection.
2. Thread HEX NUT (3) on to STOP VALVE (2) to secure the connection.

**Note:** Do not use pipe sealant or plumbing grease.



C


6

## CONNECT VALVE BODY TO VACUUM BREAKER TUBE

1. Thread HEX NUT (1) on to the bottom of VALVE BODY (2).

**Note:** Ensure that the bladder on the vacuum breaker tube makes a good connection with the bottom of the flush valve body.

**Note:** If using a wired version, ensure the wires do not get pinched while securing the flush valve body.



C



## 7

### INSTALL WIRE COVER: APPLICABLE WITH ASA IOT CERAMICS

**Note:** This step is only applicable if using ASA IoT Ceramics


1. Insert WIRE COVER (1) through FLUSH VALVE BOTTOM COVER (3) and SPUD COVER (4).
2. Cover the WIRE (2) with the WIRE COVER (1). (Applicable with AC Version) Cover the AC wire with the WIRE COVER (1) similar to WIRE (2).

**Note:** The Wire Cover will be loose until the next step to secure it. Ensure that the wire does not slip out between steps.

**Note:** Avoid pinching or excessively bending the wires.

**Note:** If the vacuum breaker tube was cut to a shorter length, the wire cover will also need to be cut. Wire cover length should be from the top of the installed spud cover to the bottom of the valve body fixation nut plus 1/8".


**Note:** WIRE COVER (1) is only included in ASA IoT Ceramics Package.



## 8

### SECURE FLUSH VALVE BOTTOM COVER

1. Secure FLUSH VALVE BOTTOM COVER (2) with the two SET SCREWS (1) on each side.



H

## 9a


### MAKE WIRED CONNECTIONS: BATTERY VERSION

**Note:** This step is only applicable for the battery version.

**Important:** Align the polarity markings (7) on the wire ends when making the connections.

1. Connect the SOLENOID WIRE (1) to the RED AND BLACK WIRE (2) in the flush valve head.
2. Connect BLACK AND PURPLE WIRE (5) to the BATTERY PACK (6) within the top of the flush valve head.
3. Place the BATTERY PACK (6) within the top of the flush valve head.

**Note:** Do not tighten flush valve head at this point.




## 9b

### MAKE HOLE FOR AC WIRE

**Note:** This step is only applicable for the AC version.

1. Secure FLUSH VALVE HEAD (1) on to the flush valve body.
2. Using the WIRE CHANNEL (2) as a template, mark the drill location on the wall.
3. Make an opening in the wall at the marked location.

**IMPORTANT:** The hole diameter should be no smaller than the wire channel and no larger than the wire channel escutcheon cover.




**Important:** Align the polarity markings (7) on the wire ends when making the connections.




**Note:** Contractor to supply ELECTRICAL BOX (11).

1. Connect the SOLENOID WIRE (1) to the RED AND BLACK WIRE (2) in the flush valve head.
2. Connect black and white power line connections to HARD-WIRED AC TRANSFORMER (12) and mount onto ELECTRICAL BOX (11)
3. Thread EXTENSION CABLE (4) through the WIRE CHANNEL (6) and through HOLE (8) in the back of the flush valve head. Connect one end of the supplied EXTENSION CABLE (4) to the BACK-UP BATTERY (14) and connect the other end of CABLE (4) to the BLACK AND PURPLE WIRE (5).
4. Connect BATTERY BACK-UP (14) to HARD-WIRED AC TRANSFORMER (12).

**Note:** Do not tighten flush valve head at this point.

**Note:** Power to the circuit must be deenergized while making hard wired connections.



**Unit #1 Already installed****Unit #2****Unit #3****Unit #4**

**MAXIMUM OF 8 UNITS PER POWER SUPPLY.  
10' MAXIMUM CABLE LENGTH BETWEEN UNITS.**

**Important: Disconnect AC Power Supply from wall outlet before making daisy-chain connections.**

**Note: For Unit #1 installation instructions, refer to AC version section (page 9).**


**For subsequent Units...**

1. Take the first 27" EXTENSION CABLE (1) and connect one end to the solenoid cable and connect the other end to a sensor cable.
2. Take the second 27" EXTENSION CABLE (2) and connect one end to the available sensor cable, the other end to the BATTERY BACK-UP KIT (5).
3. Connect the other end of the BATTERY BACK-UP KIT (5) to one of the two terminals at the one end of Y-ADAPTER (3).
4. Take the 10' EXTENSION (4) and connect one end to the single terminal of Y-ADAPTER (3), and the other end to available terminal of the previous unit's Y-ADAPTER (3a).
5. Repeat process for each subsequent unit.
6. Place Y-ADAPTERS (3) into respective electrical box.
7. Plug in AC power supply into wall outlet once all daisy-chain unit connections have been made.

**CAUTION:** Use only American Standard supplied transformers and cable sets. Using non-AS supplied cables, or cutting, splicing or modifying any components will void the warranty.

1. Connect the ORANGE WIRE (3) to the ORANGE WIRE (4).

**Note:** This step is only applicable if using ASA IoT Ceramics.




# 11

## INSTALL FLUSH VALVE HEAD:

**Note:** excess wire length should be placed in the Flush Valve Head so that is not pinched when the Flush Valve Head is installed.

1. Place FLUSH VALVE HEAD (1) on to FLUSH VALVE BODY (4) and rotate so that FLUSH VALVE HEAD (1) locks in to KEY SLOT (3).
2. Secure FLUSH VALVE HEAD (1) with SET SCREW (2).

H




# 12

## INSTALL WIRE CHANNEL

**Note:** This step is only applicable for the AC version.

1. Thread WIRE COVER (2) in to the back of FLUSH VALVE HEAD (1).
2. Secure ESCUTCHEON (3).



# 13

## IMPORTANT FLUSH VALVE ACTIVATE

1. Remove IR sensor cover sticker. Test flush functionality with a single button press (do not hold down button) and check for leaks.
2. Refer to the Quick Start Guide to complete setting up the flush valve functionality.

**IMPORTANT:** To avoid overflowing, the STOP VALVE (3) must never be opened to the point where the flow from the valve exceeds the flow capacity of the fixture.

1. After installation is complete, peel off the PROTECTIVE FILM (1) from the sensor. Standing to one side, block the sensor with your hand for 10 seconds. Remove your hand and listen for audible “click” from within the valve.
2. Remove STOP VALVE COVER (2) from STOP VALVE (3). Turn on water supply 1/4 turn to 1/2 turn (CCW) and test for leaks.

**Note:** Unit may flush for approximately 3 to 10 sec. when water is first turned on. If flow persists, turn water off and repeat step #1 above.

3. Actuate the FLUSH VALVE:


A) Cover sensor with hand for 10 seconds.

**NOTE: Stand outside of sensor detection area.**

B) Remove hand from in front of the sensor; unit will flush in approximately 3 seconds.

C) Press Button in front of the FV for 1-2 Second; Unit will flush in approximately 3 seconds.


4. Adjust STOP VALVE (3) after each flush until the stated flush volume is achieved, no splashing occurs and the fixture is properly cleansed.
5. When adjustment is complete, replace STOP VALVE COVER (2) and tighten to ensure vandal-resistance.



# 15

## MAINTENANCE: REPLACE BATTERY


1. Loosen SET SCREW (1) with 2.5mm Hex Wrench (2) in back of FLUSH VALVE COVER (3).
2. Rotate COVER (3) to the right and pull off.
3. Turn COVER (3) over and disconnect the SENSOR (4) from the BATTERY (5).
5. Remove old BATTERY (5) and replace with the new battery.
7. Connect BATTERY (5) to SENSOR (4).



# 16

## REPLACE BACK-UP BATTERY KIT FOR AC VERSION

1. Remove old back-up battery by disconnecting the two wires.
2. Install new kit by connecting it to the two wires.






## SET DETECTION RANGE (IF REQUIRED)

1. Once the device is paired, you may edit the settings by navigating to Device Management screen and finding the DEVICE CARD (1). You must be in Bluetooth range to the device.
2. Press on the DEVICE CARD (1) and scroll down to find the CONNECT (2) button.
3. Once the app connects to the device, a "Settings" button will be available.
4. Enter the Settings screen and adjust IR sensor distance as needed and press "Apply"
5. Actuate the flush valve. Cover sensor with a piece of cardboard or similar item for 10 seconds. Unit will flush for approximately 3 seconds..

***Flush durations should not be modified unless specified in the by manufacturer.***




1" - 2" (30mm - 50mm)

1 BLINKING LED

DETECTION ZONE  
400mm TO 800mm  
(Factory Setting: 400mm)

1 BLINKING LED



| PROBLEM                                             | POSSIBLE CAUSE                                                                               | CORRECTIVE ACTION                                                                                                                                                                                                                       |
|-----------------------------------------------------|----------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Valve will not operate.                             | Stop valve is closed.                                                                        | Open stop valve.                                                                                                                                                                                                                        |
|                                                     | Supply valve is closed.                                                                      | Open supply valve.                                                                                                                                                                                                                      |
|                                                     | Battery/The electric wire(s) is not connected.                                               | Connect the wires.                                                                                                                                                                                                                      |
|                                                     | Sensor lens is dirty.                                                                        | Clean lens.                                                                                                                                                                                                                             |
|                                                     | Reflective surface in front of sensor.                                                       | Remove the reflective surface from in front of the sensor.                                                                                                                                                                              |
|                                                     | Detection range not adjusted properly.                                                       | Adjust the detection range.                                                                                                                                                                                                             |
|                                                     | The infrared sensor or the actuator is out of order.                                         | Contact distributor for replacement.                                                                                                                                                                                                    |
|                                                     | Battery is critical.                                                                         | Press the button for 3-5 seconds. If LED does not blink blue, the battery is critically low and needs to be replaced.                                                                                                                   |
|                                                     | Flush Valve Electronic is faulty.                                                            | Replace Flush Valve Electronic.                                                                                                                                                                                                         |
|                                                     | No power provided by battery/power supply.                                                   | Replace battery/power supply.                                                                                                                                                                                                           |
| Flush valve does not activate after user leaves.    | Sensor does not recognize a user.                                                            | Using the DetectLnk™ app, enter the device settings and adjust IR Distance.                                                                                                                                                             |
|                                                     | Battery/Power Supply is disrupted.                                                           | Verify connection to sensor.<br>Check available voltage where Battery/Power supply is connected with sensor with DC voltmeter. 5.8 to 6.5 VDC is required.                                                                              |
| Unit is constantly flushing.                        | Solenoid may be stuck open.                                                                  | Press the button for at least 3-5 sec.<br>If the LED starts blinking blue, but the water does not stop, the Solenoid needs to be replaced.<br>If the LED does not blink blue and water does not stop, the Battery needs to be replaced. |
| Insufficient volume of water to adequately fixture. | Stop valve is not open enough.                                                               | Open stop valve for desired volume of water.                                                                                                                                                                                            |
|                                                     | Insufficient flow rate or pressure at supply line.                                           | Consult fixture guide for minimum gallons per minute flow and running pressure for satisfactory performance.                                                                                                                            |
|                                                     | Water pressure is lower than recommended.                                                    | Fully open the angle stop, then using the DetectLnk™ app, enter the device settings and increase the flush durations. Test at every 0.125 sec. increment.                                                                               |
| Valve is flushing too long or not shutting off.     | Trip mechanism not seating properly due to foreign material between trip mechanism and seat. | Disassemble parts and rinse thoroughly.                                                                                                                                                                                                 |
|                                                     | By-pass orifice is plugged or partially plugged.                                             | Examine by-pass orifice and clean if necessary, being certain not to enlarge orifice opening.                                                                                                                                           |
|                                                     | Line pressure is not adequate to force trip mechanism to seal.                               | Pressure is inadequate or has dropped below minimum operating range. Steps should be taken to increase the line pressure.                                                                                                               |
| Water splashes out of fixture.                      | Supply flow rate is higher than is necessary.                                                | Adjust downward on control stop.                                                                                                                                                                                                        |
|                                                     | Lime accumulation on vortex or spreader holes of fixture.                                    | Remove the lime build up.                                                                                                                                                                                                               |

| PROBLEM                                                                 | POSSIBLE CAUSE                                    | CORRECTIVE ACTION                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------|---------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flush is not considered quiet.                                          | Control stop is not adjusted for quiet operation. | Adjust the control stop for quiet operation keeping in mind the fixture evacuation requirements.                                                                                                                                                          |
|                                                                         | Fixture is contributing to noise.                 | Check noise created by fixture by placing a cover over the bowl opening to separate valve noise from bowl noise. If it is determined the fixture is too noisy, consult with fixture manufacturer.                                                         |
|                                                                         | Piping system is source of noise.                 | High pressure in the system can sometimes be controlled by the stop valve. Other sources of noise may be the absence of air chamber and shock arrestors, loose pipes, improper size pipes, etc. In these cases the building engineer should be consulted. |
| Flush valve "ghost" flushes or activates randomly with no user present. | Sensor lens is dirty.                             | Clean lens.                                                                                                                                                                                                                                               |
|                                                                         | Sensor is detecting stall door.                   | Using the DetectLnk™ app, enter the device settings and adjust IR Distance.                                                                                                                                                                               |
| Unit only flushes with the button and not automatically.                | User Detection minimum timing may be too long.    | Using the DetectLnk™ app, enter the device settings and verify Detect Interval setting. This is the time a user needs to be in range, before the automatic flush starts. Recommended time = 5 sec.                                                        |
| Device is not communicating.                                            | Device lost power.                                | Double check power connections and supply. If using AC version, check backup battery & replace.                                                                                                                                                           |
|                                                                         | Multi AC power cable was not connected.           | Ensure that cable is securely connected.                                                                                                                                                                                                                  |
|                                                                         | Sensor not advertising.                           | Press Button for 3 second, then Blue LED stats blinking, connect through DetectLnk™ app.                                                                                                                                                                  |

**Have a question or need help on install?**

For questions or help on installation call us at **855-815-0004**.

## APPENDIX A

### Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

**Unique Identifier:** IoT DetectLnk UPS and 6078013.002, 6078051.002, 607B013.002, 607B051.002

**Responsible Party :** AS America, Inc. d/b/a LIXIL Americas

**Address :**

AS America, Inc. d/b/a LIXIL Americas

865 Centennial Ave.

Piscataway, New Jersey 08854

[www.americanstandard.com](http://www.americanstandard.com) | [www.d xv.com](http://www.d xv.com) | [www.grohe.com/us](http://www.grohe.com/us) | [lixil.com](http://lixil.com)

**FCC Compliance Statement : According to FCC Part 15**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- The equipment complies with the safety requirements for RF exposure for mobile (>20 cm) use conditions in accordance with FCC rule part 2.1091.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.
3. The equipment complies with the safety requirements for RF exposure in accordance with RSS-102 Issue 5 section 2.5.2 for mobile (>20 cm) use conditions.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
3. L'équipement est conforme aux exigences de sécurité pour l'exposition aux RF conformément à la norme RSS-102 Édition 5 section 2.5.2 pour les conditions d'utilisation mobiles (>20 cm).

# TELL US WHAT YOU THINK!

Please leave us a product review or story  
at **AmericanStandard.com/reviews**

Find installation videos at  
**youtube.com/americanstandard**

Register your warranty and sign up for an idea-filled newsletter at  
**AmericanStandard-us.com/support/warranty**

## PLEASE COMPLETE AMERICAN STANDARD WARRANTY REGISTRATION PROCESS AND

### SAVE THIS WARRANTY INFORMATION IMPORTANT:

Registration of the sink must be completed for this warranty to become effective. Your registration will make it easier to contact you in the event of a product recall.\*

**INSTRUCTIONS:** Register your sink at [www.americanstandard.com](http://www.americanstandard.com). Please save your proof of purchase (sale receipt). If you need assistance or do not have access to our website, please contact American Standard Customer Care at: (800) 442-1902. An American Standard representative will assist in completing the warranty registration.

\*In California, your warranty rights remain intact even if you do not complete the registration process.



## SHARE YOUR NEW PRODUCT!

Tag us @american\_standard on Instagram  
and show us how your new product looks.

## ≡ WANT MORE INFO?

For questions or help call us at **855-815-0004**,  
or visit **AmericanStandard.com**

### UNITED STATES

American Standard Brands  
865 Centennial Ave.  
Piscataway, New Jersey 08854  
Attention: Director of Customer Care  
For residents of the United States,  
warranty information may also be  
obtained by calling the following  
toll free number: (855) 815-0004  
[www.AmericanStandard.co](http://www.AmericanStandard.co)

### CANADA

LIXIL Canada, Inc.  
5900 Avebury Rd.  
Mississauga, Ontario  
Canada L5R 3M3  
Toll Free: (800) 387-0369  
[AmericanStandard.ca/support/warranty](http://AmericanStandard.ca/support/warranty)

### MEXICO

American Standard B&K Mexico  
S. de R.L. de C.V.  
Via Morelos #330  
Col. Santa Clara  
Ecatepec 55540 Edo. Mexico  
Toll Free: 800-839-1200  
[AmericanStandard.com.mx/garantia](http://AmericanStandard.com.mx/garantia)

M985146 EN (7/23)  
607B121/607B051/607B013/607B013/607B051

PART OF **LIXIL**

*American Standard*  
DetectLnk