

# EFR32ZG14 Zen Gecko

## UZB-7 Z-Wave Controller USB Dongle

### BRD1001A Datasheet

The Silicon Labs UZB-7, Z-Wave Controller USB Dongle, is a simple reference design featuring the latest generation Z-Wave SoC, EFR32ZG14 Zen Gecko, as a gateway and controller in smart home application.

UZB-7 exposes the well-documented and proven Z-Wave Serial API via USB. It allows the host processor to control up to 232 Z-Wave devices and Z-Wave Plus devices through Z-Wave protocol. With the developer PC application software, PC Controller, or any software compliance with Z-Wave Serial API, the host is empowered to communicate with various Z-Wave devices through Z-Wave Command Classes, making your computer the heart of your Z-Wave network

With the benefits of Z/IP from Silicon Labs, controller software base on Z/IP such as Z-Ware from Silicon Labs, enable you to create your own Z-Wave gateway that is locally or remotely hosted.

Z-Wave is an established short range interoperable two-way RF mesh network technology. Refer to <http://www.z-wave.com> for the technology description, various Z-Wave Plus ready certified products, and Z-Wave Alliances

Safer.  
Smarter.  
**ZWAVE®**



## Key Features & Benefits

- Z-Wave 700 Series SoC EFR32ZG14 Zen Gecko
- +6 dBm sensitivity improvement in 100kbps channels
- Firmware upgradable through USB
- AES 128-bit encrypted communication and security feature
- Compliance approval (tbc)

EU	EN 300220
US	FCC CFR47 Part 15.249
ANZ	ANZ 4268
Japan	ARID STD-T108
- Worldwide SAW filters for additional out-of-band blocking consideration
- CP2102N USB-to-UART SoC for VCP
- USB 2.0 Full Speed Compliance
- Royalty-free Virtual COM port drivers, CP210x VCP Driver
- Work with Windows / Mac / Linux

# Product Specification

## General Specification

ERF32ZG14 Zen Gecko SoC	
USB powered	5.00 $\pm$ 0.25V
RF Transmit current	22 mA (typ.)
RF Receive current	20 mA (typ.)
RF Transmit power <sup>*1</sup>	Up to +13 dBm (max.)
RF Sensitivity	
9.6 kbps	101 dBm (typ.)
40 kbps	100 dBm (typ.)
100 kbps	97 dBm (typ.)
Operating Temperature	-15 to 55°C
Internal antenna	PCB antenna
Sleep current <sup>*2</sup>	< 25uA
Range <sup>*1</sup>	> 40 m open space line-of-sight

## Z-Wave Libraries

Z-Wave Library	Bridge Controller
Z/IP Application	Version 5.64
Z-Wave DLL	Version 5.64


## Ordering Information

SLUSB7000A	UZB-7 Z-Wave Controller
------------	-------------------------

Note<sup>\* 1</sup> Allowable transmit power are governed by respective regulatory

Note<sup>\* 2</sup> UZB-7 is typically always active

## Block diagram



Refer to [1] UZB-7 Reference Manual for further descriptions of each blocks, and design considerations and options for UZB-7.

## Frequency Allocation


Table 1. Frequencies Allocation

Region	US	EU	Australia New Zealand	Japan	Korea
Model	UZB-7				
Firmware	Z-Wave 7.00				
Data Rate	9.6 kbps / 40 kbps / 100 kbps			100 kbps	
Number of Channels	2 / 3				
Frequency	908.42 MHz 908.40 MHz 916.00 MHz	868.42 MHz 868.40 MHz 869.85 MHz	921.42 MHz 921.40 MHz 919.80 MHz	922.50 MHz 923.90 MHz 926.30 MHz	920.90 MHz 923.90 MHz 926.30 MHz
Max. Power	-1 dBm	13 dBm	12 dBm	0dBm	13dBm


## Quick Start Up

Here is a Quick Start Up guide to get UZB-7 to work with Z-Wave PC Controller. The Z-Wave PC Controller is a PC application software tool enable communications to Z-Wave nodes such as switches and sensors.


1. Connect UZB-7 to your computer
2. Install the Virtual COM Port (VCP) drivers UZB-7, CP210x UART-to-USB Driver, *CP210x VCP Driver*.  
The latest drivers are available at [www.silabs.com/interface-software](http://www.silabs.com/interface-software).
3. Install and Run Z-Wave PC Controller from Simplicity Studio




4. Click on the “Setting-wheel”  on Right-Top corner of PC Controller and select “Silicon Labs CP210x USB to UART Bridge”. Click OK



5. Click on Next Work Management



6. UZB-7 is detected and appears as [S2] Pc Controller. The bottom panel display information and Z-Wave Command Class supported by UZB-7.



7. From here, you can perform basic commands to end devices. Refer to [3] PC Controller User Guide for more info.

## EU Declaration of Conformity

This device complies with Radio Equipment Directive 2014/53/EU issued by the Commission of the European Community. The following test methods have been applied to prove presumption of conformity with the essential requirement of the directive.

EN 300 220-1: V3.1.1 (2017-02)

EN 300 220-2: V3.1.1 (2017-02)

EN 301 489-1: V2.1.1 (2017-02)

Final draft EN 301 489-3: V2.1.1 (2017-03)

EN 62311 : 2008

EN 60950-1:2006 + A11:2009 + A1:2010 + A12:2011 + A2:2013

## FCC Federal Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## Document Revision History

Revision 0.30 2019-01-05 Beta-2 document revision

## Contacts

Silicon Labs	400 West Cesar Chavez, Austin TX78701 USA
Silicon Labs International	18 Tai Seng, #05-01 18 Tai Seng Street, Singapore 539775
Silicon Labs Denmark	Emdrupvej 28B, 2100 Copenhagen Denmark
Silicon Labs Norway	Sandakerveien 118 0484 Oslo Norway

**Simplicity Studio**

One-click access to MCU and wireless tools, documentation, software, source code libraries & more. Available for Windows, Mac and Linux!



IoT Portfolio  
[www.silabs.com/iot](http://www.silabs.com/iot)



SW/HW  
[www.silabs.com/simplicity](http://www.silabs.com/simplicity)



Quality  
[www.silabs.com/quality](http://www.silabs.com/quality)



Support and Community  
[community.silabs.com](http://community.silabs.com)

#### Disclaimer

Silicon Labs intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Labs products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Labs reserves the right to make changes without further notice and limitation to product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Silicon Labs shall have no liability for the consequences of use of the information supplied herein. This document does not imply or express copyright licenses granted hereunder to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any Life Support System without the specific written consent of Silicon Labs. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Labs products are not designed or authorized for military applications. Silicon Labs products shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons.

#### Trademark Information

Silicon Laboratories Inc.®, Silicon Laboratories®, Silicon Labs®, SiLabs® and the Silicon Labs logo®, Bluegiga®, Bluegiga Logo®, Clockbuilder®, CMEMS®, DSPLL®, EFM®, EFM32®, EFR, Ember®, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Ember®, EZLink®, EZRadio®, EZRadioPRO®, Gecko®, ISOmodem®, Micrium, Precision32®, ProSLIC®, Simplicity Studio®, SiPHY®, Telegesis, the Telegesis Logo®, USBXpress®, Zentri, Z-Wave, and others are trademarks or registered trademarks of Silicon Labs. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. All other products and brand names mentioned herein are trademarks of their respective holders.



Silicon Laboratories Inc.  
400 West Cesar Chavez  
Austin, TX 78701  
USA

<http://www.silabs.com>

