User Manual

H0055

Smart Bird House Lamp Speaker

Operation Manual

Thank you for choosing our product.

Please read this manual and safety instruction before usage.

Please keep the manual for future reference.

- · Unique design with a bird house shape.
- · A perfect combination of Bluetooth speaker and mood light.
- · Connect to siri or google now with one button, easy to control.
- · Touch sensitive switch, easy to control the light.

Specifications:

· Name: Smart Bird House Lamp Speaker · Item No:. H0055

· Input: DC5V 1000mA Battery: 3.7V/2000mAH

· Speaker power: 5W · Speaker size: 52mm

· LED power: 0.3W · Color temperature: 2700K-2900K

Frequency range: 70HZ – 18KHZ SNR: >70dB

· Distortion: < 1% · Bluetooth version: 4.2

Product size: 105x80x210mm Material: ABS +Silicone

· Weight: 398 g · Charging Time: 2.5-3 hours

Battery information: After fully charged, it can work up to **8** hours to play music (music is played at 70% of its highest volume), work up to **10** hours when using lighting.

· The label is located on the bottom of the unit.

Components and Accessories:

· Bird house speaker x 1 · USB cable x 1

Functions

Speaker net

Siri/google now

Play/Pause/Hand-free/Double press: next song/ Triple press: previous song

Speaker power button

Microphone

Volume

Touch sensitive switch

Bluetooth indicator

Micro USB charging jack

Power indicator

Charging

- · Please make sure that the product is fully charged before first use.
- · Connect the USB cable with the product and 5V1A adapter to charge.
- The indicator will flash with white when charging. The first indicator lighting means the battery is charged to 0-25% of its full capacity. The second indicator lighting, 25%-50% battery capacity is charged. The third indicator lighting, 50%-75% battery capacity is charged. The fourth indicator lighting, battery is fully charged.
- · When in use (no charging), the first indicator lighting means 0-25% of the battery capacity remains. The second indicator lighting, 25%-50% of battery capacity remains. The third indicator lighting, 50%-75% of battery capacity remains. The fourth indicator lighting, the battery is full.

Play music

Play music from Bluetooth enabled devices, like smart phones, tablet and etc.

- Press and hold the power button for 1 second to turn on the unit until the indicator flashes with white light.
- · Search "emoi Bird house Speaker" on your devices' Bluetooth list, and select to pair it with the speaker. When paired successfully, a sound will be heard and the mode indicator will stay in white.
- · After paired, please select and play songs from the Bluetooth enabled device, any songs of your choice.
- Long press the play button for 2.5s to quit the paired mode in order to add or change to pair to the new Bluetooth devices.

Hands-free calling

- · Short press the hands-free button to answer the call when a beep sound will be heard.
- Long press the hands-free button to reject the call, a beep sound will be

heard.

· If your want to end the talk during the call, short press the hands-free button, a beep sound will be heard.

Light control

· Gently tap the switch to adjust the light between dim and normal light modes.

Restart

If crash or other abnormal occurs, put the paperclip or the like into the reset hole to restart the product.

emoi Nature Music APP

Apple user can download emoi Nature Music from APP Store.

Android user can download and install the app from emoi official website (http://www.emoi.com/support/).

Safety Instruction

Safety Information

Please read and follow these instructions, beware all warnings, and keep this document for future reference.

- Set up your product in accordance with product manual, and place your product in a stable location so it will not fall and cause product damage or bodily harm.
- Do not use your product near water, including dripping or splashing sources (e.g. indoor fountain), or near object filled with liquids, such as flower vase or fish tanks.
- Do not use your product near heat sources (e.g. radiators, heat registers, stoves, open flame, such as lighted candles, or other heat-producing devices, such as audio amplifiers or TVs).
- Refer all servicing and repair to qualified service personnel. Servicing is required when your product dose not operates normally, the power cord/plug has been damaged, the product has been exposed to water, rain, liquid or moisture, the product has been dropped, or an object has been inserted into a product port or vent.

- Please use the product in specified voltage, or it may cause electric shock, damage or fire.
- · Place the product in a proper place to avoid injury to children.
- Please do not disassemble and make any modifications to the product, this may lead to electric shock, fire or electric leakage.
- · Warning: Do not change the LED light by yourself.
- Use the product in an environment within the temperature of 0° C ~ 40° C.
- •This is not a toy, children under 3 are forbidden to use. Children from 3 to 8 should use this product under parents' supervision.

Cleaning

- · Do not clean when the product is charging, clean with soft and dry cloth.
- · Do not use solvents, chemicals or sprays.
- · Do not allow liquids to spill or objects to drop into any openings.

Power Supply Warning: Caution electric shock/fire hazard! The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Caution: Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type.

Battery information and disposal guidelines at product end of life

If the product use a non-serviceable, rechargeable battery, which should last the duration of a product's warranty period under normal use. Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions in the documentation that accompanies your product. Also consult local laws and regulations for the proper disposal of batteries and electronic devices in your region. If there are no local regulations concerning electronic waste disposal, place your product (and its battery) in a waste bin for electronic devices.

Caution: There is a risk of explosion, fire or chemical burns if battery is replaced by an incorrect type, mutilated, or exposed to conducting materials,

liquid, fire or heat (54°C or 130°F). Do not use or recharge a damaged rechargeable battery. Do no use or charge a battery if it appears to be leaking, discolored, deformed or in any way abnormal. Do not leave a battery discharged or unused for extended periods of time. Do not mix battery types. When a battery is misused, it may explode or leak, causing burns and personal injury. If a battery leaks, use normal precaution and discard it immediately following the local laws and regulations in your area. Keep all batteries out of the reach of children.

China 3C Caution:

- · There will be a risk of explosion if the battery is changed improperly.
- · Change the battery with the same type or same capacity.
- · Battery or battery unit should not be exposed to sunshine, open fire or store in other over heated places.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada Statement

This device complies with Industry Canada RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2)

this device must accept any interference, including interference that may cause undesired operation of the device. The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Information to Consumers in Application of EU WEEE Directive 96/2002

This product is subject to European Union regulations that promote the re-use and recycling of used electrical and electronic equipment. This product required the extraction and use of natural resources and may contain hazardous substances. The symbol above, on the product or on its packaging, indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handling it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop of your waste equipment for recycling, please contact your local city office, your household waste disposal service, or the store from which you purchased the product.