

User Instruction Mi-light LED Bulb with Remote Control System

Welcome to use Mi-light LED Bulb with Remote Control System. Please read the user manual carefully before using, please follow the instructions to experience the ideal functions of our product. Please keep this user manual for the correct operation.

Content

1. Product Introduction P1

2. First Operation P2

2.1 Battery Installation

2.2 LED Bulb Installation

2.3 Remote and LED Bulb Programming(code matching& code clearing), Group Division and Control

3. Replacement and Addition P5

3.1 Battery

3.2 LED Bulb

3.3 Remote Control

4. FAQ P6

5. Fault&Solution P7

6. Discard P7

7. Technical Parameters P7

1. Product Introduction

Easy Operation, please install Mi-light LED Bulb just the way as the common incandescent light bulb, energy saving light bulb or LED bulb, after installation, you can realize the wireless operation between the remote and light bulb, on/off, dimming and color temperature changing, no additional antenna needed.


Caution: Mi-light LED Bulb with Remote Control does not apply to all the lamps with dimming functions.

Caution: Mi-light LED Bulb's Control System is independent, only workable with our product, not compatible with common energy saving lamp, incandescent lamp or led remote controllable lamp made by other factories.

P1

For customer's convenience, our factory not only offers the basic combination of two led bulbs and one remote control, but also offers single led bulb or remote control.

Key Functions:




2. First Operation

If this is the first time of using our product, please follow the below steps to finish the installation correctly.

2.1 Battery Installation

Please take out the remote control and carefully press the battery cover to pull the cover out of the remote control.

Please install two pcs of AAA batteries as is shown on the picture, please exactly match the positive and negative pole.



Please put the battery cover back and install tightly.

Caution: Due to the uncontrollable factors, battery is not along with our product, we are sorry for the inconvenience.

2.2 LED Bulb Installation (Please hold the metal part of the bulb during operation!)


Please take the led bulb out from the package.

Please switch off the power before installation.

Please replace the original light bulb with Mi-light led bulb.
Please switch on the power, the led bulb lights under normal circumstances.

2.3 Remote and LED Bulb Programming(code matching& code clearing), Group Division and Control

(Only on condition that the remote is programmed to the led bulb, it can operate the bulb, besides Mi-light control system can group different lamps (at most 4 groups), and operate separately, please refer to the below pictures.)



① Please make sure that the battery and bulb installation is done.

② Programming(code matching& code clearing) and Group Division

Please choose the lamps which you want to program with the remote, then switch off the power, please switch on the power again after 10 seconds, please press this key on the upper side(channel-on) once(within 3 seconds) the moment you see the light is on. The lamp blinks three time when it's done.

Please just repeat the above steps to program more lamps with the remote as needed.

③ Group Division with the remote

After the programming and group division, the below wireless control can be realized.

Please switch on the power.

Please press the "all-on" button, (1), all the lamps are on.

Please press this central control panel, (2), up and down, dimming function; left and right, color temperature changing. Please press this "all-on" button, (1), and hold for a while, all the lamps can get brightest.

Please Press the "all-off" button, (3), all the lamps are off.

Please press the corresponding group button, (4), to operate the exact group which you want.

Please press central control panel, (5), up and down, dimming function; left and right, color temperature changing for the exact group.

Please Press the "channel-on" button of each group, (6), and hold for a while, all the lamps can get brightest (for the exact group).

Please Press the "channel-off" button of each group (7), the lamps are off (for the exact group).

Tip 1: If you need to operate more than two groups (not more than four groups) at the same time, please press the "all-on" button, turn on all the lamps, then turn off the groups which are not needed, then use central control panel, (5), to operate.

Tip 2: When the power is on, the led bulb is turned off by the remote, it switches into standby mode, the power consumption of each lamp is 0.3W under this state.

Tip 3: Resume function. The previous settings are resumed while you switch on the power or turn on the bulbs again.

P4

Remarks:

If you turn off the bulbs and switch off the power, the previous setting (before the bulbs are turned off) is resumed when you switch it on.

If you turn off the bulbs or switch off the power under the night light mode, the previous setting before the night light mode is resumed when you switch it on or turn it on.

Please switch off or switch on the power as needed.

④ Night light mode

Mi-light Bulbs release the soft light like moon light with night light function. Good for sleep, energy-saving when used in corridor.

Press "all-off" button (1) for a while, all bulbs are switched into night light mode at the same time.

Press "channel-off" button of each group (2) for a while, all bulbs of this group are switched into night light mode at the same time.

Each bulb consumes 0.4W under the night light mode.

⑤ Remote and LED Bulb programming(code clearing), Group Division

You can change the previous settings and regroup the bulbs as needed by matching code. But you have to clear the address code before it.

⑥ Please choose the bulb that you want to clear the code, switch off the power and press the "all-on"-button (1) or "channel-on" button (2) 5 times within 3 seconds when you switch it on again after 10 seconds. If the light blinks 6 times, it indicates the code clearing is successful.

You can match the code and regroup the bulbs as Number (2).

③ Replacement, Addition and Reset

3.1 Battery Replacement

The remote can be used directly after reloading the batteries, the previous settings are resumed.

3.2 Replacement or Addition(for bulb)

Please follow the below steps to rematch or regroup when you need to add new bulbs or replace the original ones.

Please switch off the power of the bulb which you want to replace.

When you want to replace the bulb, please hold the metal part to make it.

Please take out the bulb and screw into the lighting fixture carefully.

Please switch it on.

Please set the new bulb as No. 2.3 (2).

3.3 Replacement or Addition(for remote)

Please set the new remote after installing the batteries as No. 2.3 (2).

Remarks: Each Mi-light bulb can be controlled by 4 remotes (Max.). When you use another remote (the fifth one) to match the code with the same bulb, the first matched remote can not operate the corresponding bulb any more.

4. FAQ

Question 1: When I turn off the bulb with remote, does the bulb consume the power?

Answer1: Yes, 0.3W/bulb.

Question 2: How many bulbs can be controlled by one remote?

Answer 2: Each remote can control countless bulbs by matching code, so can each channel.

Question3: Can I use two or more remotes to control one bulb or one group of bulbs?

Answer3: Yes, 4 remotes (Max.) can control one bulb or one group of bulbs.

Question4: What's the remote distance and frequency?

Answer4: The remote control system is designed according to IEEE 802.15.4, remote distance is 20 meters, frequency is 2.4GHz.

Question 5: Does the remote have to point at the LED bulb when I use it to control the light?

Answer5: No, RF signal has the penetrating power.

5. Fault&Solution

Fault phenomenon 1: The bulb doesn't respond to the remote?

Please check as the below steps:

Please check if the power is switched on.

Please check if the batteries of the remote are normal.

Please check if the bulb is matched with the remote.

Fault phenomenon 2: The bulb changes unexpectedly itself.

Possible reason: The bulb may be controlled by another remote.

Solution: You can solve it as No. 2.3 (6).

6. Discard

Please deal with the used products according to the local regulations.

Please take out the batteries before you discard the remote, the used batteries should be dealt with according to the local regulations.

7. Technical Parameters

Item No.	Picture	Voltage (V)	Frequency (Hz)	LED Power (W)	Luminous flux (Lm)	Light effect (Lm/w)	Color temperature (K)	Lifespan (h)	PF (cosΦ)	Current (mA)	Max diameter (mm)	Max length (mm)	Lamp base
RB13425163		86-265V	50-60	6	560	70	3000-6500	50000	0.65	35-65	60	120	E26
RB13425263													E27

User Instruction

Mi-light LED Bulb with Remote Control System

P4

P5

P6

P7

0017

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.