

# Table of contents

First Steps	(
Introduction	4
Getting to know your tablet	5
Front View	5
Rear View	7
Top View	8
Bottom View	9
Side Views	10
Packing List	11
Optional Accessories	12

Getting Started	13
Connecting the AC Power 1	13
Turning the tablet on and off	
The optimised use for sunlight readable	
touch screen15	

# **First Steps**

This manual will help you get the most from your tablet. Please read it carefully before starting

### Let your tablet acclimatise itself

Do not power up your tablet immediately if it has been exposed to hot or cold conditions. Instead, allow it to adjust gradually to room temperature over a three to four hour period.

Please note that you must fully charge the battery before using your tablet.

## Where to use your tablet

Your tablet will run well under most conditions but avoid extreme temperatures and humidity levels.

Allow sufficient air circulation around the computer when you are working indoors to prevent overheating.

Do not block the ventilation opening or place your tablet in direct sunlight.

There are some things you can tolerate that your tablet can't – things like static electricity, dust, water, steam and oil.

# Introduction

Your tablet features the latest advances in portable computing technology with a modular design that provides maximum expandability without compromising portability.



WARNING - Never try to disassemble or back engineer your tablet as we will not be responsible for any damage caused if you do so and this action would void your warranty

Please note that some of the features mentioned in this manual might not be included on your tablet or may vary slightly.

#### **Unpacking your tablet**

Your tablet comes securely packaged in a shipping carton. Please contact your supplier if you find that anything is missing or damaged after examining the contents.


Do not throw the packaging materials away. You may need them later if you have to ship the computer.

#### What is in the box

Tablet PC

# Getting to know your tablet

# Front View with Capacitive touch panel



#### 1. LCD Panel

This tablet is equipped with a 10.1" LCD display with a resolution of up to 1280 x 800

2. Speaker

Two Piezoelectric speaker


3. Front Camera (option)

200MP, USB interface

4. Reset Function

Hall IC switch on handle(EC Control) – External magnet action

# **Right Side View**



### 5. Wi-Fi Indicator & Power LED

#### 5.1 WIFI Indicator

Lights up Green when the Wi-Fi device is turned on.

Light will flicking when data transferring

No light when Wi-Fi stops operation

#### 5.2 Power Indicator

Blue: Connect to DC Power No Light: No DC Power Flash: System standby

# 6. Lock LED: Controlled by Power Crate

Device location	U30 change of status	White LED	
Slid in to Power Crate	Magnet in locking arm moving into detection range of U30	2 second pulse white LED	
Locked in Power Crate	Magnet still in detected range	OFF	
Unlocked from Power Crate	Magnet in locking arm Leaving detection range of U30	Flashing(1 second on/1 second off) for 10 seconds	
Removed Power Crate	No Magnet detected	OFF	
Slid in to Power Crate	the most of charging	On	


Note: When Device removed from Power Crate, EC must set PCA9555 PIN4 to "High"

# 7. Battery Indicator


Status		Red	Amber	GREEN	
Charge(S0,S3,S5)	0%-40%	Flash	OFF	OFF	
	41%-80%	OFF	Flash	OFF	
	81%-100%	OFF	OFF	Flash	
No Charge (S0)	0%-40%	ON	OFF	OFF	
	41%-80%	OFF	ON	OFF	
	81%-100%	OFF	OFF	ON	
No Charge (S3,S5)	0%-40%	OFF	OFF	OFF	
	41%-80%	OFF	OFF	OFF	
	81%-100%	OFF	OFF	OFF	

Note: Battery charge current had 3 level can be selected. Low voltage charge: 0.368A; Normal Charge: 2A; Fast charge: 4A. And the charge current behaviors selected base on customer requirement.

# Rear View with 8000mAh battery



# Rear View with 16000mAh battery



8. Lock hole

For Kingston locker

9. Rear Camera (option)

Rear facing 5Mega Pixel with auto flash and LED flash


10. VESA Mounting

11.WIFI Logo

IEEE 802.11b/g/n/ Wireless card with WIFI Antenna

12. Kick stand

Integrated rear friction grip kickstand for use in both landscape & portrait orientation, with Indexing for portrait.



13. SIM Card Slot

Slot for fitting a SIM Card

14. Micro-SD Slot

Slot for fitting a Micro-SD card

15. DC Jack

DC jack port for charging the tablet (12V --- 4A).

16. Pogo connector

For changing the tablet when used with a docking station

17. HDMI / LAN

Mini HDMI for fast earth net (10/100) via HDMI to LAN cable.

18. USB 2.0 port

Mini USB 2.0 hidden port

19. 3.5mm audio Jack

For headphone insert.

20. Power Button

Power button to turn the tablet on

# Packaging list

This product is shipped with the items list below. Please make sure that all are in Gift box.

➤ 1 piece of Rugged Tablet PC

# **Getting Started**

This chapter guides you to get the tablet ready for operating.

#### **Connecting the AC Power**

Our tablet PC can operate either on the external AC power adapter or internal battery power. It is suggested that you use AC power when you start up the tablet PC first time.



**Caution -** Use only the AC adapter included with your tablet PC. Using other AC adapters may damage the tablet PC.

- 1. Plug the DC cord of the AC adapter to the power connector of the tablet PC.
- 2. Plug the female end of the AC power cord to the AC adapter and the male end to the power electrical outlet.
- 3. When the AC adapter is connected, the Battery Pack is also charging. You can check the Battery Status LED indicator to see the current progress. The indicator turns to green when it is fully charged.



**Caution -** When you disconnect the AC adaptor, disconnect from the electrical outlet first and then from the tablet PC. A reverse procedure may damage the AC adapter or the tablet PC. When unplugging the connector, always hold the plug head. Never pull on the cord.

## Turning the tablet on and off

## **Turning on the tablet PC**

- 1. Place your tablet PC on a flat and stable surface or holding the tablet PC on your hand.
- 2. Make sure that the tablet PC is either connected to AC power or the battery pack with power.
- 3. Press the power button on the right side by 2-3 seconds to start it.

#### Turning off the tablet PC

1. To turn off the tablet PC power, use the 'Shut Down' command on your operating system.



**Caution -** If you have to turn the tablet PC on again immediately after turning it off, wait for at least five seconds. Turning the tablet PC off and on rapidly can damage it.

#### The optmised Use for Sunlight Readable Touch Screen

With the imposed reflective function, the modified LCD can reflect the ambient light passing the LCD cell and utilize the reflected light beams as its illumination. The stronger the ambient light is, the brighter the LCD will appear.

As a result, the modified LCD is viewable under lighting conditions.

The optimised angle of view is forty-five degrees. The optimised viewing distance is 30cm.

.

**Caution -** Although transflective LCD is mainly used in outdoor environment and it may increase the reflective lights under sunlight, it is suggested that you should keep the LCD in an appropriate temperature for operation and storage, and avoid direct sunlight if possible. To ensure the transflective LCD works stably, 0~50°C (32-121°F) operation and storage temperature is suit

#### The Optimised Use for Sunlight Readable Touch Screen

With the imposed reflective function, the modified LCD can reflect the ambient lightpassing the LCD cell and utilize

the reflected light beams as its illumination.

The stronger the ambient light is, the brighter the LCD will appear.


The Optimised Use for Sunlight Readable Touch Screen

CAUTION - Although the transflective LCD is mainly used in an outdoor environment it may increase the reflective lights under sunlight. It is suggested you should keep the LCD in an appropriate temperature for operation and storage. Avoid direct sunlight if possible. To ensure the stability of the transreflective LCD, use in temperatures between 0°C and 50°C (32°F-121°F).

As a result, the modified LCD is viewable under lighting conditions. The optimised angle of view is 45°.

The optimised viewing distance is 30cm.

#### Troubleshoot in g



Reflected Light

This chapter describes how to locate and solve problems that you may experience when using your tablet.

#### A freeze on the system during program operation

#### **General Hardware Problems / Possible Causes and Solutions**

Should an error occur when a program is being used and your tablet becomes unresponsive, please turn your tablet off by the pin hole power switch by holding down the power button for greater than 5 seconds. If this does not work please remove and re-fit the external battery.

In the event of an error with the Windows OS, reboot your tablet.

#### System not resuming normal operation

The battery may be defective or discharged to a critically low level. To correct this problem, connect the AC adapter to the nearest power supply.

## The system can not shutdown properly

Press and hold the power button for 4~6 seconds until your tablet shuts down manually.

### What are the major steps to follow when your tablet does not turn on

#### properly after a shutdown

If your tablet turns on after connecting the AC adapter, this indicates that the battery needs recharging.

#### How to extend battery life

Adjust the display brightness to minimum level.

Adjust the volume to minimum level.

#### The wireless LAN connection disconnects after 2~3 minutes and does not reconnect.

This may be caused by channel interference. Try changing the access point channel and reconnect.

#### The computer is unable to connect to the Internet.

Check that your account with your Internet service provider (ISP) is properly configured. Ask your ISP for further assistance.

The Wireless LAN shows a connection but I have no internet access or the wireless is not working

Microsoft Windows- If the driver is not properly installed, you will find a yellow exclamation mark on the network icon by clicking

Start > Control Panel > System > Device Manager > Network Adapters.

If there is a yellow exclamation mark, please reinstall the device driver with the system software media. Check that the signal strength of the wireless access point is good and that the encryption settings are correct.

Linux- Ensure that the Linux image you are using supports the wireless card either using out ofthe box drivers or by adding the correct wireless card drivers. Check the signal strength of your access point and that the encryption password is correct.

### The signal strength is excellent but you cannot connect to the network.

Check the TCP/IP properties are configured properly. When you connect to an access point, click the Wireless Network Connection icon on the taskbar and select the Support tab.

#### **Contacting Your Supplier**

If you still have a problem after reading the troubleshooting section, your next step is to contact your supplier who will be able to determine if the tablet needs to be returned to where it was purchased. Before you call your dealer, please have the following information available:

How is your tablet configured?

What peripheral devices you are using.

What messages, if any, are on the screen?

What software were you running at the time?

Tablet serial number?

Place and date of purchase?

What have you done already to try to solve the problem?

If you have overlooked a step, your supplier may be able to solve the problem over the phone.

#### **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

-Connect the equipment into an ou	tlet on a cir	rcuit different f	rom that to	which the re	eceiver is co	onnected.
-----------------------------------	---------------	-------------------	-------------	--------------	---------------	-----------

-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This Antenna should be installed and operated with minimum distance 20mm between the edge of shell & your body.