


QUICK START GUIDE

Digital Media Receiver




To download a complete owner's manual visit www.jensenmobile.com or call customer service 1-888-921-4088 (Monday-Friday, 9AM-5PM EST)


Wiring Diagram-Inputs/Outputs



TYPICAL FRONT-LOAD DIN MOUNTING METHOD



Button Operation



1. Mute/Power	10. Introduce
2. Voice Activation	11. Random
3. Open	12. Reapt
4. End Call	13. Band/Disp
5. USB	14. Mode
6. Aux Input	15. VOL Up/Down/Menu
7. Folder Up	16. Tune/Track Up
8. Folder Down	17. MIC
9. Play/Pause	18. Tune/Track Down

General Operation

Power On/Off	Press the U button to turn the unit on. Press U again to turn unit off.
Changing Modes	Press MODE to select between Radio, USB, Bluetooth, AUX. Modes of operation are shown in the display.
Volume	Adjust volume using volume knob.
Mute	Press M to silence the audio. Press M again to resume listening at the previously selected volume.
Auxiliary Inputs	Insert a 3.5mm cable in the unit's front AUX port.
Reset	Press the RESET button to reset the unit back to the factory settings if abnormal operation occurs. The reset button is located on the front panel.
Setting the Clock	With the unit on, long press DISP to display clock time. Press and hold DISP until the hours or minutes begin to flash, then release. Rotate the volume knob to adjust the time. Long press DISP to finish the clock setting.
Display	Press DISP to toggle display between various displayed information.
Audio / Menu	Press volume knob momentarily to select between the audio functions. Press and hold volume knob for more than two seconds to select between the menu functions. Rotate the volume knob left/right to adjust or activate the desired function/audio.

To download the complete Owner's Manual for your radio, please visit www.dualav.com/support/manuals.php.

AM/FM Tuner Operation

Seek Tuning	Press TUNE << or TUNE >> to seek to previous or next strong station.
Manual Tuning	Press and hold the TUNE << or TUNE >> to enter manual tuning mode. Then press TUNE << or TUNE >> momentarily to move radio frequency down or up one step at a time. Press and hold TUNE << or TUNE >> to advance quickly.
Band	Press BAND to select between FM1, FM2, FM3, AM1 and AM2 bands. Up to six presets can be programmed for each band, enabling up to 18 FM stations and 12 AM stations to be stored in memory.
Storing Presets	Up to 18 FM and 12 AM stations can be stored. To store a station, select the desired band and station. Press and hold the desired preset button (1-6) for more than two seconds. When stored, the preset number will appear in the display.
Recalling Presets	Preset stations can be recalled any time by pressing the corresponding preset button.
Auto store	Press and hold MENU for more than 2 seconds, then press DISP to store 18 FM stations and 12 AM stations automatically.
Preset Scan	Touch PS to recall each preset station that has been stored in memory for each band. (Available with the Dual Smart Remote App only)

To download the complete Owner's Manual for your radio, please visit www.dualav.com/support/manuals.php.

USB Operation

Playing MP3 Files	Front panel USB port support 1A charging/Playback.
Track Select	To play MP3 files, insert a USB device containing MP3 files. Press TUNE >> to skip to the beginning of the next song. Press TUNE << to skip to the beginning of the previous song.
Fast Forward and Reverse	Press and hold TUNE >> or TUNE << to fast forward or reverse a track.
Pause	Press >/II to temporarily stop playback. Press >/II again to resume playback.
Folder Access	Folder can be found by pressing Folder Up or Folder Down . About 1 second after the folder name is displayed, the first file under the selected folder will be displayed and playback.
Repeat	Press RPT to toggle between RPT ALL and RPT ONE . <ul style="list-style-type: none"> • RPT ALL - Plays all tracks on USB device. • RPT ONE - Continuously repeats selected track.
Random	Press RDM to play tracks in random order, press again to cancel the RDM function.
Intro	Press INT to play first 10 seconds of each track. Press again to cancel the INT function.

To download the complete Owner's Manual for your radio, please visit www.dualav.com/support/manuals.php.

Bluetooth® Operation

Preparation	Before using a Bluetooth device, it must be paired and connected. Ensure that Bluetooth is activated on your device before beginning the pairing process.
Pairing a New Device	The head unit broadcasts the pairing signal constantly when no devices are connected. Complete the pairing sequence from your Bluetooth device. Refer to the owner's manual for your device for more details.
Note:	The device name is "Dual Media Player" The Bluetooth passcode is "1234".
Note:	If passcode "1234" does not pair your device to the receiver, use passcode "0000".
Streaming Audio Troubleshooting	The head unit can be in any mode of operation when pairing is performed.
	The head unit supports A2DP wireless streaming audio from a Bluetooth mobile device directly to your head unit. The following functions can be used to control the music: <ul style="list-style-type: none"> • Press > to skip to the next available audio track. • Press < to skip to the previous audio track. • Press >/II to toggle between play and pause during playback.


To download the complete Owner's Manual for your radio, please visit www.dualav.com/support/manuals.php.

Wireless Charging Operation

Putting Phone on Wireless Charging Pad	Press the Open button on the front panel, and the Wireless Charging Pad will automatically pop up from the unit. Open the Wireless Charging Pad switch after the pad has completely slid into the position, and open the buckle on the top of the pad to support the phone (With Wireless Charging Function) and put down the buckle tightly.
Charging Status	After the phone enters charging mode, it's in normal charging mode when the red and green LED indicator on the pad has 3S flashing. It starts to enter the fast charge mode after the red LED indicator off and the green LED indicator has 3S flashing. The green LED indicator is always on when the phone is fully charged.
Phone Removal	If you don't need to charge it, please lift up the buckle on top of the pad and remove the phone, then close the wireless charging switch under the pad and press the Open button on the front panel to retract the wireless charging pad automatically.

LED Indicator:	LED Indication Standby Normal Charging Fast Charging Full FOD/Error Low Power Over Temperature
LED-A(Red)	Off/after 10s On 3S Flashing Off Off Off On Off
LED-B(Green)	Off 3S Flashing 3S Flashing On 0.5S Flashing 0.5S Flashing Off

Wireless Charging sequence



APP Operation

The Jensen Smart App is the ultimate wireless remote control for your receiver. You can download Jensen Smart app from Apple App Store or Google Play Store and install it on your smartphone or tablet. Please scan the following QR code to download **Jensen J Link APP P2** to your smart phone.



Voice Activation Operation

Bluetooth should be paired between your smartphone and the receiver. Press the voice activation button (1), and the receiver will switch into Bluetooth mode. This will activate Siri® or Google Assistant™ on your smartphone. You will need to manually switch back to the previous or desired mode once this operation is terminated.

Limited One-Year Warranty

This warranty gives you specific legal rights. You may also have other rights which vary from state to state. Samsung America Inc. warrants this product to the original purchaser to be free from defects in material and workmanship for a period of one year from the date of the original purchase. Samsung America Inc. agrees, at its option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase. Subsequent replacement products are warranted for the balance of the original warranty period.

Who is covered? This warranty is extended to the original retail purchaser for products purchased and used in the U.S.A.

What is covered? This warranty covers all defects in material and workmanship in this product. The following are not covered: installation/removal costs, damage resulting from accident, misuse, abuse, neglect, product modification, improper installation, incorrect line voltage, unauthorized repair or failure to follow instructions supplied with the product, or damage occurring during return shipment of the product.

What to do?

1. Before you call for service, check the troubleshooting guide in your owner's manual. A slight adjustment of any custom controls may save you a service call.
2. If you require service during the warranty period, you must carefully pack the product (preferably in the original package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to an authorized service center.
3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not acceptable), and a daytime phone number with your shipment.
4. For more information and for the location of the nearest authorized service center, please contact us toll-free at 1-888-921-4088 or by email at cs@duelav.com.

Exclusion of Certain Damages: This warranty is exclusive and in lieu of any and all other warranties, expressed or implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose and any obligation, liability, right, claim or remedy in contract or tort, whether or not arising from the company's negligence, actual or imputed. No person or representative is authorized to assume for the company any other liability in connection with the sale of this product. In no event shall the company be liable for indirect, incidental or consequential damages.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio technician for help.

FCC Radiation Exposure Statement: The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

FCCID: 2AFAXA-MPQ914