

# WIFI SMART HEATER USER MANUAL



# Please read these instructions carefully and keep for future reference

In order to prevent the risks of a fire , an electrical sho ck, burns and other injuries, it is imperative to observe basic safety measures when using electrical appliances.

Please read the following infor mation carefully before using the appliance for the first time for your own safety and to ensure correct use.

## **IMPORTANT NOTES**

- The specified voltage must match the mains voltage. Use an adequate wire cross-section.
- The appliance air inlet and outlet openings must not be obstructed in any way!
- Never move the heater during operating, always unplug heater when not in use.
- Never use the appliance if the appliance or cord is damaged. The appliance may only be opened up and repaired by authorized qualified personnel.

## SAFETY INSTRUCTIONS

When using any electrically powered product, basic safety precautions should always be followed, including the following:

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT.

WARNING - to reduce the risk of fire, electrical shock or injury to persons or property:

- Always operate the product from a power source of the same voltage, frequency and rating as indicated on the product identification plate.
- Remove the unit from its packaging and check to make sure it is in good condition before using.
- Do not let children play with parts of the packing ( such as plastic bags)
- Close supervision is necessary when the product is used by or near children or infirm persons. Do not allow children to use it as a toy.
- Do not operate any product with a damaged cord or plug, or after the product malfunctions, or is dropped or appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Before unplugging the power cord, be sure to turn the power off. When touching the unit, be sure your hands are dry to prevent electrical shock.
- Ensure the cord is fully extended before use and arrange it so that it is not in contact with any part of the heater.
- In use, some parts of the heater are hot. When moving, hold the heater only by the handle provided.
- Do not use the heater in areas such as garages where petrol, paint or other flammable substances are used or stored.
- Do not use near or point the heater to furniture, animals, curtains or other inflammable objects. Keep combustible materials such as furniture, bedding and any other combustible materials at least 1 metre from the front and sides, and from the rear of the heater.
- Do not place the cord under carpet or cover with throw rugs or furniture. Arrange the cord so that it cannot be tripped over.
- Do not place the heater on bedding or on thick and long pile carpet where the openings may be blocked.
- To reduce the risk of electric shock, do not immerse or expose the product or flexible cord to rain, moisture or any liquid other than those necessary for correct operation of the product.
- This product should not be used in the immediate vicinity of water, such as bathtub, washbowls, bathroom swimming pool etc. where the likelihood of immersion or splashing could occur.
- Switch off and unplug from outlet when not in use, before assembling or disassembling parts and before cleaning. Remove by grasping the plug - do not pull on the cord.
- A common cause of overheating is deposits of dust and fluff entering the heater. Ensure
  these deposits are removed regularly by unplugging the heater, allowing it to cool and
  cleaning as described in the Care, Cleaning and Storage section.
- Be sure that no other high current appliances are plugged into the same circuit with your heater as an overload can occur.
- Avoid the use of an extension cord as the extension cord may overheat and cause a risk
  of fire.
- Do not use the appliance for other than its intended use.

- Do not use outdoors. FOR INDOOR USE ONLY.
- Do not leave the appliance unattended when switched on.
- Do not place objects on the product or allow objects to obstruct the inlet or outlet openings, or operate in close proximity to walls or curtains, etc. Do not cover the unit when in operation.
- Do not locate the heater immediately below a socket-outlet.
- The use of attachments or accessories not recommended or sold by the product distributor may cause personal or property hazards or injuries.
- This product is intended for normal domestic/household use only.
- Use this heater as described in this manual. Any other uses, not recommended by the manufacturer, may cause fire, electric shock, or injury to persons and may void the warranty.

# LOCATION

• The appliance should be placed with a minimum distance of 90cm away from flammable objects (e.g. curtains), walls or other structures!

## POWER CORD

- Use only an approved extension cord that is suitable for the appliance rating!
- Do not lay the cord under a carpet. Do not lay rugs, mats or similar articles on it. Position the cord so that it does not pose an obstruction or a tripping hazard.
- Never pull the plug out of the socket at the cord!
- Always disconnect the mains plug when the appliance is not in use.
- Attention! The appliance may only be used for normal domestic use and not for industrial purpose.

# BEFORE USE

- Before use, remove all packaging and inspect the appliance for any damages. If there
  areappears to be any damages, please take back to place of purchase for a replacement.
- Ensure that all the accessories are included as per diagram above before you can continue with the installation.
- Ensure that the location of the heater installed is not directly under a power socket and that a power socket is available to power the appliances for use.
- Refer to the installation guide for further instruction.

## **USING THE HEATER**

- Before inserting the plug into an electri cal outlet, make sure that the electrical supply in your area matches that on the rating label on the unit.
- When plugged in, turn on the Main power switch at the base side of unit.
- When in Standby mode, only ON/OF F on the control panel will respond to your touch.
   Press ON/OFF to access the rest of the control panel.
  - a) Low Power:875W (Press POWER to switch it)
  - b) High Power: 1500W (Press POWER to switch it)
  - c) Timer: Press this repeatedly to set a period after which the heater will turn itself off (between 0 hour 12 hours)
  - d) + , : adj ust room te mperature .Temp erature setting from 1 5-35 degree. "+" to increase the desire d temperatu re and "-" to decre ase the desi red tempe rature. When the around tempe rature reaches higher or lower 3 deg rees above the setted temperature of unit, the heater will cut off heating or turn on he ating . Tempe rature can setting from 15 degree to 35 degree, switch only up key available.
  - e) Swing: Press this to activate oscillation. Press again to cancel.
  - f) O, turn on or turn off item. item always keep working 30 seconds of cool air after turn off it. this design can protect item use longer.



#### Warning:

• Before removing the plug from the socket, switching off and better work for 30-60 second for cool down in condition that protecting inner parts.


## **OVERHEAT PROTECTION**

This heater is protected with an overheat protection that switches off the appliance automatically in case of overheat,e.g. due to the total or partial obstruction of the grids. In this case, unplug the appliance, wait about 30 minutes for it to cool and remove the object which is obstructing the grids. Then switch it back on as decribed above. The appliance should operate normally. Should the problem persist, please contact the nearest customer service.

NOTE: To assist in maintaining the internal components, after pressing the OFF button the fan will continue to blow room air for a period of 30-60 seconds before shutting down to standby.

# Battery

The remote control use one button cells, model No. CR2025 (3V). We recommend the use of Lithium type battery for longer use.



Note: Please follow battery disposal instruction on battery packaging, or contact your local councils for safely disposal of batteries.

## SAFETY SYSTEM

- In the event of abnormal overheating, a safety device shuts down the appliance automatically. After a short cooling down phase, the appliance is ready for use again.
- If you still notice the same defect as above mentioned, remove the plug from the socket and consult your authorized dealer to your after-sales service department.
- During use, do not touch or cover the air outlet. This may cause the unit to over heat, and the safety device to operate.

• The unit is also fitted with a tip over switch. Do not use on thick and long pile carpets, as the heater may not work, due the tip over switch not been activated.

# MAINTENANCE

- Your appliance must be switch OFF via the main power supply and unplugged before proceeding with any cleaning work.
- Clean the housing with a lightly damp cloth, a vacuum cleaner or a dusting brush.
- Never use flammable or abrasive cleaning agents such as benzene or spirit to clean the appliance.
- Never immerse the appliance in water!
- Clean the air inlet and outlet regularly with a vacuum cleaner.
- If the appliance is not used for an extended period it must be protected against excessive dust and dirt. Please dismount the heater and store in a dry place away from sunlight and dirt.

## **SPECIFICATIONS**

| Model No         | AX-WF269 |
|------------------|----------|
| Voltage          | 120V~    |
| Frequency        | 60Hz     |
| Output Power (W) | 1500W    |

## **CORRECT DISPOSAL OF THIS PRODUCT**

When the time comes to eliminate this product, please consider the environmental impact and take it to recognized recycling facility instead of disposing it with general household waste. Take the equipment to a waste disposal site. Plastic and metal parts that are used in the construction of this appliance can be separated into pure grade which allow recycling. Ask to your service center for details. Everyone of us can participate on the environmental protection.

## ADD DEVICE:


1. Download smart life app




Please scan the QR code, or get smart life to download on APP store or Google play.

# 2.Registration


 Enter the register/login interface, input the phone number for getting verification code to register or through other methods at the bottom of page connecting to related authorization interface to log in.






# 3.Easy Mode(Recommend)


- Preparation:Device has connected with electricity,long press "power"button for 5 seconds until indicator light quickly flashes,the application already stepped into"My Device"interface.
- Phone has connect to wifi router and been able to connecerd to internet.
- Tap the icon"+"on the top right corner of "My Device",choose your device type,enter into "Add Device".
- Make sure the indicator light is flashing quickly, then tap the related button in application.
- Choose the local wifi and enter the correct password,tap"Next".
- Wait for configuring successful, then tap "Complete".







# Enable Smart life skill in Alexa APP

 Open Alexa (amazon account), choose 'Skills' in the options bar, and then search"Smart life" in the input box.







Select Smart life in the search results, and then click "Enable Skill.



 Then input the user name and password of smart life APP that you had previously registered.



 Go back to Alexa home page, choose 'smart home' in the option bar, press '+'(add device) button, searching devices related to applications automatically.



• After the above operation is successful, you can control the device Via Alexa.

# **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The distance between user and products should be no less than 20cm

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.