

Remote control Circuit Description

When pressing the button S1 or S2, TX-3E is powered by the internal power supply, pin 1 will output a coded signal to the first-stage clock frequency, at the same time, pin 3 also output a coded signal to the second-stage signal amplifier, then the car will received the enlarge signal from remote control.