## Instructions

Open the package, remove the remote control, use the special cross screwdriver to open the remote controller back cover, install the 2\*1.5V battery, close the cover and turn the screw

First, open the first step of the remote control car cover, open the battery cover with a special cross screwdriver, put 3\*1.5V batteries in the box, close the lid,turn the screws tightly, turn on the power switch and put the car on the relatively smooth ground

Pick up the remote control handle forwards the car forward to back the car, pushing back. If you need to handle the car left turn to the left at the remote control handle to move the handle forward at the same time to operate at the same time so that the car can move forward and turn left, turn right if the car needs to handle to the right while pushing forward the handle to push this car to forward and right, note that the remote control car of this product requires a corresponding frequency to normal operation such as remote control is 49.865MHz, the car must be 49.865MHz. This corresponds to normal operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.