

# tekmar® Installation & Operation Manual

## Smart Boiler Control 294



## Table of Contents

Installation .....	4	View Menu (1 of 2).....	41
Installation Location.....	4	View Menu (2 of 2).....	42
Wiring Schematic.....	5	Setup Menu (1 of 6) .....	43
Wiring Instructions.....	6	Setup Menu (2 of 6) .....	44
Testing the Sensor Wiring .....	8	Setup Menu (3 of 6) .....	45
User Interface.....	14	Setup Menu (4 of 6) .....	46
Lock Screen.....	14	Setup Menu (5 of 6) .....	47
Home Screen.....	14	Setup Menu (6 of 6) .....	48
Symbols.....	15	Source # Menu (1 of 2).....	49
System Inputs Screen .....	16	Source # Menu (2 of 2).....	50
System Outputs Screen .....	16	BAS Menu (1 of 2).....	51
Boiler Status Screens.....	17	BAS Menu (2 of 2) .....	52
Sequence of Operation .....	19	Monitor # Menu (1 of 1).....	53
Boiler (Source (#) Menu) Setup & Operation.....	19	Monitor Menu (1 of 2).....	54
System Setup & Operation.....	22	Monitor Menu (2 of 2) .....	55
Outdoor Temperature Reset Operation .....	27	Time Menu (1 of 1).....	55
Setpoint Operation .....	29	Schedule Menu (1 of 1).....	56
Energy Management System (EMS) Operation.....	30	Toolbox Menu (1 of 2) .....	57
Indirect Domestic Hot Water (IDHW) Operation .....	31	Manual Override .....	58
Dedicated Domestic Hot Water (DDHW) Operation .....	34	Selecting a Manual Override Mode.....	59
Building Automation System (BAS) .....	34	Troubleshooting.....	60
Pump Operation .....	35	Error Messages (1 of 3).....	60
Combustion Air (C.A.) Damper & DHW Recirculation		Error Messages (2 of 3).....	61
Pump Settings .....	36	Error Messages (3 of 3).....	62
Setting the Schedule .....	36	Technical Data.....	63
Time Clock.....	37	Limited Warranty & Product Return Procedure.....	63
tekmarNet®4 Communication .....	37		
Testing the Control Wiring .....	38		
Control Settings.....	41		

## Important Safety Information

It is your responsibility to ensure that this control is safely installed according to all applicable codes and standards. tekmar is not responsible for damages resulting from improper installation and/or maintenance.



This is a safety-alert symbol. The safety alert symbol is shown alone or used with a signal word (DANGER, WARNING, or CAUTION), a pictorial and/or a safety message to identify hazards.

When you see this symbol alone or with a signal word on your equipment or in this Manual, be alert to the potential for death or serious personal injury.



This pictorial alerts you to electricity, electrocution, and shock hazards.



Double insulated.

### ⚠ WARNING

This symbol identifies hazards which, if not avoided, could result in death or serious injury.

### ⚠ CAUTION

This symbol identifies hazards which, if not avoided, could result in minor or moderate injury.

### NOTICE

This symbol identifies practices, actions, or failure to act which could result in property damage or damage to the equipment.

### ⚠ WARNING



Read Manual and all product labels BEFORE using the equipment. Do not use unless you know the safe and proper operation of this equipment. Keep this Manual available for easy access by all users. Replacement Manuals are available at [tekmarControls.com](http://tekmarControls.com)

### ⚠ WARNING

- It is the installer's responsibility to ensure that this control is safely installed according to all applicable codes and standards.
- Improper installation and operation of this control could result in damage to the equipment and possibly even personal injury or death.
- This control is not intended for use as a primary limit control. Other controls that are intended and certified as safety limits must be placed into the control circuit.

### NOTICE

Do not attempt to service the control. There are no user serviceable parts inside the control. Attempting to do so voids warranty.

## Radio Frequency Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The antenna used for this radio must be properly installed and maintained and must provide a separation distance of at least 7.9 inches (20 cm) from all persons.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

*Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:*

*(1) l'appareil ne doit pas produire de brouillage, et*

*(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*


# Installation

## Installation Location


When choosing the location for the control, consider the following:

- Keep dry. Avoid potential leakage onto the control.  
RH ≤ 90% to 104°F (40°C).
- Non-condensing environment.
- Do not expose to operating temperatures beyond 32-104°F (0-40°C)
- Provide adequate ventilation.
- Keep away from equipment, appliances or other sources of electrical interference.
- Provide easy access for wiring, viewing, & adjusting the display screen.


- Mount approximately 5 ft. (1.5 m) off the finished floor.
- Locate the control near pumps &/or zone valves if possible.
- Provide a solid backing to mount the enclosure to. For example: plywood, studs, etc
- Use the conduit knockouts provided on the upper, lower, back & sides of the enclosure.




Use a Phillips screwdriver to remove the two screws on the cover.




Pull the front cover towards you. The top of the cover will pivot on a hinge. Remove the cover by releasing the pivot hooks.




Mount the enclosure to a wall using #6 wood screws in the four mounting holes. Use screw anchors if drilling into masonry.



Use the 24 knock-outs to install connecting conduits and cabling to the control.



To install the cover, hook the top of the cover to the enclosure, then pivot the bottom to shut.




Use a Phillips screwdriver to fasten the two bottom screws.

## Wiring Schematic

This section provides a wiring schematic for the control.

### ⚠ WARNING

- Before wiring, ensure all power is turned off and take all necessary precautions.
- Sensor wiring may be extended to a total length of 500 feet (152 m) using 18 AWG solid conductor wire.
- Strip all wiring to a length of 3/8 in. or 10 mm for all terminals.
- A circuit breaker or power disconnect that provides power to the control should be located nearby & clearly labeled.
- Refer to the current & voltage ratings at the back of this brochure before connecting devices to this control.
- Only qualified personnel should install or service the control.




## Wiring Instructions

This section explains how to wire individual devices to the Smart Boiler Control 294

### Pressure Sensor 088 (Terminals 1, 2, 3)

An optional Pressure Sensor 088 (sold separately) can connect to the 294 to provide pressure monitoring for hydronic systems up to 150 psi (1034 kPa). The pressure sensor requires the installation of a tee with a 1/8"-27 NPT port to be installed near the expansion tank.





- Connect the pressure signal green wire to terminal 1.
- Connect the reference voltage red wire to terminal 2.
- Connect the power common black wire to terminal 3.




### Outdoor Sensor 070 (Terminals 4, 5)

- The 070 can be mounted directly onto a wall with the wiring entering through the back or bottom of the enclosure. Do not mount the 070 with the conduit knockout facing upwards as rain could enter the enclosure and damage the sensor.
- In order to prevent heat transmitted through the wall from affecting the sensor reading, it may be necessary to install an insulating barrier behind the enclosure.

- The 070 should be mounted on a wall which best represents the heat load on the building (a northern wall for most buildings and a southern facing wall for buildings with large south facing glass areas). The 070 should not be exposed to heat sources such as ventilation or window openings.
- The 070 should be installed at an elevation above the ground that will prevent accidental damage or tampering.



- Connect 18 AWG or similar wire to the two terminals provided in the enclosure and run the wires from the sensor to the control. Do not run the wires parallel to telephone or power cables. If the sensor wires are located in an area with strong sources of electromagnetic interference (EMI), shielded cable or twisted pair should be used or the wires can be run in a grounded metal conduit. If using shielded cable, the shield wire should be connected to the Com terminal on the control and not to earth ground.
- Replace the cover of the sensor enclosure.
- Connect the 2 wires from the outdoor sensor to the Out Sens terminals on the 294 (terminals 4 and 5).




## EMS Connection (Terminals 4, 5)

An Energy Management System (EMS) can be connected to the 294 to provide a target water temperature. This signal replaces the outdoor air temperature sensor. Either a 0 to 10 V (dc) or 2 to 10 V (dc) signal may be used.

- Connect one wire from the EMS to the Outdoor (+) terminal 4.
- Connect a second wire from the EMS to the Outdoor (-) terminal 5.

A 0 - 20 mA signal can be converted to a 0 - 10 V (dc) signal by installing a 500  $\Omega$  resistor in parallel between the Outdoor (+) and (-) terminals (4 and 5). The EMS Signal setting must be set to 0-10.

A 4 - 20 mA signal can be converted to a 2 - 10 V (dc) signal by installing a 500  $\Omega$  resistor in parallel between the Com (-) & EMS (+) In terminals (19 & 16). The EMS Signal setting must be set to 2-10.




## Mounting the Universal Sensors

**These sensors are designed to mount on a pipe or in a temperature immersion well.**

The Universal Sensor should be placed downstream of a pump or after an elbow or similar fitting. This is especially important if large diameter pipes are used as the thermal stratification within the pipe can result in erroneous sensor readings. Proper sensor location requires that the fluid is thoroughly mixed within the pipe before it reaches the sensor.

### Strapped to Pipe

The Universal Sensor can be strapped directly to the pipe using the cable tie provided. Insulation should be placed around the sensor to reduce the effect of air currents on the sensor measurement.




### Immersion Well

If a Universal Sensor is mounted onto 1" (25 mm) diameter L type copper pipe, there is approximately an 8 second delay between a sudden change in water temperature & the time the sensor measures the temperature change. This delay increases considerably when mild steel (black iron) pipe is used. In general, it is recommended that a temperature well be used for steel pipe of diameter greater than 1-1/4" (32 mm). Temperature wells are also recommended when large diameter

pipes are used & fluid stratification is present. If the well is not a snug fit on the sensor tube, use the heat transfer paste supplied with the product. Apply paste to the sides of the sensor and place a pea-sized globule on the sensor tip. Push the sensor into the well and when it bottoms out, press firmly. The paste will be forced up the sides of the well.

### Conduit Connection


The Universal Sensor & Universal Sensor Enclosure 080 (sold separately) are specifically designed to mount onto a 3/8" (10 mm) ID temperature well that is supplied with an end groove. To install the well, plumb a 'T' into the pipe & fix the well into the 'T'. The 080 enclosure has a 7/8" (22 mm) back knockout that must be removed & fitted over the temperature well. The Universal Sensor is then inserted into the well & the retaining clip supplied with the enclosure is snapped onto the well end groove. If the well has a threaded end, the installer must supply a standard threaded conduit retaining ring. The two wires from the sensor are connected to the terminal block provided in the enclosure. The other side of the terminal block is used to connect wires from the control.



## Boiler Sensor (Terminals 6, 7)

The included Universal Sensor 082 can measure the boiler supply temperature of water coming from the boiler system. This sensor should be installed on the supply pipe ahead of the tees supplying any loads.


- Connect the wires to the boiler sensor terminals 6 and 7.



## DHW Sensor (Terminals 8, 9)

A DHW sensor is used to measure the temperature of a DHW tank. For indirect DHW heating, the DHW sensor can be used instead of a DHW aquastat. For direct DHW heating, only the DHW sensor can be used to control the temperature of the DHW tank. The DHW Sensor 078 is sold separately.

- Connect the wires to the boiler sensor terminals 8 and 9.



### Testing the Sensor Wiring

A good quality test meter capable of measuring up to 5,000 kΩ (1 kΩ = 1000 Ω) is required to measure the sensor resistance. In addition to this, the actual temperature must be measured with either a good quality digital thermometer, or if a thermometer is not available, a second sensor can be placed alongside the one to be tested & the readings compared.

First measure the temperature using the thermometer & then measure the resistance of the sensor at the control. The wires from the sensor must not be connected to the control while the test is performed. Using the chart below, estimate the temperature

measured by the sensor. The sensor & thermometer readings should be close. If the test meter reads a very high resistance, there may be a broken wire, a poor wiring connection or a defective sensor. If the resistance is very low, the wiring may be shorted, there may be moisture in the sensor or the sensor may be defective. To test for a defective sensor, measure the resistance directly at the sensor location.

**Do not apply voltage to a sensor at any time as damage to the sensor may result.**


Temperature		Resistance	Temperature		Resistance	Temperature		Resistance	Temperature		Resistance
°F	°C	Ω	°F	°C	Ω	°F	°C	Ω	°F	°C	Ω
-50	-46	490,813	20	-7	46,218	90	32	7,334	160	71	1,689
-45	-43	405,710	25	-4	39,913	95	35	6,532	165	74	1,538
-40	-40	336,606	30	-1	34,558	100	38	5,828	170	77	1,403
-35	-37	280,279	35	2	29,996	105	41	5,210	175	79	1,281
-30	-34	234,196	40	4	26,099	110	43	4,665	180	82	1,172
-25	-32	196,358	45	7	22,763	115	46	4,184	185	85	1,073
-20	-29	165,180	50	10	19,900	120	49	3,760	190	88	983
-15	-26	139,403	55	13	17,436	125	52	3,383	195	91	903
-10	-23	118,018	60	16	15,311	130	54	3,050	200	93	829
-5	-21	100,221	65	18	13,474	135	57	2,754	205	96	763
0	-18	85,362	70	21	11,883	140	60	2,490	210	99	703
5	-15	72,918	75	24	10,501	145	63	2,255	215	102	648
10	-12	62,465	80	27	9,299	150	66	2,045	220	104	598
15	-9	53,658	85	29	8,250	155	68	1,857	225	107	553

## Central Heat Call (Terminals 10, 11)

---

A central heat call is required whenever the building requires heating. The heat call can be volt free or up to 24 V (ac).

- Connect the Central Heat Call terminals 10 and 11 to a switched heat demand.
- Typical heat calls are from a switching relay, zone valve control or thermostat.
- A permanent heat call can be created by installing a jumper wire between terminals 10 and 11.




## DHW Call (Terminals 12, 13)

---

If the DHW sensor option is not used, a call for indirect domestic hot water can come from an aquastat connected to terminals 12 and 13. The DHW Call can be volt free or up to 24 V (ac).

- Connect the DHW Call terminals 12 and 13 to the DHW tank aquastat.




## Setpoint Call (Terminals 14, 15)

---

The setpoint call operates the boiler system to maintain a fixed setpoint temperature. The setpoint call should respond to loads that do not change with outdoor conditions. The setpoint call can be volt free or up to 24 V (ac).

- Connect the setpoint call terminals 14 and 15 to the output terminals on a setpoint control or thermostat.



## tekmarNet4 Boiler Bus (Terminals 16, 17)


tekmarNet4 (tN4) is a wired communication network for tekmar thermostats, setpoint controls and snow melting controls to communicate to the boiler control. The network provides central heating calls, DHW calls and setpoint calls as a digital message between tekmar devices. This optimizes the heating system to operate more efficiently compared to on/off calls.

The tN4 devices connect to the Boiler bus on terminals 16 and 17. The connection is polarity sensitive.

- Connect terminal 16 (tN4) to the tN4 terminal on the device.
- Connect terminal 17 (C) to the C terminal on the device.

## Boiler Expansion (Terminals 18, 19, 20)

The control operates 4 on board boilers and is expandable in groups of 4 up to a maximum of 16 through the use of boiler expansions. The control connects to the expansion through a wired three-wire connection. The maximum bus cable length is 100 feet (30 m) using 18 AWG solid conductor cable.




- Connect terminal 21 (-) to the boiler expansion terminal 1 (-).
- Connect terminal 22 (+) to the boiler expansion terminal 2 (+).
- Connect terminal 23 (Gnd) to the boiler expansion terminal 3 (Gnd).

## Boiler Modbus® Communication (Terminals 21, 22, 23)

The control can connect to select boilers that have an available Modbus communication port to read the boiler's error and lockout codes. The supported brands include:

- Cleaver Brooks
- Fulton
- Lochinvar
- Patterson-Kelley
- Raypak




Use an 18 AWG Twisted Shielded Pair cable to connect the control to each compatible boiler. The 294 operates as the bus master, and the boilers are member devices. All boilers must use the same data rate, data type, parity bit, start bit parameters as boiler 1. Boilers 1 to 16 are sequentially addressed 1 through 16.

- Connect the A (-) terminal on the boiler to the Modbus A (-) terminal 21.
- Connect the B (+) terminal on the boiler to the Modbus B (+) terminal 22.
- Connect the ground terminal on the boiler to the Gnd terminal 23.

## Ethernet (Terminal 24)

The control can connect to the Internet through Ethernet.

- Connect the Ethernet RJ-45 port on terminal 24 to the building Local Area Network (LAN) router or network switch.




## Modulating Boilers (Terminals 25 to 32)

The control provides either a 0-10 V (dc) or a 4-20 mA output to each boiler. Polarity is important.


- Connect the control Mod (+) terminals 25, 27, 29, 31 to boilers 1, 2, 3 and 4 analog signal input (+) respectively.
- Connect the control Mod (-) terminals 26, 28, 30, 32 to boilers 1, 2, 3 and 4 analog signal input (-) respectively.

**Some modulating boilers may also require a boiler on/off enable signal in addition to the modulating signal. Please consult the boiler manual.**

The 4 to 20 mA output can be converted to a 0 - 135  $\Omega$  output for a Modutrol IV™ gas valve actuating motor using a 0 - 135  $\Omega$  tekmar Converter 005 (sold separately).



The 4 to 20 mA output can be converted to a 0 - 135  $\Omega$  output for a V9055™ gas valve actuating motor using a 0 - 135  $\Omega$  tekmar Converter 005 (sold separately).



Modutrol IV™ and V9055™ are trademarks of Honeywell, Inc.

## Boiler Enable (Terminals 33 to 40)

A single stage condensing or non-condensing boiler is enabled through the T T contacts.


- For Boiler 1 connect the Boiler Enable terminals 33 and 34 to the boiler TT contacts.
- For Boiler 2 connect the Boiler Enable terminals 35 and 36 to the boiler TT contacts.
- For Boiler 3 connect the Boiler Enable terminals 37 and 38 to the boiler TT contacts.
- For Boiler 4 connect the Boiler Enable terminals 39 and 40 to the boiler TT contacts.

## Boiler Pump / Valve (Terminals 41 to 48)

Boiler pumps or valves requiring up to 230 V (ac) 5 A, 1/3 hp can be switched through terminals 41 to 46. If a single power source is used for multiple pumps, ensure they are not tied together at any point between the pumps and the control. For simplicity in wiring and troubleshooting, a separate breaker for each pump is recommended.


For pumps:

- Connect the power source line wire (L) to terminal 41.
- Connect a wire from terminal 42 to the pump Line In terminal.
- Connect the pump Neutral (N) to the power source neutral.
- Repeat for additional boiler pumps 2 (terminals 43, 44), boiler pump 3 (45, 46) and boiler pump 4 (terminals 47, 48).
- Ensure each pump is connected to earth ground.



For valves:

- Connect the power source Red wire (R) to terminal 41.
- Connect a wire from terminal 42 to the valve power terminal.
- Connect the valve power common to the power source common (C).
- Repeat for additional boiler valves 2 (terminals 43, 44), boiler valve 3 (45, 46) and boiler valve 4 (terminals 47, 48).




## Combustion Air (C.A.) Damper (Terminals 49, 50)

A C.A. damper requiring up to 230 V (ac) 5 A, 1/3 hp can be switched through terminals 49 and 50.

For 24 V(ac) actuators:


- Connect the power supply red (R) to terminal 49.
- Connect a wire from terminal 50 to the R on the combustion air damper.
- Connect the C on the combustion air damper to the power source common C.
- For 120 V(ac) actuators:
  - Connect the power Line (L) to terminal 49.
  - Connect a wire from terminal 50 to the Line on the combustion air damper.
  - Connect the neutral (N) on the combustion air damper to the power source common C.



## System Pump (Terminals 51, 52)

A system pump requiring up to 230 V (ac) 5 A, 1/3 hp can be switched through terminals 51 and 52. For simplicity in wiring & troubleshooting, a separate breaker for each pump is recommended.


- Connect the power source line wire (L) to terminal 51.
- Connect a wire from terminal 52 to the pump Line terminal.
- Connect a wire from the pump Neutral (N) back to the power source neutral.



## DHW Pump (Terminals 53, 54)

An indirect DHW pump requiring up to 230 V (ac) 5 A, 1/3 hp can be switched through the IDHW Pump terminals.

- Connect the line wire (L) to terminal 53.
- Connect a wire from terminal 54 to the pump L.
- Connect a wire from the pump N back to the power source neutral.



## Input Power (Terminals 55, 56)

Provide a 15 Amp circuit for the input power.

- Connect the 115 V (ac) line wire (L) to terminal 55.
- Connect the neutral wire (N) to terminal 56.



# User Interface

## Lock Screen

The lock screen display



The lock screen displays the following text:

Enter Passcode

Below the text are four circular input fields, with the first one filled with a black dot.

On the right side, there is a 3x3 grid of numbers and a clear button:

1	2	3
4	5	6
7	8	9

Below the grid is a number "0" and a clear button with a "X" icon.

At the bottom right is a "CANCEL" button.

## Home Screen

The home screen displays the following text:

Enter Passcode

Below the text are four circular input fields, with the first one filled with a black dot.

On the right side, there is a 3x3 grid of numbers and a clear button:

1	2	3
4	5	6
7	8	9

Below the grid is a number "0" and a clear button with a "X" icon.

At the bottom right is a "CANCEL" button.

## Symbols

	<b>ETHERNET</b> Indicates connection to Ethernet.		<b>tekmarNet®</b> Communicating with other tekmarNet® devices.
	<b>WI-FI</b> Indicates connection to Wi-Fi.		<b>NOTIFICATIONS</b> Indicates when an error or warning notification is present.
	<b>WATTS ONSITE</b> Indicates when connected to the Watts OnSite cloud service.		
	<b>SCHEDULE</b> Indicates when a programmable schedule is on.		

## System Inputs Screen

## System Outputs Screen





# Sequence of Operation

## Boiler (Source (#) Menu) Setup & Operation

The 294 is able to operate up to four boilers as a heat source. Each boiler is independently configured allowing for maximum plant flexibility.

### Boiler Enable

This setting selects whether the boiler is operational or not.

#### OFF

The boiler is disabled & will not be included in the plant operation.

#### AUTO

The boiler is enabled & will be included in the plant operation.

### Copy Boiler 1

Many boiler installations will have multiple identical boilers. To reduce the number of settings required, certain settings of boiler 1 are copied to boiler 2 by setting the Boiler 2 Copy setting to Boil1. Copy settings are also available for boiler 3 & boiler 4.

#### OFF

The settings from boiler 1 are not copied. This allows for individual boiler settings.

#### Boil 1

The settings from boiler 1 are copied.

### Condensing

This setting selects whether the boiler is condensing or non-condensing & defines what boiler group it is part of.

#### NO

The boiler is non-condensing & is part of the non-condensing boiler group.

#### YES

The boiler is condensing & is part of the condensing boiler group.

### Boiler Type

The 294 has four different boiler types to choose from. Use the Boil TYPE setting to select one of the following:

#### MOD

The modulating output operates a modulating boiler by controlling the burner firing rate. The Stage 1 relay is also used to give a boiler enable to allow the modulating boiler to go through ignition sequence. The Stage 1 relay may not be required on all modulating boilers.

#### 1STG

The Stage 1 relay operates a single, stage boiler by cycling the burner stage on & off.

#### 2STG

The Stage 1 & Stage 2 relays operate a single, two stage boiler by cycling the burner stages on & off.

#### EMS

The modulating output operates a boiler that interprets an analog input signal as a target temperature. The temperature rails (minimum and maximum) are adjustable between 50°F (10.0°C) & 210°F (99.0°C).

- VDC SIGN MIN

Sets the minimum analog Vdc signal which corresponds to the minimum temperature (EMS TEMP MIN).

- EMS TEMP MIN

Sets the temperature on the low end which corresponds to the minimum analog signal (Vdc Min / 4 mA).

- EMS TEMP MAX

Sets the temperature on the high end which corresponds to the maximum analog signal (10 Vdc / 20 mA).

## Modulating Type

The MOD TYPE setting selects the analog output signal used for modulating (MOD) and EMS boiler types.

### 0-10

The modulating output is 0-10 V (dc).


### 4-20

The modulating output is 4-20 mA.

The 4-20 mA output can be converted to a 0 - 135 Ω output using a 0 - 135 Ω Converter 005. Refer to the Modulating Boiler Wiring section of the Control Wiring section.

## Fire Delay

The Fire Delay sets the time it takes for the boiler to generate flame from the time the boiler turns on.



## Modulation Delay

The MOD DELAY is the time that the boiler burner must hold the modulation of the boiler at a minimum before allowing it to modulate any further.

## Boiler Mass

The Boil MASS setting selects the thermal mass characteristics of each boiler. Operation of the boiler can become unstable if the incorrect Boiler Mass setting is chosen. A key sign of unstable boiler operation is that the flame will continue to increase & then decrease in short periods of time. By choosing a lower boiler mass setting, the boiler response will become more stable.

### LOW

The LO setting is selected if the boiler that is used has a low thermal mass. This means that the boiler has very small water content & has very little metal in the heat exchanger. A boiler that has a low thermal mass comes up to temperature quite rapidly when fired. This is typical of many copper fin-tube boilers.

The Low mass setting (LO) provides a fast response to the heating system.

### MED

The MED setting is selected if the boiler that is used has a medium thermal mass. This means that the boiler either has a large water content & a low metal content or a low water content & a high metal content. This is typical of many modern residential cast iron boilers or steel tube boilers.

The Med mass setting provides a moderate response to the heating system.

### HI

The HI setting is selected if the boiler that is used has a high thermal mass. This means that the boiler has both large water content & a large metal content. A boiler that has a high thermal mass is relatively slow in coming up to temperature. This is typical of many commercial cast iron & steel tube boilers.

The Hi mass setting provides a slow response to the heating system.

## Low Fire & High Fire Boiler Output

In order to accommodate different boiler capacities in the same system, a low fire & high fire boiler output for each boiler

can be set. This allows the control to properly operate the boilers using either sequential or parallel modulation. Each boiler typically has a rating plate that specifies the minimum & maximum output. This information is also available in the boiler manual.

The minimum & maximum boiler output is expressed in MBtu/h. 1 MBtu/h = 1,000 Btu / hour. The range is from 10 MBtu/h to 9,990 MBtu/h.

For example, if a boiler has a maximum output of 100,000 Btu / hr & a minimum output of 20,000 Btu / hr (turn down ratio of 5):

$$\text{Maximum Boiler Output} = \frac{100,000}{1,000} = 100 \text{ MBtu/h}$$

$$\text{Minimum Boiler Output} = \frac{20,000}{1,000} = 20 \text{ MBtu/h}$$

## Motor Speed

The MOTOR SPD is the amount of time the boiler requires to go from 0% modulation to 100% modulation.

Gas valve actuating motors have a design time from fully closed to fully opened which can be found in the manufacturer's manual. The Motor Speed should be set to this time.

The Motor Speed setting for a Variable Frequency Drive (VFD) is the amount of time required to go from a stopped position to 100% fan speed. Since a VFD has a very quick response rate, it may be necessary to increase the Motor Speed setting in order to increase the stability of the boiler modulation.



## Start Modulation

The START MOD setting is the lowest modulation output required to obtain proper ignition. Whenever boiler operation is required, the control outputs an analog signal corresponding to the Start Modulation setting & closes the boiler contact to turn on the burner. After the Fire Delay has elapsed & the burner is ignited, the control modulates the firing rate between the Minimum Modulation setting & the Maximum Modulation setting.

## Minimum Modulation

The MIN MOD is the lowest signal the control can send to modulate the boiler. This operates the boiler at low fire. Use the MIN MOD setting in the Adjust Menu to select an appropriate boiler minimum modulation.

- Refer to the boiler manufacturer's literature to determine the minimum output voltage V (dc) or current (mA) that the boiler will successfully operate at.

### For 0 to 10 V (dc):

Minimum Modulation =

$$\text{Boiler's Minimum Input Signal} \times 100\% \\ 10 \text{ V (dc)}$$

### For 4 to 20 mA:


Minimum Modulation =

$$\text{Boiler's Minimum Input Signal} - 4\text{mA} \times 100\% \\ 16 \text{ mA}$$

### Example:

A boiler requires a 1.8 V (dc) signal to fire the boiler at low fire. The boiler can be modulated to 10 V (dc) where it reaches high fire.

$$\text{Minimum Modulation} = \frac{1.8 \text{ V}}{10 \text{ V}} \times 100\% = 18\%$$



### Maximum Modulation

The Maximum Modulation is the highest signal the control can send to modulate the boiler. For boilers with electronic operators, the boiler's input signal range may not match the output signal range of the 294. Use the MAX MOD setting in the Source (#) Menu to select an appropriate boiler maximum modulation.

#### For 0 to 10 V (dc):

Maximum Modulation =

$$\frac{\text{Boiler's Maximum Input Signal}}{10 \text{ V (dc)}} \times 100\%$$

#### For 4 to 20 mA:


Maximum Modulation =

$$\frac{\text{Boiler's Maximum Input Signal} - 4\text{mA}}{16 \text{ mA}} \times 100\%$$

### Example:

A boiler's input signal range is 0 to 9 V (dc). The 294 control has an output signal range of 0 to 10 V (dc).

$$\text{Maximum Modulation} = \frac{9 \text{ V}}{10 \text{ V}} \times 100\% = 90\%$$



### Maximum Boiler Outlet

The control has the capability for each boiler outlet temperature to be monitored & limited. The MAX OUT setting sets the maximum boiler outlet temperature. For modulating boilers, as the boiler outlet temperature approaches the boiler outlet maximum temperature, the control will reduce the firing rate. Once the boiler outlet temperature reaches the boiler outlet maximum temperature less 15°F (8.0°C), firing rate reduction will begin. Once the boiler outlet temperature reaches the boiler outlet maximum temperature less 5°F (2.5°C), the firing rate will be reduced to minimum modulation. If the boiler outlet temperature reaches the boiler outlet maximum, the boiler is turned off. In order for the boiler to be able to be turned back on again, the boiler outlet temperature must drop 5°F (2.5°C) below the boiler outlet maximum.

If MAX OUT is set to OFF, the control only monitors the boiler outlet temperature.

### Boiler Pump / Valve Post Purge

This setting sets the amount of time the control operates the boiler pump / valve after the boiler is turned off. This will purge heat out of the boiler, reducing stand-by losses, & also aid in reducing "kettling". The amount of time for the boiler pump post purge is adjustable between 10 seconds & 20:00 minutes. Auto is also available in which the control automatically determines the amount of time based on the boiler mass.

## System Setup & Operation

### Application Mode

There are five possible application modes that the 294 can be configured for including:


- Outdoor Temperature Reset (RSET)
- Fixed Setpoint (SETP)
- Dedicated Domestic Hot Water (DDHW)
- Energy Management System (EMS)
- Building Automation System (BAS)

Refer to the appropriate section of this brochure for a description of the each of the application modes.

### Boiler Minimum


The Boil MIN is the lowest temperature that the control is allowed to use as a boiler target temperature. During mild conditions, if the control calculates a boiler target temperature that is below the boiler minimum setting, the boiler target temperature is adjusted to at least the boiler minimum setting. MIN is displayed in the status field while viewing the boiler supply or target & when the boiler target is boiler minimum & the boiler supply is less than boiler minimum plus 5°F (2.5°C). Set the Boiler Minimum setting to the boiler manufacturer's recommended temperature.

**The Boil MIN is only applicable when at least one of the boilers is configured for non-condensing.**



### Boiler Maximum

The Boil MAX is the highest temperature that the control is allowed to use as a boiler target temperature. MAX is displayed in the status field viewing the boiler supply or target & when the boiler target is boiler maximum & the boiler supply is greater than boiler maximum minus 5°F (2.5°C). Set the boiler maximum setting below the boiler operator or aquastat temperature.




### Boiler Differential


Both on/off (single stage & two stage) & modulating boilers are operated with a differential. In some cases, a modulating boiler must be operated with a differential at low fire. This indicates the load is smaller than the minimum modulation of the boiler. For modulating boilers, the differential no longer applies once operating the boiler above low fire.

The differential operates by turning on the boiler when the boiler supply water temperature is 1/2 of the differential below the boiler target temperature. As the boiler supply water temperature reaches 1/2 of the differential above the boiler target temperature, the boiler is shut off.

### Manual Differential



### Automatic Differential



### Exercising

The control will exercise all pumps, & tN4 zones (zone valves & zone pumps) for 10 seconds every three days of inactivity to prevent seizure. To enable exercising, switch the Exercise / Off DIP to the Exercise position.

### Boost

When the control changes from the UnOccupied mode to the Occupied mode, it enters into a boosting mode. In this mode, the supply water temperature to the system is raised above its normal values for a period of time to provide a faster recovery from the setback temperature of the building. The maximum length of the boost is selected using the BOOST setting in the Setup menu.

Typical settings for the boost function vary between 30 minutes & two hours for buildings that have a fast responding heating system. For buildings that have a slow responding heating system, a setting between four hours & eight hours is typical. After a boost time is selected, the setback timer must be adjusted to come out of setback some time in advance of the desired occupied time. This time in advance is normally the same as the BOOST setting.

If the building is not up to temperature at the correct time, the BOOST setting should be lengthened & the setback timer should be adjusted accordingly. If the building is up to temperature before the required time, the BOOST setting should be shortened & the setback timer should be adjusted accordingly. If the system is operating near its design conditions or if the supply water temperature is being limited by settings made in the control, the time required to bring the building up to temperature may be longer than expected.

## Flow Monitoring

---

The control has the capability to monitor flow rate through the connection of a 4-20 mA style flow sensor. Flow is measured in either gallons per minute (gpm) or meters cubed per hour (m<sup>3</sup>/h). The units are adjustable through the FLOW UNIT setting in the Toolbox menu.

Varying flow rates are accommodated & the flow range of the flow sensor being used is configured using the following items in the Setup menu:

- FLOW RATE 4 mA

Sets the flow rate on the low end which corresponds to 4 mA.

- FLOW RATE 20 mA

Sets the flow rate on the high end which corresponds to 20mA.

Examples of compatible aftermarket flow sensors include the Kele SDI series, 2200 & 3100 series and 200 series (requires 310 transmitter).

In addition to flow monitoring, the flow sensor can also be used to prove primary pump flow. Refer to the Pump Operation section of this brochure for additional details.

## Energy Monitoring

---

The control has the capability to monitor Energy. The control requires the boiler supply, boiler return sensor & the flow sensor in order to calculate & display energy in either Therms (THRM) or Gigajoules (GJ). The units are adjustable through the ENERGY UNIT setting in the Toolbox menu. Select MBtu for display in THRM and kWh for display in GJ.

## Pressure Monitoring

---

The control has the capability to monitor system pressure through the connection of a V(dc) style pressure sensor with a signal range of 0.5 to 4.5 V (dc). Pressure is measured in either psi or kPa. The units are adjustable through the PRESSURE UNIT setting in the Toolbox menu.

The Pressure Sensor Range item in the Setup menu selects from the available pressure ranges for the pressure sensor to be used.

Examples of compatible aftermarket pressure sensors include the Honeywell PX2 (AA) series and the Measurement Specialties 7100 series.

## Vent Temperature Monitoring & Limiting

---

The control has the capability to measure & limit the vent temperature. The VENT MAX setting defines the operation of the vent sensor. If the vent temperature exceeds the VENT MAX, the boiler plant is shut down. The boiler plan will not be allowed to operate until the vent temperature drops 10°F (6°C) below the VENT MAX. If OFF is selected, the vent temperature is only monitored.

## Alert Relay

---

The control has an Alert relay that closes whenever a control or sensor error is detected, or when a warning or limiting condition is detected. When the alert contact closes, refer to the Error Messages section of this brochure to determine the cause of the alert & how to clear the error.

## Boiler Alert

If no temperature increase is detected at the boiler supply sensor within this delay period, the Alert relay will close & the control will display the NO HEAT error message. To clear the error, press the CLEAR button while viewing the error message.

## Boiler Plant Operation

The 294 is able to operate up to four boilers to maintain a boiler target temperature. Proportional, Integral & Derivative (PID) logic is used in order to satisfy the boiler target temperature for all plant configurations with the exception of Dedicated Domestic Hot Water (DDHW). Proportional (P) logic is used for DDHW. For proper operation of the boilers, the 294 must be the only control that determines when a boiler is to fire.

**\*Important:** The boiler operator, or aquastat, remains in the burner circuit & acts as a secondary upper limit on the boiler temperature. The boiler aquastat temperature setting must be adjusted above the 294's boiler maximum setting in order to prevent short cycling of the burner.

### Boiler Operation

#### Single Stage On/Off Boiler

Once a boiler is required to operate, the control turns on the Stage 1 relay. Once the control turns on the Stage 1 relay, it will display the "Boiler" icon & "100%" under the respective boiler output status in the display.

#### Two Stage On/Off Boiler

Once a boiler is required to operate, the control turns on the Stage 1 relay. Once the Fire Delay time plus the Stage Delay time has expired, the control can turn on the Stage 2 relay if it is required. Once the control turns on the Stage 1 relay, it will display the "Boiler" icon & "50%" under the respective boiler output status in the display. Once the control turns on the Stage 2 relay, it will display "100%".

#### Modulating Boiler

Once a boiler is required to operate, the control outputs an analog signal corresponding to the Start Modulation setting & then turns on the Stage 1 relay. Once the Fire Delay time has expired, the modulating output is adjusted to the Minimum Modulation setting. The control then holds the modulating output at the Minimum Modulation until the Minimum Modulation Delay time has elapsed. The control can then adjust the modulating output from the Minimum Modulation as required. Once the control turns on the Stage 1 relay, it will display the "Boiler" under the respective boiler output status in the display. The current firing rate is also displayed in the boiler output field.

#### EMS Boiler

Once a boiler is required to operate, the control outputs an appropriate analog signal corresponding to the boiler target temperature & then turns on the Stage 1 relay. Once the control turns on the Stage 1 relay, it will display the "Boiler" under the respective boiler output status in the display. The target water temperature is also displayed in the boiler output field.

#### Boiler Target Temperature

The Boil TARG temperature is determined by the application mode & the type of call received. The control displays the temperature that it is currently trying to maintain at the boiler supply sensor in the View menu. If the control does not presently have a requirement for heat, it does not show a boiler target temperature. Instead, "---" is displayed in the LCD.

#### Stage Delay

The STG DELAY is the minimum time delay between the firing of each boiler or boiler stage. After this delay has expired the control can fire the next boiler or boiler stage if it is required. This

setting can be adjusted manually or set to an automatic setting. When the automatic setting is used, the control determines the best stage delay based on the operation of the system.

#### Modulation Mode

When using multiple modulating boilers, a selection must be made regarding the sequencing of the boilers. Two modulation mode settings are provided considering condensing & non-condensing boiler groups.

Modulation Mode is not available when the Application Mode is configured for Dedicated Domestic Hot Water (DDHW).

- MOD COND (Modulation Mode - Modulating, Condensing Boiler Group)


This setting is applicable for a group at least two modulating, condensing boilers.

- MOD NC (Modulation Mode - Modulating, Non-Condensing Boiler Group)

This setting is applicable for a group of at least two modulating, non-condensing boilers.


#### Sequential Modulation (SEQ)

With Sequential Modulation, the control will turn on the fewest boilers possible to meet the load. The control will bring a boiler from its Minimum Modulation setting up to its Maximum Modulation setting before bringing on another boiler. When another boiler is turned on, the previous boiler will keep its output at full fire.



#### Parallel Modulation (PAR)

With Parallel Modulation, the control will turn on the most boilers possible to meet the load. The control will bring on the first boiler at Minimum Modulation & does not increase its modulation. If more boiler output is required, the second boiler will turn on at Minimum Modulation & does not increase its modulation. Additional boilers are turned on at their Minimum Modulation setting until all boilers are on. If still more boiler output is required, all boilers are modulated up in parallel until they reach their Maximum Modulation settings.



#### Staging Mode Setup

When using multiple two-stage boilers, a selection must be made regarding the staging order of the boilers. Two staging modes are provided considering condensing & non-condensing boiler groups.

- STG COND (Staging Mode - Two-Stage, Condensing Boiler Group)

This setting is applicable for a group of at least two, two-stage condensing boilers.

- STG NC (Staging Mode - Two-Stage Non-Condensing Boiler Group)

This setting is applicable for a group of at least two, two-stage non-condensing boilers.

#### Lo/Hi

If the Lo/Hi staging option is selected the control stages in sequence all of the stages in a single boiler. Once all of the stages are turned on, the control then stages in sequence all of the stages of the next boiler in the rotation sequence.

#### Lo/Lo

If the Lo/Lo staging option is selected, the control stages all of the Lo stage outputs in all of the boilers first. Once all of the boilers are operating on their Lo stages, the control then operates the second stage in each boiler in the same order.

### Boiler Group Rotation

The control has two rotation settings including one for the condensing boiler group & another for the non-condensing boiler group.

- ROT COND (Rotation - Condensing Boiler Group)

This setting is applicable for a group of at least two, two-stage condensing boilers.

- ROT NC (Rotation - Non-Condensing Boiler Group)

This setting is applicable for a group of at least two, two-stage non-condensing boilers.

The Rotate feature changes the firing order of the boilers whenever one boiler accumulates 48 hours more run time than any other boiler. Rotation will be forced if any boiler accumulates 60 hours more run time. After each rotation, the boiler with the least running hours is the first to fire & the boiler with the most running hours is the last to fire. This function ensures that all of the boilers receive equal amounts of use. When the Rotation setting is set to Off, the firing sequence always begins with lowest boiler to the highest boiler.



To reset the rotation sequence, clear the Burner Run Time in the Monitor (#) Menu.

### Boiler Run Time Monitoring

The running time of each boiler is logged in its respective Monitor (#) menu. To reset the running time, select the appropriate BURNER item in the Monitor (#) menu & select CLEAR until "0" is displayed.

### Fixed Lead

When the boiler plant includes only one boiler group, either a condensing or a non-condensing group, a selection must be made regarding operation of the lead boiler.

#### ON

In some applications, it may be desirable to have the first boiler fire first at all times while the firing sequence of the remaining boilers is changed using Equal Run Time Rotation. This configuration is typical of installations where the boiler plant includes similar boilers but the first boiler is required to be the first to fire in order to establish sufficient draft for venting. With a fixed lead rotation, the lead boiler is always turned on first & turned off first. The Fixed Lead is always applied to the boiler 1 output.

#### OFF

The lead boiler is not fixed to operate first in the firing sequence. It is included in the rotation sequence with the other boilers.

### Fixed Last

When the boiler plant includes only one boiler group, either a condensing or a non-condensing group, a selection must be made regarding operation of the last boiler.

#### ON

In some applications, it may be desirable to have the last boiler fire last at all times while the firing sequence of the remaining boilers is changed using Equal Run Time Rotation. This configuration is typical of installations where the boiler plant includes higher efficient boilers & a single lesser efficient boiler. The lesser efficient boiler is only desired to be operated when all other boilers in the plant are on & the load cannot be satisfied. With a fixed last rotation, the last boiler is the last to turn on & the first to turn off. The Fixed Last is always applied to the boiler 4 output.

#### OFF

The last boiler is not fixed to operate last in the firing sequence. It is included in the rotation sequence with the other boilers.

### Condensing & Non-Condensing Boiler Groups

Operating a boiler plant that contains both condensing (high initial cost) & non-condensing (lower initial cost) boilers allows the boiler plant to achieve nearly the same operating efficiencies as operating all condensing boilers but at a much lower installed cost to the building owner. High system efficiency can be achieved as long as the condensing boilers are the first to operate in the firing sequence. During mild weather, the lead condensing boilers operate at lower boiler temperatures & achieve their peak boiler efficiencies while the non-condensing boilers are rarely operated. During very cold weather, the boiler target temperature is often above the boiler's condensation point & the condensing & non-condensing boilers operate together at roughly the same efficiency level.

When a condensing boiler is operating, it is desirable to operate the boilers without a boiler minimum temperature being applied to the boiler target. This allows the condensing boiler to operate at its maximum efficiency. When a non-condensing boiler is operating, a boiler minimum temperature should be applied to the boiler target to prevent damage to the non-condensing boiler's heat exchanger from sustained flue gas condensation.

The 294 supports operation of a condensing & a non-condensing boiler group. A condensing boiler group is created when at least one boiler is selected to be condensing & a non-condensing boiler group is created when at least one boiler is selected to be non-condensing. The condensing boiler group is always sequenced on first, followed by the non-condensing boiler group.

### **Boiler Plant Flow (PLANT FLW)**

The control supports the option of having all boilers in the plant to use either a pump or an isolation valve.

#### **Boiler Pump (PUMP)**

PUMP is to be selected when each boiler in the plant includes its own circulator. This is typical of a conventional boiler plant configuration that includes boilers that are flow sensitive.

PUMP is also to be selected when each boiler in the plant neither includes a pump nor an isolation valve. This boiler plant configuration could be used with boilers that are not flow sensitive. It is expected that the primary pump provides flow through all boilers, regardless of whether they are on or off.

#### **Boiler Isolation Valve (VALV)**

VALVE is to be selected when each boiler in the plant includes an isolation valve. This boiler plant configuration could be used with boilers that are not flow sensitive & is typical of systems that incorporate a variable frequency drive (VFD) with the primary pump. Systems incorporating variable speed primary pumping (via a VFD) allow for increased pump electrical energy savings during milder heating loads.

The purpose of the isolation valve is to isolate the boiler from plant operation when the boiler is turned off. As a boiler is isolated, the VFD will adjust the flow rate accordingly. The isolation valve must include a spring return motor that is of the normally open / fail open type. As the control does not include a proof input for proving that the isolation valve is fully open prior to burner ignition, the motor end switch, if available, should be wired into the burner's safety circuit.

Boiler isolation valve operation is dependent on whether the Heat Call is permanent or intermittent.

- Permanent Heat Call (e.g. external Heat Call shorted)

As the heating load becomes satisfied & a boiler is required to be turned off, the boiler will turn off while its isolation valve remains open for the boiler purge period time. After the boiler purge time expires, the isolation valve will close. When the last boiler in the plant turns off, its isolation valve will remain open, allowing for a flow path of the primary pump.

When there is a subsequent requirement for plant operation and a boiler is required to be turned on, its isolation valve will be opened (if not already open) prior to burner ignition. Also, if applicable, the isolation valve of the last boiler turned off in the previous cycle will be turned off.

- Intermittent Heat Call (e.g. external Heat Call interlocked

with space heating thermostat)

When the Heat Call is present, operation is consistent with the operation defined for a Permanent Heat Call.

When the external Heat Call is removed, the isolation valve of every boiler will be opened. When the external Heat Call is re-applied, the control will keep open the valve of the boiler that is due to be turned on first. The isolation valves of all other boilers will be closed.

## Outdoor Temperature Reset Operation

Outdoor Temperature Reset is available by setting the Application Mode in the Setup Menu to RSET.

In a heating system, the rate of heat supplied to the building must equal the rate at which heat is lost. If the two rates are not equal, the building will either cool off or over heat.

The rate of building heat loss depends mostly on the outdoor temperature. Outdoor Reset allows a hot water heating system to increase the water temperature, adding heat to the building, as the outdoor temperature drops. The rate at which the water temperature is changed as a function of outdoor temperature is defined by the characterized heating curve.

**Indirect Domestic Hot Water (IDHW) & setpoint operation are both available during outdoor temperature reset operation.**

### Heat Call

A Heat Call is required in order for the control to provide target water temperature for the space heating system. Once the control registers a Heat Call, it will display the "Heat" icon under the Calls in the display. A heat call can be provided in two ways:

#### Contact Closure

A dry contact or 24 V (ac) signal is applied across the Heat Call terminals 5 & 6.


#### tekmarNet® Device

A tN4 thermostat wired to one of the tN4 Bus terminals.

### Characterized Heating Curve

A characterized heating curve determines the amount the target water temperature is raised for every 1° drop in outdoor air temperature.

The characterized heating curve takes into account the type of terminal unit that the system is using. Since different types of heating terminal units transfer heat to a space using different proportions of radiation, convection & conduction, the supply water temperature must be controlled differently. The control uses the terminal unit setting to vary the supply water temperature to suit the terminal unit being used. This improves the control of the air temperature in the building.




### Terminal Unit

Select the appropriate terminal unit in the Setup Menu. This will change the shape of the characterized heating curve to better match the heat transfer properties of that specific terminal unit.


#### Hydronic Radiant Floor (HRF1)

A heavy or high mass, hydronic radiant floor system. This type of a hydronic radiant floor is embedded in either a thick concrete or gypsum pour. This heating system has a large thermal mass & is slow acting.




#### Hydronic Radiant Floor (HRF2)

A light or low mass, hydronic radiant floor system. Most commonly, this type of radiant heating system is attached to the bottom of a wood sub floor, suspended in the joist space, or sandwiched between the subfloor & the surface. This type of radiant system has a relatively low thermal mass & responds faster than a high mass system.




#### Fancoil (COIL)

A fancoil terminal unit or air handling unit (AHU) consisting of a hydronic heating coil & either a fan or blower. Air is forced across the coil at a constant velocity by the fan or blower & is then delivered into the building space.




#### Fin-tube Convector (CONV)

A convector terminal unit is made up of a heating element with fins on it. This type of terminal unit relies on the natural convection of air across the heating element to deliver heated air into the space. The amount of natural convection is dependent on the supply water temperature to the heating element & the room air temperature.




## Radiator (RAD)

A radiator terminal unit has a large heated surface that is exposed to the room. A radiator provides heat to the room through radiant heat transfer & natural convection.



## Baseboard (BASE)

A baseboard terminal unit is similar to a radiator, but has a low profile & is installed at the base of the wall. The proportion of heat transferred by radiation from a baseboard is greater than that from a fin-tube convector.



## Boiler Terminal Unit Defaults

When a terminal unit is selected for boiler zones, the control loads default values for the boiler design, boiler maximum supply, & boiler minimum supply temperatures. The factory defaults can be changed to better match the installed system. Locate the Terminal Unit setting in the Setup menu.

Terminal Unit	Boil DSGN	Boil MAX	*Boil MIN
High Mass Radiant	120°F (49.0°C)	140°F (60.0°C)	140°F (60.0°C)
Low Mass Radiant	140°F (60.0°C)	160°F (71°C)	140°F (60.0°C)
Fancoil	190°F (88.0°C)	210°F (99.0°C)	140°F (60.0°C)
Fin-Tube Convector	180°F (82.0°C)	200°F (93.5°C)	140°F (60.0°C)
Radiator	160°F (71.0°C)	180°F (82.0°C)	140°F (60.0°C)
Baseboard	150°F (65.5°C)	170°F (76.5°C)	140°F (60.0°C)

**Boil MIN is only available if at least one boiler is set to non-condensing. If all available boilers are set to condensing, Boil MIN is not available & is hard-coded to OFF.**

## Room

The Room setting is the desired room air temperature, according to the outdoor reset heating curve. The Room setting parallel shifts the heating curve up or down to change the target water temperature. Adjust the Room setting to increase or decrease the amount of heat available to the building. Once the heating curve has been set up properly, the Room setting is the only setting that needs to be adjusted. The default Room setting is 70°F (21.0°C), & it can be adjusted for both the occupied & unoccupied periods.

## Outdoor Design

The outdoor design temperature is typically the coldest outdoor air temperature of the year. This temperature is used when doing the heat loss calculations for the building & is used to size the heating system equipment. If a cold outdoor design temperature is selected, the supply water temperature rises gradually as the outdoor temperature drops. If a warm outdoor design temperature is selected, the supply water temperature rises rapidly as the outdoor temperature drops.

## Boiler Indoor

The boiler indoor design temperature is the indoor temperature the heating designer chose while calculating the heat loss for the boiler water heated zones. This temperature is typically 70°F (21.0°C). This setting establishes the beginning of the boiler characterized heating curve.

## Boiler Design

The boiler design supply temperature is the boiler water temperature required to heat the zones at the outdoor design temperature, or on the typical coldest day of the year.

(Default automatically changes based on terminal unit setting)

## Warm Weather Shut Down (WWSD)

Warm Weather Shut Down disables the heating system when the outdoor air temperature rises above this programmable setting. When the control enters into WWSD, WWSD is indicated in the status field. WWSD is only available when the Application Mode is set to RSET.

**While in WWSD, the control will still operate to provide Indirect Domestic Hot Water or Setpoint operation.**

## Setpoint Operation

Setpoint operation is dependent on the application mode setting.

- If the Application Mode is configured for Outdoor Temperature Reset (RSET) or Energy Management System (EMS), the control provides heat for an additional setpoint load. The control does respond to a Heat Call from a space heating system.
- If the Application Mode is configured for Setpoint (SETP), the control provides heat only for the setpoint load. The control does not respond to a Heat Call for space heating.

**Indirect Domestic Hot Water (IDHW) operation is available during setpoint operation.**

### Setpoint Call

A Setpoint Call is required in order for the control to provide heat to a setpoint load, such as a spa, pool or snowmelt load. Once the control registers a Setpoint Call, it will display the "Setpoint" icon under the Calls in the display. A setpoint call can be provided in two ways:

#### Contact Closure

A dry contact or 24 V (ac) signal is applied across the Setpoint Call terminals 9 & 10.

#### tekmarNet® Setpoint Control with Sensor

A Setpoint Call is provided through the tekmarNet® system. This can be done through the tN4 Boiler Bus terminals with a tekmarNet® setpoint device such as a Setpoint Control 161.

### Boiler Target Temperature During a Setpoint Call

When a Setpoint Call is present, a boiler target is determined.

- When using a Contact Closure, the boiler target is set to the SETP Setpoint setting.
- When using a tekmarNet® Setpoint Control, the boiler target is set to the devices Exchange Supply setting.

If there are multiple devices calling for heat, the boiler target is set to the highest temperature requirement.

### Setpoint During UnOccupied

When using a Contact Closure, a second SETP Setpoint setting is available for the Unoccupied periods.

DIP Switch must be set to Setback to view UnOccupied items.

During the Away Scene, Setpoint Calls are ignored.

### Setpoint Mode

The control has a Setpoint Mode setting that selects whether or not setpoint heating is operational.

#### OFF

Setpoint operation is not provided. All Setpoint Calls are ignored. If this mode is selected while setpoint operation is underway, all setpoint operation ceases.

#### ON


Setpoint heating is provided. All Setpoint Calls are responded to. Operation is dependent on the Primary Pump During Setpoint operation setting.

### Primary Pump During Setpoint

This setting selects whether or not primary pump operation is required during setpoint heating.


#### OFF

The primary pump does not turn on during setpoint heating. It is assumed that the setpoint load pump will provide adequate flow through the setpoint load & the boiler system loop.



#### ON

The primary pump turns on during setpoint heating.



### Setpoint Priority

This setting selects whether or not priority of setpoint over space heating is required. Setpoint priority stops or limits the delivery of heat to the space heating system while the setpoint load calls for heat. This allows for quick recovery of the load.

#### OFF

Setpoint priority is not provided. The primary pump can operate when a Heat Call is present. Heating zones are unaffected by setpoint heating.

#### ON

Setpoint priority is provided & is dependent on the type of space heating zones & whether or not the primary pump is required to operate during setpoint heating.

For non-tN4 space heating, the primary pump shuts off to provide priority. If the primary pump is required to operate for setpoint heating, priority requires the use of an external relay to force the heating zones off.

For tN4 space heating, the primary pump can operate when a Heat Call is present. If the boilers are unable to maintain the boiler target temperature, the tN4 zones are sequentially shut off using tN4 communication to provide priority.

## Priority Override

Priority Override applies when Setpoint Priority is set to ON. It prevents the building from cooling off too much or the possibility of a potential freeze up during setpoint priority.

When set to auto, the priority time is calculated based on outdoor temperature. At or below the design outdoor temperature, 15 minutes are allowed for setpoint priority. At or above the Indoor Design temperature, 2 hours are allowed for setpoint priority. The time allowed for setpoint priority varies linearly between the above two points. There is a manual setting also available in the Setup menu.

The priority timer does not start timing until priority is selected & both a Setpoint Call & a Heat Call exist together. Once the allowed time for priority has elapsed, the control overrides the setpoint priority & resumes space heating.

## Conditional Setpoint Priority

If the boiler supply temperature is maintained at or above the required temperature during setpoint heating, this indicates that the boilers have enough capacity for setpoint & possibly space heating as well. As long as the boiler supply temperature is maintained near the target, setpoint & heating occurs simultaneously.

## Setpoint Post Purge

After a Setpoint Call from a tN4 device is removed, the control can perform a post purge. The control shuts off the boilers & continues to operate, if applicable, the primary pump. This purges the residual heat from the boilers into the setpoint load. The control continues this purge until one of the following occurs:

1. A Heat Call is detected.
2. The boiler supply drops 20°F (11.0°C) below the setpoint target temperature.
3. Two minutes elapse.

## Energy Management System (EMS) Operation

The control can accept an external DC signal from an Energy Management System (EMS). The control converts the DC signal into the appropriate boiler target temperature for the space heating system.

EMS is available by setting the APP MODE in the Setup Menu to EMS.

Indirect Domestic Hot Water (IDHW) & setpoint are both available during EMS operation.

### Heat Call

A Heat Call is required in order for the control to provide a target water temperature for the space heating system. Once the control registers a Heat Call, it will display the "Heat" icon under the Calls in the display.

A Heat Call is provided by:

### Input Signal

An external signal is generated by applying a voltage between 0 V (dc) & 10 V (dc) across the EMS (+) In & Com (-) terminals (16 & 19). Voltages that exceed 10 V (dc) will still be considered a 10 V (dc) signal.

If the EMS signal goes below the minimum voltage, the "Heat" icon under the Calls in the display is turned off. The boiler target temperature is displayed as "——" to indicate that there is no longer a call for heating.

External Heat Call terminals are not operational.

### EMS Signal

The control can accept either a 0-10 V (dc) signal or a 2-10 V (dc) signal. The EMS SGNL setting must be set to the proper setting based on the signal that is being sent to the control.

### 0 - 10 V (dc) or 0 - 20 mA

When the 0-10 V (dc) signal is selected, an input voltage of 1 V (dc) corresponds to a boiler target temperature of 50°F (10.0°C). An input voltage of 10 V (dc) corresponds to a boiler target temperature of 210°F (99.0°C). As the voltage varies between 1 V (dc) & 10 V (dc) the boiler target temperature varies linearly between 50°F (10.0°C) & 210°F (99.0°C). If a voltage below 0.5 V (dc) is received the boiler target temperature is

displayed as "——" indicating that there is no longer a call for heating.

A 0 - 20 mA signal can be converted to a 0 - 10 V (dc) signal by installing a 500 Ω resistor between the EMS (+) In & Com (-) terminals (16 & 19).

### 2 - 10 V (dc) or 4 - 20 mA

When the 2 - 10 V (dc) signal is selected, an input voltage of 2 V (dc) corresponds to a boiler target temperature of 50°F (10.0°C). An input voltage of 10 V (dc) corresponds to a boiler target temperature of 210°F (99.0°C). As the voltage varies between 2 V (dc) & 10 V (dc) the boiler target temperature varies linearly between 50°F (10.0°C) & 210°F (99.0°C). If a voltage below 1.5 V (dc) is received the boiler target temperature is displayed as "——" indicating that there is no longer a call for heating.

A 4 - 20 mA signal can be converted to a 2 - 10 V (dc) signal by installing a 500 Ω resistor between the EMS (+) In & Com (-) terminals (16 & 19).

CONVERSION TABLE 0 - 10		
0 - 20 mA*	0 - 10 V (dc)	Boiler Target
0	0	— (OFF)
2	1	50°F (10.0°C)
4	2	68°F (20.0°C)
6	3	86°F (30.0°C)
8	4	103°F (39.5°C)
10	5	121°F (49.5°C)
12	6	139°F (59.5°C)
14	7	157°F (69.5°C)
16	8	174°F (79.0°C)
18	9	192°F (89.0°C)
20	10	210°F (99.0°C)

\*Requires 500 Ω Resistor in Parallel

CONVERSION TABLE 2 - 10		
4 - 20 mA*	2 - 10 V (dc)	Boiler Target
0	0	--- (OFF)
4	2	50°F (10.0°C)
6	3	70°F (21.0°C)
8	4	90°F (32.0°C)
10	5	110°F (43.5°C)
12	6	130°F (54.5°C)
14	7	150°F (65.5°C)
16	8	170°F (76.5°C)
18	9	190°F (88.0°C)
20	10	210°F (99.0°C)

\*Requires 500 Ω Resistor in Parallel

Example	
Range	= 0 - 10 V (dc)
Input	= 7 V (dc)
Offset	= +5°F (3°C)
Boiler Target	= 157°F (69°C) → +5°F (3°C) = 162°F (72°C)

The minimum & maximum settings also apply for external input operation. For example, if a boiler minimum of 140°F (60.0°C) is set & the external signal received represents 80°F (27.0°C), the boiler target will be 140°F (60.0°C). MIN will also be displayed in the status field to indicate that a limiting condition is in effect. This also applies for the MAX limit.

## EMS Offset

For external input operation, the boiler target (determined from the external input signal) may be fine tuned. The EMS OFFST setting is used to provide the fine tuning. The setting may be adjusted  $\pm 10^{\circ}\text{F}$  ( $\pm 5.5^{\circ}\text{C}$ ). When set to 0°F (0.0°C), if the temperature determined from the external signal is 140°F (60.0°C), the boiler target will be 140°F (60.0°C). When set to +5°F (+3.0°C) & with the same external signal represents 140°F (60.0°C), the boiler target will be 145°F (63.0°C).

## Indirect Domestic Hot Water (IDHW) Operation

IDHW operation is applicable during the following application modes: outdoor temperature reset, fixed setpoint & EMS.

### DHW Call

A DHW Call is required in order for the control to provide heat to an indirect DHW tank. Once the control registers a DHW Call, it will display the "DHW" icon under Calls in the display. A DHW Call can be provided in three ways:

#### DHW Tank Aquastat

If a DHW Tank Aquastat (mechanical switch) is used to apply a DHW Call, the tank is heated to the aquastat temperature setting. A dry contact or 24 V (ac) signal is applied across the IDHW Call terminals 7 & 8.

IDHW Sensor must be set to Off.

#### DHW Sensor

A DHW Tank Sensor provides superior temperature control of the tank compared to an aquastat. The control can register a DHW Call when a DHW Sensor is wired to terminals 21 & 22. Once the DHW Sensor temperature drops 1/2 of the IDHW Differential setting below the IDHW Setpoint, the control registers a DHW Call.

**The IDHW Sensor must be set to On. There cannot be an external IDHW Call when using a DHW sensor.**


#### tekmarNet® Setpoint Control with Sensor

A DHW Call is provided through the tekmarNet® system. This can be done through the tN4 Boiler Bus terminals with a tekmarNet® setpoint device such as a Setpoint Control 161.

#### DHW Differential

Due to large differences between the heating load & the DHW load, a separate DHW differential should be used whenever a DHW Call is present. This will improve staging & boiler cycling.

When using a DHW Sensor, a DHW Call is registered when the temperature at the DHW sensor drops the IDHW DIFF setting below the IDHW Setpoint setting. The DHW Call is satisfied once the temperature at the DHW Sensor rises to the IDHW Setpoint setting.



### Boiler Target Temperature during a DHW Call

When a DHW Call is present, a boiler target is determined.

- When using a DHW Tank Aquastat, the boiler target is set to the IDHW Exchange setting.
- When using a DHW Tank Sensor, the boiler target is fixed at the IDHW Setpoint setting plus 40°F (22.0°C).
- When using a tekmarNet® Setpoint Control, the boiler target is set to the devices Exchange Supply setting.

If there are multiple devices calling for heat, the boiler target is set to the highest temperature requirement.

#### IDHW During UnOccupied

When using a DHW Tank Aquastat, a second IDHW Exchange setting is available for the UnOccupied or Sleep period.

When using a DHW Sensor, a second IDHW Setpoint setting is available for the UnOccupied or Sleep period.

DIP Switch must be set to Setback to view UnOccupied items. During the Away Scene, DHW Calls are ignored.

## IDHW Mode

The control has a IDHW MODE setting that selects whether or not indirect DHW operation is active.

### OFF

IDHW operation is inactive. All DHW Calls are ignored. If this mode is selected while DHW operation is underway, all DHW operation ceases.

### ON


IDHW operation is active. All DHW Calls are responded to.

## IDHW Location

The control has a IDHW Location setting that selects where the indirect DHW tank is located in the system. This setting determines the operating sensor & affects pump operation.

### NEAR


The indirect DHW tank is piped in parallel within the near boiler piping of boiler 4. When a valid DHW Call is present, the IDHW Pump relay turns on & boiler pump 4 turns off. The control uses the boiler 4 outlet sensor as the operating sensor in order to measure the boiler supply temperature supplied to the indirect DHW tank. There are two boiler target temperatures. One for the space heating system (Boil TARG) & one for the indirect DHW system (IDHW TARG).



- All boilers are used for space heating requirements.
- Boiler 4 is used for indirect DHW when there is a DHW Call.
- The dedicated indirect DHW boiler is always boiler 4, even if there are less than four boilers.
- If boiler 4 is disabled & NEAR is selected for the IDHW Location, the dedicated indirect DHW boiler 4 will not operate.

### Boil

The indirect DHW tank is piped in the boiler system loop. When a valid DHW Call is present, the IDHW Pump relay turns on.




## Primary Pump During IDHW

The control has a Primary Pump during IDHW setting that selects whether or not the primary pump is required during indirect DHW operation.


### OFF

The primary pump does not turn on during indirect DHW operation. This would be typical of an indirect DHW tank piped in parallel in the boiler system loop. It is assumed that the DHW pump will provide adequate flow through the indirect DHW heat exchanger & the boiler system loop.



### ON

The primary pump turns on during indirect DHW operation. This would be typical of an indirect DHW tank piped in primary/secondary in the boiler system loop.



## IDHW Priority

The control has a IDHW Priority setting that selects whether or not priority of indirect DHW is required over the space heating system. Indirect DHW priority stops or limits the delivery of heat to the space heating system while the indirect DHW tank calls for heat. This allows for quick recovery of the indirect DHW tank.

### OFF

IDHW priority is not provided. The primary pump can operate when a Heat Call is present. Heating zones are unaffected by indirect DHW operation.

### ON

IDHW priority is provided & is dependent on the type of space heating zones & whether or not the primary is required to operate during IDHW operation.

For non-tN4 space heating, the primary pump shuts off to provide priority. If the primary pump is required to operate for IDHW, priority requires the use of an external relay to force the heating zones off.

For tN4 space heating, the primary pump can operate when a Heat Call is present. If the boilers are unable to maintain the boiler target temperature, the tN4 zones are sequentially shut off using tN4 communication to provide priority.


### Priority Override

Priority override applies when IDHW Priority is set to ON & prevents the building from cooling off too much or the possibility of a potential freeze up during IDHW priority.

When set to auto, the priority time is calculated based on outdoor temperature. At or below the design outdoor temperature, 15 minutes is allowed for IDHW priority. At or above the design indoor temperature, 2 hours is allowed for IDHW priority. The time allowed for IDHW priority varies linearly between the above two points. There is a manual setting also available in the Setup menu.

The priority timer does not start timing until priority is selected & both a DHW Call & a Heat Call exist together. Once the allowed time for priority has elapsed, the control overrides the DHW priority & resumes space heating.

### Automatic Priority Override



### Conditional IDHW Priority

If the boiler supply temperature is maintained at or above the required temperature during IDHW operation, this indicates that the boilers have enough capacity for IDHW & possibly heating as well. As long as the boiler supply temperature is maintained near the target, IDHW & heating occurs simultaneously.

### IDHW Post Purge

After the DHW Call is removed, the control performs a purge. The control shuts off the boilers & continues to operate the IDHW Pump & the primary pump if applicable. This purges the residual heat from the boilers into the DHW tank. The control continues this purge until one of the following occurs:

1. A Heat Call is detected.
2. The boiler supply drops 20°F (11.0°C) below the DHW target temperature.
3. The DHW tank temperature rises above the DHW setpoint plus 1/2 DHW Differential.
4. Two minutes elapse.

### IDHW Mixing Purge

After IDHW operation, the boiler is extremely hot. At the same time, the heating zones may have cooled off considerably after being off for a period of time. When restarting the heating system after a DHW Call with priority, the control shuts off the boiler & continues to operate the IDHW pump while the primary pump is turned on. This allows some of the DHW return water to mix with the cool return water from the zones & temper the boiler return water.

### IDHW with Low Temperature Boilers

If DHW heating is to be incorporated into a low temperature system such as a radiant floor heating system, a mixing device is often installed to isolate the high DHW supply temperature from the lower system temperature. If a mixing device is not installed, high temperature water could be supplied to the low temperature system while trying to satisfy the DHW Call. This may result in damage to the low temperature heating system.

The control is capable of providing IDHW heating in such a system while minimizing the chance that the temperature in the heating system exceeds the design supply water temperature. In order to do this, the following must be true:

- All available boilers are set to condensing.
- IDHW Location set to Boil.
- IDHW Priority set to ON.
- tN4 present (IF Primary Pump during IDHW operation is set to ON)


On a DHW Call, the control provides IDHW priority by sending a message on the boiler temperature bus to the tN4 thermostats to shut off the heating zones for a period of time. The length of time is based on the outdoor air temperature, or selectable time, as described in the IDHW Priority Override section. However, if the DHW Call is not satisfied within the allotted time, the boiler shuts off & the heat of the boiler is purged into the DHW tank. A IDHW mixing purge occurs in order to reduce the boiler water temperature & once the boiler supply temperature is sufficiently reduced, the IDHW Pump contact shuts off. The heating system zones are allowed to turn on for a period of time to prevent the building from cooling off. After a period of heating, & if the DHW Call is still present, the control shuts off the heating system & provides heat to the DHW tank once again.

### IDHW Boil COUNT IDHW

Selects the number of boilers to be used for IDHW operation. This applies when only there is a requirement for IDHW. All available boilers are allowed to operate if there is both a requirement for space heating & IDHW.

## Dedicated Domestic Hot Water (DDHW) Operation

The control can operate to provide heat for a Dedicated Domestic Hot Water (DDHW) system. DDHW heating is available by setting the Application Mode in the Setup Menu to DDHW.



### DHW Call


A DHW Call is required in order for the control to provide heat to a dedicated DHW tank. Once the control registers a DHW Call, it will display the "DHW" icon under Calls in the display. This can be done by:

#### DHW Sensor

The control can register a DHW Call when a DHW Sensor is wired to terminals 21 & 22. Once the DHW Sensor temperature drops 1/2 of the DDHW Differential setting below the DDHW Setpoint, the control registers a DHW Call.

### DDHW Differential

A DHW Call is registered when the temperature at the DHW sensor drops the DDHW DIFF setting below the DDHW Setpoint setting. The DHW Call is satisfied once the temperature at the DHW Sensor rises to the DDHW Setpoint setting.



### Boiler Target Temperature During a DHW Call

When a DHW Call is present, a boiler target is determined. The boiler target is set to the DDHW Setpoint setting.

### DDHW During UnOccupied

A second DDHW Setpoint setting is available for the UnOccupied periods.

DIP Switch must be set to Setback to view UnOccupied items.

During the Away Scene, DHW Calls are ignored.

## Building Automation System (BAS)

The control can communicate with a Building Automation System (BAS) to provide remote monitoring & adjustment capability.

### BAS Mode

There are two modes of BAS communication that define the interaction between the BAS & the control. The level of interaction is determined by the Application Mode setting.

Refer to the BAS Integration Manual 294\_B for more information including a listing of the read / write parameters.

### Monitor

Monitor mode is available when the Application Mode is set to either Outdoor Temperature Reset, Setpoint, Dedicated Domestic Hot Water (DDHW) or Energy Management System (EMS).

With Monitor mode, the control allows for viewing & adjustment capability of select items within the various menus.

### Temperature

Temperature mode is available when the Application Mode is set to Building Automation System (BAS).

With Temperature mode, the control operates to maintain the setpoint temperature provided over the BAS network. In order for the control to be able to operate to maintain the BAS Setpoint, the BAS must also write a Setpoint Call command over the BAS network.

If primary pump operation is desired, the BAS must write a BAS Primary Pump command over the BAS network.

If indirect DHW pump operation is desired, the BAS must write a BAS IDHW Pump command over the BAS network.

### BAS Type

The control supports Modbus® & BACnet® IP communications. Selection is made through BAS TYPE item in the BAS menu. If the control is not being connected to a BAS network, select NONE.

### Network Configuration Settings in BAS Menu

Refer to the BAS menu section of this brochure for a listing of all the BAS network configuration settings.

## Pump Operation

### Primary Pump Operation

The control includes two primary pump outputs with capability for sequencing. There is pump enable setting for each primary pump in the Setup menu. When both primary pumps are set to Auto, primary pump sequencing is activated. Primary pump 1 & 2 are operated in stand-by mode when pump sequencing is activated.

The running times of the primary pumps are logged in the Monitor Menu. To reset these values back to zero, select "Clear" while viewing this item.

Operation of the primary pump(s) is determined from the Application Mode & the presence of an appropriate call.

#### Application Mode: Outdoor Temperature Reset (RSET)

- Heat Call from Contact Closure.
- Heat Call from tN4 Device & that zone's thermostat has H1 Pump set to On. tN4 thermostats also include a thermal actuator setting which can delay the primary pump for 3 minutes to allow thermal actuators to open.
- Setpoint Call from Contact Closure & Primary Pump during Setpoint operation set to ON.
- DHW Call & the Primary Pump during IDHW operation set to ON.

#### Application Mode: Setpoint (SETP)

- Setpoint Call from Contact Closure & Primary Pump during Setpoint operation set to ON.
- DHW Call & the Primary Pump during IDHW operation set to ON.

#### Application Mode: Energy Management System (EMS)

- Heat Call from Analog Input Signal.
- DHW Call & the Primary Pump during IDHW operation set to ON.
- Setpoint Call from Contact Closure & Primary Pump during Setpoint operation set to ON.

#### Application Mode: Building Automation System (BAS)

- BAS Setpoint Pump Call.

### Boiler Pump / Valve Operation

The control includes relays to operate the boiler pumps / valves.

The control includes a boiler pre-purge which operates the respective pump / valve for a period of time before the boiler is ignited in order to purge potential residual heat out of the boiler. For isolation valves, this time also allows for the valve to spring open prior to boiler ignition. For pumps, the time is determined from the boiler mass setting. As the boiler mass setting is increased, the time is also increased. For DHW and Setpoint Calls, to help reduce boiler pick-up times, the time is fixed at 4 seconds. For isolation valves, the time is always fixed at 30 seconds.

The control includes a boiler post-purge feature that operates the respective pump / valve for a period of time after the boiler is turned off. This feature will purge heat out of the boiler & aid in reducing "kettling". The amount of time for the boiler post-purge is adjustable between 10 seconds & 20:00 minutes.

The period of time is adjustable through the boiler post-purge setting in the Source (#) Menu.

### Indirect DHW (IDHW) Pump Operation

The control includes a relay to operate an indirect DHW pump.

Operation of the IDHW pump is determined by the Application Mode & the presence of an appropriate call.

#### Application Mode: Outdoor Temperature Reset, Setpoint, Energy Management System

- DHW Call from Contact Closure.
- DHW Call from DHW Sensor.
- DHW Call from tekmarNet® Setpoint Control with Sensor.

#### Application Mode: Building Automation System

- BAS DHW Pump Call.

### DHW Recirculation Pump Operation

The control has the capability to operate a DHW Recirculation Pump when the control is configured for either Indirect Domestic Hot Water (IDHW) or Dedicated Domestic Hot Water (DDHW). IDHW is available when the application mode is set to either outdoor temperature reset, setpoint or EMS. DDHW is available when the applicable mode is set to DDHW. The Aux Relay setting in the Setup Menu must be set to DHWR to enable the DHW recirculation pump.

The DHW recirculation pump operates continuously during the Occupied period. If setback is enabled, the pump operates when heat is required during the Unoccupied period.

## Combustion Air (C.A.) Damper & DHW Recirculation Pump Settings

### Auxiliary Relay

The control includes an auxiliary relay that can be used either for a combustion / venting device or a DHW recirculation pump. Selection is made through the AUX RELAY item in the Setup menu. Off is also available if there is no Auxiliary device.

### DHW Recirculation Pump

When the Aux Relay is set to DHWR, terminals 43 & 44 operate a domestic hot water (DHW) recirculation pump. Refer to the Pump Operation section of this brochure for a description of the DHW recirculation pump operation.

### Combustion Air Damper

When the Aux Relay is set to DMPR, terminals 43 & 44 operate a combustion air damper / fan motor or power vent motor. The relay closes once an appropriate call (e.g. Heat) is received & the control has determined that one or more boilers need to be turned on.

### Combustion Air (C.A.) Proof Call

The C.A. Proof Call is used to prove a combustion air or venting device. Boiler operation cannot occur until the proof call is present. If the proof call is lost during operation, the boiler plant is sequenced off.

Once the DMPR contact is turned on, a C.A. proof call must be present before the C.A. proof delay has expired.

The C.A. proof call feature is enabled by setting the DIP switch to the External C.A. Proof position.

A C.A. proof call can be provided by:

#### Contact Closure

A dry contact or 24 V (ac) signal is applied across the C.A. Proof Call terminals 3 & 4.

### Combustion Air Proof Delay

The control includes a time delay that is associated with the C.A. proof call feature in order to determine if the proof device is functional. Once the DMPR relay closes, the control allows for this time delay to receive the C.A. proof call. If the C.A. proof call is not received within the delay time, the control will display an error message.

### Combustion Air (C.A.) Proof Call Test

The control includes a C.A. proof call test in order to determine if the proving device has failed. If the DMPR relay is opened, the C.A. proof call should not be present after 4 minutes. If the C.A. proof call remains, the control will display an error message.

### Combustion Air Delay

If the C.A. proof call feature is set to OFF (DIP switch), sequencing only occurs once a user adjustable time delay elapses.

### Combustion Air Post Purge

There is a fixed 15 second post purge of the C.A. relay after the last boiler has turned off, or the appropriate call (e.g. Heat) is removed. If there is a call still present once the last boiler has turned off, the control can look at the error & determine if sequencing is to occur in a "short" period of time. If the control does anticipate staging, the DMPR relay will remain on. Otherwise, the DMPR relay will be turned off once the 15 second post purge elapses.

## Setting the Schedule

To provide greater energy savings, you can operate the control on a programmable schedule. The schedule is stored in memory & is not affected by loss of power to the control. If a tN4 network is detected the control can become either a schedule member or schedule master.

### Control (CTRL) Schedule (tN4 present)

The schedule only applies to the control. The control follows its own schedule & the events are not communicated to tN4 thermostats.

### Master Schedule (tN4 present)

If the control is connected to tN4 thermostats, then the control can operate on a master schedule. You can set up a maximum of four master schedules on the tN4 Network. A master schedule is available to all devices on the tN4 network. Master schedules simplify installation since one master schedule may be used by multiple devices.

#### To create a master schedule:

- Assign the control to be a schedule master by setting the Heat Schedule item in the Schedule menu to Master (MST) 1 to 4. After a master schedule is selected, a clock symbol will appear in the View menu display.

The 294 Setback/Off DIP Switch must be set to Setback to access the Schedule Menu.

#### To follow a master schedule:

- Assign the control to follow a master schedule by setting the Heat Schedule in the Schedule menu to Member (MBR) 1 to 4.

#### Schedule Types

The schedule type determines when the schedule repeats itself. This control includes four different schedule types:

- 24 Hour: Repeats every 24 hours.
- 5-2: Repeats on a weekly basis. However, it breaks the week into weekend followed by the weekdays. This reduces the amount of schedule event settings.
- 5-11: Repeats on a weekly basis. However, it breaks the weekend into Saturday & Sunday followed by the weekdays. This reduces the amount of schedule event settings.
- 7 Day: Repeats on a weekly basis & allows for separate event times for each day.

Day	Schedule Type			
	24 Hour	5-2	5-11	7 day
Saturday	•	•	•	•
Sunday		•	•	•
Monday	•		•	•
Tuesday		•	•	•
Wednesday	•		•	•
Thursday		•		•
Friday	•			•

## Events / Day

The events / day can be either 4 or 2. An event is a time at which the control changes the target temperature. The event time can be set to the nearest 10 minutes. If you wish to have the thermostat skip the event, enter “--:--” as the time. The “--:--” time is found between 11:50 PM & 12:00 AM. See the table, Events / Day, for more details regarding types of events.

Events / Day	Event	24Hr	Sat	Sun	Mon	Tue	We	Thu	Fri
4 events per day	Occupied 1	6:00 AM							
	UnOccupied 1	8:00 AM							
	Occupied 2	6:00 PM							
	UnOccupied 2	10:00 PM							
or									
2 events per day	Occupied	6:00 AM							
	Unoccupied	10:00 PM							

## Time Clock

The control has a built-in time clock to allow the control to operate on a schedule. A battery-less backup allows the control to keep time for up to 4 hours without power. The time clock supports automatic adjustment for Daylight Saving Time (DST) once the day, month, & year are entered. Use the Time menu to set the correct time, day, month, & year.

**The Setback / Off DIP Switch must be set to Setback before the Time menu can be accessed.**

## tekmarNet®4 Communication

The 294 can communicate with tekmarNet® Thermostats, Wiring Centers & Setpoint Controls to maximize system efficiency & comfort. The 4 tN4 bus connections on the 294 use the boil water temperature. No mix temperatures are available to the 294. tekmarNet® Thermostats enable the Indoor Temperature Feedback feature on the 294. This allows water temperatures to be adjusted to compensate for both indoor & outdoor temperatures. Each bus can include up to 24 devices, providing a total of 96 on the tekmarNet® network.

### Cycle Length Setting in Adjust Menu (tN4)

The control includes an adjustment for the cycle length. The cycle length adjustment allows for synchronization of tN4 zones. An Auto setting allows for the cycle length to be automatically calculated to balance equipment cycling & comfort.

In the tekmarNet®4 system, all of the tekmarNet®4 Thermostats determine the best cycle length for their zone. The thermostats look at trying to maintain the longest possible cycle length while keeping temperature swings to a minimum. The Thermostats do this every cycle & send their ideal cycle length time to the 294. In order to operate the system as efficiently as possible, all of the zones must operate based on the same cycle. In order to do this, the 294 listens to all of the cycle length requests from all of the tekmarNet®4 Thermostats. The 294 then determines the average cycle length & sends this information to all of the tekmarNet®4 Thermostats, allowing them to operate on the same cycle.

### Indoor Temperature Feedback (tN4)

Indoor feedback applies when the 294 is connected to a tN4 Thermostat network operating on a boiler bus. Indoor temperature feedback fine tunes the water temperature of the system based on the requirements of the thermostats. Each thermostat tells the tN4 System Control the water temperature that it requires to heat its zone.

### Device Count (tN4)

The control includes a device count of all the tN4 devices connected to each of the four buses. This item is always found in the Toolbox Menu called BUS(#) DEV. Use this to confirm that the correct number of devices are connected to the boiler bus.

### Scenes

The 294 will respond to the following tekmarNet® scenes:

Scene	Response
1	Occupied or Schedule
2	Away, operates Room at 62°F (16.5°C) & there is no DHW heating
3	Permanent Unoccupied
4	Occupied or Schedule
5	Occupied or Schedule
6	Temporary 3 hour Occupied
7	Temporary 3 hour Occupied
8	Temporary 3 hour Occupied

## Testing the Control Wiring

### Testing the Power

Terminals 83 & 84

If the control display does not turn on, check the Power In L & N terminals (83 & 84) using an electrical multimeter. The voltage should measure between 103.5 to 126.5 V (ac).

### User Test (HAND)

*Manual Override Button*

The User Test (HAND mode) is one of the Manual Override modes of the control. Refer to the Hand mode for a description of the steps that are included to operate the outputs. The steps are dependent how the boiler(s) (Source # Menu) & the system (Setup menu) are configured.



Manual  
Override

### Testing the Auxiliary Relay

Activate the HAND mode within the Manual Override. Select the Auxiliary item & set it to ON. Using an electrical meter, measure for continuity between the Auxiliary terminals (43 & 44).

### Testing the Alert Relay

Activate the HAND mode within the Manual Override. Select the Alert item & set it to ON. Using an electrical meter, measure for continuity between the Alert terminals (45 & 46).

### Testing the Primary Pumps

Activate the HAND mode within the Manual Override.

For primary pump 1, select the Primary Pump item & set it to PMP1. Using an electrical meter, measure for continuity between the Primary Pump 1 terminals (47 & 48).

For primary pump 2, select the Primary Pump item & set it to PMP2. Using an electrical meter, measure for continuity between the Primary Pump 2 terminals (49 & 50).

### Testing the Indirect DHW Pump

Activate the HAND mode within the Manual Override. Select the DHW Pump item & set it to ON. Using an electrical meter, measure for continuity between the IDHW Pump terminals (85 & 86).

### Testing the Boiler Pump(s) / Isolation Valve(s)

Activate the HAND mode within the Manual Override.

For a boiler pump, select the Boil 1 PUMP item & set it to ON. Using an electrical meter, measure for continuity between the Boiler 1 Pump / Valve terminals (75 & 76).

For an isolation valve, select the Boil 1 VALVE item & set it to ON. Using an electrical meter, measure for an open circuit between the Boiler 1 Pump / Valve terminals (75 & 76).

Repeat the steps above for Boiler Pumps 2, 3 & 4.

### Testing the Boiler Stage(s)

This test applies for single stage & two stage boilers only. Activate the HAND mode within the Manual Override. For a single stage boiler, select the Boil STG item & set it to 1. Using an electrical meter, measure for continuity between the Boiler 1 Stage 1 terminals (53 & 54).

For a two stage boiler, select the Boil STG item & set it to 1. Using an electrical meter, measure for continuity between the Boiler 1 Stage 1 terminals (53 & 54). Set the Boil STG item to 2. Using an electrical meter, measure for continuity between the Boiler 1 Stage 2 terminal (55 & 56).

Repeat the steps above, as applicable, for Boilers 2, 3 & 4.

### Testing the Modulating Boiler Output

This test applies for modulating boilers only.

Activate the HAND mode within the Manual Override.

Select the Boil 1 MOD item & set a desired firing rate. Using an electrical meter, measure for either a V (dc) or mA signal between the Boiler + Mod - terminals (51 & 52). The reading should be between 0 V (dc) & 10 V (dc) or 4 mA & 20 mA.

Repeat the steps above for Boilers 2, 3 & 4.

### Testing the Temperature Boiler Output

This test applies for EMS boilers only. Activate the HAND mode within the Manual Override.

Select the Boil 1 TEMP item & set a desired temperature between the EMS TEMP MIN and EMS TEMP MAX values. Using an electrical meter, measure for either a V (dc) or mA signal between the Boiler + Mod - terminals (51 & 52). The reading should be between 0 V (dc) & 10 V (dc) or 4 mA & 20 mA.

Repeat the steps above, as applicable, for Boilers 2, 3 & 4.

## Testing the Heat Call

*Terminals 5 & 6*

Set the Application Mode to RSET. Remove all wires from the Heat Call terminals (5 & 6). The control display should show no Heat Call. Reconnect wires. Then apply either a

short circuit or 24 V (ac) over the Heat Call terminals. The control should now show a Heat Call.

## Testing the DHW Call

*Terminals 7 & 8*

Set the Application Mode to either RSET, SETP or EMS. Remove all wires from the DHW Call terminals (7 & 8). The control display should show no DHW Call. Reconnect wires.

Then apply either a short circuit or 24 V (ac) over the DHW Call terminals. The control should now show a DHW Call.

## Testing the Setpoint Call

*Terminals 9 & 10*

Set the Application Mode to either RSET, SETP or EMS. Remove all wires from the Setpoint Call terminals (9 & 10). The control display should show no Setpoint Call. Reconnect

wires. Then apply either a short circuit or 24 V (ac) over the Setpoint Call terminals. The control should now show a Setpoint Call.



## Control Settings

### View Menu (1 of 2)

The View Menu includes general information about boiler & pump operation, calls & temperatures. The View Menu is the default display of the 294.

Item Field	Range	Description
	<i>Access: User</i>	<b>TIME</b> Current date & time. This item is only available when the Setback / Off switch is set to Setback & Clock (Time menu) is set to ON.
	---, -76 to 149°F (-60.0 to 65.0°C)	<b>OUTDOOR</b> Current outdoor temperature as measured by the outdoor sensor. “---” is displayed if there is a sensor fault. This item is only available when Application Mode is set to RSET or an outdoor sensor is connected.
	---, -22 to 266°F (-30 to 130°C)	<b>BOILER SUPPLY</b> Current boiler supply water temperature as measured by the boiler supply sensor. “---” is displayed if there is a sensor fault.
	---, -22 to 266°F (-30 to 130°C)	<b>BOILER TARGET</b> The boiler target is the temperature the control is trying to maintain at the boiler supply sensor. “---” is displayed when no heat is required.
	---, -22 to 266°F (-30.0 to 130.0°C)	<b>INDIRECT DHW EXCHANGE TEMPERATURE</b> The indirect DHW exchange target is the temperature the control is trying to maintain at the boiler 4 outlet sensor. “---” is displayed when no heat is required. This item is only available if Application Mode is set to RSET, SETP or EMS, IDHW Mode is set to ON & IDHW Location is set to NEAR.
	---, -22 to 266°F (-30.0 to 130.0°C)	<b>INDIRECT DHW</b> Current indirect DHW tank temperature as measured by the DHW sensor. “---” is displayed if there is a sensor fault. This item is only available if Application Mode is set to RSET, SETP or EMS, IDHW Mode is set to ON & IDHW Sensor is set to ON.

## View Menu (2 of 2)

Item Field	Range	Description
	---, -22 to 266°F (-30.0 to 130.0°C)  Access: User	<b>DEDICATED DHW</b> Current dedicated DHW tank temperature as measured by the DHW sensor. “---” is displayed if there is a sensor fault. This item is only available if Application Mode is set to DDHW.
	---, -22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER RETURN</b> Current boiler return water temperature as measured by the boiler return sensor. “---” is displayed if there is a sensor fault. This item is only available if a boiler return sensor is connected.
	-22 to 266°F (-12.0 to 148.0°C)  Access: ADV	<b>BOILER SUPPLY DIFFERENTIAL</b> Current temperature difference between the boiler supply & boiler return sensors. This item is only available if boiler supply & boiler return sensors are connected.
	---, -40 to 500°F (-40.0 to 260.0°C)  Access: ADV	<b>VENT TEMPERATURE</b> Current vent temperature of the boiler plant. “---” is displayed if there is a sensor fault. This item is only available if a vent sensor is connected.
	GPM or m <sup>3</sup> /h  Access: ADV	<b>FLOW RATE</b> Current flow rate as measured by the flow sensor. This item is only available if Flow Sensor is set to ON.
	MBtu/h or kW  Access: ADV	<b>BOILER LOAD</b> Current boiler plant output. This item is only available if Flow Sensor is set to ON & if boiler supply & boiler return sensors are connected.
	psi or kPa  Access: ADV	<b>PRESSURE</b> Current system pressure as measured by the pressure sensor. This item is only available if Pressure Sensor is set to ON.
	---, -22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER INLET TEMPERATURE</b> Current boiler inlet water temperature. This item is only available if a boiler inlet sensor is connected.
	---, -22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER (#) OUTLET SENSOR</b> Current boiler outlet temperature of boiler 1. This item is available for all enabled boilers provided their respective boiler outlet sensor is connected.
	-22 to 266°F (-12.0 to 148.0°C)  Access: ADV	<b>BOILER (#) TEMPERATURE DIFFERENTIAL</b> Current temperature difference between the boiler 1 outlet & boiler inlet sensors. This item is available for all enabled boilers provided their respective boiler outlet sensor & the common boiler inlet sensor are connected.

## Setup Menu (1 of 6)

Setup Menu items are used for system specific configuration.

Item Field	Range	Description
	RSET, SETP, DDHW, EMS, BAS Default = RSET  <i>Access: INST</i>	<b>APPLICATION MODE</b> RSET = Outdoor Temperature Reset SETP = Setpoint Heating DDHW = Dedicated DHW Heating EMS = Energy Management System BAS = Building Automation System
	35 to 100°F (2.0 to 38.0°C) Default = 70°F (21.0°C)  <i>Access: INST</i>	<b>ROOM OCCUPIED</b> The desired room air temperature during the occupied periods. This item is only available if the Application Mode is set to RSET.
	35 to 100°F (2.0 to 38.0°C) Default = 65°F (18.5°C)  <i>Access: INST</i>	<b>ROOM UNOCCUPIED</b> The desired room air temperature during the unoccupied periods. This item is only available if the Application Mode is set to RSET, Setback / Off switch is set to Setback & a schedule is selected.
	OFF, 0:20 to 8:00 hrs Default: OFF  <i>Access: ADV</i>	<b>BOOST</b> The maximum amount of morning boost when change from the unoccupied to the occupied period. This item is only available if the Application Mode is set to RSET & the Setback / Off switch is set to Setback.
	-60 to 45°F (-51.0 to 7.0°C) Default: 10°F (-12.0°C)  <i>Access: INST</i>	<b>OUTDOOR DESIGN</b> The design outdoor air temperature used in the heat loss calculations for the space heating system. Typically set to the outdoor temperature of the coldest day of the year. This item is only available if the Application Mode is set to RSET.
	HRF1, HRF2, COIL, CONV, RAD, BASE Default: CONV  <i>Access: INST</i>	<b>TERMINAL UNIT</b> The type of terminal units that are being used for the space heating system. Selection includes: high mass radiant floor (HRF1), low mass radiant floor (HRF2), fancoil (COIL), fin-tube baseboard (CONV), radiator (RAD) & cast iron baseboard (BASE). This item is only available if the Application Mode is set to RSET.
	35 to 100°F (2.0 to 38.0°C) Default: 70°F (21.0°C)  <i>Access: ADV</i>	<b>BOILER INDOOR</b> The design indoor air temperature used in the heat loss calculations for the space heating system. This item is only available if the Application Mode is set to RSET.
	70 to 230°F (21.0 to 110.0°C) Default: 180°F (82.0°C)  <i>Access: ADV</i>	<b>BOILER DESIGN</b> The supply water temperature required for the space heating system on the typical coldest day of the year. This item is only available if the Application Mode is set to RSET.
	0-10 or 2-10 Default: 0-10  <i>Access: ADV</i>	<b>EMS SIGNAL</b> Selects the analog input signal range used with the Energy Management System (EMS). This item is only available if the Application Mode is set to EMS.
	-10 to 10°F (-5.5 to -5.5°C) Default: 0°F (0.0°C)  <i>Access: ADV</i>	<b>EMS OFFSET</b> Selects the offset from the boiler target temperature interpreted from the EMS analog input signal. This item is only available if the Application Mode is set to EMS.

## Setup Menu (2 of 6)

Item Field	Range	Description
	OFF, 60 to 180°F (OFF, 15.5 to 82.0°C) Default: 140°F (60.0°C)  Access: ADV	<b>BOILER MINIMUM</b> The minimum allowed boiler target temperature used for the non-condensing boiler group. Check the boiler manufacturer's manual for recommended minimum boiler supply temperatures.  This item is only available if there is at least one boiler set to auto (Boiler Enable = AUTO) & non-condensing (Boiler Condense = NO).
	90 to 225°F, OFF (32.0 to 107.0°C, OFF) Default: 200°F (93.0°C)  Access: ADV	<b>BOILER MAXIMUM</b> The maximum allowed boiler target temperature.
	PUMP or VALV Default: PUMP  Access: ADV	<b>PLANT FLOW</b> Selects whether each boiler is to use a pump or valve.
	AUTO, 2 to 42°F AUTO, 1.0 to 23.5°C Default: AUTO  Access: ADV	<b>BOILER DIFFERENTIAL</b> The temperature differential that the control is to use to cycle the boiler On & Off (half above & half below the boiler target temperature).  This item is only available if Application Mode is set to either RSET, SETP, EMS or BAS.
	OFF, DMPR, DHWR Default: OFF  Access: ADV	<b>AUXILIARY RELAY</b> Selects the operation of the auxiliary relay to be either Combustion Air Damper (DMPR) or DHW Recirculation Pump (DHWR). If the External C.A. Proof / Off switch is set to External C.A. Proof, this setting is fixed at DMPR.
	OFF or AUTO Default: AUTO  Access: ADV	<b>PRIMARY PUMP 1</b> Selects whether primary pump 1 is operational or not. This item is only available if Application Mode is set to either RSET, SETP, EMS or BAS.
	OFF or AUTO Default: OFF  Access: ADV	<b>PRIMARY PUMP 2</b> Selects whether primary pump 2 is operational or not. This item is only available if Application Mode is set to either RSET, SETP, EMS or BAS.
	12 to 180 hr, OFF Default: 96 hr  Access: ADV	<b>ROTATE PRIMARY PUMPS</b> Sets the frequency of rotation of the primary pumps. This item is only available if Application Mode is set to either RSET, SETP, EMS or BAS & Primary Pump 1 & Primary Pump 2 is set to AUTO.
	OFF, 0:10 to 20:00 min Default: 0:20 min  Access: ADV	<b>PRIMARY PUMP PURGE</b> Time the primary pump remains on once the appropriate calls (heat, setpoint or DHW) are removed to purge heat from the boiler plant. This item is only available if Application Mode is set to either RSET, SETP, EMS or BAS & Primary Pump 1 or Primary Pump 2 is set to AUTO.
	0:10 to 3:00 min Default: 0:30 min  Access: ADV	<b>FLOW PROOF DELAY</b> The time allowed for the control to receive a flow proof call once the primary pump turns on. This item is only available if the External Flow Proof / Off switch is set to External Flow Proof.
	0:10 to 3:00 min Default: 1:00 min  Access: ADV	<b>CA PROOF DELAY</b> The time allowed for the control to receive a C.A. proof call once the C.A. damper (Aux) relay turns on. This item is only available if the External C.A. Proof / Off switch is set to External C.A. Proof.

## Setup Menu (3 of 6)

Item Field	Range	Description
	OFF, 0:10 to 3:00 min Default: 1:00 min	<b>CA DELAY</b> The time delay for the first boiler to operate once the C.A. damper (Aux) relay turns on.
	Access: ADV	This item is only available if the External C.A. Proof / Off switch is set to Off & Auxiliary Relay is set to DMPR.
	150 to 350°F, OFF (65.5 to 177.0°C) Default: OFF	<b>VENT MAXIMUM</b> The maximum vent temperature that is used for vent temperature limiting. The boiler plant will be shut down if the vent temperature rises to the vent maximum temperature. Set to OFF if only vent temperature monitoring is desired.
	Access: ADV	
	AUTO, 0:30 to 40:00 min Default: AUTO	<b>STAGE DELAY</b> The minimum time delay between the operation of boiler stages, either within a boiler or between boilers.
	Access: ADV	This item is only available if there are at least two boilers set to auto (Boiler Enable = AUTO).
	SEQ or PAR Default: PAR	<b>MODULATION MODE CONDENSING</b> Selects either sequential or parallel modulation for multiple modulating condensing boilers.
	Access: ADV	This item is only available if there are at least two boilers set to auto (ENABLE=AUTO), condensing (Boiler Condense = YES) & Modulating (Boiler Type = MOD or EMS).
	SEQ, PAR Default: SEQ	<b>MODULATION MODE NON-CONDENSING</b> Selects either sequential or parallel modulation for multiple modulating non-condensing boilers.
	Access: ADV	This item is only available if there are at least two boilers set to auto (Boiler Enable = AUTO), non-condensing (Boiler Condense = NO) & Modulating (Boiler Type = MOD or EMS).
	LHLH or LLHH Default: LHLH	<b>STAGING MODE CONDENSING</b> Selects either low-high-low-high (LHLH) or low-low-high-high (LLHH) staging for multiple two-stage condensing boilers.
	Access: ADV	This item is only available if there are at least two boilers set to auto (Boiler Enable = AUTO), condensing (Boiler Condense = YES) & two stage (Boiler Type = 2STG).
	LHLH or LLHH Default: LHLH	<b>STAGING MODE NON-CONDENSING</b> Selects either low-high-low-high (LHLH) or low-low-high-high (LLHH) staging for multiple two-stage non-condensing boilers.
	Access: ADV	This item is only available if there are at least two boilers set to auto (Boiler Enable = AUTO), non-condensing (Boiler Condense=NO) & two stage (Boiler Type = 2STG).
	OFF or ON Default: ON	<b>ROTATION CONDENSING BOILER GROUP</b> Selects the equal run time rotation feature within the condensing boiler group.
	Access: ADV	This item is only available if there are at least two boilers set to auto (Boiler Enable = AUTO) & condensing (Boiler Condense = YES).
	OFF or ON Default: ON	<b>ROTATION NON-CONDENSING BOILER GROUP</b> Selects the equal run time rotation feature within the non-condensing boiler group.
	Access: ADV	This item is only available if there are at least two boilers set to auto (Boiler Enable = AUTO) & non-condensing (Boiler Condense = NO).
	OFF or ON Default: OFF	<b>FIXED LEAD</b> Selects whether or not the first boiler is to be excluded from the rotation sequence. If set to ON, boiler 1 is always the first to fire.
	Access: ADV	This item is only available if boiler 1 is enabled (Boiler Enable = AUTO) & all available boilers are either condensing or non-condensing.

## Setup Menu (4 of 6)

Item Field	Range	Description
	OFF or ON Default: OFF  Access: ADV	<b>FIXED LAST</b> Selects whether or not the last boiler is to be excluded from the rotation sequence. If set to ON, boiler 4 is always the last to fire.  This item is only available if boiler 4 is enabled (Boiler Enable = AUTO) & all available boilers are either condensing or non-condensing.
	AUTO, 5 to 30 min Default: AUTO  Access: ADV	<b>HEATING CYCLES</b> The cycle length to which all tN4 devices will synchronize. This item is only available when Application Mode is set to RSET & a tN4 device is present.
	OFF or ON Default: OFF  Access: ADV	<b>INDIRECT DHW MODE</b> Selects whether indirect DHW heating is active or not. This item is only available when Application Mode is set to RSET, SETP or EMS.
	NEAR or Boil Default: Boil  Access: ADV	<b>INDIRECT DHW LOCATION</b> Selects the location of the indirect DHW tank. NEAR = Near boiler piping supplied by boiler 4. Boil = Boiler system piping supplied by boiler plant. This item is only available when Application Mode is set to RSET, SETP or EMS & Indirect DHW Mode is set to ON. NEAR is only available when Plant Flow is set to PUMP.
	OFF or ON Default: OFF  Access: ADV	<b>INDIRECT DHW SENSOR</b> Selects if a DHW Sensor is to be used for indirect DHW heating. This item is only available when Application Mode is set to RSET, SETP or EMS & Indirect DHW Mode is set to ON.
	70 to 190°F (21.0 to 88.0°C) Default: 140°F (60.0°C)  Access: ADV	<b>INDIRECT DHW SETPOINT OCCUPIED</b> The temperature of the indirect DHW tank during the occupied periods. This item is only available when Application Mode is set to RSET, SETP or EMS, Indirect DHW Mode is set to ON & Indirect DHW Sensor is set to ON.
	OFF, 70 to 190°F (21.0 to 88.0°C) Default: OFF  Access: ADV	<b>INDIRECT DHW SETPOINT UNOCCUPIED</b> The temperature of the indirect DHW tank during the unoccupied periods. If operation is not desired during the unoccupied periods, select OFF. This item is only available when Application Mode is set to RSET, SETP or EMS, Indirect DHW Mode is set to ON, Indirect DHW Sensor is set to ON & the Setback / Off switch is set to Setback.
	1 to 42°F (0.5 to 23.5°C) Default: 6°F (3.0°C)  Access: ADV	<b>INDIRECT DHW DIFFERENTIAL</b> The temperature differential of the indirect DHW tank from the IDHW SETPOINT settings. This item is only available when Application Mode is set to RSET, SETP or EMS, Indirect DHW Mode is set to ON & Indirect DHW Sensor is set to ON.
	100 to 220°F (38.0 to 104.0°C) Default: 180°F (82.0°C)  Access: ADV	<b>INDIRECT DHW EXCHANGE OCCUPIED</b> The boiler target temperature for the indirect DHW heat exchanger during the occupied periods. This item is only available when Application Mode is set to RSET, SETP or EMS, Indirect DHW Mode is set to ON & Indirect DHW Sensor is set to OFF.
	OFF, 100 to 220°F (OFF, 38.0 to 104.0°C) Default: OFF  Access: ADV	<b>INDIRECT DHW EXCHANGE UNOCCUPIED</b> The boiler target temperature for the indirect DHW heat exchanger during the unoccupied periods. If operation is not desired during the unoccupied periods, select OFF. This item is only available when Application Mode is set to RSET, SETP or EMS, Indirect DHW Mode is set to ON, Indirect DHW Sensor is set to OFF & the Setback / Off switch is set to Setback.
	OFF or ON Default: OFF  Access: ADV	<b>INDIRECT DHW PRIORITY</b> Selects whether indirect DHW priority is active or not. This item is only available when Application Mode is set to RSET or EMS & Indirect DHW Mode is set to ON.

## Setup Menu (5 of 6)

Item Field	Range	Description
	1 to 4 Default: 2  Access: ADV	<b>INDIRECT DHW BOILER COUNT</b> Selects the number of boilers to be used when only a DHW Call is present. This item is only available when Application Mode is set to RSET, SETP or EMS, Indirect DHW Mode is set to ON & Indirect DHW Location is set to Boil.
	OFF or ON Default: OFF  Access: ADV	<b>PRIMARY PUMP DURING IDHW OPERATION</b> Selects whether or not the primary pump is required to operate when a DHW Call is present. This item is only available when APP MODE is set to RSET, SETP or EMS, Primary Pump 1 or Primary Pump 2 is set to AUTO, Indirect DHW Mode is set to ON & Indirect DHW Location is set to Boil.
	OFF or ON Default: OFF  Access: ADV	<b>SETPOINT MODE</b> Selects whether setpoint operation is active or not. This item is only available when Application Mode is set to RSET, SETP or EMS.
	OFF or ON Default: OFF  Access: ADV	<b>SETPOINT PRIORITY</b> Selects whether setpoint priority is active or not. This item is only available when Application Mode is set to RSET or EMS & Setpoint Mode is set to ON.
	OFF or ON Default: OFF  Access: ADV	<b>PRIMARY PUMP DURING SETPOINT OPERATION</b> Selects whether or not the primary pump is required to operate when a Setpoint Call is present. This item is only available when Application Mode is set to RSET, SETP or EMS, Primary Pump 1 or Primary Pump 2 is set to AUTO & Setpoint Mode is set to ON.
	60 to 220°F (15.5 to 104.0°C) Default: 180°F (82.0°C)  Access: ADV	<b>SETPOINT OCCUPIED TEMPERATURE</b> The boiler target temperature when a Setpoint Call is present during the occupied periods. This item is only available when Application Mode is set to RSET, SETP or EMS & Setpoint Mode is set to ON.
	OFF, 60 to 220°F (15.5 to 104.0°C) Default: OFF  Access: ADV	<b>SETPOINT UNOCCUPIED TEMPERATURE</b> The boiler target temperature when a Setpoint Call is present during the unoccupied periods. If operation is not desired during the unoccupied periods, select OFF. This item is only available when Application Mode is set to RSET, SETP or EMS, Setpoint Mode is set to ON & the Setback / Off switch is set to Setback
	70 to 190°F (21.0 to 88.0°C) Default: 140°F (60.0°C)  Access: ADV	<b>DEDICATED DHW OCCUPIED SETPOINT</b> The temperature of the dedicated DHW tank during the occupied periods. This item is only available when Application Mode is set to DDHW.
	OFF, 70 to 190°F (21.0 to 88.0°C) Default: OFF  Access: ADV	<b>DEDICATED DHW UNOCCUPIED SETPOINT</b> The temperature of the dedicated DHW tank during the unoccupied periods. This item is only available when Application Mode is set to DDHW & the Setback / Off switch is set to Setback.
	2 to 10°F (1.0 to 5.5°C) Default: 5°F (3.0°C)  Access: ADV	<b>DEDICATED DHW DIFFERENTIAL</b> The temperature differential of the dedicated DHW tank from the DDHW SETPOINT settings. This item is only available when Application Mode is set to DDHW.
	OFF, AUTO, 0:20 to 4:00 hrs Default: OFF  Access: ADV	<b>PRIORITY OVERRIDE</b> The amount of time priority is given for indirect DHW or setpoint operation before space heating resumes. This item is only available when Application Mode is set to RSET or EMS, & Indirect DHW Mode is set to ON & Indirect DHW Priority is set to ON, or Setpoint Mode is set to ON & Setpoint Priority is set to ON.

## Setup Menu (6 of 6)

Item Field	Range	Description
	35 to 100°F, OFF (2.0 to 38.0°C) Default: 70°F (21.0°C)  Access: ADV	<b>WWSD OCCUPIED</b> The system's warm weather shutdown temperature during the occupied periods.  This item is only available when the Application Mode is set to RSET.
	35 to 100°F, OFF (2.0 to 38.0°C) Default: 60°F (15.5°C)  Access: ADV	<b>WWSD UNOCCUPIED</b> The system's warm weather shutdown temperature during the unoccupied periods.  This item is only available when the Application Mode is set to RSET & the Setback / Off switch is set to Setback.
	OFF, 3 to 40 min Default: 20 min  Access: ADV	<b>BOILER ALERT</b> Alert signal if the boiler supply temperature does not increase in temperature, after all available boilers have been turned on, within the selected time.
	OFF or ON Default: OFF  Access: ADV	<b>FLOW SENSOR</b> Selects whether or not a flow sensor is used.
	0 to 100 gpm Default: 0 gpm  Access: ADV	<b>FLOW RATE 4MA</b> Sets the flow rate that corresponds to 4 mA for the flow sensor. This item is only available when Flow Sensor is set to ON.
	100 to 2,000 gpm Default: 500 gpm  Access: ADV	<b>FLOW RATE 20MA</b> Sets the flow rate that corresponds to 20 mA for the flow sensor. This item is only available when Flow Sensor is set to ON.
	OFF, 1 to 100% Default: OFF  Access: ADV	<b>FLOW SENSOR PROOF</b> Sets the percentage of flow used for proving primary pump flow. If the flow sensor is only used for monitoring, set to OFF. This is the minimum flow required to prove primary pump flow.  This item is only available when Flow Sensor is set to ON.
	OFF or ON Default: OFF  Access: ADV	<b>PRESSURE SENSOR</b> Selects whether or not a pressure sensor is used.
	50, 100, 150, 200, 250, 300 Default: 50  Access: ADV	<b>PRESSURE SENSOR RANGE</b> Selects the model of pressure sensor based on the pressure range in units of PSI.  This item is only available when Pressure Sensor is set to ON.

## Source # Menu (1 of 2)

There is a different Source Menu for each of the 4 boilers that the 294 can operate. Settings can vary for each boiler if desired.

	<p>OFF or AUTO Default: AUTO for Boil1 OFF for Boiler 2-4</p> <p><i>Access: INST</i></p>	<p><b>BOILER ENABLE</b> Selects whether the boiler is operational or not.</p>
	<p>OFF or Boil1 Default: OFF</p> <p><i>Access: INST</i></p>	<p><b>COPY BOILER 1</b> Selects whether or not settings from boiler 1 are copied to Boiler 2, 3 &amp; 4. This item is applicable for Boiler 2, 3 and 4 and is only available if Boiler Enable is set to AUTO.</p>
	<p>NO or YES Default: NO</p> <p><i>Access: ADV</i></p>	<p><b>BOILER CONDENSE</b> Selects if the boiler is non-condensing (NO) or condensing (YES). This item is only available if Boiler Enable is set to AUTO &amp; Copy Boiler 1 is set to OFF.</p>
	<p>MOD, 1STG, 2STG, EMS Default: MOD</p> <p><i>Access: ADV</i></p>	<p><b>BOILER TYPE</b> Selects from the different types of burner operation including modulating direct drive (MOD), single stage (1STG), two stage (2STG) &amp; target temperature (EMS). This item is only available if Boiler Enable is set to AUTO &amp; Copy Boiler 1 is set to OFF.</p>
	<p>0-10 or 4-20 Default: 0-10</p> <p><i>Access: ADV</i></p>	<p><b>MODULATION TYPE</b> Selects either 0-10 Vdc (0-10) or 4-20 mA (4-20) as the analog output for the modulating boiler. This item is only available if Boiler Enable is set to AUTO, Copy Boiler 1 is set to OFF &amp; Boiler Type is set to MOD or EMS.</p>
	<p>10 to 180 sec Default: 30 sec</p> <p><i>Access: ADV</i></p>	<p><b>FIRE DELAY</b> Delay from turn-on of ignition until the burner obtains flame. This item is only available if Boiler Enable is set to AUTO &amp; Copy Boiler 1 is set to OFF.</p>
	<p>OFF, 10 to 180 sec Default: OFF</p> <p><i>Access: ADV</i></p>	<p><b>MODULATION DELAY</b> Delay between the burner obtaining flame &amp; the boiler's ignition control releasing to modulation. This item is only available if Boiler Enable is set to AUTO, Copy Boiler 1 is set to OFF &amp; Boiler Type is set to MOD.</p>
	<p>LOW, MED, HI Default: MED</p> <p><i>Access: INST</i></p>	<p><b>BOILER MASS</b> The thermal mass characteristics of the boiler. This item is only available if Boiler Enable is set to AUTO &amp; Copy Boiler 1 is set to OFF.</p>
	<p>10 to 9990 MBtu/h Default: 80 MBtu/h</p> <p><i>Access: ADV</i></p>	<p><b>BOILER OUTPUT LOW</b> Minimum (low fire) heat output in Btu/hr/1000. This item is only available if Boiler Enable is set to AUTO, Copy Boiler 1 is set to OFF &amp; Boiler Type is set to MOD.</p>
	<p>10 to 9990 MBtu/h Default: 400 MBtu/h</p> <p><i>Access: ADV</i></p>	<p><b>BOILER OUTPUT HIGH</b> Maximum (high fire) heat output in Btu/hr/1000. This item is only available if Boiler Enable is set to AUTO &amp; Copy Boiler 1 is set to OFF.</p>
	<p>10 to 230 sec Default: 30 sec</p> <p><i>Access: ADV</i></p>	<p><b>MOTOR SPEED</b> The amount of time required for the modulating actuating motor to fully open the gas valve or operate the blower from a stopped position to full speed. This item is only available if Boiler Enable is set to AUTO, Boiler 1 Copy is set to OFF &amp; Boiler Type is set to MOD.</p>

## Source # Menu (2 of 2)

	0 to 100% Default: 0%  <i>Access: ADV</i>	<b>START MODULATION</b> The percentage modulation required for ignition. This item is only available if Boiler Enable is set to AUTO, Boiler 1 Copy is set to OFF & Boiler Type is set to MOD.
	0 to 50% Default: 0%  <i>Access: ADV</i>	<b>MINIMUM MODULATION</b> The minimum percentage modulation of the burner. This item is only available if Boiler Enable is set to AUTO, Boiler 1 Copy is set to OFF & Boiler Type is set to MOD.
	50 to 100% Default: 100%  <i>Access: ADV</i>	<b>MAXIMUM MODULATION</b> The maximum percentage modulation of the burner. This item is only available if Boiler Enable is set to AUTO, Boiler 1 Copy is set to OFF & Boiler Type is set to MOD.
	0.5 to 10.0 Default: 1.0  <i>Access: ADV</i>	<b>EMS SIGNAL MINIMUM</b> The minimum analog signal used for the EMS (temperature input) boiler and corresponds to the EMS Temperature Minimum. This item is only available if Boiler Enable is set to AUTO, Boiler 1 Copy is set to OFF, Boiler Type is set EMS & Modulation Type is set to 0-10.
	50 to 210°F, OFF (10.0 to 99.0°C) Default: 50°F  <i>Access: ADV</i>	<b>EMS TEMPERATURE MINIMUM</b> The temperature that corresponds to the bottom rail (minimum) of the analog signal (4 mA / Vdc Signal Minimum) used for the EMS (temperature input) boiler. This item is only available if Boiler Enable is set to AUTO, Boiler 1 Copy is set to OFF & Boiler Type is set to EMS.
	50 to 210°F, OFF (10.0 to 99.0°C) Default: 210°F  <i>Access: ADV</i>	<b>EMS TEMPERATURE MAXIMUM</b> The temperature that corresponds to the top rail (maximum) of the analog signal (20 mA / 10.0 Vdc) used for the EMS (temperature input) boiler. This item is only available if Boiler Enable is set to AUTO, Boiler 1 Copy is set to OFF & Boiler Type is set to EMS.
	120 to 240°F, OFF (49.0 to 115.5°C, OFF) Default: OFF  <i>Access: ADV</i>	<b>MAXIMUM OUTLET TEMPERATURE</b> The maximum boiler outlet temperature used for boiler outlet temperature limiting. The control will turn off the boiler if the boiler outlet temperature rises to the maximum outlet temperature. If OFF is selected, the control will only monitor the boiler outlet temperature. This item is only available if Boiler Enable is set to AUTO & the Boiler 1 Copy is set to OFF.
	OFF, AUTO, 0:10 to 20:00 min Default: AUTO  <i>Access: ADV</i>	<b>BOILER PUMP/VALVE POST PURGE</b> The time the boiler pump remains on (or isolation valve remains open) once the boiler turns off. If Auto is selected the control will automatically determine the time. This item is only available if Boiler Enable is set to AUTO & the Boiler 1 Copy is set to OFF.

## BAS Menu (1 of 2)

Configure Modbus® & BACnet® options.

Item Field	Range	Description
	OFF or ON Default: OFF  <i>Access: ADV</i>	<b>BAS MONITOR</b> Selects whether or not BAS monitor mode is to be used. Monitor mode allows for read / write capability of select menu items. This item is only available when Application Mode is set to either RSET, SETP, DDHW or EMS.
	BACn, MODB Default: BACn  <i>Access: ADV</i>	<b>BAS TYPE</b> Selects the communication protocol used with the BAS network. Modbus® communicates over RS485 & BACnet® is over IP.
	1 to 247 Default: 1  <i>Access: ADV</i>	<b>MODBUS ADDRESS</b> Sets the unique address within the Modbus® network. This item is only available when BAS Type is set to MODB.
	RTU or ASCII Default: RTU  <i>Access: ADV</i>	<b>MODBUS DATA</b> Selects whether the Modbus® data communication type is RTU or ASCII (ASCII). This item is only available when BAS Type is set to MODB.
	2400, 9600, 19K2, 57K6, 115K Default: 19K2  <i>Access: ADV</i>	<b>MODBUS BAUD RATE</b> Selects the communication speed. In order to ensure reliable communications, the baud rate on the control must be same as the Modbus® network. This item is only available when BAS Type is set to MODB.
	NONE, EVEN, ODD Default: EVEN  <i>Access: ADV</i>	<b>MODBUS PARITY</b> Selects the parity used for the Modbus® communication. This item is only available when BAS Type is set to MODB.
	0 to 4, 0 to 99, 0 to 99, 0 to 99 Default: 0, 0, 0, 0  <i>Access: ADV</i>	<b>BACNET DEVICE ID</b> Sets the unique address within the BACnet® network. The address is set using four number sets displayed in the source output fields. Touch the 'Next Item' button to view & adjust each number set. This item is only available when BAS Type is set to BACn.
	0x1 to 0xFFFF Default: 0xBAC0 (47808)  <i>Access: ADV</i>	<b>BACNET PORT</b> Sets the User Datagram Port (UDP) port on the BACnet® network. This item is only available when BAS Type is set to BACn.
	OFF or ON Default: ON  <i>Access: ADV</i>	<b>BACNET DHCP</b> Selects whether or not the Dynamic Host Configuration Protocol (DHCP) is used to automatically assign the IP address on the BACnet® network. If ON is selected, the address is displayed in the source output fields. This item is only available when BAS Type is set to BACn.
	0 to 255, 0 to 255, 0 to 255, 1 to 254 Default: 192,168,0,200  <i>Access: ADV</i>	<b>BACNET IP ADDRESS</b> Sets the IP address on the BACnet® network. The address is set using four number sets displayed in the source output fields. Touch the 'Next Item' button to view & adjust each number set. Touch the 'Next Item' button to view & adjust each number set. This item is only available when BAS Type is set to BACn & BACn DHCP is set to OFF.

## BAS Menu (2 of 2)

Item Field	Range	Description
	0 to 255, 0 to 255, 0 to 255, 1 to 254 Default: 192,168,0,1  <i>Access: ADV</i>	<b>BACNET GATEWAY</b> Sets the Gateway address on the BACnet® network. The address is set using four number sets displayed in the source output fields. Touch the 'Next Item' button to view & adjust each number set. Touch the 'Next Item' button to view & adjust each number set. This item is only available when BAS Type is set to BACn & BACn DHCP is set to OFF.
	0 to 255, 0 to 255, 0 to 255, 0 to 255 Default: 255,255,255,0  <i>Access: ADV</i>	<b>BACNET SUBNET</b> Sets the subnet address on the BACnet® network. The address is set using four number sets displayed in the source output fields. Touch the 'Next Item' button to view & adjust each number set. Touch the 'Next Item' button to view & adjust each number set. This item is only available when BAS Type is set to BACn & BACn DHCP is set to OFF.
	OFF, 30 to 65535 Default: OFF  <i>Access: ADV</i>	<b>BACNET BBMD TIME</b> Sets the BACnet® Broadcast Management Device (BBMD) time-to-live used for foreign device registration. This item is only available when BAS Type is set to BACn & DHCP is set to ON.
	0 to 255, 0 to 255, 0 to 255, 0 to 255 Default: 127,127,127,127	<b>BACNET BBMD IP</b> Sets the BBMD IP address on the BACnet® network. The address is set using four number sets displayed in the source output fields. Touch the 'Next Item' button to view & adjust each number set. Touch the 'Next Item' button to view & adjust each number set. This item is only available when BAS Type is set to BACn & BACnet® BBMD Time is not set to OFF.
	0x1 to 0xFFFF Default: 0xBAC0 (47808)  <i>Access: Adv</i>	<b>BACNET BBMD PORT</b> Sets the BBMD UDP port on the BACnet® network. This item is only available when BAS Type is set to BACn & BACnet® BBMD Time is not set to OFF.

## Monitor # Menu (1 of 1)

Monitor (#) items are repeated for each available boiler.

Item Field	Range	Description
	0 to 65535 hours  Access: ADV	<b>BURNER RUN TIME</b> The total running time of the boiler since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Boiler Enable is set to AUTO.
	0 to 65535 hours  Access: ADV	<b>BOILER PUMP / VALVE RUN TIME</b> The total running time of the boiler pump / valve since this item was cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Boiler Enable is set to AUTO.
	0 to 65535  Access: ADV	<b>BOILER CYCLES</b> The total number of boiler cycles since this item was cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Boiler Enable is set to AUTO.
	-22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER OUTLET HIGH</b> Records the highest boiler outlet temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Boiler Enable is set to AUTO & a boiler outlet sensor is connected.
	-22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER OUTLET LOW</b> Records the lowest boiler outlet temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Boiler Enable is set to AUTO & a boiler outlet sensor is connected.
	-22 to 266°F (-12.0 to 148.0°C)  Access: ADV	<b>BOILER TEMPERATURE DIFFERENCE HIGH</b> Records the highest temperature difference between the boiler inlet & boiler outlet sensors since this item was cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Boiler Enable is set to AUTO & boiler outlet & boiler inlet sensors are connected.

## Monitor Menu (1 of 2)

This Monitor Menu displays items that are not specific to one boiler.

Item Field	Range	Description
	0 to 65535 Therms  Access: ADV	<b>ENERGY</b> Total calculated energy being delivered to the load since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Flow Sensor is set to ON & a boiler return sensor is connected.
	0 to 65535 hours  Access: ADV	<b>PRIMARY PUMP 1 RUN TIME</b> The total running time of primary pump 1 since this item was cleared. Press & hold the 'CLEAR' button while viewing to reset.
	0 to 65535 hours  Access: ADV	<b>PRIMARY PUMP 2 RUN TIME</b> The total running time of primary pump 2 since this item was cleared. Press & hold the 'CLEAR' button while viewing to reset.
	0 to 65535 hours  Access: ADV	<b>DHW PUMP RUN TIME</b> The total running time of the IDHW pump since this item was cleared. Press & hold the 'CLEAR' button while viewing to reset.
	-22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER SUPPLY HIGH</b> Records the highest boiler supply temperature since this item was last cleared. Press & hold the 'Clear' button while viewing to reset.
	-22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER SUPPLY LOW</b> Records the lowest boiler supply temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset.
	-22 to 266°F (-30 to 130°C)  Access: ADV	<b>BOILER RETURN HIGH</b> Records the highest boiler return temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset.  This item is only available when a boiler return sensor is connected.
	-22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER RETURN LOW</b> Records the lowest boiler return temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset.  This item is only available when a boiler return sensor is connected.
	-22 to 266°F (-12.0 to 148.0°C)  Access: ADV	<b>SUPPLY TEMPERATURE DIFFERENCE HIGH</b> Records the highest temperature difference between the boiler supply & boiler return sensors since this item was cleared. Press & hold the 'CLEAR' button while viewing to reset.  This item is only available when the boiler supply & boiler return sensors are connected
	0 to 65535 gpm  Access: ADV	<b>FLOW RATE HIGH</b> Records the highest flow rate from the flow sensor since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset.  This item is only available when Flow Sensor is set to ON.
	0 to 65535 psi  Access: ADV	<b>PRESSURE HIGH</b> Records the highest pressure since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset.  This item is only available when Pressure Sensor is set to ON.
	-22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER INLET HIGH</b> Records the highest boiler inlet temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset.  This item is only available when a boiler inlet sensor is connected.
	-22 to 266°F (-30.0 to 130.0°C)  Access: ADV	<b>BOILER INLET LOW</b> Records the lowest boiler inlet temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset.  This item is only available when a boiler inlet sensor is connected.
	-76 to 149°F (-60.0 to 65.0°C)  Access: ADV	<b>OUTDOOR HIGH</b> Records the highest outdoor temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset.  This item is only available when an outdoor sensor is connected.

## Monitor Menu (2 of 2)

Item Field	Range	Description
	-76 to 149°F (-60.0 to 65.0°C)	<b>OUTDOOR LOW</b> Records the lowest outdoor temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when an outdoor sensor is connected.
	-22 to 266°F (-30.0 to 130.0°C)	<b>INDIRECT DHW HIGH</b> Records the highest indirect DHW temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Application Mode is not set to BAS, Indirect DHW Mode is set to ON & Indirect DHW Sensor is set to ON.
	-22 to 266°F (-30.0 to 130.0°C)	<b>INDIRECT DHW LOW</b> Records the lowest indirect DHW temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Application Mode is not set to BAS, Indirect DHW Mode is set to ON & Indirect DHW Sensor is set to ON.
	-22 to 266°F (-30.0 to 130.0°C)	<b>DIRECT DHW HIGH</b> Records the highest direct DHW temperature (boiler supply sensor) since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Application Mode is set to DDHW.
	-22 to 266°F (-30.0 to 130.0°C)	<b>DIRECT DHW LOW</b> Records the lowest direct DHW temperature (boiler supply sensor) since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when Application Mode is set to DDHW.
	-40 to 500°F (-40.0 to 260.0°C)	<b>VENT HIGH</b> Records the highest vent temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when a vent sensor is connected.
	-40 to 500°F (-40.0 to 260.0°C)	<b>VENT LOW</b> Records the lowest vent temperature since this item was last cleared. Press & hold the 'CLEAR' button while viewing to reset. This item is only available when a vent sensor is connected.

## Time Menu (1 of 1)

## Schedule Menu (1 of 1)

The 294 can follow an internal schedule or an available schedule on a tekmarNet® network. Four heating schedules can be present on one network. The number of available schedule times depends on selections made for the Heat Schedule, Schedule Type & Events / Day settings.

Schedule Type				
Day	24 Hour	5-2	5-11	7 day
Sa			•	•
Su		•	•	•
Mo				•
Tu	•			•
We		•	•	•
Th				•
Fr				•

### Default Times

Events / Day	Event	24Hr	Sat	Sun	Mon	Tue	Wed	Thu	Fri
4	Occupied 1	6:00 AM							
	UnOccupied 1	8:00 AM							
	Occupied 2	6:00 PM							
	UnOccupied 2	10:00 PM							
or									
2	Occupied	6:00 AM							
	Unoccupied	10:00 PM							

Item Field	Range	Description
	OFF, CTRL, MST1, MST2, MST3, MST4, MBR1, MBR2, MBR3, MBR4 Default = OFF Access: USER	<b>HEAT SCHEDULE</b> OFF = No schedule. CTRL = Schedule only used by this control. MST1 to MST4 = Schedule is shared with other tN4 devices. MBR1 to MBR4 = Schedule is set on another tN4 device. This item is only available when the Setback / Off switch is set to Setback.
	24hr, 5-2, 5-11, 7DAY Default = 24hr Access: USER	<b>SCHEDULE TYPE</b> 24hr = One schedule for all days of the week. 5-2 = One schedule for weekdays & one for weekends. 5-11 = One schedule for weekdays, one for Saturday & one for Sunday. 7DAY = A schedule for each day of the week. This item is only available when the Setback / Off switch is set to Setback & the Heat Schedule is set to CTRL or MST1 to MST4.
	2 or 4 Default = 2 Access: USER	<b>EVENTS / DAY</b> 2 = 2 Events per day (Occ, Unocc) 4 = 4 events per day (Occ 1, Unocc 1, Occ 2, Unocc 2) This item is only available when the Setback / Off switch is set to Setback & the Heat Schedule is set to CTRL or MST1 to MST4.
	12:00AM to 11:50PM, SKIP or 00:00 to 23:50, SKIP Default = 6:00AM Access: USER	<b>OCCUPIED START TIME (ALL DAYS, MON-FRI, SAT-SUN)</b> Select the time for the Occupied period to start. Additional occupied event times are available depending on the schedule type & mode settings. This item is only available when the Setback / Off switch is set to Setback, Heat Schedule is set to CTRL or MST1 to MST4.
	12:00AM to 11:50PM, SKIP or 00:00 to 23:50, SKIP Default = 8:00AM Access: USER	<b>UNOCCUPIED START TIME (ALL DAYS, MON-FRI, SAT-SUN)</b> Select the time for the Unoccupied period to start. Additional unoccupied event times are available depending on the schedule type & mode settings. This item is only available when the Setback / Off switch is set to Setback, Heat Schedule is set to CTRL or MST1 to MST4.

## Toolbox Menu (1 of 2)

Item Field	Range	Description
	Error Display  Access: ---	<b>ERROR</b> If an error is present, it will be displayed as the first item in the toolbox menu. Additional troubleshooting information scrolls on the display. For more information about error messages, refer to the Error Messages section of this document.
	USER, INST, ADV  Default: INST  Access: USER	<b>ACCESS LEVEL</b> The access level of the control. The access column shows which items are visible in each access level. This item is only available if the Lock / Unlock switch is set to Unlock.
	OFF, SEL, DONE  Default: OFF  Access: ADV	<b>DEFAULT</b> Press the Enter button to show SEL. After 3 seconds DONE will be indicated & factory defaults will be loaded to all settings.
	294, Software Version  Access: USER	<b>TYPE &amp; SOFTWARE VERSION</b> Product number of the control displayed in the number field. Software version displayed in the item field.
	°F or °C  Default: °F  Access: USER	<b>TEMPERATURE UNITS</b> Units for display of temperature.
	gpm or m³/h  Default: gpm  Access: INST	<b>FLOW RATE UNITS</b> Units for display of flow rate. This item is only available if Flow Sensor is set to ON.
	MBtu or kWh  Default: MBtu  Access: INST	<b>ENERGY UNITS</b> Units for display of Energy. If MBtu is selected, the units used for Energy are Therms (THRM). If kWh is selected, the units used for Energy are Gigajoules (GJ). This item is only available if Flow Sensor is set to ON.
	psi or kPa  Default: psi  Access: INST	<b>PRESSURE UNITS</b> Units for display of pressure. This item is only available if Pressure Sensor is set to ON.
	1 to 24  Access: INST	<b>BOILER BUS B DEVICES</b> Displays the number of tN4 devices connected to the Boiler Bus b terminals, tN4 & C0 (32 & 33).
	1 to 24  Access: INST	<b>BOILER BUS 1 DEVICES</b> Displays the number of tN4 devices connected to the Boiler Bus 1 terminals, tN4 & C1 (34 & 35).
	1 to 24  Access: INST	<b>BOILER BUS 2 DEVICES</b> Displays the number of tN4 devices connected to the Boiler Bus 2 terminals, tN4 & C2 (36 & 37).
	1 to 24  Access: INST	<b>BOILER BUS 3 DEVICES</b> Displays the number of tN4 devices connected to the Boiler Bus 3 terminals, tN4 & C3 (38 & 39).
	The error date & the type of error alternate on the screen  Access: INST	<b>ERROR HISTORY 1-5</b> Displays a history of any past errors that have occurred on the system. Will automatically clear after 30 days. To manually clear, press 'CLEAR' while viewing the error until CLR is displayed. The last 5 history items will display if present.

## Manual Override

Commissioning, testing & troubleshooting features of the 294 are accessed by holding the Manual Override button for 3 seconds. Once an item is selected in this menu, there is a 3 second delay before the feature activates. The Manual Override has five different modes including:

### Automatic (AUTO)

The normal operating mode for the control is automatic. The control operates based on the settings, calls & current conditions.

### Purge Override (PURG)

In this mode, the control overrides the normal operating mode & operates pumps. This mode is useful for purging air out of the system.

- Primary pump: operation of the primary pump is dependent on the system settings in the Setup menu. Only one enabled primary pump is turned on. If both primary pumps are enabled, primary pump 1 is turned on. If primary pump 1 is disabled & primary pump 2 is enabled, primary pump 2 is turned on. If both primary pumps are disabled, no primary pump is turned on.
- IDHW pump: operation of the IDHW pump is dependent on the system settings in the Setup menu. If IDHW Mode is turned on, the IDHW pump is turned on. If IDHW Mode is turned Off, the IDHW pump is not turned on.
- When in Purge mode, 'PURG' & 'OVR' will scroll in the status field of the display.
- Purge will operate for a fixed period of 72 hours. After the purge period expires the control will revert to Automatic operation. The purge override can also be terminated by selecting the AUTO override mode.

### Max Heat Override (MAX)

In this mode, the control overrides the normal operating mode & operates the system to maintain a boiler target temperature of 230°F. This function is useful on start-up & commissioning, & also when drying sheet rock & paint in the building.

- Operation of the equipment is dependent on the system.
- WWSD, IDHW & Setpoint Priority are disabled during Max Heat.
- While in Max Heat mode, 'MAX' & 'HEAT' will scroll in the status field of the display.
- Max Heat will operate for an adjustable timeout period. After the timeout period elapses the control will revert back to Automatic mode. The max heat override can also be terminated by selecting the AUTO override mode.

### Hand Override (HAND)

In this mode, the control overrides the normal operating mode & allows for manual operation of the equipment. This mode is useful for testing & assisting with troubleshooting.

- Operation of the equipment is dependent on the settings in the Setup menu. Refer to the 'Selecting a Manual Override Mode' for the sequence of steps.
- While in Hand mode, 'HAND' & 'OVR' will scroll in the status field of the display.
- Hand mode will operate for an adjustable timeout period. After the timeout period elapses the control will revert back to Automatic mode. The hand override can also be terminated by selecting the AUTO override mode.

### Off Override (OFF)

In this mode, the control overrides the normal operating mode & forces the entire system off. This mode is useful for conducting maintenance or changeout of mechanical components in the system.

- While in Off mode, 'OFF' & 'OVR' will scroll in the status field of the display.
- The Off override can be terminated at any time by selecting the AUTO override mode.

## Selecting a Manual Override Mode

Item Field	Range	Description
	AUTO, OFF, HAND, MAX, PURG	<b>MANUAL OVERRIDE</b> Select which mode of manual override to activate.
	1hr to 72hr	<b>TIMEOUT</b> Set the timeout used for the Hand & Maximum Heat manual overrides. This item is only available if Manual Override is set to either HAND or MAX.
	OFF or ON	<b>ALERT</b> Selects manual operation of the Alert relay. This item is only available if Manual Override is set to HAND.
	OFF or ON	<b>AUXILIARY</b> Selects manual operation of the Auxiliary relay. The Auxiliary is defined to be either a C.A. damper or a DHW recirculation pump. This item is only available if Manual Override is set to HAND.
	OFF, PMP1 or PMP2	<b>PRIMARY PUMP</b> Selects manual operation of the primary pump. Only one pump can operate. If a pump is operating & then the other pump is selected, the former pump will turn off while the latter pump remains on. This item is only available if Manual Override is set to HAND.
	OFF or ON	<b>DHW PUMP</b> Selects manual operation of the DHW pump. This item is only available if Manual Override is set to HAND & IDHW Mode is set to ON.
	OFF or ON	<b>BOILER (#) PUMP / VALVE</b> Selects operation of the boiler pump. This item is available for each of the available boilers. This item is only available if Manual Override is set to HAND,
	1STG: OFF or 1 2STG: OFF, 1 or 2	<b>BOILER (#) STG</b> Selects operation of single & two stage boilers. This item is available for each of the available single & two stage boilers. If the boiler pump / valve is not already activated, it will turn on. <ul style="list-style-type: none"><li>• OFF: boiler off (applicable for single &amp; two stage)</li><li>• 1: Turn on stage 1 (applicable for single &amp; two stage)</li><li>• 2: Turn on stage 2 (applicable for two stage)</li></ul> This item is only available if Manual Override is set to HAND & Boiler Enable is set to AUTO & Boiler Type is set to 1STG or 2STG.
	0 to 100%	<b>BOILER (#) MOD</b> Sets percentage modulation for modulating boilers. This item is available for each of the available modulating boilers. If the boiler pump / valve is not already activated, it will turn on. This item is only available if Manual Override is set to HAND & Boiler Enable is set to AUTO & Boiler Type is set to MOD.
	OFF, EMS TEMP MIN to EMS TEMP MAX	<b>BOILER (#) TEMP</b> Sets the target temperature for temperature input boilers. This item is available for each of the available temperature input boilers. If the boiler pump / valve is not already activated, it will turn on. This item is only available if Manual Override is set to HAND & Boiler Enable is set to AUTO & Boiler Type is set to EMS.

# Troubleshooting

It is recommended to complete all wiring to ensure trouble free operation. Should an error occur, simply follow these steps:

- 1. Find:** If the Boiler Control 294 flashes  on the screen, it is indicating a problem on the system.
- 2. Identify:** Press & hold the Home button for 3 seconds to view the available menus. Tap the NEXT ITEM button to locate the Toolbox Menu & press ENTER to view the toolbox menu items. The Error code should appear as the first item. The troubleshooting tips will then marquee across the Item field.
- 3. Solve:** Using the lookup chart below, match the Error code to the one on the control. Use the Description & Troubleshooting Tips in the chart to solve the problem.

## Error Messages (1 of 3)

Error Message	Description	Troubleshooting Tips
	<b>CONTROL SETUP FAILURE</b> The control failed to read the Setup menu settings, & reloaded factory default settings. Operation stops until this error message is cleared. <b>To clear, press the 'CLEAR' button while viewing this warning message.</b>	RESET DEFAULTS, VERIFY ALL SETTINGS
	<b>BOILER SUPPLY SENSOR ERROR</b> OPEN or SHRT displays on the screen. Due to an open or short circuit, the control failed to read the boiler supply sensor. As a result, & if available, the control operates using the boiler return sensor. If the boiler return sensor is unavailable, operation stops. The error message self clears once the error condition is corrected.	CHECK BOILER SUPPLY SENSOR, CHECK BOILER SUPPLY SENSOR WIRING
	<b>BOILER RETURN SENSOR ERROR</b> OPEN or SHRT displays on the screen. Due to an open or short circuit, the control failed to read the boiler return sensor. If the Boiler Supply sensor is available, the control will operate normally. If the Boiler Supply sensor is unavailable, the control can only operate to satisfy indirect DHW if its located in the near boiler piping (i.e. IDHW Location = Near). The error message self clears once the error condition is corrected.	CHECK BOILER RETURN SENSOR, CHECK BOILER RETURN SENSOR WIRING
	<b>DHW SENSOR ERROR</b> OPEN or SHRT displays on the screen. Due to an open or short circuit, the control failed to read the DHW sensor. As a result, the control stops operation for DHW heating (indirect or direct DHW). The error message self clears once the error condition is corrected.	CHECK DHW SENSOR, CHECK DHW SENSOR WIRING
	<b>OUTDOOR SENSOR ERROR</b> OPEN or SHRT displays on the screen. Due to an open or short circuit, the control failed to read the outdoor sensor. As a result, the control assumes an outdoor temperature of 32°F (0.0°C) & continues operation. The error message self clears once the error condition is corrected.	CHECK OUTDOOR SENSOR, CHECK OUTDOOR SENSOR WIRING
	<b>VENT SENSOR ERROR</b> OPEN or SHRT displays on the screen. Due to an open or short circuit, the control failed to read the vent sensor. If the Vent Maximum is set to a temperature, the control stops operation. If the Vent Maximum is set to Off, the control continues operation. The error message self clears once the error condition is cleared.	CHECK VENT SENSOR CHECK VENT SENSOR WIRING
	<b>BOILER (#) OUTLET SENSOR ERROR</b> OPEN or SHRT displays on the screen. Due to an open or short circuit, the control failed to read the boiler (#) outlet sensor. The error message self clears once the error condition is cleared.	CHECK BOILER (#) OUTLET SENSOR, CHECK BOILER (#) OUTLET SENSOR WIRING

## Error Messages (2 of 3)

Error Message	Description	Troubleshooting Tips
	<b>BOILER (#) OUTLET SENSOR MAXIMUM EXCEEDED</b> The boiler outlet (#) temperature exceeded the Maximum Outlet temperature. As a result, the control stops operation for the associated boiler. The error message self clears once the error condition is cleared.	BOILER (#) OUTLET TEMP EXCEEDS MAX OUT SETTING
	<b>BOILER INLET SENSOR ERROR</b> OPEN or SHRT displays on the screen. Due to an open or short circuit, the control failed to read the boiler inlet sensor. The control operates normally while the error message is present. The error message self clears once the error condition is corrected.	CHECK BOILER INLET SENSOR, CHECK BOILER INLET SENSOR WIRING
	<b>PRIMARY PUMP P1 FLOW PROOF FAILURE</b> The primary pump P1 has failed. Once the primary pump 1 relay closed, a flow proof call was not detected before the flow proof delay time elapsed.	CHECK FLOW PROVING DEVICE, CHECK FLOW PROVING DEVICE WIRING
	<b>PRIMARY PUMP P2 FLOW PROOF FAILURE</b> The primary pump P2 has failed. Once the primary pump 2 relay closed, a flow proof call was not detected before the flow proof delay time elapsed.	CHECK FLOW PROVING DEVICE, CHECK FLOW PROVING DEVICE WIRING
	<b>PRIMARY PUMP P1 &amp; P2 FLOW PROOF FAILURE</b> Both the primary pump P1 & P2 have failed.	CHECK FLOW PROVING DEVICE, CHECK FLOW PROVING DEVICE WIRING
	<b>FLOW PROOF CALL ERROR</b> The primary pump has been turned off but the flow proof call remains detected after 4 minutes.	CHECK FLOW PROVING DEVICE, CHECK FLOW PROVING DEVICE WIRING
	<b>COMBUSTION AIR PROOF FAILURE</b> The combustion air damper has failed. The C.A. (Aux) relay closed, but the control did not detect a C.A. proof call before the C.A. proof delay time elapsed.	CHECK CA PROVING DEVICE, CHECK CA PROVING DEVICE WIRING
	<b>COMBUSTION AIR PROOF CALL ERROR</b> The combustion air damper has been turned off but the C.A. proof call remains detected after 4 minutes.	CHECK CA PROVING DEVICE, CHECK CA PROVING DEVICE WIRING
	<b>VENT MAXIMUM EXCEEDED</b> The Vent Sensor temperature has exceeded the VENT MAX setting. As a result, the control stops operation for the entire plant.	VENT TEMP EXCEEDS MAX SETTING
	<b>NO HEAT ALERT</b> The boiler supply temperature did not increase within the boiler alert time. The control operates normally while this Alert is present. To reset the Alert, press the 'CLEAR' button while viewing this warning message.	NO CHANGE IN SUPPLY TEMP WITHIN SPECIFIED PERIOD OF TIME
	<b>tekmarNet® DEVICE LOST</b> Communication is lost to a tN4 device on one of the four Boiler Buses (b, 1, 2, 3). The number shown is the address of the lost device. The display on the lost device displays Bus Boil Opn. Ensure that there is power to the lost device. Trace the wires from the control to the lost device looking for loose or damaged wires. The error message self clears when the error condition is corrected. If the tN4 device is deliberately removed, press the 'CLEAR' button while viewing this error message/	DEVICE MISSING ON TN4 BUS (#)
	<b>tekmarNet® DUPLICATE MASTER ERROR</b> More than one tN4 system control has been detected on the tN4 Boiler Bus. The 294 is a "Master Device" & no other tekmarNet reset controls can be added to the tN4 Boiler Bus terminals. If one has been added it must be removed from the system.	DUPLICATE MASTER CONTROL DETECTED ON TN4 BUS

## Error Messages (3 of 3)

Error Message	Description	Troubleshooting Tips
	<p><b>tekmarNet® DEVICE ERROR #:##</b>          #:## is the address of the device with the error. The bus number displays before the colon, &amp; the device number display after. Go to the device with the address displayed.</p> <p><i>Possible addresses:</i></p> <ul style="list-style-type: none"> <li><b>b:01</b> to <b>b:24</b> - Device Error on Boiler Bus b</li> <li><b>1:01</b> to <b>1:24</b> - Device Error on Boiler Bus 1</li> <li><b>2:01</b> to <b>2:24</b> - Device Error on Boiler Bus 2</li> <li><b>3:01</b> to <b>3:24</b> - Device Error on Boiler Bus 3</li> </ul>	DEVICE ERROR ON TN4 BUS (#)
	<p><b>tekmarNet® DUPLICATE SCHEDULE MASTER ERROR</b>          More than one tN4 device has been assigned the same master number. The control operates using the Occupied settings while this error is present.</p> <p>To clear this error, select a different Schedule Master number, set a different Schedule Member number, set the Schedule to Control, or set the Schedule to None.</p>	DUPLICATE MASTER SCHEDULE DETECTED ON TN4 BUS
	<p><b>tekmarNet® SCHEDULE MEMBER ERROR</b>          The control can no longer detect its schedule master. The control operates using the Occupied settings while this error is present.</p> <p>To clear this error, select a different Schedule Member number, set the Schedule to Control, or set the Schedule to None.</p>	CHECK SCHEDULE MASTER WIRING ON TN4 BUS CHECK SCHEDULE MASTER ADDRESS ON TN4 BUS

# Technical Data

Smart Boiler Control 294	
Literature	Submittal, Application, Installation and Operating Manual, Job Record
Packaged weight	TBD lb. (TBD g)
Dimensions	9" H x 8" W x 2-11/16" D (229 x 203 x 60 mm)
Enclosure	Blue ABS plastic, NEMA type 1
Approvals	CSA C US, meets FCC Part 15B, ICES-003 Class A
Ambient conditions	Indoor use only, 32 to 122°F (0 to 50°C), < 90% RH non-condensing, non-condensing, Altitude < 6560 feet (2000 m), Installation Category II, Pollution Degree 2
Power supply	115 V (ac) ±10%, 60 Hz, 9 W
Relays	230 V (ac), 5 A, 1/3 hp
Modulating outputs	0-10 V (dc) 500 Ω minimum load impedance or 4-20 mA 1 kΩ max load impedance
Calls	24 V (ac) or Short
Sensors	NTC thermistor, 10 kΩ @ 77°F (25°C ±0.2°C) β=3892
-Included	Outdoor Sensor 070, Universal Sensor 082
-Optional	tekmar type: 071, 078, 087, 088
Warranty	Limited 3 Year

## Limited Warranty & Product Return Procedure

**Limited Warranty** *The liability of tekmar under this warranty is limited. The Purchaser, by taking receipt of any tekmar product ("Product"), acknowledges the terms of the Limited Warranty in effect at the time of such Product sale & acknowledges that it has read & understands same.*

The tekmar Limited Warranty to the Purchaser on the Products sold hereunder is a manufacturer's pass-through warranty which the Purchaser is authorized to pass through to its customers. Under the Limited Warranty, each tekmar Product is warranted against defects in workmanship & materials if the Product is installed & used in compliance with tekmar's instructions, ordinary wear & tear excepted. The pass-through warranty period is for a period of twenty-four (24) months from the production date if the Product is not installed during that period, or twelve (12) months from the documented date of installation if installed within twenty-four (24) months from the production date.

The liability of tekmar under the Limited Warranty shall be limited to, at tekmar's sole discretion: the cost of parts & labor provided by tekmar to repair defects in materials &/or workmanship of the defective product; or to the exchange of the defective product for a warranty replacement product; or to the granting of credit limited to the original cost of the defective product, & such repair, exchange or credit shall be the sole remedy available from tekmar, &, without limiting the foregoing in any way, tekmar is not responsible, in contract, tort or strict product liability, for any other losses, costs, expenses, inconveniences, or damages, whether direct, indirect, special, secondary, incidental or consequential, arising from ownership or use of the product, or from defects in workmanship or materials, including any liability for fundamental breach of contract.

The pass-through Limited Warranty applies only to those defective Products returned to tekmar during the warranty period. This Limited Warranty does not cover the cost of the parts or labor to remove or transport the defective Product, or to reinstall the repaired or replacement Product, all such costs & expenses being subject to Purchaser's agreement & warranty with its customers.

Any representations or warranties about the Products made by Purchaser to its customers which are different from or in excess of the tekmar Limited Warranty are the Purchaser's sole responsibility & obligation. Purchaser shall indemnify & hold tekmar harmless from & against any & all claims, liabilities & damages of any kind or nature which arise out of or are related to any such representations or warranties by Purchaser to its customers.

The pass-through Limited Warranty does not apply if the returned Product has been damaged by negligence by persons other than tekmar, accident, fire, Act of God, abuse or misuse; or has been damaged by modifications, alterations or attachments made subsequent to purchase which have not been authorized by tekmar; or if the Product was not installed in compliance with tekmar's instructions &/or the local codes & ordinances; or if due to defective installation of the Product; or if the Product was not used in compliance with tekmar's instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, WHICH THE GOVERNING LAW ALLOWS PARTIES TO CONTRACTUALLY EXCLUDE, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY & FITNESS FOR A PARTICULAR PURPOSE, DURABILITY OR DESCRIPTION OF THE PRODUCT, ITS NON-INFRINGEMENT OF ANY RELEVANT PATENTS OR TRADEMARKS, & ITS COMPLIANCE WITH OR NON-VIOLATION OF ANY APPLICABLE ENVIRONMENTAL, HEALTH OR SAFETY LEGISLATION; THE TERM OF ANY OTHER WARRANTY NOT HEREBY CONTRACTUALLY EXCLUDED IS LIMITED SUCH THAT IT SHALL NOT EXTEND BEYOND TWENTY-FOUR (24) MONTHS FROM THE PRODUCTION DATE, TO THE EXTENT THAT SUCH LIMITATION IS ALLOWED BY THE GOVERNING LAW.

**Product Warranty Return Procedure** All Products that are believed to have defects in workmanship or materials must be returned, together with a written description of the defect, to the tekmar Representative assigned to the territory in which such Product is located. If tekmar receives an inquiry from someone other than a tekmar Representative, including an inquiry from Purchaser (if not a tekmar Representative) or Purchaser's customers, regarding a potential warranty claim, tekmar's sole obligation shall be to provide the address & other contact information regarding the appropriate Representative.

tekmar Control Systems Ltd., A Watts Water Technologies Company. Head Office: 5100 Silver Star Road, Vernon, B.C. Canada V1B 3K4, 250-545-7749, Fax. 250-984-0815 Web Site: [tekmarControls.com](http://tekmarControls.com)

