


802.11be-EHT160 - Ant 0

Channel 15 (6025MHz)

The Reference Level




The Mask Data




Channel 47 (6185MHz)

The Reference Level




The Mask Data




Channel 79 (6345MHz)

The Reference Level




The Mask Data




802.11be-EHT160 - Ant 0

Channel 111 (6505MHz)

The Reference Level



The Mask Data




Channel 143 (6665MHz)

The Reference Level




The Mask Data




Channel 175 (6825MHz)

The Reference Level




The Mask Data




802.11be-EHT160 - Ant 0

Channel 207 (6985MHz)

The Reference Level




The Mask Data



802.11be-EHT320 - Ant 0

Channel 31 (6105MHz)

The Reference Level




The Mask Data




Channel 63 (6265MHz)

The Reference Level




The Mask Data




Channel 95 (6425MHz)

The Reference Level




The Mask Data




802.11be-EHT320 - Ant 0

Channel 127 (6585MHz)

The Reference Level




The Mask Data




Channel 159 (6745MHz)

The Reference Level



The Mask Data




Channel 191 (6905MHz)

The Reference Level




The Mask Data




802.11ax-HE20 - Ant 1

Channel 1 (5955MHz)

The Reference Level




The Mask Data




Channel 49 (6195MHz)

The Reference Level




The Mask Data




Channel 93 (6415MHz)

The Reference Level




The Mask Data




802.11ax-HE20 - Ant 1

Channel 97 (6435MHz)

The Reference Level




The Mask Data




Channel 105 (6475MHz)

The Reference Level




The Mask Data




Channel 113 (6515MHz)

The Reference Level




The Mask Data




802.11ax-HE20 - Ant 1

Channel 117 (6535MHz)

The Reference Level




The Mask Data




Channel 149 (6695MHz)

The Reference Level




The Mask Data




Channel 181 (6855MHz)

The Reference Level




The Mask Data




802.11ax-HE20 - Ant 1

Channel 185 (6875MHz)

The Reference Level




The Mask Data




Channel 189 (6895MHz)

The Reference Level




The Mask Data




Channel 209 (6995MHz)

The Reference Level



The Mask Data




802.11ax-HE20 - Ant 1

Channel 229 (7095MHz)

The Reference Level




The Mask Data




802.11ax-HE40 - Ant 1

Channel 3 (5965MHz)

The Reference Level




The Mask Data




Channel 51 (6205MHz)

The Reference Level




The Mask Data




Channel 91 (6405MHz)

The Reference Level




The Mask Data




802.11ax-HE40 - Ant 1

Channel 99 (6445MHz)

The Reference Level




The Mask Data




Channel 107 (6485MHz)

The Reference Level




The Mask Data




Channel 115 (6525MHz)

The Reference Level



The Mask Data




802.11ax-HE40 - Ant 1

Channel 123 (6565MHz)

The Reference Level




The Mask Data




Channel 147 (6685MHz)

The Reference Level




The Mask Data




Channel 179 (6845MHz)

The Reference Level




The Mask Data




802.11ax-HE40 - Ant 1

Channel 187 (6885MHz)

The Reference Level




The Mask Data




Channel 195 (6925MHz)

The Reference Level




The Mask Data



Channel 211 (7005MHz)

The Reference Level



The Mask Data

