6 USE INSTRUCTION

1.To ensure correct voltage, insert electronic source cable, turn on the power switch button and adjust function keys to your desired sound effect.

7 CONTENTS:

1.Main Unit1 pc
2.DC adaptor1 pc
3.Remote Control1 pc
5.User Manual1 pc

8 PRECAUTION

In order to prevent operating problems or serious damage to the device, please comply with the

1. Hold the Adapter plug while pulling out from the wall plug. Do not pull the wire.

vase, is not supposed to be placed on or above the appliance

- 2. Operating audio appliances should be kept away from heating facilities.
- 3.Do not attempt to fix or amend the circuit.
- 4. Do not touch the internal parts to avoid electric shock or serious damage to the device.
- 5. Pull out the adapter plug if not in use
- 6. Ensure that product is in ventilated dry condition with about 10 cms distance around it to avoid over heating

Warning:Do not expose this appliance to rain or moisture, and vessel containing liquids, such as a cup,

9 TROUBLE SHOOTING

Symptom	Possible Problem	Solution
No Function Light or No Sound	1.Plug is not well connected	Insert the plug into electric outlet
	2.Speaker power button is not turned on	Turn ON the power button
Unit is on but	1. USB /TF Card/cable not connected correctly.	Turn off the power, check the input device/ jack to ensure proper audio signal is connected to relevant input jack
No Sound	2.Audio signal is not transmitted to speaker	Check the input device if it has valid media formats supported by this device

Do not attempt to open the cover, to avoid any possile Electric Shocks.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee $that \, interference \, will \, not \, occur \, in \, a \, particular \, installation. \, If \, this \, equipment \, does \, cause \, harmful \, interference \, and \, continuous \, continuo$ to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver
- is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

Professional Outdoor Portable Audio System

USER MANUAL

- Please read this Manual carefully before using.
- Although we have taken care of all the features and their operation in this manual, However due to continous development some changes may be there for which no notice will be provided.
- Please store this manual carefully for future reference.

CAUTION

- 1. Protecting of electric power supply: Please ensure that electric power cable is not tramped or pressed by heavy objects. Pay special attention to the plug of power supply and outlet on the device are not loosely connected. DO NOT extend the length of cable, DO NOT pull or drag or the power cable.
- 2. Ventilation: This unit must be stored/operated in proper ventilated atmosphere. DO NOT put sharp objects on it or cover it plastic/cloth while operating. Minimum 10 centimenter distance from the wall should not be observed before operating the unit. DO NOT use the unit on the bed, sofa, carpet other objects with similar surface to ensure good ventilation.
- ${\bf 3. Dismant ling: DO\ NOT\ dismant le\ the\ case.\ Possibility\ of\ serious\ electric\ shock\ when\ in\ \ contact\ with\ \ }$
- 4. Unusual smell: If you notice unusual smell or smoke, cutoff power supply immediately and pull out the plug from the power outlet on the wall. Contact authorized service personnel for repairs. Attention: This unit is provided with AC 110V~240V/50Hz~60Hz power adaptor. Please use this power supply only. Please replace this power supply with same specifications only.















HEAR IT ENJOY IT

Before using this unit, please read all the safety and operating instructions, please ensure all precautions for safe operation. These safety and operating instructions should be kept safely for future reference











(<u>O</u>)

 \circ

1 BACK PANEL FUNCTION INSTRUCTION

- 1. Volume: Main Volume control adjustment knob. Adjust the output sound of the speaker.
- 2. Treble / Bass Control: Adjust the Treble and Bass levels to your desired sound output.
- 3. MIC VOL: Microphone Volume control adjustment. Adjust the output sound of the Microphone connected 4. Echo: Echo volume control adjustment knob. Allows to
- adjust the echo effect by increasing or decreasing the echo depth of the microphone output. 5. Guitar VOL: Adjusts the guitar output levels for the
- guitar connected to Guitar input jack.
- 6.MIC/GUITAR input: input Jack for wired microphone /
- 7.USB input:Input Jack for USB drive to play supported
- music files stored in the USB Drive. 8.TF: Input Jack for TF Card.
- 9. LED indicator: During charging Red LED light indicates low
- power, once fully charged this LED light turns green. 10.DC battery charging socket: Connect with external battery powersupply to operate the unit. Once fully charged this unit can be used for 4-5 hours.
- 11. DC Jack: Connect to power adaptor for charging the unit. 12. Power Switch: Power ON/OFF switch.
- 13. Flash LED Switch: Turn ON/OFF the Flashing LED light
- on the woofer. 14.MIC Priority ON/OFF: Switch ON/OFF microphone priority
- over background music.
- 15. AUX Input: Connect external playback device with RCA/Jack pin for Line in. 16. FM Antenna: Extend the antena completely for best reception of built in FM Radio
- 17.Rec MIC hole: Record the external sound on the USB Disc via built in Microphone
- 18.LED display: Display the current status.
- 19. MODE/INPUT: Select the mode / Input device for playback.
- 20.Prev/CH-: Choose the previous track of MP3 or previous channel of radio; Long press
- 21.Play/Pause/FM scan: Play/Pause MP3 file from U-Disk/TF Card. Scan for FM radio stations in FM Mode.
- 22. Next/CH+: Choose the next track of MP3 or next channel of radio, Long press increases
- 23.Repeat: Press once will repeat the current track press again will cancel repeat same track to play all the files on the drive
- 24. Rec: Press one time to start record the sound, press again will stop recording and playback the recorded file.

Remark:

Above instructions are for reference only, they same can be updated without prior notice.

2 REMOTE CONTROL INSTRUCTION



Voltage:	AC 110-220V/50~60Hz±10%
Consumer Power:	<150W
Main Channel Frequency response:	20Hz-20KHz±1.5dB
THD:	<0.2%
S/N(Main Channel):	86dB

4 RECHARGE INDICATION

If battery voltage is not enough, The sound will be distorted and will auto poweroff it is time to recharge Please dicontiune usage and manually turn the main Power switch to OFF status. Recharge for 8-10 hours before using again. Once fully charged the unit can use for 4-5 hours.

Once the battery voltage is low, please fully recharge the unit within 48 hours, If the unit is not used for long time the battery will slowly drain out. Please make sure to recharge the unit atleat once in every 30-40 days to avoid any damage to the battery. Please use original AC adaptor provided connect to AC power outlet and set the main power switch to "ON" postion and connect the device with AC adapter jack pin, charging indicator LED will turn Red indicating the unit is charging. Please charge for 8-10 hours. Once fully charged, the indicator light will turn Green . Please turn the power switch to OFF status.

5 PRODUCT FEATURES

- 1. High output power;
- 2. With Karaoke function;
- 3. Clear natural treble and powerful bass;
- 4. Compatible with DVD/VCD/CD/TAPE/MP3/AUX
- 5.Built-in high-capacity battery
- 6. Seperate Volume Control for Microphone & Guitar.
- 7. With recording function