Products

Valid as of version 01.00.zz (Device firmware)

Operating Instructions **Picomag IO-Link**

Electromagnetic flowmeter





- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Picomag IO-Link Table of contents

Table of contents

1	About this document	4	8	System integration	18
1.1 1.2	Document function	4 4	8.1 8.2	Overview of device description files Device master file	
	1.2.1 Safety symbols	4	9	Commissioning	19
	1.2.3 Communication symbols	4	9.1 9.2	Switching ON the measuring device Configuring the measuring device	
1.3	1.2.5 Symbols in graphics	5		9.2.1 Configuring the display	20
1.4	Registered trademarks	5		9.2.3 Setting the installation direction and measurement	
2 2.1	Basic safety instructions	6		9.2.5 Simulation	
2.2 2.3	Designated use	6	10	Operation	27
2.4	Operational safety	7	10.1 10.2	Reading measured values	
2.5 2.6 2.7	Product safety	7 7 7	10.3	Administration	
۷.7	Device-specific IT security	7	11	Diagnostics and troubleshooting	29
	2.7.2 Access via Bluetooth® wireless technology	7	11.1 11.2	Diagnostic information on local display	30
3	Incoming acceptance and product		11.3 11.4	Overview of diagnostic events	31
0 1	identification		11.5	Device information	32
3.1 3.2	Incoming acceptance		11.6	Firmware history	32
	3.2.1 Symbols on measuring device	9	12	Accessories	33
4	Storage and transport 1		13	Technical data	34
4.1 4.2	Storage conditions		13.1	Input	
4.3	Packaging disposal		13.2	Output	34
			13.3 13.4	Power supply	
5	Installation	.1	13.5		
5.1	Installation conditions		13.6	Environment	34
5.2	5.1.1 Mounting position		13.7		35
5.4	Mounting the measuring device	LT	13.8 13.9		35 36
6	Electrical connection	.3			36
6.1		13	14	Appendix	38
	6.1.1 Requirements for connecting cables 1 6.1.2 Pin assignment, device plug	13	14.1	Radio approvals	
6.2	Connecting the measuring device		11.1		
6.3	Post-connection check	16		14.1.2 Canada and USA	38
7	Operation options	.7			
7.1	Access to the operating menu via the		Index	 .	39
	SmartBlue App	17			

About this document Picomag IO-Link

1 About this document

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used

1.2.1 Safety symbols

Symbol	Meaning		
▲ DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.		
A WARNING	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.		
▲ CAUTION	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.		
NOTICE	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.		

1.2.2 Electrical symbols

Symbol	Meaning			
===	Direct current			
~	Alternating current			
$\overline{\sim}$	Direct and alternating current			
Ground connection A grounded terminal which, as far as the operator is concerned, is grounding system.				

1.2.3 Communication symbols

Symbol	Meaning
*	Bluetooth Wireless data transmission between devices over a short distance.

1.2.4 Symbols for certain types of information

Symbol	Meaning	
	Permitted Procedures, processes or actions that are permitted.	
✓ ✓	Preferred Procedures, processes or actions that are preferred.	

Picomag IO-Link About this document

Symbol	Meaning	
X	Forbidden Procedures, processes or actions that are forbidden.	
Tip Indicates additional information.		
Reference to documentation		
A	Reference to page	
	Reference to graphic	
Notice or individual step to be observed		
1., 2., 3	Series of steps	
L-	Result of a step	

1.2.5 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
A, B, C,	Views

1.3 **Documentation**



For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer*: Enter the serial number of the measuring device (www.endress.com/deviceviewer)
- The Endress+Hauser Operations App: Enter the serial number of the measuring device or scan the 2-D matrix code on the measuring device.

1.4 Registered trademarks

❷ IO-Link[®]

Is a registered trademark. It may only be used in conjunction with products and services by members of the IO-Link Community or by non-members who hold an appropriate license. For more detailed information on the use of IO-Link, please refer to the rules of the IO-Link Community at: www.io.link.com.

Bluetooth® wireless technology



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license.

Apple[®]

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

Basic safety instructions Picomag IO-Link

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Designated use

Application and media

The measuring device described in these Brief Operating Instructions is intended only for flow measurement of liquids with a minimum conductivity of 20 μ S/cm.

To ensure that the measuring device remains in proper condition for the operation time:

► Use the measuring device only for media against which the process-wetted materials are adequately resistant.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

A WARNING

Danger of breakage due to corrosive or abrasive fluids!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ► Ensure the resistance of all fluid-wetted materials in the process.
- ► Keep within the specified pressure and temperature range.

Residual risks

WARNING

The electronics and the medium may cause the surfaces to heat up. This presents a burn hazard!

► For elevated fluid temperatures, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

► Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

▶ Do not ground the welding unit via the measuring device.

Picomag IO-Link Basic safety instructions

2.4 Operational safety

Risk of injury!

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

2.7 Device-specific IT security

2.7.1 Access via the SmartBlue App

Two access levels (user roles) are defined for the device: the **Operator** user role and the **Maintenance** user role. The **Maintenance** user role is the default setting.

If a user-specific access code is not defined (in the **Set access code** parameter), the default setting **0000** continues to apply and the **Maintenance** user role is automatically enabled. The device's configuration data are not write-protected and can be edited at all times.

If a user-specific access code has been defined (in the **Set access code** parameter), all the parameters are write-protected and the device is accessed with the **Operator** user role. The previously defined access code must first be entered again before the **Maintenance** user role is enabled and all the parameters can be write-accessed.


2.7.2 Access via Bluetooth® wireless technology

Signal transmission via Bluetooth® wireless technology uses a cryptographic technique tested by the Fraunhofer Institute

- The device is not visible via *Bluetooth*® wireless technology without the SmartBlue App.
- Only one point-to-point connection is established between a sensor and a smartphone or tablet
- The *Bluetooth*® wireless technology interface can be disabled via SmartBlue.

3 Incoming acceptance and product identification

3.1 Incoming acceptance



- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
 - Depending on the device version, the CD-ROM might not be part of the delivery! The Technical Documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section .

3.2 Product identification

The following options are available for identification of the measuring device:

- The device label
- Order code with breakdown of the device features on the delivery note
- Enter the serial number on the device label in *W@M Device Viewer* (www.endress.com/deviceviewer): all the information about the measuring device is displayed.
- Enter the serial number on the device label into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the measuring device with the *Endress+Hauser Operations App*: all the information about the measuring device is displayed.

3.2.1 Symbols on measuring device

Symbol	Meaning
Δ	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
[i	Reference to documentation Refers to the corresponding device documentation.

Storage and transport Picomag IO-Link

4 Storage and transport

4.1 Storage conditions

Observe the following notes for storage:

- ► Store in the original packaging to ensure protection from shock.
- ► Store in a dry place.
- ▶ Do not store outdoors.

Storage temperature → 🗎 34

4.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.

Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.

4.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable: Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.


Picomag IO-Link Installation

5 Installation

5.1 Installation conditions

5.1.1 Mounting position


Mounting location



Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow: $h \ge 2 \times DN$

Inlet and outlet runs

Observe the following inlet and outlet runs to comply with accuracy specifications:



Installation dimensions: information on the dimensions and installed lengths of the device $\rightarrow \stackrel{\triangle}{=} 35$

5.2 Mounting the measuring device


A WARNING

Burn hazard!

If medium temperatures or ambient temperatures exceed 50 °C, areas of the housing can heat to over 65 °C.

▶ Safeguard the housing so that it cannot be touched accidentally.

Picomag IO-Link Installation



- 1
- 2 3 4 5
- Pipe Seal (not supplied) Adapter: available adapters → 🖺 33 Seal (included in delivery) Measuring device connection

Picomag IO-Link Electrical connection

6 Electrical connection


6.1 Connection conditions

6.1.1 Requirements for connecting cables

National regulations and standards apply.

Connecting cable	M12 × 1 A-coded
Conductor cross-section	At least 0.12 mm ² (AWG26)
Temperature range	−10 to +80 °C (+14 to +176 °F)
Degree of protection	IP65/67

6.1.2 Pin assignment, device plug



A Socket


B Connector

Pin	Assignment	Description	
1 L+ Supply voltage + (18 to 30 V _{DC} /max. 3 W)		Supply voltage + (18 to 30 V _{DC} /max. 3 W)	
2 Output 2 Output 2, can be configured independently of output 1 3 L- Supply voltage - 4 Output 1 Output 1, can be configured independently of output 2		Output 2, can be configured independently of output 1	
		Supply voltage -	
		Output 1, can be configured independently of output 2	

Electrical connection Picomag IO-Link


Switch/pulse output configuration version

Configurable switching behavior:



- 1) positive negative positive (high side switch)
- 2) negative positive negative (low side switch)


Current output configuration version



- 1 Current output, active, 4 to 20 mA
- A Socket
- B Connector
- L+ Supply voltage +
- L- Supply voltage -

The current flows from the output to L-. The maximum load may not exceed 500 Ω . A bigger load distorts the output signal.

Voltage output configuration version



A00330


- 2 Voltage output, active, 2 to 10 V
- A Socket
- B Connector
- L+ Supply voltage +
- L- Supply voltage -

Picomag IO-Link Electrical connection

The voltage from the output applies to L-. The load must be at least 500 Ω . The output is overload-resistant.

Status input configuration version

- 15 V (switch-on threshold)
- 5 V (switch-off threshold)



■ 3 Status input

A Socket

B Connector

L+ Supply voltage +

L- Supply voltage -

Internal resistance: 7.5Ω

IO-Link configuration version

ho Option only available for output 1 in the **Output 1**ightarrow ho 22 submenu


The measuring device has a Type 2 IO-Link communication interface with a second IO function on pin 2 and with a baud rate of 38 400. This requires an IO-Link-enabled module (IO-Link Master) for operation. The IO-Link communication interface allows direct access to the process and diagnostics data.

6.2 Connecting the measuring device

NOTICE

The measuring device may only be installed by properly trained technicians.

- ► Comply with national and international regulations regarding the installation of electrotechnical systems.
- ▶ Power supply according to EN 50178, SELV, PELV or Class 2.
- 1. De-energize the system.
- 2. Connect the measuring device via the connector.



A003300

In the case of non-grounded pipes:

The device must be grounded using the ground terminal accessory.

Electrical connection Picomag IO-Link

6.3 Post-connection check

Are cables or the device undamaged (visual inspection)?		
Do the cables have adequate strain relief?		
Is the connector connected correctly?		
Does the supply voltage match the specifications on the measuring device?		
Is the pin assignment of the connector correct?		
Is the potential equalization established correctly?		

Picomag IO-Link Operation options

7 Operation options

7.1 Access to the operating menu via the SmartBlue App

The device can be operated and configured via the SmartBlue App. In this case, the connection is established via the Bluetooth® wireless technology interface.

Supported functions

- Device selection in Live List and access to the device (login)
- Configuration of the device
- Access to measured values, device status and diagnostics information

The SmartBlue App is available for free download for Android devices (Google Playstore) and iOS devices (iTunes Apple Shop) : *Endress+Hauser SmartBlue*

Directly to the app with the QR code:



A0033202

System requirements

- Devices with iOS:
 - iPhone 4S or higher, from iOS9.0
 - iPad2 or higher, from iOS9.0
 - iPod Touch 5th generation or higher, from iOS9.0
- Devices with Android:

Android 4.4 KitKat or higher

Download the SmartBlue App:

- 1. Install and start the SmartBlue App.
 - → A Live List shows all the devices available.

 The list displays the devices with the configured tag name. The default setting for the tag name is **EH_DMA_XYZZ** (XYZZ = the last 7 digits of the device serial number).
- 2. Select the device from the Live List.
 - The Login dialog box opens.

Logging in:

- 3. Enter the user name: **admin**.
- 4. Enter the initial password: serial number of the device.
- 5. Confirm your entry.
 - ► The main menu opens.
- Navigate through the various items of information about the device: swipe the screen to the side.

System integration Picomag IO-Link

8 System integration

The measuring device has an IO-Link communication interface. The IO-Link interface allows direct access to process and diagnostics data and enables the user to configure the measuring device on the fly.

Properties:

- IO-Link Specification: Version 1.1
- IO-Link Smart Sensor Profile 2nd Edition
- SIO mode: yes
- Speed: COM2 (38.4 kBaud)
- Minimum cycle time: depends on device and is defined by a number of factors including the process data to be transmitted.

10 ms

- Process data width: depends on device and is defined by a number of factors including the process data to be transmitted.
 80 bit
- IO-Link data storage: yes
- Block configuration: no
 - More information on IO-Link is available at www.io-link.com

8.1 Overview of device description files

Current version data for the device

Firmware version	01.00.zz	 On the title page of the Operating instructions On the device label Parameter Firmware version System → Device info → Firmware version
Release date of firmware version	09.2017	
Profile version	1.1Smart Sensor Profile	

8.2 Device master file

In order to integrate field devices into a digital communication system, the IO-Link system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate.

These data are available in the device master file (IODD 1) which is provided to the IO-Link Master via generic modules when the communication system is commissioned.

The IODD can be downloaded as follows:

■ Endress+Hauser: www.endress.com

■ IODDfinder: ioddfinder.io-link.com

1)

IO Device Description

Picomag IO-Link Commissioning


9 Commissioning

9.1 Switching ON the measuring device

Once the supply voltage has been switched on, the measuring device adopts the normal mode after a maximum of 5 s. During the start-up phase, the outputs are in the same state as the measuring device in the switched-off state.

9.2 Configuring the measuring device

Overview of the operating menu



Commissioning Picomag IO-Link

9.2.1 Configuring the display

The **Display** submenu contains all the parameters that can be configured for the configuration of the onsite display.

Navigation

Menu: "System" \rightarrow Display

Parameter overview with brief description

Parameter	Description	Selection/input	Factory setting
Format display	Select how measured values are shown on the display.	Display value 1st line + display value 2nd line: Volume flow + temperature Volume flow + totalizer Temperature + totalizer	Volume flow + temperature
Rotation display	Select local display rotation.	 Auto (automatic) The display rotates automatically depending on the installation position 0° Can be read in the horizontal installation position with flow from left to right ≈ → □ □ □ A0033013 90° Can be read in the vertical installation position with flow from bottom to top 	Auto
		 180° Can be read in the horizontal installation position with flow from right to left 	
		□	
		 270° Can be read in the vertical installation position with flow from top to bottom 	
Backlight	Set the intensity of the backlighting.	0 to 100 %	50 %

Picomag IO-Link Commissioning

9.2.2 Configuring system units

In the **System units** submenu, you can configure the units of all measured values.

Navigation

Menu: "Application" \rightarrow System units

Parameter overview with brief description

Parameter	Description	Options	Factory setting
Volume flow unit	Select volume flow unit.	• l/s, m³/h, l/min • gal/min (us)	l/min
Volume unit	Select volume unit.	 ml, l, m³ fl. oz (us), gal (us) 	ml
Temperature unit	Select temperature unit.	• °C • °F	°C
Totalizer unit	Select totalizer unit.	 l, m³ 1000 l, 1000 m³ fl. oz (us), gal (us) 1000 gal (us) 	m³

9.2.3 Setting the installation direction and measurement

The **Sensor** submenu contains parameters for specific settings of the measuring device.

Navigation

Menu: "Application" \rightarrow Sensor

Parameter overview with brief description

Parameter	Description	Selection/input	Factory setting
Installation direction	Select the installation direction.	 Flow in arrow direction (forwards) Positive flow measurement in the direction of the arrow. Flow against arrow direction (backwards) Positive flow measurement in the opposite direction of the arrow. 	Flow in arrow direction (forwards)
On value	Enter the on value for low flow cut off.	Positive floating point number A flow measured value that is less than the value of the on value forces the display to zero. In the event of plant downtime, this prevents the totalizer from continuing to totalize even though there is no flow.	Depends on the nominal diameter: DN 15 (½"): 0.4 l/min (0.1 gal/min) DN 20 (¾"): 0.75 l/min (0.2 gal/min) DN 25 (1"): 1.2 l/min (0.3 gal/min) DN 50 (2"): 5.0 l/min (1.3 gal/min)
Damping	Enter the time constant for damping the flow measured value.	0 to 10 s	0 s

Commissioning Picomag IO-Link

9.2.4 Configuring the IO modules

The measuring device has two signal inputs or signal outputs that can be configured independently of one another:

■ Current output → 🗎 22

■ Pulse output→ 🗎 22

■ Switch output → 🗎 23

■ Voltage output → 🗎 24

■ Status input → 🗎 25

Navigation

Menu: "Application" \rightarrow Output 1 Menu: "Application" \rightarrow Output 2

Parameter overview with brief description

Parameter	Description	Options	Factory setting
I/O module 1 type	Select the operating mode of output 1.	 Pulse output Current output Switch output Voltage output Digital input IO-Link Off 	IO-Link
I/O module 2 type	Select the operating mode of output 2.	 Pulse output Current output Switch output Voltage output Digital input Off 	Switch output

Configuring the current output

The Current output submenu contains all the parameters that must be configured for the configuration of the current output.

The output is used to output process variables by analog means in the form of a 4-20 mA current.

Navigation

Menu: "Application" \rightarrow Output $1 \rightarrow$ Current output Menu: "Application" \rightarrow Output $2 \rightarrow$ Current output

Parameter overview with brief description

Parameter	Description	Selection/input	Factory setting
Assign current output	Select process variable for current output.	OffVolume flowTemperature	Volume flow
4 mA value	Enter 4 mA value.	Floating point number with sign	0 l/min
20 mA value	Enter 20 mA value.	Floating point number with sign	Depends on the nominal diameter: DN 15 (½"): 25 l/min (6.6 gal/min) DN 20 (¾"): 50 l/min (13.2 gal/min) DN 25 (1"): 100 l/min (26.4 gal/min) DN 50 (2"): 750 l/min (198.1 gal/min)

Configuring the pulse output

The Pulse output submenu contains all the parameters that must be configured for the configuration of the pulse output.

Navigation

Picomag IO-Link Commissioning

Menu: "Application" \rightarrow Output $1 \rightarrow$ Pulse output Menu: "Application" \rightarrow Output $2 \rightarrow$ Pulse output

Parameter overview with brief description

Parameter	Description	Entry	Factory setting
Value per pulse	Enter the value for the pulse output.	Floating point number with sign	Depends on the nominal diameter: DN 15 (½"): 0.5 l/min (0.1 gal/min) DN 20 (¾"): 1.0 l/min (0.3 gal/min) DN 25 (1"): 2.0 l/min (0.5 gal/min) DN 50 (2"): 10.0 l/min (2.6 gal/min)

The current pulse repetition frequency is calculated from the current flow and the configured pulse value:

Pulse repetition frequency = flow/pulse value

Example

• Flow: 300 l/min (79.25 gal/min)

■ Pulse value: 0.001 l

■ Pulse repetition frequency = 5 000 Pulse/s

• The maximum pulse repetition frequency is 10 kHz.

The Pulse output only outputs positive flow components in the set installation direction. Negative flow components are ignored and not balanced.

Configuring the switch output

The Switch output submenu contains all the parameters that must be configured for the configuration of the switch output.


Navigation

Menu: "Application" \rightarrow Output $1 \rightarrow$ Switch output Menu: "Application" \rightarrow Output $2 \rightarrow$ Switch output

Parameter overview with brief description

Parameter	Description	Selection/input	Factory setting
Polarity	Select the switching behavior.	 NPN (low-side-switch) Switches load to low side to L- PNP (high-side-switch) Switches load to high side to L+ 	PNP (high-side-switch)
Switch output function		 Diagnostic behavior The output switches when an event with the status signal F occurs Off The switch output is permanently switched off (open, non-conductive). On The switch output is permanently switched on (closed, conductive). Limit volume flow Indicates if a specified limit value has been reached for the process variable. Limit temperature Indicates if a specified limit value has been reached for the process variable. Range volume flow Range temperature Empty pipe detection Output switches on when empty pipe detection is active. 	Diagnostic behavior
Switch-on value	Enter the measured value for the switch-on value.	Floating point number with sign	Country-specific: 1000 m³/h 1000 gal/min (us)
Switch-off value	Enter the measured value for the switch-off value.	Floating point number with sign	Country-specific: 1000 m³/h 1000 gal/min (us)

Commissioning Picomag IO-Link



- 3.1 Input variables
- 3.2 Switch output
- A On-value (lower range limit)
- B Off-value (upper range limit)
- D Window

- 4.1 Input variables
- 4.2 Switch output
- A On-value (lower range limit)
- B Off-value (upper range limit)
- D Window

Configuring the voltage output

The Voltage output submenu contains all the parameters that must be configured for the configuration of the voltage output.

Navigation

Menu: "Application" \rightarrow Output $1 \rightarrow$ Voltage output


Menu: "Application" \rightarrow Output 2 \rightarrow Voltage output

Parameter overview with brief description

Parameter	Description	Selection/input	Factory setting
Assign voltage output	Select process variable for voltage output.	 Off Volume flow Temperature	Volume flow
2 V value	Enter the lower-range value.	Floating point number with sign	0 l/min
10 V value	Enter the upper-range value.	Floating point number with sign	Depends on the nominal diameter: DN 15 (½"): 25 l/min (6.6 gal/min) DN 20 (¾"): 50 l/min (13.2 gal/min) DN 25 (1"): 100 l/min (26.4 gal/min) DN 50 (2"): 750 l/min (198.1 gal/min)

Picomag IO-Link Commissioning

Unidirectional flow measurement (Q)




A Lower-range value = 0

- B Upper-range value
- Q Flow

• Current I or voltage U are interpolated linearly between the lower-range value (A) and upper-range value (B).

■ The output range ends at 20.5 mA or 10.5 V.

Bidirectional flow measurement (Q) or temperature measurement (T)



A Lower value

B Upper-range value

Q Flow

• Current I or voltage U are interpolated linearly between the lower-range value (A) and upper-range value (B).

• Rather than having a hard upper and lower limit, the output range ends at 20.5 mA or 10.5 V at the top end, and at 3.8 mA or 1.9 V at the bottom end.

Configuring the status input

The **Digital input** submenu contains all the parameters that must be configured for the configuration of the digital input.

The input is used to control an action with an external voltage signal. The minimum pulse duration is 100 ms.

Navigation

Menu: "Application" \rightarrow Output $1 \rightarrow$ Digital input

Commissioning Picomag IO-Link

Menu: "Application" \rightarrow Output 2 \rightarrow Digital input

Parameter overview with brief description

Parameter	Description	Options	Factory setting
Active level	Select the switching behavior of the digital input.	High Input reacts to high levelLow Input reacts to low level	High
Assign status input	Select process variable for status input.	 Off Reset totalizer Resets the totalizer Flow override Flow measured value = 0 Does not affect the temperature measurement 	Reset totalizer

9.2.5 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, different process variables in the process and the device alarm behavior and to verify downstream signal chains (switching of valves or closed-control loops).

Navigation

Menu: "Diagnostics" \rightarrow Simulation 1

Parameter overview with brief description

Parameter	Description	Selection/input	Factory setting
Simulation process variable	Activate the simulation of process variables.	 Off Simulation is deactivated. On Simulation is activated. Deactivate the simulation again once the test has been performed. 	Off
Volume flow value	Enter the value for volume flow simulation.	Positive floating point number	_
Temperature value	Enter the value for temperature simulation.	Positive floating point number	-

Picomag IO-Link Operation

10 Operation

10.1 Reading measured values

You can read all measured values using the $\boldsymbol{Measured\ values\ }$ submenu.

Navigation

Menu: "Application" \rightarrow Measured values

Parameter overview with brief description

Parameter	Description	Display/options	Factory setting
Volume flow	Displays the volume flow currently measured.	Floating point number with sign	_
Temperature	Displays the temperature currently measured.	Floating point number with sign	-
Totalizer	Displays the current totalizer counter value. The totalizer continuously totalizes only positive flow measured values in the set flow direction. Negative components are not counted.	Floating point number with sign	-
Reset totalizer	Reset the totalizer.	 Cancel The totalizer is not reset. Reset + totalize The totalizer is reset. 	Cancel

Operation Picomag IO-Link

10.2 Configuring Bluetooth

The **Bluetooth configuration** submenu contains all the parameters to configure the Bluetooth connection.

Navigation

Menu: "System" \rightarrow Bluetooth configuration

Parameter overview with brief description

Parameter	Description	Options	Factory setting
Bluetooth	Enable or disable the <i>Bluetooth®</i> wireless technology interface. If the interface is disabled, it can only be re-enabled by tapping the device.	 Disable Disable the interface. The connection to the measuring device is torn down. Enable Enable the interface. The connection to the measuring device is established. 	Enable

10.3 Administration

The **Administration** submenu contains all the parameters that can be used for the administration of the device.

Navigation

Menu: "System" \rightarrow Administration

Parameter overview with brief description

Parameter	Description	Entry/selection/display	Factory setting
Set access code	Enter a user-specific access code to restrict write access to numbers, letters and special characters. Max. 4-digit character string components in the components of the comp		0000
Enter access code	Enter the access code. Restrict write access to parameters in order to protect the device configuration from unauthorized modification.	Max. 4-digit character string comprising numbers, letters and special characters	0000
Device reset	Reset the entire device configuration or some of the configuration to a defined state.	CancelTo factory defaultsRestart device	Cancel
Access status tooling	Displays the access status.	OperatorMaintenance	Maintenance

11 Diagnostics and troubleshooting

11.1 General troubleshooting

For local display

Error	Possible causes	Solution
Local display dark and no output signals	Supply voltage does not match the value indicated on the nameplate.	Apply the correct supply voltage → 🖺 34.
	The polarity of the supply voltage is wrong.	Correct the polarity.
	The connecting cables are not connected correctly.	Check the cable connection and correct if necessary.

For output signals

Error	Possible causes	Solution
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct the parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	Check and correct parameter configuration. Observe limit values specified in the "Technical Data".


For access

Error	Possible causes	Solution
No connection established via Bluetooth	Bluetooth communication is disabled	Check whether the Bluetooth logo is visible on the local display or not. Re-enable Bluetooth communication by tapping the device.
No communication with device via SmartBlue App	No Bluetooth connection	Enable Bluetooth function on smartphone or tablet.
		The device is already connected with another smartphone/tablet.
Login via SmartBlue App not possible	Device is being put into operation for the first time	Enter initial password (device serial number) and change.
Device cannot be operated via	Incorrect password entered	Enter correct password.
SmartBlue App	Password forgotten	Contact Endress+Hauser Service.

11.2 Diagnostic information on local display

11.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required

Symbol	Meaning
F	Failure An operating error has occurred. The measured value is no longer valid.
С	Function check The device is in simulation mode.
S	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)

Diagnostic behavior

Diagnostic message	Meaning	
8	 Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. 	
W	Function check Process measured values are simulated to test the outputs/wiring.	
<u>^</u>	 Warning Measurement is resumed. Measuring operation with limited accuracy The signal outputs and totalizers are not affected. A diagnostic message is generated. 	

Diagnostics behavior of outputs

Output	Diagnostic behavior	
Switch output	 Setting for reporting events with the status signal F Switch output is switched on if an event occurs No further response to events with other status signals 	
Pulse output	 Pulse output stops if events with the status signal F occur No further response to events with other status signals 	
Totalizer	 Totalizing stops if events with the status signal F occur No further response to events with other status signals 	
Current output	 3.5 mA output to report events with the status signal F No further response to events with other status signals 	
Voltage output	 1.75 V output to report events with the status signal F No further response to events with other status signals 	
IO-Link	 All events reported to the Master Events read and processed further by the Master 	

11.3 Overview of diagnostic events

Diagnostic event	Event text	Reason	Remedial measures	Status signal [ex- factory]
181	Coil. circ. fail.	Coil/frequency failure Coil current PWM outside tolerance range	Replace the measuring device.	F
180	Temp. circ. fail.	Temperature sensor open circuit/short-circuit	Replace the measuring device.	
201	Device fail.	No communication to ADC/Nordic/BMA	Replace the measuring device.	F
283	Memory fail.	CRC failure	Reset to factory settings.	F
446	I/O 1 overload	Overload at output 1	Increase load impedance.	С
447	I/O 2 overload	Overload at output 2	Increase load impedance.	С
485	Simulation act.	Measured value simulation active (via remote configuration)	-	С
453	Flow override	Flow override active (via auxiliary input)	_	С
441	I-Out 1 range	I-output 1 at range limit	Adjust parameter or process.	S
444	U-Out 1 range	U-output 1 at range limit	Adjust parameter or process.	S
443	P-Out 1 range	P-output 1 at range limit	Adjust parameter or process. S	
442	I-Out 2 range	I-output 2 at range limit	t Adjust parameter or process. S	
445	U-Out 2 range	U-output 2 at range limit	Adjust parameter or process. S	
448	P-Out 2 range	P-output 2 at range limit	Adjust parameter or process. S	
962	Empty pipe	Pipe is completely or partially empty	Adjust the process.	S

Diagnostic event	Event text	Reason	Remedial measures	Status signal [ex- factory]
834	Temperat. range	Medium temperature outside the permitted range	Adjust the process.	S
841	Flow range	Flow rate outside the permitted range	Adjust the process.	S

11.4 Pending diagnostic events

Navigation

 $Menu: "Diagnostics" \rightarrow Diagnostics$

Parameter overview with brief description

Parameter	Prerequisite	Description	Display
Actual diagnostic	A diagnostic event has occurred.	Displays the current diagnostic event along with the diagnostic information. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.

11.5 Device information

The **Device info** submenu contains all parameters that display different information for device identification.

Navigation

Menu: "System" \rightarrow Device info

Parameter overview with brief description

Parameter	Description	Display
Device name	Displays the name of the measuring device.	Picomag
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).
Serial number	Displays the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.
Firmware version	Displays the device firmware version installed.	Character string in the format xx.yy.zz
Extended order code	Displays the extended order code.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).

11.6 Firmware history

Release date	Firmware version	Firmware changes	Documentation type	Documentation
09.2017	01.00.zz	Original firmware	Operating Instructions	BA01697D/06/EN/01.17

Picomag IO-Link Accessories

12 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Technical data Picomag IO-Link

13 Technical data

13.1 Input

Measured values • Volume flow

Temperature

Totalizer

Measuring range (upper-range value E) DN 15 ($\frac{1}{2}$ "): 25 l/min (6.6 gal/min)

DN 20 (¾"): 50 l/min (13.2 gal/min)
DN 25 (1"): 100 l/min (26.4 gal/min)
DN 50 (2"):750 l/min (198.1 gal/min)

13.2 Output

Output	Max. load
Current output	500Ω The load may not be any greater
Voltage output	500Ω The load resistance may not any smaller
Digital output (SmartBlue App)	Bluetooth® wireless technology The device has a <i>Bluetooth®</i> wireless technology interface and can be operated and configured via the SmartBlue App.
	 The range under reference conditions is 10 m (33 ft) Incorrect operation by unauthorized persons is prevented by means of encrypted communication and password encryption. The Bluetooth® wireless technology interface can be deactivated.
Signal on alarm	 Status signal (as per NAMUR Recommendation NE 107) Plain text display with remedial action

13.3 Power supply

 $\begin{tabular}{lll} Supply voltage range & 18 to 30 V_{DC} (SELV, PELV, Class 2) \\ Power consumption & Max. 3 W (excluding outputs IO1 and IO2) \\ \end{tabular}$

13.4 Performance characteristics

Volume flow measurement	
Maximum measured error	±2 % o.r. ±0.5 % o.f.s.
Repeatability	± 0.2 % o.r. (95% confidence interval, measuring time 30 s)
Response time	The response time depends on the configuration (damping).
Medium temperature measurement	
Maximum measured error	±2.5 ℃
Repeatability	$\pm 0.5~^{\circ}\text{C}$ (95% confidence interval, measuring time 30 s)

13.5 Installation

→ 🖺 11

13.6 Environment

Ambient temperature range $-10 \text{ to } +60 \, ^{\circ}\text{C (} +14 \text{ to } +140 \, ^{\circ}\text{F)}$ Storage temperature $-25 \text{ to } +85 \, ^{\circ}\text{C (} -13 \text{ to } +185 \, ^{\circ}\text{F)}$

Picomag IO-Link Technical data

Degree of protection IP65/67

Shock resistance 20 g (11 ms) as per IEC/EN60068-2-27


 $\begin{tabular}{ll} Vibration resistance & Acceleration up to 5 g (10 to 2000 Hz) as per IEC/EN60068-2-6 \\ Electromagnetic compatibility (EMC) & In accordance with IEC/EN61326 and/or IEC/EN55011 (Class A) \\ \end{tabular}$

13.7 Process

 $\begin{tabular}{ll} Medium temperature range & -10 to +70 °C (+14 to +158 °F) \\ Medium properties & Liquid, conductivity > 20 μS/cm \\ \end{tabular}$

 $Pressure \hspace{1.5cm} \text{Max. 16 bar}_{rel}$

13.8 Mechanical construction



Dimensions in SI units

DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	G [mm]	H [mm]	I [mm]
15, 20, 25	110	73	40.5	69.5	M12 × 1	43	½" ¾" 1"	56	56
50	200	113	80	120	M12 × 1	58	2"	86	86

Dimensions in US units

DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	F [in]	G [in]	H [in]	I [in]	
¹ / ₂ , ³ / ₄ , 1	4.33	2.87	1.59	2.74	M12 × 1	1.69	½" ¾" 1"	2.20	2.20	
2	7.87	4.45	3.15	4.72	M12 × 1	2.28	2"	3.39	3.39	

Weight in SI units

DN [mm]	Weight [kg]
15	0.34
20	0.35
25	0.36
50	1.55

Technical data Picomag IO-Link

Weight in US units

DN [in]	Weight [lbs]
1/2"	0.75
3/4"	0.77
1"	0.79
2"	3.42


Materials

Component	Material
Measuring tube	PEEK
Electrodes, temperature sensor	1.4404/316L
Process connection	1.4404/316L
Housing	1.4404/316L
Seal	FKM
Display window	Polycarbonate

13.9 Operability

Onsite display

The device has an onsite display:



- 1 Tag name (configurable)
- Measured variable 1 (configurable), with sign 2
- 3 Measured variable 2 (configurable), with sign
- Active Bluetooth connection
- Active I/O-Link connection
- Device status

Display element

A maximum of 2 readings from the 3 measured variables (volume flow, temperature, totalizer) can be displayed

Remote operation	Via Bluetooth® wireless technology	
Digital communication	Via IO-Link	

13.10 Certificates and approvals

The measuring system is in conformity with the statutory requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

Radio approval

The measuring device has radio approval.

For detailed information on the radio approval, see the Appendix → ■ 38

Pressure Equipment

Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art. 4, Par. 3 of the Pressure Equipment Directive 2014/68/EU. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EC.

Technical data

 $_{\text{C}}UL_{\text{US}}$ listing

Picomag IO-Link

The measuring device is UL-listed.

Appendix Picomag IO-Link

14 Appendix

14.1 Radio approvals

14.1.1 Europe

This device meets the requirements of the Telecommunications Directive RED 2014/53/EU:

- EN 300 328 V2.1.1
- EN 301 489-1 V1.9.2
- EN 301 489-17 V2.2.1
- EN 62311: 2008


14.1.2 Canada and USA

English

This device complies with Part 15 of the FCC Rules and with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.



Français

Le présent appareil est conforme aux CNR d'industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- L'appareil ne doit pas produire de brouillage, et
- L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



14.1.3 Other countries

Other national approvals are available on request.

Picomag IO-Link Index

Index

A	Installation conditions
About this document 4	IO-Link configuration version
Accessories	M
Application 38	Materials
Application Media	Mounting location
Wedia	Mounting position
В	Mounting the measuring device
Basic safety instructions 6	0
Bidirectional flow measurement (Q) or temperature	Operation
measurement (T)	Operation options
C	SmartBlue App
CE mark	Operational safety
Commissioning	Overview of device description files
Configuring system units	Overview of diagnostic events
Configuring the current output	Overview of the operating menu
Configuring the display	P
Configuring the IO modules	Packaging disposal
Configuring the measuring device	Pending diagnostic events
Configuring the pulse output	Pin assignment, device plug
Configuring the voltage output	Post-connection check
Connecting the measuring device	Pressure Equipment Directive
Connection conditions	Product safety
Current output configuration version	R
Current version data for the device	Radio approval
D	Radio approvals
Declaration of Conformity	Reading measured values
Designated use 6	Registered trademarks
Device information	Requirements for connecting cables
Device master file	Requirements for personnel 6
Diagnostic behavior	S
Diagnostic information on local display	Setting the installation direction and measurement 21
Diagnostic message	Status input configuration version
Dimensions in SI units	Status signals
Dimensions in US units	Storage conditions
Document function 4	Storage temperature
Documentation 5	Switch/pulse output configuration version
r.	Switching ON the measuring device
Electrical connection	System integration
Electrical connection	
F	T
Field of application	Technical data
Residual risks 6	Certificates and approvals
Firmware history	Environment
I	Installation
Identifying the measuring device 8	Mechanical construction
Incoming acceptance	Operability
Inlet and outlet runs	Output
Inspection	Performance characteristics
Received goods	Power supply
Installation	Process

Index Picomag IO-Link

Temperature range Storage temperature
Transporting the measuring device
Troubleshooting General
U
Unidirectional flow measurement (Q)
Using measuring device Borderline cases 6 Incorrect use 6
V
Voltage output configuration version 14
W
W@M Device Viewer
Transport (notes) 10 Weight in SI units 35 Weight in US units 36 Workplace safety 6



