

A close-up photograph of a person's arm resting on a grey, textured surface. A blue Whoop fitness tracker is visible on the wrist. The person is wearing a gold ring on their middle finger. The background is blurred.

USER MANUAL

GEN 5

WHOOP



WHOOP // USER MANUAL

MEMBERSHIP TIERS



WHOOP ONE

WHOOP 5.0 Sensor (WG50)
CoreKnit Band
Basic Charger (WD50)



WHOOP PEAK

WHOOP 5.0 Sensor (WG50)
SuperKnit Band
Wireless PowerPack (WB50)
USB-C Cable (WC50)



WHOOP LIFE

WHOOP MG Sensor (WS50)
Coreknit Band
Basic Charger (WB50)
USB-C Cable (WC50)

**WHOOP unveils
three membership
tiers, each
featuring a unique
combination of
Gen 5 hardware
options**



WHOOP // USER MANUAL

HARDWARE PORTFOLIO



WHOOP MG
(WS50)



WHOOP 5.0
(WG50)



WIRELESS POWERPACK
(WB50)

Cable (WC50)



BASIC CHARGER
(WD50)

State-of-the-art medical grade **MG sensor** paired with our signature knit designed for 24/7 wear

State-of-the-art **5.0 sensor** delivering the core capabilities paired with an everyday-performance band

Wireless and waterproof **battery pack** that provides charging on-the-go while you wear it

Includes a USB-C to USB-C cable (130 cm)

Wired charging with an integrated 1 meter USB-C cable

No built-in battery. Requires to be plugged into power for charging




WHOOP // USER MANUAL

HOW TO USE

Same process can be followed for both WHOOP MG (WS50) and WHOOP 5.0 (WG50) sensors

HOW TO WEAR

Learn the basics on how to wear your WHOOP




OPEN

Pull open the clasp




ADJUST

Your band should feel snug but comfortable. Adjust the tightness by pulling the loose end of the band




CLOSE

Snap the clasp closed with the WHOOP logo facing you



HOW TO CHARGE

Slide the PowerPack (WB50) or Basic Charger (WD50) on to charge your WHOOP



Use the provided USB-C (WC50) cable to ensure the PowerPack (WB50) is charged, prior to charging your WHOOP

Ensure Basic Charger (WD50) is plugged into power to be able to charge your WHOOP



WHOOP // USER MANUAL

GETTING STARTED

Same process can be followed for both
WHOOP MG (WS50) and WHOOP 5.0 (WG50) sensors

1



DOWNLOAD

Download the WHOOP app in the Apple or Google Play store. Login or create an account.

2



CHARGE

PowerPack (WB50)

Ensure the pack is charged using the provided USB-C cable.

Basic Charger (WD50)

Ensure the USB-C cable is plugged into power.

3



WAKE UP TO PAIR

Slide the PowerPack or Basic Charger on your WHOOP to begin pairing

A blue light will appear on the side of your WHOOP, which indicates it is ready to pair.

Make sure Bluetooth is enabled on your phone.




WHOOP // USER MANUAL

GETTING STARTED

Same process can be followed for both WHOOP MG (WS50) and WHOOP 5.0 (WG50) sensors

WHOOP APP

PAIRING FLOW SCREENS



The app will initiate search for your WHOOP device

All nearby WHOOP devices in pairing mode are shown

Your WHOOP device will initiate pairing with the phone

Your WHOOP device is now paired & ready to use!



WHOOP // USER MANUAL

BATTERY

Same process can be followed for both WHOOP MG (WS50) and WHOOP 5.0 (WG50) sensors

BATTERY STATUS

You can check the current battery status on your **WHOOP sensor** (WS50 & WG50) and **PowerPack** (WB50) by firmly tapping twice on the top surface of the device

The LED shown below will light up to indicate the status



Color	Charge Level
Green	50% to 100%
Yellow	25% to 49%
Red	< 25%

Color	Charge Level
Green	90% to 100%
Yellow	25% to 89%
Red	< 25%



VIA THE WHOOP APP

You can also check the current battery status on your WHOOP app by viewing the highlighted area

This icon will also indicate if the WHOOP sensor is actively being charged



WHOOP // USER MANUAL

DEVICE SETTINGS

Same process can be followed for both WHOOP MG (WS50) and WHOOP 5.0 (WG50) sensors

DEVICE SETTINGS

CONNECTED TO MARTIN'S WHOOP

LAST SYNC 10:35 AM

STATUS ADVANCED

80 % WHOOP 4.0

FIRMWARE UPDATE AVAILABLE

BROADCAST HEART RATE TO COMPATIBLE APPS & DEVICES

UPDATING DEVICE

Keep your WHOOP and phone nearby during the update.

CANCEL

DEVICE SETTINGS

CONNECTED TO MARTIN'S WHOOP

LAST SYNC 10:35 AM

STATUS ADVANCED

DEVICE ID W00234563

FIRMWARE 5.13.0.0

PAIR A DEVICE

UNPAIR DEVICE

FIRMWARE CHECK

ERASE DEVICE DATA

REBOOT DEVICE

FIRMWARE UPDATES

All required firmware updates are shown in the Device Settings section in the app

Additional device settings can be accessed through the “Advanced” tab