





Packing List



Instructions for the buttons /ports/indicators






Buttons	Description			
Power button	0	Press and release Press and held for two seco Press and held for eight sec	nds Power on/	
Return button	0	Press and release Ri Press and hold for two seconds	atum to previous Return to Ho	
Touchpad	<u>-</u>		Slide Tap	Scroll Enter
Volume button)	Adjusting sour	d volu e


Ports	Description 3.5m carphone (Volu a adjust ent/play/pause function on the earphone eatle is not supported)	
Headphone jack		
Micro-USB port	Connect to the charger to charge (device does no charge when worn)Can be connected to a co-pu- ter for data transfers, OTG supported	
TF card slot	Opening up the dust cover, then insert TF card as shown in the picture	

Indicator status	Description	
Steady blue light	Power on/Device is operating normally	
Steady green light	Charging complete	
Steady red light	Low battery	
Steady yellow light	Device is charging	



Mounting and adjusting head strap

The head strap passes through the rings on both sides and the top respectively, and then attach to the appropriate position





Touchpad instructions

- Turn your head to move the screen cursor to the desired menu.
 Tap on the touchpad with your finger.。





p

Network Connection Directions.

- Connect the Internet for online services, games and applications.

 1.Enter the system settings, get into the WiFi settings.

 2.Select a network, enter the password by tapping letters and numbers from the keyboard popped up. Touchpad would be used.


 3.Click "complete" and wait for the the connection to the network.



Cursor positioning instruction



Selection



Safety information

Please read the following safety information prior to using the device to ensure your safety and the correct use of the device.

Please adhere to the following advises to prevent incidents such as fires and explosions. -Reuse prevent physical impact like from callains or dispals or damage to the dwize. -Like the dwize together with chargers and other accessories approved by the manufacture.

- Flease do not touch the device with wet or damp hands.
 In addition, please do not use the device in wet environments (such as in the bathroom) or during activities such as swimming.

- Please adhere to the following advises to avoid injury or damage to the device

 —Resea do not pleas or store the device in a location with overly high or but temperatures. We recommend that the device be used in an environment where the temperature is between OC and 40°C.

 - —When the device is not in use, store it in a cool, dry place. Do not expose the lans to direct sunlight or strong light sources to prevent screen burns.
 - Keep the device dry. Please do not use the device outdoors on a rainy or thunderstorm day.
 - —To prevent hearing impairment due to earphone or headphone use, please do not listen at a high volume for a long time.
 - -We do not recommend the use of the daylos by minors aged under 13. When the device is used by minors aged under 13 or by elders aged above 65, a guardian must seek to limit the hours of use and ensure that the user takes breaks in between periods of use.

Any Changes or modifications not expressly approved by the party responsible for Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may

RF warning for Portable device:

cause undesired operation.

The device has been evaluated to meet general RF exposure requirment. The device can be used in portable exposure condition without restriction.

Note: This equipment has been tested and found to comply with the limits for a Class B Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver
- is connected. -Consult the dealer or an experienced radio/TV technician for help.