

Q6703

User Manual



Conventions used in this guide

In this user guide, we use the following symbols to indicate useful and important information:

NOTE

Notes, usage tips, or additional information

Warning

Situations that could cause injury to yourself or others

Caution

Situations that could cause damage to your device or other equipment

Specifications	2
Basics	3
In Box	3
Phone Overview	3

Battery	3	Changing Messaging Settings	28
Turning Phone On or Off.....	4	Google	29
Phone Options	5	Gmail.....	29
Touchscreen Gestures.....	5	Maps	30
Using the Onscreen Keyboard.....	6	Calendar.....	32
Editing Text	7	Play Music	34
Getting Started.....	9	Google Play Store	35
Google Account.....	9	Web.....	37
Getting to Know the Home Screen	10	Chrome	37
Customizing the Home Screen.....	10	YouTube	39
Essential Display Icons.....	11	Wi-Fi	41
Notifications Panel.....	12	Downloads.....	42
Opening & Switching Between Applications	12	Bluetooth.....	43
Sleep Mode.....	13	Using Bluetooth	43
Adjusting Volume	14	Disconnecting or Un-pairing from a Bluetooth Device	43
Searching Your Phone and the Web	14	Connecting to a Bluetooth Headset.....	44
Connecting Your Phone to a Computer.....	15	Sending and Receiving Information Using Bluetooth	44
Phone Calls.....	16	Entertainment.....	46
Making Calls	16	Camera/Camcorder.....	46
Answering or Rejecting Calls	17	Sound Recorder.....	47
Using In-Call Options.....	18	Tools	48
Using Call Log.....	18	Clock	48
Listening to Your Voicemail	19	Calculator.....	48
Using Voice Dialer	20	Settings.....	50
Contacts.....	21	Settings on Your Phone.....	50
About contacts.....	21	Firmware Upgrade	53
Opening Your contacts.....	21	Safety and use	54
Getting Started.....	21	Product safety & warranty information.....	56
Editing/Deleting Contacts	23		
Communicating	24		
Account Setting.....	24		
Messaging.....	25		
About Messaging.....	25		
Sending Messages	25		
Reading Messages	26		
Receiving Emergency Alerts Messages	27		

Specifications

1. Display

- 6.745 HD+/720(RGB)*1600 Display
- Capacitive Touch Screen

2. Camera

- Front camera:2MP
- Rear camera: 8MP

3. Dimensions and Weight

- Dimensions: 172*78.8*9.5mm
- Weight: 180g.

4. Memory

- 32GB (ROM)/3GB (RAM)
- External memory : Supports up to 256GB

5. Operating System

- Android™ 13 GO

6. Connectivity

- WIFI(802.11 b/g/n), Bluetooth4.1

7. Sensors

- Accelerometer; Proximity&Light Sensor;Barometer

8. Power Management (Performance)

Battery Type	Capacity	Standby Time	Talk Time
Lithium-Ion(Li-ion)	5000mAh	Up to 200Hours (8.33Days)	Up to 360minutes

Basics

In Box

The Q6703 comes with the following items included in the box:



Battery

Note that browsing the web frequently, extended data usage, being in a poor signal area, or subjecting the device to extreme temperatures will cause the battery to discharge quicker than normal. To increase battery life, limit your data usage, or turn off GPS and Bluetooth when not required.

Charging your battery


Before you turn on your device and start using it, it is recommended that you charge the battery.

1. Plug the USB cable into the USB power adapter.
2. Plug the power adapter into a standard outlet.
3. Locate the USB port located on the underneath of your device.
4. Plug the other end of the USB cable into the phone's micro USB port.
5. The USB icon on the cable should always face up when connecting the cable to your device as shown.

NOTE

- It is more efficient to charge the battery with your device powered off.
- Battery operating time gradually decreases over time.

Phone Overview





MicroSD Card

Use the microSD card to store your photos, videos, music and certain apps from Google Play™ Store. You can also move and copy files to your computer from your device.

NOTE When you insert or remove the microSD card, you should remove the battery cover.

1. Insert the microSD card

1. Locate the microSD card slot and remove the cover.

Insert the microSD card into the slot with its gold contacts facing right above battery until it clicks into place.



2. Removing the microSD card

1. Remove the microSD card cover.
2. Press the microSD card to eject it from the slot then slide it out the rest of the way.

3. Removing the microSD card while the phone is on

If you need to remove the microSD card while the phone is on, unmount the microSD card first to prevent corrupting or damaging the files in the microSD card.

1. From the Home screen, tap Apps > Settings.
2. Tap Storage >Unmount SD card >OK.
3. Remove the microSD card by following the steps in "Removing the microSD card".

Turning Phone On or Off

1. Turning your phone on

1. Press and hold **Power/Lock**.

NOTE The first time you use your phone you'll need to set it up. See the Getting Started chapter for details.

2. Turning your phone off

1. If the display is off, press **Power/Lock** to turn it back on.
2. Press and hold **Power/Lock** for a few seconds.
3. When Phone options menu appears, tap  **Power off >OK**.

NOTE To turn airplane mode off, press and hold **Power/Lock** and then tap  **Airplane mode** again.

Phone Options

1. Silent mode

1. Press and hold **Power/Lock** to display Phone Options.
2. Tap  **Silent mode**.
 - When you select Silent mode,  is displayed in the Status bar. Ringtones, alerts, and all audible sounds except media and alarms are silenced.


NOTE To turn silent mode off, press and hold **Power/Lock** and then tap .

2. Airplane mode

1. Press and hold **Power/Lock** to display Phone Options.
2. Tap  **Airplane mode**.
 - When you set Airplane mode,  is displayed in the Status bar. Wi-Fi, Bluetooth, and mobile network functions are all disabled.

Touchscreen Gestures

Tap	To select onscreen items such as application and settings icons or press onscreen buttons, simply touch them with your finger.
Tap and hold	To open available options for the item, simply touch and hold your finger on the screen over the item.
Swipe or slide	Quickly drag your finger vertically or horizontally across the screen.
Drag	Tap and hold your finger before you start to drag. While dragging, do not release your finger until the item reaches your desired location.
Flick	Flicking the screen is similar to swiping, but you only need to swipe your finger in lighter and quicker strokes. This finger gesture is always in a vertical direction, such as flicking through the contacts or the message lists.
Rotate	For most screens, you can automatically change the screen orientation from portrait to landscape by turning the phone sideways. When entering text, you can turn the phone sideways to bring up a bigger on-screen keyboard.



Using the Onscreen Keyboard

You can enter text using the onscreen keyboard. Some applications open the keyboard automatically. In others, tap anywhere in a text field to open the keyboard.

1. Tap each letter on the on-screen keypad.
2. Tap and hold a letter for additional key options (not all keys have additional options). Additional key options include numbers and letters with accent marks. If options are available, you will see a box with all the options shown. Slide your finger to select the character you want.
3. Continue until you have finished the word.

You can also use the following icons:

- Tap 3 while you type. When you release the key, the lowercase letters reappear.
- Turn caps lock on. double-tap or touch & hold
- Tap 3, so it changes to . Touch again to return to lowercase.
- Tap 1 you can to delete words, tap 4 you can change to the number and sign keyboard.
- To hide the Android keyboard, press Back .
- When you write a new message, you can tap 2 to skip from the receiver frame to text frame.

NOTE When you type the notification panel will have a “select input method” you can set the input methods.

Adding, Editing or Deleting Words in the User Dictionary

Sometimes you may need to add a word to the predictive text dictionary, for example, a name or a specialized technical word. If you want to add a word to your User dictionary while entering text, double tap the word to highlight it, then tap and hold the word and select **Add ** to dictionary**.

Adding a word manually

1. From the Home screen, tap  Apps >  Settings.
2. Tap  Language & input >Personal dictionary.
3. Press  Add.
4. Type the word >tap OK.

Editing or deleting a word

1. From the Home screen, tap  Apps >  Settings.
2. Tap  Language & input >Personal dictionary.

- To edit words from the dictionary, tap the word you want to edit >Edit > Edit the word > Tap OK.
- To delete words from the dictionary, tap the word you want to delete >Delete.

Editing Text

You can select, copy or cut the text you've entered, then paste it in another text field within the user interface.

NOTE Some applications may offer different text editing methods.

1. Selecting text

1. Tap the text field.
2. Move the cursor to the beginning or end of the desired text by tapping in the location you want the cursor.
3. Tap and hold the text field.
4. Tap **Select word** in the pop-up menu.
 - Or tap **Select all** to select all the text in the text field.
5. Drag your finger to move the text cursor to a letter within the text that you want to select. The selected text is highlighted in orange.

2. Cutting and copying the text

1. Double-click to select the text to cut or copy it.
2. Tap and hold the selected text.
3. Tap **Cut** or **Copy** in the menu that opens.



- If you tap **Cut**, the selected text is removed from the text field. In this case, the text is saved to the clipboard, so that you can paste it into another text field.

3. Pasting the text

1. Cut or copy the text to paste.
2. Tap the text field where you want to paste the text and move the cursor to your desired location.

- You can paste text that you copied from one application into the text field in any other application.

3. Tap and hold then select **Paste** in the pop up menu.

- The text is inserted after the cursor. The text also remains in the clipboard, so you can paste that same text into another location.

Getting Started

Google Account

You must sign in to a Google account to use Gmail, Google Calendar, and other Google applications; to download applications from Google Play Store; to back up your settings to Google servers; and to take advantage of other Google services on your phone.

1. Registering a Google account

Gmail, Google Play Store, and other applications require a valid Google account for use. You will be prompted to login into Google the first time you use these applications.

1. Tap **Existing**>**Sign in** to register your Google account.
 - If you don't have a Google account, tap **New** instead.
See the next section for more details.
2. Enter your Google account **Email** and **Password** > Tap **Sign in**.

2. Creating a new Google account

1. Tap **New** > Enter **First name**, **Last name** and **Email** > Tap **Next**.
2. Enter a password in to the **Type a password**, **Confirm password** fields, then tap **Next**.
 - Password tip: Your password must be a minimum of 8 characters in length.


3. Select **Security question** and enter the **Answer**, which will be needed if you forget your password and then enter a **Secondary Email** >**Create**.
4. Read through Google Terms of Service > Tap **I agree**, **Next**.
5. Enter the letters shown on the screen > Tap **Next** > Tap **Finish**.

3. Adding a Google account

1. From the Home screen, tap  **Apps** >  **Settings**.
2. Tap **Accounts** >  **Add account**.
3. Tap **Google** > Tap **Existing**.
4. Tap **Sign in** to register your Google account.
5. Enter your Google account **Email** and **Password** > Tap **Sign in** >**Finish**.
 - The UL40 supports multiple Google accounts.
 - If you have the same contact across multiple Google accounts, you can merge duplicates into a single item in the contact list.

Getting to Know the Home Screen

1. The Home screen is displayed when the device is in idle mode. You can add your favorite apps, shortcuts, folders and widgets to the Home screen so they're only a tap away.
2. Press  **Home** to return to the center home screen.



1. Previewing the Home screens

1. From any Home screen, tap and hold an application.
2. When you choose a desired Home screen, the application shifts to the selected Home screen.

Customizing the Home Screen

The Home screens and display wallpaper are customizable.

1. Home screen customization options

Open the Home screen you want to customize.

2. Moving an item on the Home screen

1. From the Home screen, tap and hold the item you want to move until it vibrates. Don't lift your finger.
2. Drag the item to a new location on the Home screen.
3. Lift your finger at the location where you want the item.

To add a shortcut for any application to a Home screen, tap  **Apps**, tap and hold the item, then drag it onto a Home screen.

3. Removing an item from the Home screen

1. From the Home screen, tap and hold an item until it vibrates. Don't lift your finger. The  Remove icon will appear at the top of the display.
2. Drag the item to  Remove.
3. When the item turns blue, lift your finger.

4. Changing the Wallpaper of the Home screen

1. From the Home screen, tap and hold any empty area on a Home screen long time.
2. Tap **WALLPAPERS**:
From the list of menus, Choose a photo from your camera gallery or memory card storage.
3. Tap **Set wallpaper**.

Essential Display Icons

1. Status icons

You can tell a lot about your phone when you understand the icons in the Status bar. Here's what each one means:

	Signal strength		Synchronized with the web
	No signal		Vibrate only mode
	3G network connected		Speakerphone is on
	Wi-Fi signal strength		Silent mode-no audio or vibration
	Airplane mode		Microphone is muted
	Data synchronizing		It indicates that battery is remaining
	Bluetooth is on		Connected to a computer via USB cable
	Storage is insufficient		

2. Notification icons

Notification icons in the Status bar alert you to items that may require your attention such as new messages, calendar event reminders, missed call notifications, etc. Here's what each one means:


	Call in progress		Downloading data
	Missed call		Uploading data (animated)
	Call Diverted		General Warning Icon
	More (not displayed) notifications		No microSD card installed
	New Google Talk instant message		MicroSD card is being prepared
	New voicemail		Upcoming event
	New message		Alarm is set
	New Gmail		Wi-Fi is on and wireless networks are available
	Connected to or disconnected from VPN		Song is playing
	New Email		

Notifications Panel

When you receive a new notification, an icon will be displayed in your status bar at the top of your screen.

1. Viewing and responding to Notifications

1. Tap and hold Status bar, and then slide your finger downward to open the Notifications panel.



2. If you have multiple notifications, you may need to scroll to see them all.
3. Tap a notification to respond to it.

2. Closing the Notifications panel

Drag the bottom bar of the panel up. Or just press Back.


Opening & Switching Between Applications

1. Opening and closing the Applications List

1. From the Home screen, tap Apps.
2. To close, press Home or Back.

2. Switching to a recently used application

1. From any screen, tap Recent apps. Scroll to see all recently used application.



2. Tap an icon to open the application or press  **Back** to return to your previous screen.

Sleep Mode

Sleep mode saves battery power by turning off your display. You will still receive messages and calls when the display is turned off.

1. Switching to Sleep mode

1. Press **Power/Lock** to switch your phone to Sleep mode.
2. Your phone automatically turns off the display after a period of inactivity. To customize the screen timeout settings, from the Home screen, tap  **Apps** >  **Settings** >  **Display** > **Sleep**.

2. Waking up from Sleep mode

1. Your phone automatically wakes up when you have an incoming call.
2. To wake it up manually, press **Power/Lock**. You'll need to unlock the screen as described below.

3. Unlocking the screen

On the lock screen, tap the unlock icon and slide your finger in the direction of the arrows to unlock the screen. The screen unlocks automatically when you answer an incoming call.

NOTE If you have set up a screen unlock pattern, pin, or password, you will be asked to draw the pattern on the screen or enter the PIN or password to access the phone software.

4. Activating Secure Screen Lock

1. From the Home screen, tap  **Apps** >  **Settings**.
2. Tap  **security** > **screen lock**.
 - If you have already configured the screen lock, tap **screen lock** to change how to lock or unlock your screen.
3. Tap Pattern, PIN, Password, or Face Unlock. Then enter a custom pattern, PIN or password as prompted.

- If you select 'None', screen unlock security is cancelled

Adjusting Volume

Ringtone and Media volume are independent of each other and adjusted separately.

1. Adjusting the ringer volume

From the Home screen, press **Volume up** or **Volume down** on the right side of the phone to adjust the ringer volume to your desired level.

- While in the lowest ringer volume level, press **Volume up** or **Volume down** once to set your phone to Vibrate mode. To set your phone to Silent mode, you can press **Volume down** once again.
- While in the Silent mode or Vibrate mode, press **Volume up** once to switch to ringtone mode.

2. Adjusting the media volume

While playing music, watching a video or using preloaded or downloaded games or applications, press **Volume up** or **Volume down** on the right side of the phone to adjust the media volume.

3. Adjusting the earpiece volume for phone calls

During a phone call, press **Volume up** or **Volume down**.

4. Adjusting the volume via Settings menu

1. From the Home screen, tap  **Apps** >  **Settings**.

2. Tap  **Sound** > **Volumes**.
3. Drag the volume sliders left or right to adjust your phone's Ringtone, Media, and Alarm. Your phone plays a sample tone at the selected volume level while you drag the slider.
4. When you're done, tap  **Back** or  **Home**.

Searching Your Phone and the Web

The search key is a powerful part of the UL40's software and enables you to quickly locate files, contacts, and applications. You can also search the web using your favorite web search service.

1. Tap  **Apps** >  **Google**.
2. Begin entering text, or tap a previously used search term.
 - As you enter the text, matching items on your phone and suggestions from Google web search will appear on the screen.
3. Tap a suggestion to go directly to that result.

Connecting Your Phone to a Computer

1. Copying files to/from the microSD card

You can copy your music, photos, and other files to the microSD card of your phone.

NOTE This option is available only when a microSD card is inserted into the slot of your phone. While your phone is connected to a computer, USB Mass storage mode prevents you from using applications that access the memory card.

1. Connect your phone to your computer using the supplied USB cable.
2. Open the Notifications panel > tap **USB options**.
3. On your computer, the connected phone is recognized as a removable hard drive.
4. Navigate to the removable drive and open it.
5. Do one of the following:
 - Copy the files from the computer to the microSD card's root folder.
 - Copy the files from the phone's microSD card to a folder in your computer.
6. After copying the files, un-mount the removable drive (that is, your phone) as required by your computer's operating system to safely remove your phone.

7. After you have un-mounted the removable drive, you can disconnect the phone from the computer.

Phone Calls

Making Calls

The simplest way to make a call is to dial the number directly. You can also call numbers listed in your call log or Contacts list.

1. Making a call from the dialer screen

1. From the Home screen, tap  Phone. Or tap  Apps >  Phone.
2. Tap the number you want to dial.
 - If you make a mistake, tap  to erase a single character. Tap and hold  to erase the entire string.
3. Tap  Dial.
 - The Calling screen is shown and  appears in the Status bar while the call is active.
 - To change the volume during a call, press **Volume up** / **Volume down**.
4. To end the call, tap  End Call.

2. Entering a Pause/Wait

Pause and wait options can help you dial additional numbers such as a voicemail password, or phone banking system menus.

1. From the Home screen, tap  Phone.
2. Tap the number you wish to dial > tap  Option >Add 2-sec pause or Add wait.
 - **Add 2-sec pause:** Your phone will wait for 2 seconds then continue to dial the remaining numbers automatically.

- **Add wait:** Your phone will wait with the message, 'Send the following tone?' until **Send** is tapped, then continue dialing the remaining numbers.

3. Making an international call

1. From the Home screen, tap  Phone.
2. Tap and hold **0** until the international prefix '+' appears.
3. Tap the country code, area code, and phone number.
4. Tap  Dial.

4. Calling a number from the Call log

Your phone logs all incoming and outgoing calls.

1. From the Home screen, tap  Phone >  Call log.
2. Tap  Dial at the right of any entry to dial.
 - Calls are listed with the most recent at the top.
 - Calls to the same phone number are grouped together.
 - Scroll up or down to view additional entries in the log.
 - If you want to edit a number before calling, tap and hold the desired number, and then tap  Menu >Edit number before call.

5. Making a call from the Contact list

1. From the Home screen, tap  Phone >  People. Or tap  Apps >  People.
2. Scroll through the contact list.
 - To find a specific contact, you can search by tapping  Search. Enter the name of the contact you're

searching for. As you type, contacts with matching names appear below the search box. Or you can use the tab on the right hand side of the screen to scroll through the alphabetical contacts.

3. Tap the contact you want to call.
4. Tap the phone or mobile number.

6. Making an emergency call

Your phone supports international emergency numbers such as 911. Emergency calling is supported anywhere the phone has a network signal.

1. Making an emergency call

1. From the Home screen, tap  Phone.
2. Tap the emergency number for your location.
This is usually 911, *911 or #911.
3. Tap  Dial.
4. To end the emergency call, tap  End Call.

2. Making an emergency call while the phone is locked

1. When your phone is no service status, Emergency call button is displayed on the lock screen. Tap Emergency call.
2. Tap the emergency number for your location. This is usually 911, *911 or #911.
3. Tap  Dial.
4. To end the emergency call, tap  End Call.

Answering or Rejecting Calls

When you receive a phone call, the screen displays the caller's name, phone number, and caller ID icon (if stored in Contacts). When you receive a phone call from a phone

number not stored in your Contacts, only the default caller ID icon and phone number are shown.


All incoming calls are recorded in the Call log. If you miss a call, you receive a reminder notification.

1. Answering or rejecting an incoming call

1. Drag the  icon in the direction of the arrows to answer the call.
 - If you were already in a call, the first call is placed on hold during answering the new call.
 - To silence the ringer before answering the call, press either of the volume keys.

NOTE

The caller you reject is sent directly to your voicemail box to leave a message.



2. Checking missed calls

- If you miss a call,  is displayed in the Status bar.
- If you open the Notifications panel, you will see the number of missed calls. Tap the notification to be taken to the call log and view detailed information.

Using In-Call Options

When a call is in progress, the following options are available:

Dial Pad	Tap Dial Pad to enter additional numbers during your call.
Mute	You can unmute the microphone by tapping Mute icon again.
Audio	You can turn the speakerphone off by tapping the Speaker icon again.
Bluetooth	When a Bluetooth device is paired and connected to your phone, you can conduct all calls using Bluetooth for hands-free conversation. When using Bluetooth headset during a call, the current call screen has a blue border and the Ongoing Call icon turns blue in the Status bar. Tap Bluetooth icon to toggle in-call audio to and from the Bluetooth accessory.

NOTE To avoid damaging your hearing, do not hold the phone up to your ear when the speakerphone is on.


Using Call Log

The phone stores the numbers of all incoming and outgoing calls in the Call log. The Call log displays the details of the call including time, date, and duration.

1. Opening the Call log

1. From the Home screen, tap   Call log.
- Calls are listed with the most recent at the top. Calls of the same phone number are grouped together. Scroll to view earlier entries in the log.

NOTE You can tap and hold the desired number in the call log list to select options such as **Call**, **View contact**, **Edit number before call**, **Send a message**, **Add to contacts**, **Call details**, **Copy number**, **Block number**.



2. Calling a number from the Call log

1. From the Home screen, tap Phone > Call log.
1. If you want to call a number directly, tap at the right of the entry. Or select a contact > tap Dial
 - If you want to edit a number before calling, tap and hold the desired entry, and then tap Option >Edit number before call.

3. Adding a phone number from your Call log to your Contacts list

1. From the Home screen, tap Phone > Call log.
2. Tap the desired entry >Add to contacts.
3. In the list of contacts that opens, tap Create new contact or add to an existing contact.
4. Tap Done.

4. Sending a text message from the Call log

1. From the Home screen, tap Phone > Call log.
2. Tap the contact > Send text message.
3. Enter your message and tap to Send.

5. Clearing the Call log

1. From the Home screen, tap Phone > Call log.
2. Tap Option >Call log>Tap >Clear call log >OK.
 - To remove just one entry from the Call log, tap the entry. In the pop up options, tap Call details >click Delete icon>OK.

Listening to Your Voicemail

Voicemail application is displayed only when phone calls are available. When you have a new voicemail message, appears in the Status bar.

1. Calling your voicemail from the Dial Pad

1. From the Home screen, tap Phone.
2. Tap your phone number and tap Dial.

2 Calling your voicemail from the Notification panel

1. Open the Notifications panel and tap " New voicemail".

Using Voice Dialer

You can use the Voice Search application or Voice Dialer application to place a phone call by speaking the name of a contact or a phone number.

1. From the Home screen, tap  Phone >  Search contacts.

- If you have a Bluetooth headset that supports “voice-recognition” or “voice-dialing,” you may be able to open Voice Search by pressing and holding your headset’s main button and dial by voice using your headset. For details, see your headset manual.
- 2. Say the name of the contact you want to call
 - Or, follow one of the suggestions for dialing a number or controlling your phone in other ways.

Contacts

About contacts

Contacts give you quick and easy access to the people you want to reach. Contacts from Google accounts are also downloaded and synced with the Contact list.

You can manage your communications with your contacts via phone, messaging, and email without the need to jump from one app to another.

Opening Your contacts

Open contacts to add, view, and communicate with your friends and acquaintances.

1. From the Home screen, tap  Apps >  contacts.
 - All of your contacts are displayed alphabetically in a scrolling list.
 - You can use the tab on the right hand side of the screen, or flick your finger up or down to scroll quickly.

Getting Started

1. Adding a new contact

1. From the Home screen, tap  Apps >  contacts.
2. Tap  ALL > .
3. If you have more than one account, select an account then enter the information for the contact.
- Tap  > select **Take photo** or **Choose photo from Gallery** to add a picture.

- Enter your contact's information.

4. Tap **Done**.

Saving a phone number from the Dial Pad

1. From the Home screen, tap  Phone.
2. Enter the number >Tap  Create new contact.
3. Enter the information for the contact > tap **Done**.

Storing a contact using Call log

1. From the Home screen, tap  Apps >  Phone.
2. Tap  Call log > tap the number you want to save > **Add to contacts**.
3. Tap **Create new contact** or select an existing contact.
4. If you have more than one account, tap the account where you want to save the contact > enter the information for the contact > tap **Done**

2. Importing / Exporting / Sharing contacts

Importing contacts from your microSD card


If you have contacts stored in vCard format on the microSD card, you can import them into Contacts on your phone.

1. From the Home screen, tap  Apps >  contacts.
2. Tap  Option > **Import/Export**.
3. Tap **Import from .vcf file**.
4. If you have more than one account on your phone, select the desired account.
5. Tap the vCard files on the microSD card. The contacts are imported.

Exporting contacts to your microSD card

1. From the Home screen, tap  Apps >  contacts.
2. Tap  Option > Import/Export.
3. Tap Export to .vcf file.
4. Select contacts, tap OK to confirm.

- This process creates a file containing all your selected contacts with a .vcf extension on your microSD card.




Sharing visible contacts

1. From the Home screen, tap  Apps >  contacts.
2. Tap  Option > Import/Export.
3. Tap Share all contacts > Select  Bluetooth,  Gmail.

3. Viewing details about a contact

1. From the Home screen, tap  Apps >  contacts.
2. Tap the contact whose details you want to view.
3. Tap the communication icon to start dialing, texting, or emailing the contact.



4. Search for a contact

1. From the Home screen, tap  Apps >  contacts.
2. Tap  Search.
3. Start entering the contact's name.
As you type, contacts with matching names appear below the search box.
4. Tap the matching contact in the list to open

Editing/Deleting Contacts

1. Editing contact details

1. From the Home screen, tap  Apps >  contacts.
2. Tap the contact you want to edit > Tap  Edit contact.
3. Edit the contact information.
4. Tap Done.

2. Setting a contact's default phone number/email

Setting a contact's default phone number

The default phone number is used when you initiate a call or text message by tapping and holding a contact.

1. From the Home screen, tap  Apps >  contacts.
2. Find the desired contact > Tap and hold the phone number to designate it as the default phone number.
3. Tap Set default.

- The default phone number is indicated with a checkmark.

Setting a contact's default email

The default email is used when you send an email from the list by tapping and holding a contact.

1. From the Home screen, tap  Apps >  contacts.
2. Find the desired contact > Tap and hold the email address to designate it as the default email address.
3. Tap Set default.

- The default email is indicated with a checkmark.

3. Setting a ringtone for a contact

1. From the Home screen, tap  Apps >  contacts.

2. Tap the desired contact > Tap  Edit contact.

3. Tap  Option > Set ringtone.

- Tap a ringtone from the list to play when the contact calls. A sample of the ringtone is played.

4. Tap OK.

4. Adding a contact to your favorites

1. From the Home screen, tap  Apps >  contacts.

2. Tap the desired contact > Tap .

- To remove a contact from your favorites list, tap  contacts > tap the desired contact > Tap .

5. Linking contacts

1. From the Home screen, tap  Apps >  contacts.

2. Tap the contact you want to save. The others will merge into this file. This is the contact you will see in contacts after linking.

3. Tap  Edit contact > Tap  Option > link.

4. Tap the contact you want to join with the first contact. The information from the second contact is added to the first contact, and the second contact is hidden.

6. Deleting a contact

1. From the Home screen, tap  Apps >  contacts.

2. Tap the contact you want to delete, tap  Option > Delete.

3. Tap OK.

Communicating

1. Sending text message

1. From the Home screen, tap  Apps >  contacts.
2. Tap and hold the contact you want to send > tap .

 - The Primary Phone Number is used, or you are prompted to choose a phone number.

2. Making calls

1. From the Home screen, tap  Apps >  contacts.
2. Tap and hold the contact to call > tap **the number**.
 - The Primary Phone Number is used, or you are prompted to choose a phone number.

3. Connecting by using Quick Contact

1. From the Home screen, tap  Apps >  contacts.
2. Tap the icon or photo next to your desired contact > tap the desired communication method.
 - Only the icons relevant to your contact's data are displayed.
 - If there are too many icons to fit on the screen, drag to the left or right to select an icon.

Account Setting

1. Working with Google accounts

1. From the Home screen, tap  Apps >  contacts.
2. Tap  Menu > **Manage accounts**.
 - After registering your Google account, your online Google contacts are synchronized to your phone. Changes made online or on the phone are automatically synchronized and updated in both

locations. This address book will be used throughout the user interface.

- If you register two or more accounts, you can merge address books from the multiple accounts into one address book.

2. Contact List Display and Settings Options

1. From the Home screen, tap  Apps >  contacts.
2. Tap  Option > **Contacts to display**.
 - All contacts display in the contacts list.
3. Tap  Option > **Settings**.
 - Sort list by: Select **First name** or **Last name**.
 - View contact names as: Select **First name first** or **Last name first**.
 - About Contacts: Build version, Open source licenses, Privacy policy, Terms of service.

Messaging

About Messaging

Use Messaging to send text messages (SMS) and multimedia messages (MMS) to other mobile phones and email addresses.

1. From the Home screen, tap  Apps >  Messaging.

On the Messaging screen, your sent and received messages are neatly grouped into conversations, by contact names or phone number. You can:

- Scroll up or down the list of conversations by flicking your finger on the screen.
- Tap a contact name or number to view the conversation history.
- Tap the photo or  to open additional menu options.

Sending Messages

1. Sending a Text Message

NOTE Depending on your billing plan, if you exceed the single text message character limit, you will be billed for multiple messages.

1. From the Home screen, tap  Apps >  Messaging.
2. Tap  Create New message.

3. Enter the phone number in the **To** field. Fill in one or more recipients. You can:

- Enter the first few letters of a contact name or phone number. Matching contacts are displayed. Continue typing or tap a name or phone number from the search results.
- Tap  Select message recipients from your contact list >Ok.

4. Tap **Type message** >enter your message.
 - Tap  Menu to see more options.

Add subject	Add subject.
Attach	Attach Media Files or a Slideshow within the message.
Send	Send the message.
Insert smiley	Insert a smiley in the message.
Discard	Delete the message in progress.
Import Temple	Some default text

5. Tap  to **Send**.

- Tap  **Back** to save the message as a draft.

NOTE Your text message automatically becomes a multimedia message on below condition:

- Add subject
- Attach an item

2. Sending a multimedia message (MMS)

To compose a multimedia message, start by creating a new text message. Then simply add an attachment.

1. From the Home screen, tap   Apps >  Messaging.
2. Tap  Create New message.
3. Enter the phone number in the **To** field. Or select recipients from the contact list.
4. Tap **Type message** > enter your message. Tap  to add the message template.
5. Tap  Attach > choose the type of attachment.

• Pictures	Select a photo.
• Capture picture	Capture a new photo.
• Videos	Select a video.
• Capture video	Record a new video.
• Audio	Select an audio file.
• Record audio	Record a new audio file.
• Slideshow	Create a slideshow from up to 10 of your photos.

6. From the message body, tap:
 - **View**: To view the attached item.
 - **Replace**: To change attached files.
 - **Remove**: To remove attached files.
7. Tap  Send MMS.
 - Tap  Back to save it as a draft.

3. Resuming a draft message

1. From the Home screen, tap   Apps >  Messaging.
2. Tap the message indicated by "Draft" to resume editing.

3. When you finish editing, tap **Send**.

Reading Messages

1. From the Home screen, tap   Apps >  Messaging.
2. Tap a message thread.
3. Tap and hold an individual message to see more options.

Save to SIM card	To save the message to SIM card.
Call icon	To call the message sender
Add to Contacts	To save the phone number or email address to Contacts. (Only on messages from unknown number)
Forward	To forward a message. Enter a recipient, edit the content of the message as needed > tap Send .
Copy message text	To copy text from a message.
View message details	To view details about a message.
Delete message	To delete a message.

1. Deleting a message thread

1. From the Home screen, tap   Apps >  Messaging.
2. Tap and hold to select the message thread, tap  Delete thread.
 - If you want to delete all message threads, tap and hold a message thread and select all, tap  Delete all threads.
3. Tap **Delete**.

2. Searching messages

1. From the Home screen, tap   Apps >  Messaging.

2. Tap  **Search** to search.
3. Enter the search term > tap  **Search**.

3. Replying to a message

1. From the Home screen, tap  **Apps** >  **Messaging**.
2. Tap the received message > tap **Type message** > enter your message.
3. Tap  **Send**.

Receiving Emergency Alerts Messages

Emergency Alerts service allows you to receive automatic alerts in times of crisis (e.g., earthquake, hurricanes, etc.). Wireless Emergency Alerts (WEA), also known as CMAS, is a part of a national alerting system called IPAWS (Integrated Public Alert and Warning System) that enables emergency management officials to rapidly disseminate the warnings and safety information via text alerts to wireless phones based on the phones' geographic location. The Federal Emergency Management Agency or FEMA is responsible for receiving the alerting information and forwarding the alerts to participating wireless carriers such as Sprint. Such alerts may come from the President of the United States; the National Weather Service, state or county public safety officials. This system is integrated into the same national alerting services that serve television and radio today. For more information regarding WEA/CMAS please go to: [FEMA website](#).

<http://www.fema.gov/emergency/ipaws/projects.shtm#6>

1. Receiving Emergency Alerts Messages

1. From the Home screen, tap  **Apps** >  **Messaging**.
2. Tap Emergency alerts message you want to view. Emergency alert messages are indicated with  Emergency alert icon.
 - If Emergency alert arrives on your phone during a call,  is displayed in the Status bar. If Presidential Emergency Alert, emergency alert icon will flashes. If non-Presidential, Emergency alert icon is static icon.
 - Only the Presidential Emergency Alert icon is displayed under the Time/Date on the unlock/lock screen.
 - If you are on an Emergency alert message screen in the Messaging application, the following options are removed or disabled : **Reply**, **Forward**, and **Call**.
 - If you have power cycled your phone and a Presidential Emergency Alert has not been viewed, the Presidential Emergency Alert icon will continue to flash when the device is powered on again.

Changing Messaging Settings

1. From the Home screen, tap  Apps >  Messaging.
2. Tap  Option >Settings.

1. Storage settings

Delete old messages	Check to delete older messages in a thread when messaging memory or thread limits are reached. Uncheck to keep all messages. You may need to manually delete messages if the messaging memory limit is reached.
Text message limit	Tap to set the number of messages to save per message thread. When the limit is reached, older text messages are deleted if 'Delete old messages' is checked.
Multimedia message limit	Tap to set the number of multimedia messages to save per message thread. When the limit is reached, older multimedia messages are deleted if 'Delete old messages' is checked.

2. Multimedia message (MMS) settings

Auto-retrieve	Uncheck to download only the heading of multimedia messages. You will need to tap the MMS message heading and manually download each MMS message. You may want to use this feature when roaming or when connected to a slow data network.
---------------	---

MMS Validity period	Set MMS Validity period to Maximum or Two days
---------------------	--

3. Notification settings

Sound	Select a ringtone to sound when you receive new message notifications.
Vibrate	Set the phone to vibrate every time you receive a new message notification, only when silent mode, or never.

4. Receive Emergency Alerts

Show extreme threats	Set to receive Extreme Emergency Alerts.
Show Severe alerts	Set to receive Severe Emergency Alerts.
Show Amber alerts	Set to receive Amber Emergency Alerts.
Turn on notifications	Set to display emergency alert broadcasts
Alert reminder	Set alert reminder to once, every 2 minutes, every 15 minutes or off
Speak alert message	Set to use text-to-speech to speak emergency alert messages

Google

Gmail

1. Opening your Inbox and Reading your Gmail

The inbox is your default Gmail view. All your received emails are delivered to your inbox.

1. From the Home screen, tap  Apps >  Gmail.
2. Tap the email you want to read.
 - Tap  to star the email.
 - If the sender is a friend in Google Talk, you can see your friend's online status.
 - Tap **Archive** to archive the message.
 - Tap **Delete** to delete the message from your inbox.
 - Slid left and right to see the previous or next message in the list.

Replying to or forwarding an email message

1. From the Home screen, tap  Apps >  Gmail.
2. When reading a message:
 - To reply to the sender, tap .
 - To reply to all message recipients, tap  Option > **Reply all**.
 - To forward the message, tap  Option > **forward**.

2. Sending a new email

1. From the Home screen, tap  Apps >  Gmail.
2. From any message list, tap .

3. Enter a name or address in the **To** field. To send the email to several recipients, separate each email address with a comma.
4. Enter a subject in the **Subject** field.
5. Type the message text in the **Compose Mail** field.
 - To attach an image file, Tap  Option > **Attach file** > select the picture you want to attach.
6. Tap  **Send**.
 - To save the message as a draft, tap  Option > **Save draft**.

3. Working with Multiple Email Messages

You can archive, delete or label groups of email messages at the same time.

1. From the Home screen, tap  Apps >  Gmail.
2. From any message list,  check the box next to the email messages you want to work with.

Tap **Archive** to move messages out of your inbox without deleting. Archived emails are assigned the All Mail label.

- Tap **Delete** to delete selected messages.
- Tap **Labels** > select the labels that you want to assign > tap **OK**.

4. Switching between Google accounts

If you have set up two or more Google Accounts on your phone, you can switch between them in Gmail. Gmail displays only one Google Account at a time. The current account is shown at the top right of any message list.

1. From the Home screen, tap  Apps >  Gmail.

2. From any message list, tap  **Option >Accounts**.
3. Tap the account that you want to view. You can also tap the account name at the top of the screen to see a list of your accounts.

5. Labeling email messages

You can organize your emails by label. Gmail has preset labels. Or you can create your own labels in Gmail when viewed on a computer. (Note: Custom label colors created on the web are not supported on your phone).

Labeling an email

1. From the Home screen, tap  **Apps >  Gmail**.
2. When reading a message, tap  **>Change labels**.
3. Select a label > tap **OK**.

6. Viewing emails by label

1. From the Home screen, tap  **Apps >  Gmail**.
2. From any message list, tap  **>Go to labels**.
3. Tap a label to view matching email messages.

7. Starring/un-starring an email message

You can star an important email to make it easy to find again. Starred emails are assigned the Starred labels.

1. From the Home screen, tap  **Apps >  Gmail**.
2. From any message list:
 - Tap  to star a message.
 - Tap  to un-star a message.

Maps

Use Maps to find your current location and get directions. You can search for addresses, landmarks and businesses directly on a street map or satellite image.

NOTE You need an active mobile data or Wi-Fi connection to use Maps. To see your location and get directions, you must turn on location services. From the Home screen, tap  **Apps >  Settings >  Location services**. Select one or both from **Use wireless networks** or **Use GPS satellites**. Maps may not be available for all locations.

1. Opening and viewing Maps

Viewing your location

1. From the Home screen, tap  **Apps >  Maps**.
2. Shows your location on the map and points north for your reference.

Using Maps

1. From the Home screen, tap  **Apps >  Maps**.
2. While viewing a map, swipe to any direction on the screen.

2. Viewing location details

Viewing information for a location

1. From the Home screen, tap  **Apps >  Maps**.
2. While viewing a map, tap and hold a location, starred place, or a search result on the map.
 - A balloon opens over the location, with summary information.

3. Tap the balloon to see the address or more information.

Starring or un-starring a location

Add a Star to bookmark and easily return to a map location.

1. While viewing detail information for a location,

- Tap  to star the location.
- Tap  to un-star the location.

Viewing a location in Street view

Street view mode provides a street-level view of the location. Street view may not be available for all areas.

1. From the Home screen, tap   Maps.

2. While viewing detailed information for a location, tap .

- To view surrounding areas, swipe the screen in any direction.

3. Searching for a location

You can search Google Maps for specific locations, company names, or business types.

1. From the Home screen, tap   Maps.

2. Tap  Search.

3. Enter the search criteria. As you type, suggested matches from your contacts, the web, and previously searched items are displayed.

- Tap  to search
- Tap a suggested search term.

4. The search results are displayed as  markers with letter labels on the map.

- Tap markers and titles to view more information.
- Tap  to show the search results as a list > tap each item to see more information.

4. Viewing map layers

Initially, Google Maps opens with a street map. You can view additional map layers, such as satellite images and traffic information. You can also view custom Web created Google Maps.

1. From the Home screen, tap   Maps.
2. Tap  Option >Layers. A dialog opens with a list of layers.
3. Turn layers on or off by tapping the layer name. A check mark indicates the layer is selected.
- Tap  Option > Clear Map to deselect all layers.

Layers may change the map entirely or overlay additional information. Tap icons or interactive items to explore different layer types.

5. Getting directions

1. From the Home screen, tap   Maps.
2. Tap  >Directions.
3. Use your current location as the starting point, or enter a location in the **Start point** field.
4. Enter your destination in the **End point** field.
5. Tap  or  or  to select your transportation method > tap **Get directions**.

Calendar

The Calendar application data on your phone syncs with the web-based Google Calendar service. It is also compatible with Microsoft Exchange ActiveSync Calendar.

1. Opening Calendar

1. From the Home screen, tap  Apps >  Calendar.

Events are color coded to enable you to distinguish between multiple calendars. Events times are shown using your local time zone, which is provided by your active mobile network. When traveling, you may want to set a home time zone in Calendar.

2. Creating an event

Events created on your phone will be synced to Google Calendar or Microsoft Exchange automatically.

1. From the Home screen, tap  Apps >  Calendar.
2. There are two ways to create an event:
 - Tap  Option >New event.
 - In Day, Week, or Month view, tap and hold the screen at the date and/or time you want >New event.
3. Enter the name, time, location, description, and optional additional details for your event.
 - If you have more than one calendar, choose the calendar to which to add the event.
 - In the Guests field, enter email addresses of anyone you want to invite. Separate multiple addresses with commas (,). If your invitees use Google Calendar, they'll receive an invitation in Calendar and by email.

- If the event occurs on a regular basis, tap the Repetition box and choose the reoccurrence information.

- You can set multiple reminders for an event.

4. Tap Done.

3. Viewing calendar and events

Changing calendar view

When you open Calendar, Month view is shown by default. You can also view the Calendar by Agenda, Day, or Week.

1. From the Home screen, tap  Apps >  Calendar.
2. Tap **Option** > **Settings** >General settings choose the type of view that you want

Day	Displays a chart of the events of one day,in a table of one-hour rows,ALL-day and multiday events are displayed at the top.Each event is displayed at the corresponding time.Swipe left or right to change dates, and swipe up or down to view earlier or later times.
Week	Displays one week calendar. All-day and multiday events are displayed at the top. Swipe left or right to change weeks, and swipe up or down to view earlier or later times.
Month	Displays a chart of the events of the month. Events are shown as blue bars on each calendar date. Swipe left or right to change months.

Agenda	A list of your events in chronological order. All-day and multiday events are listed at the start of each day. Days without events are not shown. Flick up or down to view earlier or later events.
Today	Displays a chart of the events of today.
⋮ Option	You can select New event, Calendars or Settings.

Viewing event details

- In Day, Week, or Agenda view, tap an event.
- In Month view, tap a day to switch to Day view > tap an event.

4. Editing or deleting an event

1. In event details view, press the event >  **Edit event** to edit the event.
2. Make your changes to the event > tap **Done**.
 - To delete the event, press the event >  **Delete event** > tap **OK**.

5. Synchronizing and displaying calendars

You can select which calendars to show or hide on your phone's Calendar, and which ones to synchronize.

1. From the Home screen, tap  **Apps** >  **Calendar**.
2. Tap  **Option** > **Calendars to display**.

All the calendars you've added or subscribed to are displayed. (Calendars for accounts you've configured not to synchronize are not included in the list.)

3. Tap the icon next to a calendar to change storage and visibility settings.

	Calendar events stored on phone and visible in Calendar.
	Calendar events stored on phone but not visible in Calendar.
	Calendar events not synchronized to phone.

4. Tap **OK**.

6. Changing Calendar settings

1. From the Home screen, tap  **Apps** >  **Calendar**.
2. Tap  **Option** > **Settings**.


Calendar view setting	Hide declined events	Check if you don't want to see events to which you've declined invitations.
	Use home time zone	Displays calendars and event times in your home time zone when traveling.
	Home time zone	If Use home time zone is checked, you can set home time zone.
Week number setting	Display week number	Check if you want to see week number in Calendar.
	First week of year	If Display week number is checked, you can set first week of year.
Reminder settings	Set alerts & notifications	Configure event reminders.
	Select ringtone	Select which ringtone will sound when you receive an event reminder.
	Vibrate	Configure the phone to vibrate whenever you receive an event reminder.
	Default reminder time	Select the default reminder time used when creating new calendar events.

Play Music

Play music and audio files with Music application.

NOTE You need to copy music files to your microSD card to use the Music application.

1. Viewing your music library



1. From the Home screen, tap  Apps >  Play Music
2. You can select library to open at the bottom of the screen.
 - You can view the lists of music in the microSD card.
 - The lists are automatically organized according information contained in the music files. To view each list of music, you can tap the corresponding category; **Artists**, **Albums**, **Songs**, **Playlists** or **Genres**.

Google Play Store

Google Play Store provides direct access to applications and games to download and install on your phone. To access Google Play Store, you must first sign into your Google account using a Wi-Fi or data connection. When you open Google Play Store for the first time, you must read and accept the terms of service to continue.

1. Finding applications

1.Browsing applications

You can browse and sort applications by category.

1. From the Home screen, tap  Apps >  Play Store.
2. Tap **GAMES, BOOKS & REFERENCE, BUSINESS** or **COMICS**, etc. at the left of the Market screen.
 - Scroll to view subcategories and tap one to explore.
3. Tap the subcategory you want.

2.Searching for applications

1. From the Home screen, tap  Apps >  Play Store.
2. Tap  at the top right of the screen to search apps.
3. Enter the name or type of app you're looking for > tap  to search.

3.Viewing details about an application

1. While browsing Google Play Store, or in a list of search results, tap an application to view more details.

Application details screens include a description, ratings, and specific information about the application. The Comments tab includes comments from people who have

used the application. You can download and install an application from this screen.

2. Installing applications

1.Installing an application

1. From the Home screen, tap  Apps >  Play Store
2. Find the application you want to purchase and view the application details.
3. Tap **Download** to download and install the application. For paid applications, the download button is labeled with the application's price. Tap the price to buy the application. The subsequent screen notifies you whether the app will require access to your personal information or access to certain functions or settings of your phone.
1. Tap **Accept & download** to begin downloading and installing the app. If you selected a paid app, you will be redirected to the Google Checkout screen to pay for the app before it's downloaded to your phone.

NOTE

Be cautious when downloading apps that have access to phone functionality or a significant amount of personal data. You're responsible for the results of using downloaded apps on your phone.

2. Creating a Google Checkout account

You must have a Google Checkout account to purchase items from Google Play Store. You can set up a Checkout account with your first purchase from Google Play Store.

- In a web browser, go to <http://checkout.google.com> to create a Google Checkout account.
- From the phone, you will be prompted to enter your billing and credit card information when you buy your first application from Google Play Store.

NOTE Once you've purchased something from Google Play Store, the phone remembers your password, so you don't need to enter it the next time. Be sure to secure your phone with a password to prevent unauthorized purchases.

3. Managing your downloads

1. Viewing downloaded applications

1. From the Home screen, tap  Apps >  Play Store
2. Tap  Option >  My Apps.

In the list of the free and paid applications that opens, you can tap an application to rate it, uninstall it, request a refund, and more.

2. Updating an application

You can update downloaded applications.

1. From the Home screen, tap  Apps >  Play Store.
2. Tap  Option >  My Apps > tap the application to update.
3. Tap **Update >Accept & download.**
4. Tap the explanation that best matches why you're installing > tap **Open** or press  Back.

The application is installed. You can uninstall the application again at any time. If you paid to buy the application, you will not be charged again.

3. Uninstalling an application

You can uninstall applications from Google Play Store. You can also uninstall downloaded applications from the Settings.

1. From the Home screen, tap  Apps >  Settings > Apps.
2. Tap **Manage apps >DOWNLOADED** > tap the application to uninstall.
3. Tap **Uninstall >OK.**
4. Tap the explanation that best matches why you're uninstalling > tap **OK**.

The application is uninstalled. You can install the application again at any time. If you paid to buy the application, you will not be charged again.

Web

Chrome

Search for information or browse web pages using the Chrome. To access the internet, you must have an active data or Wi-Fi connection.

1. Opening Chrome

1. From the Home screen, tap  Apps >  Chrome.
 - When you open the Browser, the default homepage is displayed. If you have used the Browser recently, your most recently viewed webpage is displayed.
 - The Browser also opens when you select a web link in other applications like email or text messaging.

2. Accessing a webpage or searching the web

1. From the Home screen, tap  Apps >  Chrome.
2. Tap the URL field on top of the screen.
3. Enter the URL of a webpage or search term and tap "Go".
 - As you type, suggestions of web pages and key words will appear on the screen. Tap a suggestion to go directly to that webpage or view search results.

3. Using Browser options

1. Stopping page loading
 - While webpage is loading, tap  Option >Stop. Or tap  on the left of the URL field.

2. the current page

Tap  Option >Refresh.

3. Finding the text on the current page

1. While viewing any web pages, tap  Option >Find on page.

2. Enter the search term.

- As you type, matching characters will be highlighted. Tap  or  to scroll to the previous or next matching term.

4. Sharing a webpage

1. While viewing any web pages, tap  Option >Share page.

2. Tap an application to send the URL. The application opens with the URL you've entered.

4. Downloading files

You can download images, files, and applications from web pages. All downloaded files are saved to the microSD card.

1. Tap and hold an image, a link or a file you want to download.
2. Tap the desired action (Save image, View image, or Set as wallpaper).

1. Navigating between webpages

- Press  Back to return to the previous web pages.

- Or tap  Option >Forward if you pressed  Back by accident.

2. Switching between Browser windows
 1. From any web pages, tap  **Option >Bookmarks** >tap **HISTORY**.
 2. Tap the window to view it full screen. You can also tap  to close a window.

NOTE You can have up to 8 browser windows open at one time.

5. Using bookmarks

Browser bookmarks are stored shortcuts which allow you to quickly access webpages without having to type in its full address.

1. Bookmarking a webpage

1. While viewing webpages, tap  **Option >tap  Save to bookmarks.**
2. Edit the name or location if needed >tap **OK**.

2. Opening a bookmark

1. When viewing any webpages, tap  **Option >Bookmarks**.
2. Tap a bookmark to open it.
 - If you prefer to open the webpages in a new window, tap and hold the bookmark and tap **Open in new tab**.

3. Editing a bookmark

1. From any webpages, tap  **Option >Bookmarks**.
2. Tap  on the right of the bookmark to edit >**Edit**.

3. Edit the name and/or location >tap **OK**.

4. Deleting a bookmark

1. From any webpages, tap  **Option >Bookmarks**.
2. Tap  on the right of the bookmark to delete >**Delete >OK**.

6. Browser settings

Customize your browser settings to optimize your browsing experience.

1. From the Home screen, tap  **Apps >  Browser**.
2. Tap  **Option >Settings**.

	Set home page	Select the home page
General settings	Form auto-fill	Fill out web forms with a single touch
	Auto-fill text	Set up text to auto-fill in web forms
Privacy & Security	Clear cache	Tap it you can clear locally cached content and databases
	Clear history	You can clear the browser navigation history
	Show security warning	If you tap it ,it will show warning if there's a problem with a site's security
	Accept cookies	Allow sites to save and read cookie data
	Clear all cookie data	Delete all cookie data

Privacy & Security	Remember form data	Remember what you enter in form fields
	Clear form data	Delete all the information the browser remembered
	Enable location	Allow sites to request access to your location
	Clear location access	Delete location access for all websites
	Remember passwords	Save your passwords for some webpages that require you to sign in.
	Clear passwords	Delete all saved passwords
	Force enable zoom	Override a website's request to control zoom behavior
	TEXT SIZE	Text scaling ,Zoom on double-tap and Minimum font size
Accessibility settings	INVERTED SCREEN RENDERING	Making the black becomes white and vice versa
	Set search engine	You can choose Google, Yahoo, Bing Etc to browse the web
Advanced settings	Open in background	Tap to open new tabs behind the current tab
	Enable JavaScript	Allow JavaScript to run on web pages.
	Website settings	Set for individual websites.
	Reset to default	Restore default settings
	Search result preloading	Allow browser to pre load high confidence search results in the background
Bandwidth management	Load images	Display images on web pages

Labs settings	Fullscreen	Use full screen mode to hide the status bar
	Slide Tab Transitions	Swipe from the edge to reveal the next/previous tab in the list

YouTube

YouTube is Google's online video streaming service for viewing, discovering, and sharing videos.

1. Opening and signing into YouTube

1. Signing into YouTube

You can discover and watch YouTube videos without a YouTube account, but if you want to take advantage of many YouTube features, you must sign into your YouTube account.

1. From the Home screen, tap   YouTube.

2. Tap Option > Sign in

The first time you use a YouTube feature that requires an account, you're prompted to sign in. Create a new account or enter your YouTube sign in information if you already have an account. For more information about YouTube accounts, visit YouTube on the web.

2. Finding videos

1. Browsing videos by category

1. From the Home screen, tap   YouTube.

2. Tap YouTube Trending

3. Tap a category in the scrolling list.

- Tap the current time filter setting at the top of the category screen to change the time period and reduce the number of videos listed.
- Tap **Most viewed, Top rated, Most discussed or Top favorite.**

2. Searching for videos

1. From the Home screen, tap   **YouTube**.
2. Tap  **Search**.
3. Enter the search criteria > tap  to search.
4. Scroll through the search results and tap a video to watch it.

3. Watching videos

1. From the Home screen, tap   **YouTube**.
2. Tap a video to begin playback.
 - Tap the video to pause or resume playback.
 - Tap **Info, Related videos or Comments** to learn more about the video.
 - Rotate your phone to watch the video in full-screen view. You can also double-tap the video to toggle full-screen view on and off.

	Watch later	Bookmark the video to watch it later.
	Favorites	Add the video to your Favorites.
	New playlist	Add your new playlist.
Share	Share the video via  Bluetooth ,  Email ,  Gmail	

4. Uploading videos

1. To shoot and upload a new video
 1. From the Home screen, tap   **YouTube**.
 2. Tap  . The Camera will open in video mode.
 3. Tap  to start recording > tap  to stop recording.
 4. Enter a title for the video and more details > tap **Upload**.

2. To upload an existing video

1. From the Home screen, tap   **YouTube**.
2. Tap  **Option>Upload**. The Gallery will open.
3. Tap the video you want to upload.
4. Enter the title for the video and more details > tap **Upload**.

5. Sharing videos

1. From the Home screen, tap   **YouTube**.
2. Tap a video to play.
3. Tap  **Share**.
4. Tap the application you want to use to share the video.

6. YouTube settings

You can change the following settings for YouTube on your phone.

1. From the Home screen, tap   **YouTube**.
2. Tap  **Option>Settings**.

General settings	High quality on mobile	Check if you prefer to watch videos in high resolution by default when connected to mobile networks. Watch videos in standard mode to reduce startup time and data use. This setting has no effect if you are connected to a Wi-Fi network, where videos are always shown in higher resolution.
	Caption font size	Set the preferred text size when viewing video captions.
	Uploads	Specify network preferences for uploads.
Search settings	Clear search history	Remove previous YouTube video search results.
	SafeSearch filtering	Select if you want Google SafeSearch filtering to block some results when you search for videos. Settings are: Block no search results (Don't filter), only explicit or offensive videos (Moderate), or both explicit and offensive text and videos
Preloading	Preload subscriptions	Enable preload to fetch videos in advance while on Wi-Fi and charging, so you can enjoy watching them later on slow networks
	Preload watch later	Open the YouTube Help Center in your phone's Browser.

About	Feedback	Open a YouTube feedback form in your phone's Browser.
	Google Mobile Terms of Service	Display the Google Mobile Terms of Service.
	YouTube Terms of Service	Display the YouTube Terms of Service.
	Google Mobile Privacy Policy	Display the Google Mobile Privacy Policy.
	YouTube Privacy Policy	Display the YouTube Privacy Policy.
	Application version	The YouTube application version number installed on your phone.

Wi-Fi

1. Turning Wi-Fi on and connecting to a wireless network

1. From the Home screen, tap  Apps >  Settings.
2. Tap  Wireless & networks > Wi-Fi.
3. Select the Wi-Fi check box to turn Wi-Fi on.
4. The network names and security settings of detected Wi-Fi networks are displayed.
5. Tap a Wi-Fi network to connect.
 - If you selected a network that is secured, enter the security key and then tap Connect. Depending on the network type and security settings, you may also

need to enter more information or choose a security certificate.

2. Connecting to a Wi-Fi network with EAP-TLS security

You may need to install a network certificate to your phone before you can connect to a Wi-Fi network with EAP-TLS authentication protocol.

1. Save the certificate file to the root folder of the microSD card.
2. From the Home screen, tap  Apps >  Settings.
3. Tap  security > Install from SD card.
4. Select the network certificate needed to connect to the EAP-TLS network.
5. After the certificate is installed, follow the steps in the previous section to connect to the Wi-Fi network.

3. Checking wireless network status

1. From the Home screen, tap  Apps >  Settings.
2. Tap **Wi-Fi**.
3. Tap the wireless network that the phone is currently connected to.

A message box is then displayed showing the Wi-Fi network name, status, speed, signal strength, and more.

4. Connecting to another Wi-Fi network

1. From the Home screen, tap  Apps >  Settings.
2. Tap **Wi-Fi**.

3. Detected Wi-Fi networks are displayed in the Wi-Fi networks section. To manually scan for available Wi-Fi networks, on the Wi-Fi settings screen, tap **Scan**.
- To set advanced settings, on the Wi-Fi settings screen, tap  Option > **Advanced**.
4. Tap another Wi-Fi network to connect to it.

Downloads

Images, files and other items you download in Browser, Gmail, is stored on your phone. You can view, manage or delete what you have downloaded.

1. Opening Downloads

1. From the Home screen, tap  Apps >  Downloads.
2. Tap an item you want to view it.
 - Check the checkbox of the item you want to delete and then tap **Delete**.
 - Tap  Option to select **Sort by size** or **Sort by date**.

2. Viewing a file

1. From the Home screen, tap  Apps >  Downloads.
2. Tap the file you want to open.
 - Turn your phone left or right to view the file in upright (portrait) or sideways (landscape) orientation.

3. Working with files

1. From the Home screen, tap  Apps >  Downloads.
2. Tap the file you want to manage.
3. Tap  Option to **Share**, **Delete**.
 - Tap **Share** to share the selected file.
 - Tap **Delete** to delete the selected file.

Bluetooth

Using Bluetooth

Bluetooth is a short-range wireless communications technology that devices can use to exchange information over a distance of about 30 feet. The most common Bluetooth devices are headphones, hands-free car kits, and portable devices, including laptops and cell phones.

1. Turning Bluetooth on or off

1. From the Home screen, tap  Apps >  Settings >  Bluetooth.
2. Check or uncheck Bluetooth to turn it on or off.

2. Changing the phone's Bluetooth name

The phone name identifies your phone to other devices.

1. From the Home screen, tap  Apps >  Settings.
2. Tap  Bluetooth.
3. If Bluetooth isn't turned on, check Bluetooth to turn it on.
4. Tap  Option > Rename this device > Enter the name for your phone in the dialog box > OK.

3. Pairing your phone with a Bluetooth device

1. From the Home screen, tap  Apps >  Settings.
2. If Bluetooth isn't turned on, check Bluetooth to turn it on.
3. Tap **Bluetooth >Search for devices**. A list of nearby Bluetooth devices is displayed.
4. Tap the ID of the other device to pair them.

4. Connecting to a Bluetooth device

Once paired, your phone will automatically connect whenever it detects a paired Bluetooth device. You can also manually connect Bluetooth devices as follows:

1. From the Home screen, tap  Apps >  Settings.
2. If Bluetooth isn't turned on, check Bluetooth to turn it on.
3. Tap **Bluetooth >Search for devices**.
4. When the phone and the device are connected, the device is displayed as connected in the list.

Disconnecting or Un-pairing from a Bluetooth Device

1. Disconnecting a Bluetooth device

1. From the Home screen, tap  Apps >  Settings.
2. Tap **Bluetooth**.
3. In the Bluetooth devices section, tap and hold the device name to disconnect.
4. Tap **Forget**.

2. Un-pairing from a Bluetooth device

You can make your phone forget its pairing connection with another Bluetooth device.

1. From the Home screen, tap  Apps >  Settings.
2. Tap **Bluetooth**.
3. In the Bluetooth devices section, tap  of the device name to un-pair.
4. Tap **Un-pair**.

Connecting to a Bluetooth Headset

1. From the Home screen, tap  Apps >  Settings.
2. Tap **Bluetooth**.
3. If Bluetooth isn't turned on, check Bluetooth to turn it on.
4. Tap **Search for devices**. Your phone will start to scan for Bluetooth devices within range.
5. When you see the name of your headset displayed in the Bluetooth devices section, tap the name. Your phone then automatically tries to pair with the Bluetooth device.
6. If automatic pairing fails, enter the passcode supplied with your headset.

1. Reconnecting a headset

1. Put the Bluetooth device in pairing mode.
2. From the Home screen, tap  Apps >  Settings.
3. Tap **Bluetooth**.
4. If Bluetooth isn't turned on, check Bluetooth to turn it on.
5. Tap the device's name in the Bluetooth devices section.
6. If prompted to enter a passcode, try 0000 or 1234, or consult the headset documentation to find the passcode.

Sending and Receiving Information Using Bluetooth

You can use Bluetooth to transfer information between your phone and another Bluetooth-enabled device such as a phone or laptop computer. You can send the following types of information, depending on the device you are sending to:

- Images and videos
- Contacts
- Audio files

To send files, your phone must have a microSD card installed.

NOTE The first time you transfer information between your phone and another device, you need to enter or confirm a security passcode. Your phone and the other device are then paired, and you will not need to exchange passcodes to transfer information in the future.

1. On your phone, open the application that contains the item you want to send.
2. Follow the steps for the type of the application, select **Send File** or **Send** in the menu. Then select **Bluetooth**.
3. If you are prompted to turn on Bluetooth, tap **Turn on**.
4. Tap the name of the receiving device.
5. On the receiving device, accept the file.

1. Receiving information from another device

Your device is capable of receiving a wide variety of file types with Bluetooth, including photos, music tracks, and documents such as PDFs.

To receive files from another device, your phone must have a microSD card installed.

1. From the Home screen, tap  Apps >  Settings.
2. Tap **Bluetooth**.
3. If Bluetooth isn't turned on, check Bluetooth to turn it on.
4. Tap the name of the bluetooth to make the device available.
5. On the sending device, send one or more files to your phone.
6. If a Bluetooth authorization request is displayed on your phone, enter the same passcode on both your phone and the other device, or confirm the auto-generated passcode.
7. When your phone receives a file transfer request notification, slide down the notifications panel, and then tap **Accept**.
8. When the transfer is complete, a notification is displayed. To open the file immediately, slide down the notifications panel, and tap the notification.

Entertainment

Camera/Camcorder

You can take pictures and shoot videos with Camera/Camcorder. Photos and videos captured with the camera will be stored on the internal memory.

1. Opening Camera

- From the Home screen, tap   Camera.
- Or, when in Camcorder mode, tap  to choose  change to camera.

2. Camera settings

When in Camera mode, Camera settings are displayed on screen. Before taking the photo, you can adjust your camera settings or leave the controls in automatic mode.

- From the Home screen, tap   Camera.
- Tap  Option. The settings open over the screen.

Tap the setting you want to change.

General settings	Exposure	+2, +1, 0, -1, -2
	Picture size	3M Pixels, 2M Pixels, 1M Pixels, VGA, QVGA
	Picture quality	Super fine, Fine, Normal
	Color effect	None, Mono, Sepia, Negative
	Camera settings	Restore defaults

GPS location	Off / On	Activate to use your phone's location-based services. Take pictures wherever you are and tag them with the location.
White balance	 Auto,  Incandescent,  Daylight,  Fluorescent,  Cloudy.	
Storage	Phone/SD Card	To set the storage location

- Tap screen to close the settings menus.

3. Taking a picture

- From the Home screen, tap   Camera.
- Frame your subject on screen.
- Tap  . The camera brings the image into focus. When the image is in focus, the camera takes a picture. The picture you just took is briefly previewed full-screen, and then is displayed as a thumbnail in the lower left corner. Tap the thumbnail to view, share, or work with your pictures in Gallery.

4. Opening Camcorder

- When you're in Camera mode, tap  to choose  change to camcorder.

Camcorder.

1. Camcorder settings

When in Camcorder mode, Camcorder settings are displayed on screen. Before recording, you can

adjust your camcorder settings or leave them in automatic mode.



Tap **Option**. The settings open over the screen.

- Tap **screen** to close the settings menus

Tap the setting you want to change.

General settings	Color effect	None, Mono, Sepia, Negative
	Video quality	WVGA, VGA, CIF, QVGA,
	Video Encoder	MPEG4, H263, H264
	Audio Encoder	AMRNB, AAC
	Video duration	30 seconds (MMS), 10 minutes, 30 minutes
	Camera settings	Restore defaults
White balance	Auto, Incandescent, Daylight, Fluorescent, Cloudy.	
Video quality	High (30m), Low (30m), MMS (Low, 15s), YouTube (High, 10m), Custom	

NOTE Depending on the selected video quality, not all video quality and video encoder options may be available.

Sound Recorder

1. Opening Sound Recorder.

1. From the Home screen, tap Apps > Sound Recorder.
2. Tap to start recording a voice clip.
3. Tap to stop recording.
 - To save the voice clip, enter voice record name > tap Done.
 - To discard the voice clip, tap **Discard**.
 - Tap to listen to the recording.

2. Recording videos

1. From the Home screen, tap Apps > Camera > tap > choose .
2. Frame the scene where you want to start recording.
3. Tap to start recording.
4. Tap to stop recording.

An image from your most recent video is displayed as a thumbnail at the top right. Tap the thumbnail to view, share, or work with your videos in Gallery.

Tools

Clock

1. Opening the Clock

1. From the Home screen, tap  Apps >  Clock.
 - The Clock application opens and displays the date, time and other useful information.
 - Tap **Set alarm** to set alarm.



2. Managing Alarms

1. Adding a new alarm

1. From the Home screen, tap  Apps >  Clock.
2. Tap  Set alarm >  Add alarm.
3. To change the alarm time, scroll up and down to type the number. Then toggle AM/PM > Set.
4. Check the checkbox, 'Turn alarm on'.
5. Edit Turn alarm on, Time, Repeat, Ringtone, Vibrate and Label > Ok.

2. Editing an alarm

1. From the Home screen, tap  Apps >  Clock.
2. Tap  > Tap an existing alarm.
3. Turn the alarm on or off by checking or un-checking the checkbox, 'Turn alarm on'. In the alarm list, set alarms are underlined in green.
4. Edit Time, Repeat, Ringtone, Vibrate and Label > Done. Or tap Delete to remove the alarm > OK.

3. Changing alarm settings

1. From the Home screen, tap  Apps >  Clock
2. Tap  > tap  Option > Settings.

Alarm in silent mode	Check to play alarms even when the phone is in silent mode.
Alarm volume	Set the volume of alarms.
Snooze duration	Set how long Clock waits before playing an alarm again.
Auto-silence	Alarm will silence after 10 minutes
Volume button	Set the side button behavior for alarms.
Set default ringtone	Set ringtone default

4. Stopping an alarm

1. When the alarm sounds, tap **Dismiss** to stop the alarm.
- Tap **Snooze** to repeat the alarm after a specified length of time.

Calculator

Using Calculator

1. From the Home screen, tap  Apps >  Calculator.
2. Enter numbers and arithmetic operators.

- Tap  **Option >Advanced panel.**
- Tap and hold the Calculator's display to open a text editing menu. You can cut, copy, and select text for use in Calculator or other Applications.
- Tap **Clear history** to delete the last number or operator you entered. Tap and hold **DELETE** to delete everything in the display.

Settings

Settings on Your Phone

Control and customize phone settings on the Settings screen.

1. From the Home screen, tap  Apps >  Settings.

- **Wireless & networks**

Wi-Fi/ Wi-Fi settings	Wi-Fi On / Off. Set up and manage Wi-Fi networks. For details about working with these settings, see "Wi-Fi".
Bluetooth/ Bluetooth settings	Bluetooth On / Off. For details about working with these settings, see "Bluetooth".
Data usage	This setting you can see mobile data and wi-fi data statistics, and you can turn on or turn off the data.
more	VPN settings Set up and manage Virtual Private Networks (VPNs).
	Airplane mode Airplane mode On / Off. Check to turn off all the phone's radios that transmit voice or data.
	Mobile network The settings include Data enable, Data roaming, Access Point Names. And you can choose use only 2G network
	Emergency alerts Select the types of emergency alerts to display

Sound

Volume	Set the volume of ringtones that sound when you receive a phone call or notification, media (music, videos, and so on), and alarms.
Phone ringtone	Select the ringtone to sound when you receive a phone call.
Default notification	Select the ringtone to sound when you receive a notification.
Vibrate when ring	Vibrate when the ringtone ring out.
Dial pad touch tones	Check to play tones when using dial pad.
Touch sound	Check to play sound when touching the panel.
Screen lock sounds	Check to play sounds when locking and unlocking the screen.
Vibrate on touch	When touch the panel will vibrate.
Emergency tone	Select the Emergency tone

Display

Brightness	Adjusting the brightness of the screen.
Auto-rotate screen	Automatically switch the orientation of the screen as you turn the phone sideways or even upside down.
Wallpaper	You can set wallpaper.
Sleep	Adjust the delay before the screen automatically turns off.
Font size	You can set the size of display.

Storage

Storage manager, you can see the SD card and the phone space.

Unmount SD card	Unmount the SD card so you can safely remove it.
Erase SD card	Erases all data on the SD card, such as music and photos.
Mount SD card	Add SD card.
Erase Phone storage	Erases all data on the phone storage, such as music and photos.
Primary storage	Switch primary storage.

Battery

Tap Battery you can see how much the apps using the battery and the all battery.

Apps

Manage apps	Manage and remove installed applications.
-------------	---

Location

Access to my location	Let apps that have asked your permission use your location information.
GPS satellites	Let apps use GPS on your phone to pinpoint your location.
Wi-Fi & mobile network location	Let apps use Google's location service to estimate your location faster. Anonymous location data will be collected and sent to Google.

Security

Screen lock	Configure your phone to require a pattern, PIN, or password to unlock your screen.
Owner info	Show owner info on lock screen, you can type text to display on the lock screen.
Make passwords visible	Show password characters as you enter them.
Device administrators	View or deactivate device administrators.
Unknown sources	Check to allow installation of non-Market applications.

Trusted credentials	Display trusted CA certificates.
Install from SD card	Install certificates from SD card.
Clear credential	You can remove all credentials.

Language & input

language	Select the language to use for the text on your phone.
Personal dictionary	Add or delete the words suggested when entering text.
Android keyboard	Set Vibrate on key-press, Sound on key-press, Popup on key-press, Touch to correct words, Auto-capitalization, Show settings key, Voice input, Input languages, Quick fixes, Show suggestions or Auto-complete. For details about working with these settings, see "Using the onscreen keyboard".
Voice search	You can set the voice search.
Text-to-speech output	You can set the Text-to-speech output.
Pointer speed	You can set the speed of point.

Back & reset

Back up my data	Back up app data, Wi-Fi passwords, and other settings to Google servers.
Back up account	Backing up to debug-only private cache.

Automatic restore	When reinstalling an app, restore backed up settings and data.
Factory data reset	Erases all data on phone and reset.

Accounts

You can add an account for Corporate, Email, Facebook, Google, and Twitter.

Date & time

Automatic time zone	Use network-provided time zone.
Use 24-hour format	Display the time using 24-hour format.
choose date Format	Select the format for displaying date.

Accessibility

Talkback	When talkback is on, your device provides spoken feedback to help blind and low-vision users. For example, it describes what you touch, select, and activate.
Large text	Let the word large or normal
Power button ends call	When the icon is on, you can press power on/off icon ends call.
Auto-rotate screen	Let the phone auto rotate .
Speak passwords	If you set the passwords, you can speak password unlock the phone.

Touch & hold delay	Set the time of touch & hold short, medium, long.
Enhance web accessibility	If you install scripts from Google that make their web content more accessible.

ⓘ About phone

System updates	You can upgrade your system to up-to-date version.
Status	Information about your Phone number, signal, etc.
Legal information	Legal information about Open source licenses and Google legal.
Model number	Check the Model number.
Android version	Check the android version.
Baseband version	Check the baseband version.
Kernel version	Check the Kernel version.
Software version	The phone's build number.
Hardware version	You can check hardware version.



3. Upgrade according to tips.
4. During the period of update, the target device will automatically reboot for TWO times. Please don't operate the device until the update is completed.

Firmware Upgrade

1. Make sure the target device is power on with a fully charged battery.
2. Tap to go to Settings>**About phone** and tap **System update**.

Safety and use

Product safety &
warranty information.

Important Safety Information

Keep the phone (“Product”) away from dust, water, damp areas, precipitation and humidity. Dust, water, liquids, precipitation and humidity may cause overheating, electrical leakage, and/or Product failure. The Product, battery, charger and AC adapter are not waterproof. Keep them away from liquid, fuels and chemicals. If the Product gets wet, do not place the Product in an oven, microwave or dryer, as this will damage the Product and could cause a fire or explosion.

Only use the battery and charger approved by the manufacturer. Using other brands may cause battery leakage, overheating, explosion or even fire. Do not use the Product where it might cause danger. Do NOT text and drive.

Battery Use

Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling of removable battery and, particularly, from

the continued use of damaged batteries.

- Do not disassemble or open, crush, bend or deform, puncture or shred
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery for the system for which it is specified
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.
- Only authorized service providers shall replace battery. (If the battery is non-user replaceable).
- Promptly dispose of used batteries in accordance with local regulations
- Battery usage by children should be supervised.

- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.

- Improper battery use may result in a fire, explosion or other hazard.
- The maximum operating temperature is 45° C.

Note: The battery shall only be serviced by the manufacturer.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries in accordance with local regulations.

Cleaning and Maintenance

The Product, the battery and the charger are not waterproof. Do not use them in places with high humidity like a bathroom and also avoid spilling any liquids on the Product, battery or charger. Use a soft cloth to clean the Product, the battery and the charger. Do not use alcohol, diluted liquid or benzene to clean the Product.

Disposal of Product and Batteries

Follow local regulations regarding disposal of mobile devices and batteries. In some areas, the disposal of these items in household or business trash may be prohibited. Please follow your local regulations and recycle Product if required. Batteries must be recycled or disposed of properly.

Certification Information (RoHS)

We at Sprint take our social responsibility seriously and are committed to the cause of serving our environment. It is in keeping with these commitments that we are proud to state that Sprint phones are RoHS compliant.

Hearing Aid Compatibility Information

This phone meets the M3/T3 level rating. This phone has been tested and rated for use with hearing aids for some of the wireless technologies it uses. However, there may be some newer technologies that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Ask your service provider or the manufacturer of this phone for information on hearing aid compatibility. When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this

interference noise and phones also vary in the amount of interference they generate.

L51 device is HAC M3/T3 compatible, reference ANSI C63.19-2011.

FCC SAR Warning

This model phone meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government:

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. The SAR guideline includes a considerable safety margin designed to assure the safety of all persons regardless of age and health.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on:

FCC ID: 2AM9L-SV67Q or at <http://Sprint.us/>

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and positions the handset a minimum of 1 cm from the body. Use of other enhancements may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1 cm from your body when the phone is switched on.

FCC Statement

This Product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This Product may not cause harmful interference, and
- (2) This Product must accept any interference received, including interference that may cause undesired operation.

NOTE 1:

This Product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This Product generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this Product does cause harmful interference to radio or television reception, which can be determined by turning the Product off and on, the user is encouraged to try to correct the interference by one or more of the

following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2:

Sprint or the manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to the Product. Such modifications could void the user's authority to operate the equipment. To view device FCC E-label information:

Main Menu ->Settings - -> About phone

Data transmission is always initiated by software, which is then passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it then turns off at the end of the packet. Therefore, the transmitter will be on only while one of the aforementioned packets is being transmitted. In other words, this device automatically

discontinues transmission in case of either absence of information to transmit or operational failure.

Sprint Limited Warranty

WHO THIS WARRANTY COVERS

This 12 month limited warranty extends only to the original purchaser of this product within the United States. This warranty is not transferable. This warranty is conditioned upon the proper use of the Product.

WHAT THIS WARRANTY COVERS

Sprint offers you a limited warranty that extends for the first twelve (12) month period to the original purchaser from the date of original purchase with proof of purchase. Without valid proof of purchase, Sprint offers a limited warranty extending fifteen (15) months from date of manufacture, which is coded on the product label ("Warranty Period").

Should the Product, inbox accessories or any part during normal consumer usage and conditions be proven defective in material or workmanship that results in Product failure, such defect(s) will be repaired or replaced (with new or rebuilt parts) at Sprint's discretion, without charge for parts or labor directly related to the defect.

WHAT THIS WARRANTY DOES NOT COVER

1. Warranty claims outside of the Product warranty Period.
2. Damage or defects caused by using the Product other than in the normal course.
3. Defects or damages resulting from accidental, misuse, abnormal use, abnormal conditions, improper storage, unauthorized modifications, unauthorized repair, improper installation, or other acts which are not the fault of Sprint.
4. Defects or damage resulting from excessive force or use of a metallic object when pressing the touch screen.
5. Product with altered, defaced or removed serial number.
6. Damage resulting from use of accessories not approved by Sprint.

7. Damage from exposure to moisture, humidity, excessive temperature or extreme environment.
8. Liquid damage due to not properly sealed/locked accessories, ports and or battery latches of water resistance devices.
9. All surfaces and externally exposed parts that are scratched or damaged due to normal customer use.
10. All software, including operating system software, third-party software, applications, and all other software of any kind.
11. Damage caused by ordinary wear and tear of the Product.
12. Customer abuse or other physical abuse or mistreatment of Product as evidenced by:
 - a. Missing required faceplate;
 - b. Damaged LCD or Lens (e.g., the product is either broken, cracked, smashed, bleeding, etc.);
 - c. IMEI is unreadable electronically or due to missing or altered serial number, IMEI and/or reliance date label so as to affect readability;
 - d. Missing keys on keypad beyond normal wear and tear;
 - e. Unapproved Product modification;
 - f. Visible Product surface physical damage resulting in product being smashed, chewed, gouged, burned or melted;
 - g. Liquid damage as evidenced by submission in liquid or any other evidence of liquid ingress, including corrosion of any of the connections and noticeable excessive residue.

WHAT ARE THE LIMITS OF Sprint' S LIABILITY

THIS LIMITED WARRANTY SETS OUT THE FULL EXTENT OF Sprint' S RESPONSIBILITIES AND THE EXCLUSIVE REMEDY REGARDING THE PRODUCT. ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL Sprint BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR FOR, WITHOUT LIMITATION, COMMERCIAL LOSS OF ANY SORT; LOSS OF USE, TIME, DATA, REPUTATION, OPPORTUNITY, GOODWILL, PROFITS, OR SAVINGS; INCONVENIENCE; INCIDENTAL, SPECIAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES ARISING FROM THE USE OR INABILITY TO USE THE PRODUCT. SOME STATES AND

JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE DISCLAIMER OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND DISCLAIMERS MAY NOT APPLY TO YOU.

SPRINT MAKES NO WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT USED IN CONJUNCTION WITH THE PRODUCT, OR THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT DISTRIBUTED BY Sprint OR OTHERWISE.

RESPONSIBILITY FOR THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT RESTS SOLELY WITH THE USER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT.

Nothing in the Product instructions or information shall be construed to create an express warranty of any kind with respect to the Product. No agent, employee, dealer, representative or reseller is authorized to modify or extend this Limited Warranty or to make binding representations or claims, whether in advertising, presentations or otherwise, on behalf of Sprint regarding the Product or this Limited Warranty. This Limited Warrant gives you specific legal rights and you may also have other rights that vary from state to state.

WHAT ARE THE PROCEDURES FOR RESOLVING DISPUTES?

ALL DISPUTES WITH Sprint ARISING IN ANY WAY FROM THIS LIMITED WARRANTY OR THE SALE, CONDITION OR PERFORMANCE OF THE PRODUCT SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY. Any such dispute shall not be combined or consolidated with a dispute involving any other person's or entity's products or claim and, specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration

Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of New York, without reference to its choice of laws principles, shall govern the interpretation of the Limited Warranty and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the Limited Warranty. This arbitration provision also applies to claims against Sprint's employees, representatives and affiliates if any such claim arises from the Product's sale, condition or performance.

HOW TO GET WARRANTY SERVICE

To obtain warranty service, please call the following telephone number from anywhere in the continental United States: 0755-86638990

Información sobre la garantía y seguridad del producto.

Seguridad y garantía guía

Información importante sobre seguridad

Mantenga el teléfono (el “Producto”) alejado del polvo, agua, zonas húmedas, lluvia y humedad. El polvo, el agua, los líquidos, la lluvia y la humedad podrían provocar recalentamiento, fuga de corriente y/o fallas en el Producto. El Producto, batería, cargador y adaptador de CA no son resistentes al agua. Manténgalos alejados de líquidos, combustibles y productos químicos. Si el Producto se moja, no lo coloque dentro del horno, microondas o secador; esto dañaría el Producto y podría provocar un incendio o explosión. Solo utilice la batería y el cargador aprobados por el fabricante. Usar productos de otras marcas podría ocasionar la fuga de ácidos de la batería, recalentamiento, una explosión o incluso un incendio. No utilice el Producto donde resulte peligroso. NO envíe mensajes de texto mientras conduce.

Uso de la batería

Manipule y guarde las baterías de manera adecuada para evitar lesiones o daños. La mayoría de los problemas de batería surge debido al uso inadecuado de las baterías, especialmente, por el uso prolongado de baterías dañadas.

a) No desarme, abra, rompa, doble, deforme, perfore o destruya la batería.

- No modifique o re manufacture, no intente insertar objetos extraños en la batería, no sumerja o exponga al agua u otros líquidos, no exponga al fuego, explosión u otro peligro.

- Utilice únicamente la batería para el sistema para el que está especificada

- Utilice la batería solo con un sistema de carga que haya sido calificado según los requisitos del Certificado de CTIA para el cumplimiento del sistema de batería según IEEE 1725. El uso de una batería o cargador no calificado puede presentar un riesgo de incendio, explosión, fuga u otro peligro.

- No haga cortocircuito la batería ni permita que objetos conductores metálicos entren en contacto con los terminales de la batería.

- Reemplace la batería solo con otra batería que haya sido calificada con el sistema según el estándar IEEE-Std-1725. El uso de una batería no calificada puede presentar un riesgo de incendio, explosión, fuga u otro peligro.

- Solo los proveedores de servicio autorizados deben reemplazar la batería. (Si la batería no es reemplazable por el usuario).

- Deseche de inmediato las baterías usadas de acuerdo con las regulaciones locales

- El uso de la batería por parte de los niños debe ser supervisado.

- Evite dejar caer el teléfono o la batería. Si el teléfono o la batería se caen, especialmente en una superficie dura y el usuario sospecha que hay daños, llévelo a un centro de servicio para su inspección.

- El uso incorrecto de la batería puede provocar un incendio, una explosión u otro peligro.

- La temperatura máxima de funcionamiento es de 45 ° C.

Nota : La batería sólo debe ser reparado por el fabricante .

PRECAUCIÓN : Existe riesgo de explosión si la batería se sustituye por un tipo

incorrecto. Deseche las baterías usadas de acuerdo con las regulaciones locales.

Limpieza y mantenimiento

El Producto, la batería y el cargador no son resistentes al agua. No los utilice en lugares con mucha humedad como un baño y evite derramar cualquier líquido sobre el Producto, batería o cargador. Utilice un paño suave para limpiar el Producto, la batería y el cargador. No utilice alcohol, líquido diluido o benceno para limpiar el Producto.

Desecho del Producto y las baterías

Respete las regulaciones locales relativas al desecho de dispositivos móviles y baterías. En algunos lugares, el desecho de estos artículos junto con la basura doméstica o de comercios podría estar prohibido. Por favor, respete las regulaciones locales y recicle el Producto si las baterías requeridas deben reciclarse o desecharse adecuadamente.

Información de certificación (RoHS)

En Sprint nos tomamos nuestra responsabilidad social muy en serio y tenemos un compromiso con la causa de servir al medioambiente. En consonancia con estos compromisos tenemos el placer de afirmar que los teléfonos Sprint cumplen con la directiva RoHS.

Información sobre compatibilidad con audífonos

Este teléfono cumple con la clasificación de nivel M3 / T3. Este teléfono ha sido probado y clasificado para usar con audífonos para algunas de las tecnologías inalámbricas que utiliza. Sin embargo, puede haber algunas nuevas tecnologías que aún no han sido probadas para su uso con audífonos. Es importante probar las diferentes características de este teléfono a fondo y en diferentes lugares, usando su audífono o implante coclear, para determinar si escucha algún ruido de interferencia. Consulte a su proveedor de servicios o al fabricante de este teléfono para obtener información sobre la compatibilidad de los audífonos. Cuando se usan algunos teléfonos móviles cerca de algunos dispositivos auditivos (audífonos e implantes cocleares), los usuarios pueden detectar zumbidos, zumbidos o ruidos. Algunos dispositivos auditivos son más inmunes que otros a este ruido de interferencia y los teléfonos también varían en la cantidad de interferencia que generan.

El dispositivo L51 es compatible con HAC M3 / T3, referencia ANSI C63. 19-2011.

Advertencia de la Comisión Federal de Comunicaciones (FCC) sobre la Tasa de Absorción Específica (SAR)

Este modelo de teléfono cumple con las exigencias del gobierno para la exposición a ondas de radio. Este teléfono está diseñado y fabricado para no superar los límites de emisión de exposición a la energía de radiofrecuencia (RF) establecidos por la Comisión Federal de Comunicaciones del Gobierno de los EE. UU: El estándar de exposición para teléfonos móviles inalámbricos emplea una unidad de medición conocida como Tasa de Absorción Específica o SAR. El límite de SAR establecido por la FCC es de 1.6W/kg. Las pruebas de la SAR se llevan a cabo mediante el uso de posiciones de funcionamiento estándar aceptadas por la FCC con el teléfono transmitiendo a su nivel de potencia certificado más alto en todas las bandas de frecuencia probadas. La directriz SAR incluye un considerable margen de seguridad diseñado para garantizar la seguridad de todas las personas, independientemente de su edad y salud.

La FCC ha concedido una Autorización de Equipo para este modelo de teléfono con todos los niveles de SAR informados que se evaluaron conforme a los lineamientos de exposición a RF de la FCC. La información sobre SAR de este modelo de teléfono se encuentra archivada en la FCC y puede encontrarse en la sección "Display Grant" (Mostrar Permiso) en <http://www.fcc.gov/oet/fccid> después de buscar en FCC ID: L51 o en <http://Sprint.us/>

Al usarlo junto al cuerpo, este teléfono ha sido probado y cumple con los lineamientos de exposición a la RF de la FCC para el uso con un accesorio que no contenga metal y posicionando los auriculares a una distancia mínima de 1 cm del cuerpo. El uso de otros accesorios podría no garantizar el cumplimiento de los lineamientos de exposición a la RF de la FCC. Si no emplea un accesorio para utilizarlo en el cuerpo y no sujeta el teléfono junto al oído, coloque los auriculares a un mínimo de 1 cm de su cuerpo cuando el teléfono esté encendido.

Declaración FCC

Este Producto cumple con la parte 15 de las Reglas FCC. El uso está sujeto a las siguientes dos condiciones:

(1) Este Producto no debe causar interferencias dañinas, y

(2) Este Producto debe aceptar las interferencias recibidas, incluidas las interferencias que puedan causar un funcionamiento no deseado.

NOTA 1:

Se ha comprobado que este Producto cumple con los límites de dispositivo digital Clase B, de conformidad con la parte 15 de las Reglas FCC. Estos límites están diseñados para proporcionar protección razonable contra interferencia en una instalación residencial. Este Producto genera, utiliza y puede irradiar energía de radiofrecuencia y si no se instala y utiliza de acuerdo con las instrucciones, podría causar interferencia dañina en las comunicaciones por radio. Sin embargo, no se puede garantizar que dicha interferencia no ocurra en una instalación determinada. Si el Producto ocasiona interferencia dañina en la recepción de radio o televisión, lo cual puede determinarse al apagar y encender el Producto, se le recomienda al usuario tratar de corregir la interferencia haciendo algunas de las siguientes cosas:

- Reorientar o ubicar en otro lado la antena receptora.
- Incrementar la separación entre los dispositivos y el receptor.
- Conectar los dispositivos a un enchufe de energía de un circuito diferente al que se encuentra conectado el receptor.
- Consulte con el distribuidor o con un técnico de radio / TV experimentado para obtener ayuda.

NOTA 2:

Ni Sprint ni el fabricante son responsables por cualquier interferencia de radio o televisión causada por modificaciones no autorizadas al Producto. Dichas modificaciones podrían anular el derecho del usuario a hacer uso del dispositivo.

Para ver la información de la etiqueta E de la FCC del dispositivo:
Menú principal -> Configuraciones - -> Acerca del teléfono

La transmisión de datos siempre es iniciada por el software, que es el transmitido a través del MAC, a través de la banda de base digital y analógica, y finalmente a la Chip de RF. El MAC inicia varios paquetes especiales. Estos son los únicos formas en que la parte de banda de banda digital encenderá el transmisor de RF, que luego se apaga al final del paquete. Por lo tanto, el transmisor estará encendido solo mientras se transmite uno de los paquetes antes mencionados. En

otra palabras, este dispositivo interrumpe automáticamente la transmisión en caso de que ausencia de información para transmitir o falla operativa.

GARANTÍA LIMITADA DE Sprint

¿A QUIÉN CUBRE LA GARANTÍA?

La garantía limitada de 12 meses se extenderá únicamente al comprador original del producto dentro de los Estados Unidos. Esta garantía no es transferible. Esta garantía está sujeta al uso adecuado del Producto.

¿QUÉ CUBRE LA GARANTÍA?

Sprint le ofrece una garantía limitada al comprador original por los primeros doce (12) meses a partir de la fecha de compra y siempre y cuando disponga del comprobante de compra. Ante la falta de un comprobante de compra válido, Sprint ofrece una garantía limitada de quince (15) meses a partir de la fecha de fabricación, la cual figura en la etiqueta del producto ("Período de garantía").

En caso de que el Producto, los accesorios de la caja o cualquier otra parte presente defectos de material o de mano de obra durante uso y condiciones normales que ocasionen la falla del Producto, dichos defectos serán reparados o se sustituirán las partes defectuosas (con partes nuevas o reparadas) a la entera discreción de Sprint, sin cargos adicionales por las partes o el trabajo relacionado directamente con el defecto.

¿QUÉ NO CUBRE LA GARANTÍA?

1. Reclamos de garantía fuera del Período de garantía del Producto.
2. Daños o defectos ocasionados al Producto debido a un uso que no es el habitual.
3. Defectos o daños provenientes de un accidente, uso indebido, uso anormal, condiciones anormales, almacenamiento inadecuado, modificaciones no autorizadas, reparaciones no autorizadas, instalación incorrecta u otras acciones que no pueden atribuirse a Sprint.
4. Defectos o daños provenientes del uso excesivo de fuerza o el uso de un objeto metálico al presionar la pantalla la pantalla.
5. Un Producto sin número de serie o con un número de serie alterado o

desgastado.

6. Daños provenientes del uso de accesorios no aprobados por Sprint.
7. Daños provenientes de la exposición a la humedad, temperaturas excesivas o condiciones ambientales extremas.
8. Daños por líquidos provenientes de accesorios, puertos y/o seguros de la batería de los dispositivos resistentes al agua que no se han sellado bloqueado correctamente.
9. Todas las superficies y partes externamente expuestas que se rayen o dañen debido al uso habitual del cliente.
10. Todo el software, incluido el sistema operativo, software de terceros, aplicaciones y cualquier otro software de cualquier tipo.
11. Daños causados por el desgaste normal del Producto.
12. Abuso del cliente o cualquier otro abuso físico o maltrato al Producto tal como demuestra:
 - a. La falta de la carcasa requerida.
 - b. El LCD o Lente dañado (es decir, el producto está roto, agrietado, destrozado, descolorido, etc.).
 - c. El IMEI no puede leerse electrónicamente o falta el número de serie, IMEI y/o la etiqueta de datos confiables, o estos han sido alterados en un modo que afecta la legibilidad.
 - d. Teclas faltantes en el teclado, lo cual excede el desgaste normal.
 - e. Modificaciones no aprobadas del Producto.
 - f. Daños físicos visibles en la superficie del Producto debido a que el producto ha sido destrozado, masticado, perforado, quemado o derretido.
 - g. Daños por líquidos evidenciados por el sumergimiento en líquido o cualquier otra prueba de ingreso de líquido, incluida la corrosión de cualquiera de las conexiones y residuos excesivos evidentes.

¿CUÁLES SON LOS LÍMITES DE LA RESPONSABILIDAD DE Sprint?

LA PRESENTE GARANTÍA LIMITADA ESTABLECE EL ALCANCE TOTAL DE LAS RESPONSABILIDADES DE Sprint Y EL RECURSO EXCLUSIVO EN LO RELATIVO AL PRODUCTO. TODAS LAS GARANTÍAS IMPLÍCITAS, INCLUIDAS A MERO TÍTULO ENUNCIATIVO, LAS GARANTÍAS IMPLÍCITAS DE COMERCIABILIDAD O APTITUD PARA UN FIN DETERMINADO, QUEDAN RESTRINGIDAS A LA DURACIÓN DE

LA PRESENTE GARANTÍA. BAJO NINGUNA CIRCUNSTANCIA Sprint SERÁ RESPONSABLE POR DAÑOS QUE SUPEREN EL PRECIO DE COMPRA DEL PRODUCTO O POR, ENTRE OTROS, PÉRDIDA COMERCIAL DE CUALQUIER TIPO; PÉRDIDA DE USO, TIEMPO, DATOS, REPUTACIÓN, OPORTUNIDAD, FONDO DE COMERCIO, GANANCIAS O AHORROS; INCONVENIENTES; DAÑOS INCIDENTALES, ESPECIALES, CONSECUENTES O PUNITIVOS QUE SURJAN DEL USO O LA IMPOSIBILIDAD DE USO DEL PRODUCTO. ALGUNOS ESTADOS Y JURISDICCIONES NO PERMITEN RESTRICCIONES EN CUANTO A LA DURACIÓN DE UNA GARANTÍA LIMITADA O EL DESCARGO DE RESPONSABILIDAD O RESTRICCIÓN DE LOS DAÑOS INCIDENTALES O CONSECUENTES, POR LO QUE LAS RESTRICCIONES Y DESCARGOS DE RESPONSABILIDAD ANTERIORES PODRÍAN NO SER APLICABLES EN SU CASO.

SPRINT NO OFRECE NINGUNA GARANTÍA NI REALIZA NINGUNA DECLARACIÓN, EXPRESA O IMPLÍCITA, ESTATUTARIA O DE OTRO TIPO, EN CUANTO A LA CALIDAD, CAPACIDADES, FUNCIONAMIENTO, RENDIMIENTO O APTITUD DE NINGÚN SOFTWARE O EQUIPO DE UN TERCERO UTILIZADO EN CONJUNTO CON EL PRODUCTO, O EN CUANTO A LA POSIBILIDAD DE INTEGRAR DICHO SOFTWARE O EQUIPO AL PRODUCTO DISTRIBUIDO POR Sprint O POR OTRO MEDIO. LA RESPONSABILIDAD POR LA CALIDAD, CAPACIDADES, FUNCIONAMIENTO, RENDIMIENTO Y APTITUD DE DICHO SOFTWARE O EQUIPO DE UN TERCERO PERTENECE ÚNICAMENTE AL USUARIO Y AL VENDEDOR, DUEÑO O PROVEEDOR DIRECTO DE DICHO SOFTWARE O EQUIPO DE UN TERCERO.

Ni las instrucciones ni la información del Producto serán interpretadas como concesión de una garantía expresa de ningún tipo con respecto al Producto. Ningún agente, empleado, vendedor, representante o revendedor está autorizado a modificar o extender esta Garantía limitada o hacer declaraciones o afirmaciones, ya sea en anuncios, presentaciones o de cualquier otra forma, en nombre de Sprint en relación con el Producto o esta Garantía limitada. La presente Garantía limitada le confiere derechos legales específicos y podrá tener además

otros derechos que varí an según el estado.

¿CUÁLES SON LOS PROCEDIMIENTOS PARA RESOLVER CONTROVERSIAS? TODA CONTROVERSIAS CON Sprint QUE SURJA DE ALGÚN MODO DE ESTA GARANTÍA LIMITADA O LA VENTA, CONDICIÓN O RENDIMIENTO DEL PRODUCTO SERÁ RESUELTA ÚNICAMENTE A TRAVÉS DE UN ARBITRAJE VINCULANTE Y DEFINITIVO, Y NO POR UN TRIBUNAL O JURADO. No se combinará o consolidará ninguna controversia con otra controversia que involucre los productos o reclamos de cualquier otra persona o entidad y, sin perjuicio de lo anterior, bajo ninguna circunstancia se desarrollará esta controversia como parte de una demanda colectiva. El arbitraje se llevará a cabo ante un único árbitro, cuyo laudo arbitral no podrá superar, en su forma o cantidad, el resarcimiento permitido por las leyes aplicables. El arbitraje se llevará a cabo de acuerdo con las Reglas de Arbitraje Comercial de la Asociación Estadounidense de Arbitraje

(American Arbitration Association, AAA) aplicables a las controversias en materia de consumo. Se incorpora esta disposición de arbitraje de conformidad con la Ley Federal de Arbitraje. La interpretación de la Garantía limitada y todas las controversias sujetas a esta disposición de arbitraje serán reguladas por las leyes del estado de New York, sin remisión alguna a sus normas de conflicto. El árbitro decidirá todas las cuestiones de interpretación y aplicación de esta disposición de arbitraje y la Garantía limitada. Esta disposición de arbitraje también se aplica a demandas que se realicen en contra de los empleados, representantes y socios de Sprint si el reclamo surgiera de la venta, condición o rendimiento del Producto.

¿CÓMO OBTENER EL SERVICIO DE GARANTÍA?

Para recibir el servicio de garantía, llame al siguiente número de teléfono desde cualquier ubicación continental de los Estados Unidos: 0755-86638990