

Overview of Buttons

Quick Guide to NeuroTennis

Overview of Buttons

>

Charging and Power

>

Pairing and Communication

>

NT Adjustments on the Court

>

Lesson and Drill Selection

>

Customizing Coaching Instructions, Drills and Lessons

>

Editing and Copying Coaching Instructions, Drills, and Lessons

>

Settings

>

<

Overview of Buttons

Done



Each of the NT200 buttons can have multiple functions, depending on whether you press and release, or you press and hold (for about 3 sec.)

“Source” / Device-to-Device Pairing

Press to set the “source” that triggers coaching instructions.

Press and hold for device-to-device pairing.

Next

<

Overview of Buttons

Done



Frequency / Bluetooth Pairing with App

Press to set Frequency of coaching instruction generation.

Press and hold for Bluetooth Pairing.

Prev

Next

<

Overview of Buttons

Done



Play / Pause

Press to find out current drill; press again to go to next drill.

Press and hold to pause lesson; press and hold again to switch lessons.

Prev

Next

<

Overview of Buttons

Done



Volume / Return Coaching Instruction (indicated by “R”)

Press to set volume level.

Press and hold to hear a “Return” coaching instruction.

Prev

Next

<

Overview of Buttons

Done



Sensitivity / Serve Coaching Instruction (indicated by “S”)

Press to set impact sensitivity.

Press and hold to hear a “Serve” coaching instruction.

Prev