




Inxpect SRE 200 Series

SRE - Safety Radar Equipment

5 meters range sensors - With Teach-In function



Instruction manual v1.7 - EN

Original instructions



WARNING! Anyone who uses this system must read the instruction manual to ensure safety. Read and adhere to the "Safety information" chapter in its entirety before using the system for the first time.

Copyright © 2021-2024, Inxpect SpA

All rights reserved in all countries.

Any distribution, alteration, translation or reproduction, partial or total, of this document is strictly prohibited unless with prior authorization in writing from Inxpect SpA, with the following exceptions:

- Printing the document in its original format, totally or partially.
- Transferring the document on websites or other electronic systems.
- Copying contents without any modification and stating Inxpect SpA as copyright owner.

Inxpect SpA reserves the right to make modifications or improvements to the relative documentation without prior notice.

Requests for authorizations, additional copies of this manual or technical information about this manual must be addressed to:

Inxpect SpA
Via Serpente, 91
25131 Brescia (BS)
Italy
safety-support@inxpect.com
+39 030 5785105

Contents

Glossary of terms	v
1. This manual	7
1.1 Information on this manual	7
2. Safety	10
2.1 Safety information	10
2.2 Conformity	13
3. Get to know Inxpect SRE 200 Series	14
3.1 Inxpect SRE 200 Series	14
3.2 Control units	16
3.3 Control unit inputs	23
3.4 Control unit outputs	24
3.5 Sensors	28
3.6 System applications	31
3.7 System configuration	33
4. System communication	36
4.1 Fieldbus communication (PROFIsafe)	36
4.2 Fieldbus communication (Safety over EtherCAT® - FSofE)	37
4.3 Fieldbus communication (CIP Safety™ on Ethernet/IT™)	39
4.4 MODBUS communication	40
5. Functioning principles	41
5.1 Sensor functioning principles	41
5.2 Detection fields	41
6. Safety functions	47
6.1 Safety working modes and safety functions	47
6.2 Safety working mode: Access detection and restart prevention (default)	48
6.3 Safety working mode: Always-on access detection	48
6.4 Restart prevention function: static object detection option	49
6.5 Features of the restart prevention function	49
7. Other functions	52
7.1 Muting	52
7.2 Teach-In function (-WT sensors only)	53
7.3 Anti-tampering functions: anti-rotation around axes	57
7.4 Anti-tampering functions: anti-masking	59
7.5 Auto-resume (5.x sensors only)	60
7.6 Electromagnetic Robustness	61
8. Sensor position	62
8.1 Basic concepts	62
8.2 Sensor field of view	63
8.3 Advanced field of view (5.x sensors only)	69
8.4 Cuboid shape (only for S202A-MC sensors)	71
8.5 Separation distance calculation	72
8.6 Calculation of range of distances	78
8.7 Sensor position recommendations	80
8.8 Installations on moving elements (Mobile application)	81
8.9 Outdoor installations	83
9. Installation and use procedures	84
9.1 Before installation	84
9.2 Install Inxpect SRE 200 Series	84
9.3 Set the sensor inclination with a 1° precision	91
9.4 Configure Inxpect SRE 200 Series	94
9.5 Validate the safety functions	96
9.6 Fieldbus network integration	100
9.7 Manage the configuration	100
9.8 Other procedures	101
10. Troubleshooting	104
10.1 Troubleshooting procedures	104
10.2 Event log management	108

10.3 INFO events	112
10.4 ERROR events (control unit)	115
10.5 ERROR events (sensor)	117
10.6 ERROR events (CAN bus)	119
11. Maintenance	120
11.1 Planned maintenance	120
11.2 Extraordinary maintenance	120
12. Technical references	123
12.1 Technical data	124
12.2 Terminal blocks and connector pin-outs	128
12.3 Target position angle conventions	129
12.4 Electrical connections	131
12.5 Configuration application parameters	138
12.6 Digital input signals	143
13. Appendix	156
13.1 System software	156
13.2 Disposal	157
13.3 Service and warranty	157
13.4 Intellectual property	157
13.5 Checklist for installing ESPE	157

Glossary of terms

A

Activated output (ON-state)

Output that switches from OFF to ON-state.

D

Dangerous area

Area to be monitored because it is dangerous for people.

Deactivated output (OFF-state)

Output that switches from ON to OFF-state.

Detection distance x

Depth of the field of view configured for detection field x.

Detection field x

Portion of the field of view of the sensor. Detection field 1 is the field closer to the sensor.

Detection signal x

Output signal that describes the monitoring status of the detection field x.

E

ESPE (Electro-Sensitive Protective Equipment)

Device or system of devices used for the safety-related detection of people or parts of the body. ESPEs provide personal protection at machines and plants/systems where there is a risk of physical injury. These devices/systems cause the machine or plant/system to switch over to a safe status before a person is exposed to a dangerous situation.

F

Field of view

Sensor area of vision characterized by a specific angular coverage.

Fieldset

Structure of the field of view which can be composed of up to four detection fields.

FMCW

Frequency Modulated Continuous Wave

H

Horizontal angular coverage

Property of the field of view that corresponds to the coverage on the horizontal plane.

I

Inclination

Sensor rotation around the x-axis. The sensor inclination is the angle between a line perpendicular to the sensor and a line parallel to the ground.

M

Machinery

The system for which the dangerous area is monitored.

Monitored area

Area that is monitored by Inxpect SRE 200 Series. It is composed of all the fields of all the sensors.

O

OSSD

Output Signal Switching Device

R

RCS

Radar Cross-Section. Measure of how detectable an object is by radar. It depends, among other factors, on the material, dimension and position of the object.

T

Tolerance area

Area of the field of view where detection or not of a moving object/person depends on the characteristics of the same object itself.

V

Vertical angular coverage

Property of the field of view that corresponds to the coverage on the vertical plane.

1. This manual

1.1 Information on this manual

1.1.1 Objectives of this instruction manual

This manual explains how to integrate Inxpect SRE 200 Series with 5 meters range sensors to safeguard the machinery operators and how to install, use and maintain them safely.

This document includes all the information as Safety Manual according to IEC 61508-2/3 Annex D. Please refer in particular to "Safety parameters" on page 124 and to "System software" on page 156.

The functioning and safety of the machinery to which Inxpect SRE 200 Series is connected is out of the scope of this document.

1.1.2 Obligations with regard to this manual

 **NOTICE:** *this manual is an integral part of the product and must be kept for its entire working life.*

It must be consulted for all situations related to the life cycle of the product, from its delivery to decommissioning.

It must be stored so that it is accessible to operators, in a clean location and in good condition.

In the event of manual loss or damage, contact Technical Support (see "Technical Support" on page 157).

Always make the manual available for consultation when the equipment is sold.

1.1.3 Provided documentation

Document	Code	Date	Distribution format
Instruction manual - 5 meters range sensors- with Teach-In function(this manual)	Inxpect SAF-IM-200S_5m_Teach-In_7_00335_en	SEP 2024	online PDF PDF downloadable from the site https://tools.inxpect.com
Instruction manual - 9 meters range sensors- with Teach-In function	Inxpect SAF-IM-200S_9m_Teach-In_7_00336_en	SEP 2024	online PDF PDF downloadable from the site https://tools.inxpect.com
Installation instructions	Inxpect SAF-MI-100S-200S_26000041_7_00046_multi	SEP 2024	printed PDF downloadable from the site https://tools.inxpect.com
PROFIsafe communication Reference guide	Inxpect 100S_200S PROFIsafe RG_7_00067_en	MAY 2023	online PDF PDF downloadable from the site https://tools.inxpect.com
FSoE communication Reference guide	Inxpect 100S_200S FSoE RG_7_00237_en	MAY 2023	online PDF PDF downloadable from the site https://tools.inxpect.com
CIP Safety communication Reference guide	Inxpect 100S_200S CIP RG_7_00326_en	MAY 2024	online PDF PDF downloadable from the site https://tools.inxpect.com
MODBUS communication Reference guide	Inxpect 100S_200S MODBUS RG_7_00075_en	MAY 2023	online PDF PDF downloadable from the site https://tools.inxpect.com

Document	Code	Date	Distribution format
National configuration addendum	Inxpect 200S National configurations addendum_7_00079_multi	-	online PDF PDF downloadable from the site https://tools.inxpect.com
Cable validator	Inxpect 100S_200S Cable Validator tool_7_00066_en	-	online Excel Excel downloadable from the site https://tools.inxpect.com
200S Inxpect Spare Parts 5 m range	Inxpect 200S_5m Spare Parts_7_00330_en	-	online PDF PDF downloadable from the site https://tools.inxpect.com

1.1.4 Instruction manual updates

Publication date	Code	Hardware version	Firmware version	Updates
SEP 2024	Inxpect SAF-IM-200S_5m_Teach-In_7_00335_en_v1.7	Control units <ul style="list-style-type: none"> Type A: 2.3.0 Type B: 2.4.0 Sensors: <ul style="list-style-type: none"> S201A model: 2.2 S203A model: 1.0 S202A model: 1.1 	Control units: <ul style="list-style-type: none"> Type A: 2.1.0 Type B: 2.1.0 Sensors: <ul style="list-style-type: none"> S201A: 3.2 S201A-W/S201A-WT: 5.0 S203A-W/S203A-WT: 5.0 S202A-M: 1.0 S202A-MC: 1.0 	Added control units: C201A-C and C201B-C. Added sensors: S201A-WT and S203A-WT. Added the Teach-In function. Added sensors: S202A-M and S202A-MC. Added Inxpect Safety 3D application. Updated Dangerous area calculation in "Separation distance calculation" on page 72. Added new Detection signals (single channel): Detection signal "N" (non-safe) and Detection signal group "N" (non-safe). Added "Control unit inputs" on page 23. Added sign conventions for the target position, see "Target position angle conventions" on page 129. Changed the maximum current from 1 A to 1.2 A. Updated standards list. Removed the list of spare parts. Other minor changes.
DEC 2023	Inxpect SAF-IM-200S_5m_7_00047_en_v1.5	Control units: <ul style="list-style-type: none"> Type A: 2.2.0 Type B: 2.4.0 Sensors: <ul style="list-style-type: none"> S201A model: 2.2 S203A model: 1.0 	Control units: <ul style="list-style-type: none"> Type A: 2.0.0 Type B: 2.0.0 Sensors: <ul style="list-style-type: none"> S201A: 3.2 S201A-W: 5.0 S203A-W: 5.0 	Changed the total maximum length of the CAN bus line into 80 m (262.5 ft). Changed control unit maximum power into 11.2 W. Changed values for Case 4 in "Dynamic configuration through the digital inputs" on page 34.

Publication date	Code	Hardware version	Firmware version	Updates
MAY 2023	Inxpect SAF-IM-200S_5m_7_00047_en_v1.4	<p>Control units:</p> <ul style="list-style-type: none"> • Type A: 2.2.0 • Type B: 2.4.0 <p>Sensors:</p> <ul style="list-style-type: none"> • S201A model: 2.2 • S203A model : 1.0 	<p>Control units:</p> <ul style="list-style-type: none"> • Type A: 2.0.0 • Type B: 2.0.0 <p>Sensors:</p> <ul style="list-style-type: none"> • S201A: 3.2 • S201A-W: 5.0 • S203A-W: 5.0 	<p>Added control units: C201A-F, C201B-P, C201B-F, C202B, C203B.</p> <p>Added sensors: S201A-W, S201A-WL, S203A-W, S203A-WL.</p> <p>Updated procedures in "Validate the safety functions" on page 96.</p> <p>Added sensor configuration error details ("Sensor configuration error (SENSOR CONFIGURATION ERROR)" on page 117).</p> <p>Added multi-user management for the Inxpect Safety application.</p> <p>Changed name of digital input function: Activate dynamic configuration > Dynamic configuration switch</p> <p>New input functions: Restart signal on a single channel (cat 2), System recondition on a single channel (cat.2), and Fieldbus controlled on a single channel (cat.2).</p> <p>New inputs options: Redundancy mode, Encoded channel.</p> <p>New output functions: Detection signal group, Fieldbus controlled on a single channel.</p> <p>Updated Factory reset procedure ("Restore factory default settings" on page 101).</p> <p>Added Electromagnetic robustness parameter ("Electromagnetic Robustness" on page 61).</p> <p>Added Static object detection sensitivity.</p> <p>Updated "Separation distance calculation" on page 72.</p> <p>Added "OSSD diagnostic checks" on page 27.</p> <p>Other minor changes.</p>

Note: the firmware of the control unit can be updated through the Inxpect Safety application. The latest firmware version available contains the features described in the manual at the system level. The sensor firmware cannot be updated.

1.1.5 Intended users of this instruction manual

The recipients of the instruction manual are:

- the machinery manufacturer onto which the system will be installed
- system installer
- machinery maintenance technician

2. SAFETY

2.1 Safety information

2.1.1 SAFETY MESSAGES

Warnings related to the safety of the user and of the equipment as envisaged in this document are as follows:

 **WARNING!** Indicates a hazardous situation which, if not avoided, may cause death or serious injury.

NOTICE: indicates obligations that if not observed may cause harm to the equipment.

2.1.2 SAFETY SYMBOLS ON THE PRODUCT

 This symbol marked on the product indicates that the manual must be consulted. In particular, pay attention to the following activities:

- wiring of the connections (see "Terminal blocks and connector pin-outs" on page 128 and "Electrical connections" on page 131)
- cable operating temperature (see "Terminal blocks and connector pin-outs" on page 128)
- control unit cover, which was subjected to a low energy impact test (see "Technical data" on page 124)

2.1.3 PERSONNEL SKILLS

The recipients of this manual and the skills required for each activity presented herein are as follows:

Recipient	Assignments	Skills
Machinery manufacturer	<ul style="list-style-type: none">• defines which protective devices should be installed and sets the installation specifications	<ul style="list-style-type: none">• knowledge of significant hazards of the machinery that must be reduced based on risk assessment• knowledge of the entire machinery safety system and the system on which it is installed
Protection system installer	<ul style="list-style-type: none">• installs the system• configures the system• prints configuration reports	<ul style="list-style-type: none">• advanced technical knowledge in the electrical and industrial safety fields• knowledge of the dimensions of the dangerous area of the machinery to be monitored• receives instructions from the machinery manufacturer
Machinery maintenance technician	<ul style="list-style-type: none">• performs maintenance on the system	<ul style="list-style-type: none">• advanced technical knowledge in the electrical and industrial safety fields

2.1.4 SAFETY ASSESSMENT

Before using a device, a safety assessment in accordance with the Machinery Directive is required.

The product as an individual component fulfills the functional safety requirements in accordance with the standards stated in "Standards and Directives" on page 13. However, this does not guarantee the functional safety of the overall plant/machine. To achieve the relevant safety level of the overall plant/machine's required safety functions, each safety function needs to be considered separately.

2.1.5 INTENDED USE

Inxpect SRE 200 Series is a human body detection system, certified SIL 2 according to IEC/EN 62061, PL d according to EN ISO 13849-1 and Performance Class D according to IEC TS 62998-1.

It performs the following safety functions:

- **Access detection function:** access of one or more persons to a hazardous area deactivates the safety outputs to stop the moving parts of the machinery.
- **Restart prevention function:** prevents unexpected starting or restarting of the machinery. Detection of motion within the dangerous area maintains the safety outputs deactivated to prevent machinery starting.

It performs the following additional safety-related functions:

- **Stop signal** (Category 3, according to EN ISO 13849-1): it forces all the safety outputs to OFF-state. Only on C201A and C201B models, it signals a stop request status with a specific safety message on the Fieldbus output interface.
- **Restart signal:** it enables the control unit to switch to ON-state the safety outputs related to all the detection fields with no motion detected. Only on C201A and C201B models, it makes disappear a stop request status with a specific safety message on the Fieldbus output interface. It can be performed:
 - using single channel inputs/OSSDs (Category 2, according to EN ISO 13849-1)
 - using dual channel inputs/OSSDs (Category 3, according to EN ISO 13849-1)
- **Muting** (Category 3, according to EN ISO 13849-1): it inhibits the detection capability of one or a group of sensors (see "Muting" on page 52).
- **Dynamic configuration switch** (Category 3, according to EN ISO 13849-1): it allows the dynamic switch among previously set configurations (see "System configuration" on page 33).
- **Fieldbus controlled:** it monitors the input status through Fieldbus communication. It can be performed:
 - using single channel inputs/OSSDs (Category 2, according to EN ISO 13849-1): it provides the capability to safely redirect the value of the input data exchanged with the Fieldbus master to a physical status of the OSSDs.
 - using dual channel inputs/OSSDs (Category 3, according to EN ISO 13849-1): it provides the capability to safely redirect the status of the digital inputs to the output data exchanged with the Fieldbus master.



WARNING! the following faults makes the Fieldbus controlled safety-related function unavailable: POWER ERROR, TEMPERATURE ERROR, FIELDBUS ERROR, PERIPHERAL ERROR, FEE ERROR and FLASH ERROR.



WARNING! only for Stop signal, Restart signal, Muting and Dynamic configuration switch. Any fault on the sensors or the control unit brings the system to the safe state and makes the safety-related functions unavailable.

Inxpect SRE 200 Series is suitable for protecting the human body in the following scenarios:

- dangerous area protection in stationary and mobile applications
- indoor and outdoor applications

Inxpect SRE 200 Series meets requirements of applications safety functions that require a risk reduction level of:

- up to SIL 2, HFT = 0 according to IEC/EN 62061
- up to PL d, Category 3 according to EN ISO 13849-1
- up to Performance Class D according to IEC TS 62998-1

Inxpect SRE 200 Series, in combination with additional risk reduction means, can be used for applications safety functions that require higher risk reduction levels.

2.1.6 IMPROPER USE

The following is deemed improper use in particular:

- any component, technical or electrical modification to the product
- use of the product outside the areas described in this document
- use of the product outside the technical details, see "Technical data" on page 124

2.1.7 EMC-COMPLIANT ELECTRICAL INSTALLATION

NOTICE: The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

2.1.8 GENERAL WARNINGS

- Incorrect installation and configuration of the system decreases or inhibits the protective function of the system. Follow the instructions provided in this manual for correct installation, configuration and validation of the system.
- Changes to the system configuration may compromise the protective function of the system. After any changes made to the configuration, validate correct functioning of the system by following the instructions provided in this manual.
- If the system configuration allows access to the dangerous area without detection, implement additional safety measures (e.g., guards).
- The presence of static objects, in particular metallic objects, within the field of view may limit the efficiency of sensor detection. Keep the sensor field of view unobstructed.
- The system protection level (SIL 2, PL d) must be compatible with the requirements set forth in the risk assessment.
- Check that the temperature of the areas where the system is stored and installed is compatible with the storage and operating temperatures indicated in the technical data of this manual.
- Radiation from this device does not interfere with pacemakers or other medical devices.

2.1.9 WARNINGS FOR THE RESTART PREVENTION FUNCTION

- The restart prevention function is not guaranteed in blind spots. If required by the risk assessment, implement adequate safety measures in those areas.
- Machinery restarting must be enabled only in safe conditions. The button for the restart signal, when needed, must be installed:
 - outside of the dangerous area
 - not accessible from the dangerous area
 - in a point where the dangerous area is fully visible

2.1.10 RESPONSIBILITY

The machinery manufacturer and system installer are responsible for the operations listed below:

- Providing adequate integration of the safety output signals of the system.
- Checking the monitored area of the system and validating it based on the needs of the application and risk assessment.
- Following the instructions provided in this manual.

2.1.11 LIMITS

- If the static object detection option is disabled, the system cannot detect the presence of people who are immobile and not breathing or objects within the dangerous area.
- The system does not offer protection from pieces ejected from the machinery, from radiation, and objects falling from above.
- The machinery command must be electronically controlled.

2.1.12 DISPOSAL

In safety-related applications, comply with the mission time reported in "General specifications" on page 124. For decommissioning follow the instructions reported in "Disposal" on page 157.

2.2 Conformity

2.2.1 STANDARDS AND DIRECTIVES

Directives	2006/42/EC (MD - Machinery) 2014/53/EU (RED - Radio equipment)
Harmonized standards	EN ISO 13849-1: 2023 PL d EN ISO 13849-2: 2012 EN IEC 62061: 2021 ETSI EN 305 550-2 V1.2.1 IEC/EN 61010-1: 2010, A1:2019 ETSI EN 301 489-1 v2.2.3 (only emissions) ETSI EN 301 489-3 v2.1.1 (only emissions) EN IEC 61000-6-2:2019
Non-harmonized standards	EN IEC 61326-3-1:2017 EN IEC 61496-1: 2020 IEC/EN 61508: 2010 Part 1-7 SIL 2 ETSI EN 305 550-1 V1.2.1 IEC TS 62998-1:2019 UL 61010-1:2023 CAN/CSA 61010-1:2023 UL 61496-1:2021 EN IEC 61784-3-3:2021 for the PROFIsafe Fieldbus IEC/EN 61784-3-12:2010, A1:2019 for FSoE Fieldbus IEC/EN 61784-3-2:2021 for CIP Safety™ Fieldbus IEC TS 61496-5:2023

Note: no type of failure has been excluded during the system analysis and design phase.

All updated certifications can be downloaded from <https://www.inxpect.com/en/downloads>.

2.2.2 CE

The manufacturer, Inxpect SpA, states that Inxpect SRE 200 Series (Safety Radar Equipment) complies with the 2014/53/EU and 2006/42/EC directives. The full EU Declaration of Conformity text is available on the company's website: <https://www.inxpect.com/en/downloads>.

2.2.3 UKCA

The manufacturer, Inxpect SpA, states that Inxpect SRE 200 Series (Safety Radar Equipment) complies with Radio Equipment Regulations 2017 and Supply of Machinery (Safety) Regulations 2008. The full UKCA Declaration of Conformity text is available on the company's website: <https://www.inxpect.com/en/downloads>.

2.2.4 OTHER CONFORMITIES AND NATIONAL CONFIGURATIONS

For a complete, up-to-date list of product conformities and any national configurations, please refer to the National configuration addendum document. The PDF can be downloaded from the site <https://tools.inxpect.com>.

3. Get to know Inxpect SRE 200 Series

Contents

This section includes the following topics:

3.1 Inxpect SRE 200 Series	14
3.2 Control units	16
3.3 Control unit inputs	23
3.4 Control unit outputs	24
3.5 Sensors	28
3.6 System applications	31
3.7 System configuration	33

Product label description

The following table describes the information contained in the product label:

Part	Description
SID	Sensor ID
DC	"yy/ww" : year and week of the product manufacture
SRE	Safety Radar Equipment
Model	Product model (e.g., S201A, C201A)
Type	Product variant, used for commercial purposes only
S/N	Serial number

3.1 Inxpect SRE 200 Series

3.1.1 Definition

Inxpect SRE 200 Series is an active protection radar system that monitors the dangerous areas of machinery.

3.1.2 Special features


Some of the special features of this protection system are the following:

- detection of current distance and angle of the targets detected by each sensor
- customization of the detection field with advanced shapes (if available)
- up to four safe detection fields to define different behaviors of the machines
- programmable coverage angle for each detection field
- rotation around three axes during installation to allow better coverage of detection areas
- Safety Fieldbus to safely communicate with the PLC of the machinery (if available)
- possibility to switch dynamically between different preset configurations (max. 32 through Fieldbus, if available, and max. 8 with digital inputs)
- muting on the entire system or only on some sensors
- immunity to dust and smoke
- reduction of undesired alarms caused by the presence of water or processing waste
- communication and data exchange through MODBUS (if available)

3.1.3 Main components

Inxpect SRE 200 Series is composed of a control unit and up to six sensors. The system application allows system operation configuration and checks.

NOTICE: if at least one sensor is a S202A model, the maximum number of sensors is 5.



3.1.4 Control unit and sensor compatibility

The models and types of control unit and sensors are shown below, with their compatibility.

Control units	
Type A	Type B
C201A-PNS	C201B-P
C201A-F	C201B-F
C201A-C	C201B-C
C202A	C202B
C203A	C203B

↓

Sensors	
3.x sensors	5.x sensors
S201A	S201A-W S203A-W S201A-WT S203A-WT S202A-M S202A-MC

Each control unit, updated to firmware version 2.1.0, can communicate with any sensor.

NOTICE: do not connect the control unit with other types of sensors (e.g., 9 meters range sensors).

The control unit can be simultaneously connected to both 3.x sensors and 5.x sensors. For more details about the available features, see "Sensors" on page 28.

3.1.5 Control unit - sensor communication

The sensors communicate with the control unit via CAN bus using diagnostic mechanisms in compliance with standard EN 50325-5 to guarantee SIL 2 and PL d.

For correct functioning, each sensor must be assigned an identification number (Node ID).

Sensors on the same bus must have different Node IDs. By default, the sensor does not have a pre-assigned Node ID.

3.1.6 Control unit - machinery communication

The control units communicate with the machinery via I/O (see "Control unit inputs" on page 23 and "Control unit outputs" on page 24).

Moreover, according to the model-type, the control unit is provided with:

- a safe communication on a Fieldbus interface. The Fieldbus interface allows the control unit to communicate in real-time with the PLC of the machinery to send information about the system to the PLC (e.g., the position of the detected target) or to receive information from the PLC (e.g., to change the configuration dynamically). For details, see "Fieldbus communication (PROFIsafe)" on page 36, "Fieldbus communication (CIP Safety™ on Ethernet/IT™)" on page 39 or see "Fieldbus communication (Safety over EtherCAT® - FSoE)" on page 37.
- an Ethernet port that allows unsafe communication on a MODBUS interface (see "MODBUS communication" on page 40).

3.1.7 Applications

Inxpect SRE 200 Series integrates with the machinery control system: when performing safety functions or detecting failures, Inxpect SRE 200 Series deactivates the safety outputs and keeps them deactivated, so the control system can put the area into a safe condition and/or prevent restarting of the machinery.

In the absence of other control systems, Inxpect SRE 200 Series can be connected to the devices that control the power supply or machinery start-up.

Inxpect SRE 200 Series does not perform normal machinery control functions.

For connection examples, see "Electrical connections" on page 131.

3.2 Control units


3.2.1 Interfaces

The Inxpect SRE 200 Series supports different control units. The main difference among them is the connection ports, and therefore the communication interfaces available, and the presence of the microSD slot:

	Model	Type	micro-USB port	Ethernet port	Fieldbus port	microSD slot
Type A	C201A	-PNS	x	x	x (PROFIsafe)	-
	C201A	-F	x	x	x (FSoE)	-
	C201A	-C	x	x	x (CIP Safety™)	-
	C202A	-	x	x	-	-
	C203A	-	x	-	-	-
Type B	C201B	-P	x	x	x (PROFIsafe)	x
	C201B	-F	x	x	x (FSoE)	x
	C201B	-C	x	x	x (CIP Safety™)	x
	C202B	-	x	x	-	x
	C203B	-	x	-	-	x

3.2.2 Communication architecture

According to the model-type, this is the communication architecture between the control unit, PLC and PC.




3.2.3 Functions


The control unit performs the following functions:

- Collects information from all the sensors via CAN bus.
- Compares the position of detected motion with the set values.
- Deactivates the selected safety output when at least one sensor detects motion in the detection field.
- Deactivates all the safety outputs if a failure is detected in one of the sensors or the control unit.
- Manages the inputs and outputs.
- Communicates with the Inxpect Safety application for all configuration and diagnostic functions.
- Allows dynamically switching between different configurations.
- Communicates with a safety PLC through the safe Fieldbus connection (if available).
- Communicates and exchanges data through MODBUS protocol (if available).
- Performs a backup and a restore system configuration and password to/from microSD card (if available).


3.2.4 Type A control units



C201A-PNS, C201A-F, C201A-C



C202A




C203A

Part	Description	C201A	C202A	C203A
A	I/O terminal block	x	x	x
B	System status LEDs	x	x	x
C	Network parameter reset button / Factory reset button	x	x	x
D	Reserved for internal use. Output reset button	x	x	x
E	Micro-USB port (micro-B type) for connecting the PC and communicating with the Inxpect Safety application	x	x	x
F	Micro-USB port, if mounted (reserved)	x	-	-


Part	Description	C201A	C202A	C203A
G	Fieldbus status LEDs See "PROFIsafe Fieldbus status LEDs" on page 20 or "FSoE Fieldbus status LEDs" on page 21.	x	-	-
H	Ethernet port with LEDs for connecting the PC, communicating with the Inxpect Safety application, and for MODBUS communication	x	x	-
I	Power supply terminal block	x	x	x
J	Power supply LEDs (steady green)	x	x	x
K	CAN bus terminal block for connecting the first sensor	x	x	x
L	DIP switch to turn on/off the bus termination resistance: <ul style="list-style-type: none">On (top position, default) = resistance includedOff (bottom position) = resistance excluded	x	x	x
M1	Status LED of hardware functions of the secondary micro-controller: <ul style="list-style-type: none">slow flashing orange: normal behaviorother status: contact Technical Support	x	x	x
M2	Status LED of hardware functions of the primary micro-controller: <ul style="list-style-type: none">off: normal behaviorsteady red: contact Technical Support	x	x	x
N	Fieldbus port no.1 with LEDs (PROFIsafe, CIP Safety™ or EtherCAT® IN)	x	-	-
O	Fieldbus port no.2 with LEDs (PROFIsafe, CIP Safety™ or EtherCAT® OUT)	x	-	-

Note: only for C201A-F: the processing direction is from the N connection to the O connection. In normal operation, the device receives the data from the controller on N and sends the outgoing data on O.


3.2.5 Type B control units



C201B-P, C201B-F, C201B-C



C202B



C203B

Part	Description	C201B	C202B	C203B
A	I/O terminal block	x	x	x
B	System status LEDs	x	x	x
C	Network parameter reset button / Factory reset button	x	x	x
D	Micro-USB port (micro-B type) for connecting the PC and communicating with the Inxpect Safety application	x	x	x
E	Fieldbus status LEDs See "PROFIsafe Fieldbus status LEDs" on the next page or "FSoE Fieldbus status LEDs" on page 21.	x	-	-
F	SD Restore button	x	x	x
G	MicroSD slot	x	x	x
H	Ethernet port with LEDs for connecting the PC, communicating with the Inxpect Safety application, and for MODBUS communication	x	x	-
I	Power supply terminal block	x	x	x
J	Power supply LEDs (steady green)	x	x	x
K	CAN bus terminal block for connecting the first sensor	x	x	x
L	DIP switch to turn on/off the bus termination resistance: • On (top position, default) = resistance included • Off (bottom position) = resistance excluded	x	x	x
M1	Status LED of hardware functions of the secondary micro-controller: • slow flashing orange: normal behavior • other status: contact Technical Support	x	x	x
M2	Status LED of hardware functions of the primary micro-controller: • off: normal behavior • steady red: contact Technical Support	x	x	x

Part	Description	C201B	C202B	C203B
N	Fieldbus port no.1 with LEDs (PROFIsafe, CIP Safety™ or EtherCAT® IN)	x	-	-
O	Fieldbus port no.2 with LEDs (PROFIsafe, CIP Safety™ or EtherCAT® OUT)	x	-	-

Note: only for C201B-F: the processing direction is from the N connection to the O connection. In normal operation, the device receives the data from the controller on N and sends the outgoing data on O.

3.2.6 System status LEDs


The LEDs are each dedicated to a sensor, and can display the following statuses:

Status	Meaning
Steady green	Normal sensor function and no motion detected
Orange	Normal sensor function and some motion detected
Flashing red	Sensor in error (see "Sensor LED" on page 106)
Steady red	System error (see "Control unit LED" on page 104)
Flashing green	Sensor in boot status (see "Control unit LED" on page 104)

3.2.7 PROFIsafe Fieldbus status LEDs

The LEDs reflect the status of the PROFIsafe Fieldbus, and their meanings are reported below.

LEDs



LEDs	Type	Description
F1	SYS	System status
F2		
F3	BF	Bus failure
F4		
F5	SF	System failure
F6		

Meaning of SYS LEDs

F1 status	F2 status	Meaning
Steady green	Off	Normal behavior
Flashing green	Off	Contact technical support
Off	Flashing yellow	Contact technical support
Off	Steady yellow	Contact technical support
Off	Off	Contact technical support

Meaning of BF LEDs

F3 status	F4 status	Meaning
Off	Off (not used)	Data exchange is running with the host
Flashing red	Off (not used)	No data exchange
Steady red	Off (not used)	No physical link


Meaning of SF LEDs

F5 status	F6 status	Meaning
Off	Off (not used)	Normal behavior
Steady red	Off (not used)	Diagnostic error at PROFIsafe layer (wrong F Dest Address, watchdog timeout, wrong CRC) or at PROFINET layer (watchdog timeout; channel, generic or extended diagnosis present; system error)
Flashing red	Off (not used)	DCP signal service is initiated via the bus

3.2.8 FSoE Fieldbus status LEDs

The LEDs reflect the status of the FSoE Fieldbus, and their meanings are reported below.

LEDs



LEDs	Type	Description
F1	SYS	System status
F2		
F3	ERR	Error code
F4		
F5	RUN	Current state of the State Machine
F6		

Meaning of SYS LEDs

F1 status	F2 status	Meaning
Steady green	Off	Normal behavior
Flashing green	Off	Contact technical support
Off	Flashing yellow	Contact technical support
Off	Steady yellow	Contact technical support
Off	Off	Contact technical support

Meaning of ERR LEDs

F3 status	F4 status	Meaning
Off	Off (not used)	Normal behavior
Flashing red	Off (not used)	Invalid configuration: General Configuration Error. Possible reason: State change commanded by master is impossible due to register or object settings
Single flash red	Off (not used)	Local error: Slave device application has changed the EtherCAT state autonomously. Possible reason 1: A host watchdog timeout has occurred. Possible reason 2: Synchronization error, device enters Safe-Operational automatically
Double flash red	Off (not used)	Application watchdog timeout. Possible reason: Sync Manager Watchdog timeout

Meaning of RUN LEDs


F5 status	F6 status	Meaning
Off (not used)	Off	INIT state
Off (not used)	Steady green	OPERATIONAL state
Off (not used)	Single flash green	SAFE-OPERATIONAL state
Off (not used)	Flashing green	SAFE-OPERATIONAL state

3.2.9 CIP Safety™ status LEDs

The LEDs reflect the status of the CIP Safety Fieldbus, and their meanings are reported below.

WARNING! CIP Safety status LEDs are NOT reliable indicators and cannot be guaranteed to provide accurate information. They should ONLY be used for general diagnostics during commissioning or troubleshooting. Do not attempt to use LEDs as operational indicators.

LEDs



LEDs	Type	Description
F1	SYS	System status
F2		
F3	NS	Network Status
F4		
F5	MS	Module Status
F6		

Meaning of SYS LEDs

F1 status	F2 status	Meaning
Steady green	Off	Normal behavior
Flashing green	Off	Contact technical support
Off	Flashing yellow	Contact technical support
Off	Steady yellow	Contact technical support
Off	Off	Contact technical support

Meaning of NS LEDs

F3 status	F4 status	Meaning
Steady red	Off	Duplicate IP address
Flashing red	Off	Connection timeout: an IP address is configured and an Exclusive Owner connection for which this device is the target has timed out
Off	Steady green	Connected: an IP address is configured, at least one CIP connection is established and an Exclusive Owner connection has not timed out
Off	Flashing green	No CIP connections
Flashing red	Flashing green	[Sequence F4-F3-Off] Self-test: the device is performing its power-up testing
Off	Off	Not powered or no IP address

Meaning of MS LEDs

F5 status	F6 status	Meaning
Steady red	Off	Major unrecoverable fault
Flashing red	Off	Major recoverable fault, e.g. an incorrect or inconsistent configuration
Off	Steady green	The device is operating correctly
Off	Flashing green	Standby: the device has not been configured
Flashing red	Flashing green	[Sequence F6-F5-Off] Self-test: the device is performing its power-up testing. The MS indicator test sequence occurs before the NS indicator test sequence
Off	Off	Not powered

3.3 Control unit inputs

3.3.1 Introduction

The system has two type 3 dual channel digital inputs (according to IEC/EN 61131-2). Alternatively, the four channels can be used as single channel digital inputs (category 2). The ground reference is common for all the inputs (see "Technical references" on page 123).

When using digital inputs, it is mandatory that the additional SNS input "V+ (SNS)" is connected to 24 V DC and that the GND input "V- (SNS)" is connected to the ground in order to:

- perform the correct input diagnostic
- assure the system safety level

3.3.2 Input functions

The function of each digital input must be programmed through the Inxpect Safety application. The available functions are the following:

- **Stop signal**: additional safety-related function, which manages a specific signal to force all the safety outputs (detection signals, if present) to OFF-state.
- **Restart signal**: additional safety-related function, which manages a specific signal which enables the control unit to switch to ON-state the safety outputs related to all the detection fields with no motion detected.
- **Muting group "N"**: additional safety-related function, which manages a specific signal, allowing the control unit to ignore the information from a selected sensor group.
- **Dynamic configuration switch**: additional safety-related function, which allows the control unit to select a specific dynamic configuration.
- **Fieldbus controlled** (if available): additional safety-related function monitors the input status through Fieldbus communication. For example, a generic ESPE can be connected to the input, respecting electrical specifications.
- **System recondition**: configures the system without changing any settings.
- **Teach-In**: adjusts the detection distance of the last detection field automatically according to the position of static or moving objects in the field of view.
- **Restart signal + System recondition**: according to the input signal duration, performs the **Restart signal** function or the **System recondition** function.

For details about digital input signals, see "Digital input signals" on page 143.

3.3.3 Single or dual channel option

By default, each digital input function needs a signal on both channels to provide the redundancy required by Category 3.

The following digital input functions can also be used as a single channel (Category 2):

- **Restart signal**
- **Fieldbus controlled**
- **System recondition**
- **Teach-In**
- **Restart signal + System recondition**

In the Inxpect Safety application in **Settings > Digital Input-Output**, set the digital input function to **Single channel (Category 2)** and then choose the input function for each channel.

3.3.4 Redundancy mode

Two types of redundancy mode are available for the dual channels input functions:

- **Coherent redundancy**

Input Channel 1	Input Channel 2	Input logic value
0	0	Low
1	1	High
0	1	Error
1	0	Error

- **Inverted redundancy**

Input Channel 1	Input Channel 2	Input logic value
0	1	Low
1	0	High
0	0	Error
1	1	Error

By default, the redundancy mode is coherent. For the following input functions, the inverted redundancy mode can be set to guarantee compatibility with different connected devices:

- **Muting group “N”** (only if pulse width = 0)
- **Restart signal**
- **Fieldbus controlled**
- **Dynamic configuration switch**
- **System recondition**
- **Teach-In**
- **Restart signal + System recondition**

3.3.5 Stop signal debounce filter

The debounce filter allows to filter test pulses in a digital input configured as **Stop signal**. Its enabling is recommended when an ESPE device equipped with OSSD is connected to the digital input.

Per default, the filter is disabled. It can be activated through the Inxpect Safety application (**Settings > Advanced > Stop signal debounce filter**).

3.3.6 SNS input

The control unit is provided with an **SNS** input (high logic level (1) = 24 V) needed to check the correct functioning of the inputs.

NOTICE: if at least one input is connected, the SNS input "V+ (SNS)" and the GND input "V- (SNS)" must also be connected.

3.4 Control unit outputs

3.4.1 Outputs

The system has four digital OSSD short-circuit protected outputs that can be used individually (non-safe) or can be programmed as dual channel safety outputs (safe) in order to ensure the system safety level.

An output is activated when it switches from OFF to ON-state (from 0 V to 24 V) and it is deactivated when it switches from ON to OFF-state (from 24 V to 0).

3.4.2 Output functions

The function of each digital output must be programmed through the Inxpect Safety application.

The available functions are the following:

- **System diagnostic signal:** switches the selected output to OFF-state when a system fault is detected.
- **Muting enable feedback signal:** switches the selected output to ON-state in the following cases:
 - when a muting signal is received over the configured input and at least one group is in muting
 - when a muting command is received through Fieldbus communication (if available) and at least one sensor is in muting
- **Detection signal "N":** (e.g., alarm signal) switches the selected output to OFF-state when a sensor detects a motion in detection field N*, receives a stop signal from the related input, or when there is a system failure. The selected output remains in OFF-state for at least 100 ms.

Note*: "N" is the number of the corresponding detection field (e.g.: **Detection signal 1** for detection field 1, **Detection signal 2** for detection field 2).

Note: when an OSSD is configured as **Detection signal "N"**, a second OSSD is automatically assigned to it to provide a safe signal.

- **Detection signal "N" (non-safe):** (e.g., alarm signal) switches the selected output to OFF-state when a sensor detects a motion in detection field N*, receives a stop signal from the related input, or when there is a system failure. The selected output remains in OFF-state for at least 100 ms.

Note*: N is the number of the corresponding detection field (e.g.: **Detection signal 1** for detection field 1, **Detection signal 2** for detection field 2).

- **Fieldbus controlled** (if available): allows the specific output to be set through the Fieldbus communication.

- **Restart feedback signal:** switches the selected output to ON-state when it is possible to manually restart at least one detection field (Restart signal). It can be set as **Standard** or **Pulsed**.
 - If all the used detection fields are configured as **Automatic** restart (in **Settings > Restart function**), the selected output is always in OFF-state;
 - If at least one detection field in use is configured as **Manual** or **Safe manual** restart (in **Settings > Restart function**), the behavior depends on the option selected (see "Restart feedback signal option settings" on the next page).

- **Static object detection feedback signal:** switches the selected output to ON-state when at least one sensor detects a static object in one of its detection fields. The selected output remains in ON-state for at least 100 ms. If, at the same time, a moving target is detected in the detection field, the **Static object detection feedback signal** will switch its selected output to OFF-state for the duration of the movement.
- **Teach-In feedback signal:** switches the selected output to the following states:
 - ON-state when the Teach-In function is activated
 - slow flashing-state (500 ms ON-state followed by 1500 ms OFF-state) when the Teach-In function has completed the automatic configuration
 - fast flashing-state (500 ms ON-state followed by 500 ms OFF-state) in case of fault condition given by the Teach-in function
 - OFF-state when the operator has validated the new configuration

- **Detection signal group 1 or Detection signal group 2:** switches the selected output to OFF-state when at least one sensor detects a motion in a detection field belonging to the group (see "Detection signal group settings" on the next page), receives a stop signal from the related input, or when there is a system failure. The selected output remains in OFF-state for at least 100 ms.

Note: when an OSSD is configured as **Detection signal group 1 or Detection signal group 2**, a second OSSD is automatically assigned to it to provide a safe signal.

- **Detection signal group 1 (non-safe) or Detection signal group 2 (non-safe):** switches the selected output to OFF-state when at least one sensor detects a motion in a detection field belonging to the group (see "Detection signal group settings" on the next page), receives a stop signal from the related input, or when there is a system failure. The selected output remains in OFF-state for at least 100 ms.

Each output status can be retrieved by Fieldbus communication (if available).

In the Inxpect Safety application in **Settings > Digital Input-Output**, set the digital output function to **Single channel (Category 2)** and then choose the output function for each channel.

3.4.3 Output configurations

The system installer can decide to configure the system as follows:

- two dual channel safety outputs (e.g., **Detection signal 1** and **Detection signal 2**, usually alarm and warning signals)
- one dual channel safety output (e.g., **Detection signal 1**) and two single channel output (e.g., **System diagnostic signal** and **Detection signal 2 (non-safe)**)

- each output as a single output (e.g., **System diagnostic signal**, **Muting enable feedback signal** and **Restart feedback signal**)

⚠ WARNING! To use Inxpect SRE 200 Series for a category 3 safety system, both the channels of a safety output must be connected to the safety system. Configuring a safety system with only one channel safety output may result in serious injuries due to an output circuit fault and a failure of the machine to stop.

3.4.4 Dual channel safety output configuration

The dual channel safety output is automatically obtained by the Inxpect Safety application and it only matches the single OSSD outputs as follows:

- OSSD 1 with OSSD 2
- OSSD 3 with OSSD 4

3.4.5 Restart feedback signal option settings

If at least one detection field in use is configured as **Manual** or **Safe manual** restart (in **Settings > Restart** function), the behavior of the **Restart feedback signal** depends on the option selected:

Option	Restart feedback signal behavior
Standard	<ul style="list-style-type: none"> The selected output is activated (ON-state) if there is no more motion within at least one detection field configured as Manual or Safe manual restart. The ON-state lasts as long as there is an absence of motion within one or more detection fields (configured as Manual or Safe manual restart) and until the restart signal is activated on the selected input. The selected output remains in OFF-state if: <ul style="list-style-type: none"> none of the detection fields (configured as Manual or Safe manual restart) are ready to be restarted, and as long as a motion (or a fault) is detected within at least one detection field (configured as Manual or Safe manual restart), or as long as no motion is detected within any detection fields configured as Manual or Safe manual restart, but none can be restarted yet.
Pulsed	<ul style="list-style-type: none"> The selected output is activated (ON-state) if there is no more motion within at least one detection field configured as Manual or Safe manual restart. The ON-state lasts as long as there is an absence of motion within one or more detection fields (configured as Manual or Safe manual restart) and until the restart signal is activated on the selected input. The selected output switches continuously between ON-state and OFF-state if none of the detection fields (configured as Manual or Safe manual restart) are ready to be restarted, and as long as a motion (or a fault) is detected within at least one detection field (configured as Manual or Safe manual restart) The selected output remains in OFF-state as long as no motion is detected within any detection fields configured as Manual or Safe manual restart, but none can be restarted yet.

3.4.6 Detection signal group settings

Each detection field of each sensor can be assigned to a group to associate them with the same safety output.

Through the Inxpect Safety application (in **Settings > Detection field groups**), each detection field of each sensor can be associated with a group or both groups. By default, a detection field does not belong to any group.

⚠ WARNING! Consider the detection field dependency choice during the group's configuration. See "Detection fields dependency and detection signal generation" on page 44

Example

It is possible to configure that the following detection fields belong to group 1:

- Detection field 1 of Sensor 1
- Detection field 1 of Sensor 3
- Detection field 2 of Sensor 1

By doing so, a specific output assigned to **Detection signal group 1** will switch to the OFF-state when a movement is detected in one of these detection fields.

3.4.7 Output status of detection signal outputs

The output status is the following:

- activated output (24 V DC): idle signal, no motion detected and normal functioning
- deactivated output (0 V DC): motion detected in the detection field or failure detected in the system

3.4.8 Pulse test for detection signal outputs


A pulse test is provided for the detection signal output, in particular for the outputs configured as follows:

- **Detection signal "N"**
- **Detection signal "N" (non-safe)**
- **Detection signal group "N"**
- **Detection signal group "N" (non-safe)**

The test is performed with the idle signal periodically pulsed to 0 V to detect short-circuits to either 0 V or 24 V.

The pulse duration at 0 V (T_L) can be set at 300 μ s or 2 ms through the Inxpect Safety application (**Settings** > **Digital Input-Output** > **OSSD Pulse width**).

Note: the devices connected to the OSSD should not respond to these temporary, self-diagnostic 0 V pulses of the signal.



For details, see "Technical references" on page 123.

3.4.9 OSSD diagnostic checks

Per default, the OSSD Diagnostic check (e.g., for short-circuits) is deactivated. This check can be activated through the Inxpect Safety application (**Settings** > **Digital Input-Output**).

If activated, the control unit will monitor:

- short-circuit between OSSDs
- 24 V short-circuit
- open circuit (only trips on demand, i.e., when the safety function is activated on the transition from 24 V to GND)

Note: the short-circuit to GND (fail-safe fault) is always monitored even if the OSSD diagnostic check is deactivated.

⚠ WARNING! If an external common cause failure leads to a 24 V short-circuit on both the OSSDs, the control unit cannot communicate the safe state condition via OSSD. The integrator is responsible for avoiding this condition by monitoring the test pulses generated periodically on the OSSDs.

⚠ WARNING! To be compliant with the IEC TS 61496-5 standard, it is necessary to activate the OSSD diagnostic checks and set the Anti-masking sensitivity parameter to High.


3.4.10 External resistor for OSSD outputs

To guarantee the correct connection between the OSSDs of the control unit and an external device, it may be necessary to add an external resistor.

If the pulse width set (**OSSD Pulse width**) is 300 μ s, it is strongly recommended to add an external resistor to guarantee the discharge time of the capacitive load. If it is set at 2 ms, an external resistance must be added if the resistor of the external load is greater than the maximum resistive load allowed (see "Technical data" on page 124).

Below are some standard values for the external resistor:

OSSD Pulse width value	External resistor (R_e)
300 μ s	1 k Ω
2 ms	10 k Ω



3.5 Sensors

3.5.1 5 meters range sensors

These are the main characteristics of the sensors:

NOTICE: the sensors connected to the control unit must all be of the same type (e.g., all 5 meters range sensors or all 9 meters range sensors).

Model	Type	Access maximum distance	Restart maximum distance	Detection speed (Access detection function)	Horizontal angular coverage	Vertical angular coverage	Teach-In function
S201A	-	5 m (16.4 ft)	5 m (16.4 ft)	<ul style="list-style-type: none"> Stationary use: [0.1, 1.6] m/s ([0.33, 5.25] ft/s) Mobile use: <ul style="list-style-type: none"> for detection distance less than or equal to 4 m (13.12 ft): [0.1, 3] m/s ([0.33, 9.84] ft/s) for detection distance greater than 4 m (13.12 ft): [0.1, 2] m/s ([0.33, 6.56] ft/s) 	From 10° to 100°	20° (Downward offset 2.5°)	-
S201A	-W					20° (Downward offset 2.5°)	-
S203A	-W					12° (Downward offset 1°)	-
S201A	-WT					20° (Downward offset 2.5°)	X
S203A	-WT					12° (Downward offset 1°)	X
S202A	-M			[0.1, 1.6] m/s ([0.33, 5.25] ft/s)	From 20° to 100°	From 30° to 90°	-
S202A	-MC					(Upward offset 5°)	-

3.5.2 Comparison between 3.x sensors and 5.x sensors

Based on the firmware version, the sensors can be grouped as follows:


	Model	Type	Configuration of the field of view
3.x sensors	S201A	-	<ul style="list-style-type: none"> detection field (from 1 to 4) horizontal angular coverage detection distance
5.x sensors	S201A	-W	<ul style="list-style-type: none"> detection field (from 1 to 4) horizontal angular coverage only for S202A sensors, vertical angular coverage detection distance classic and corridor shape (see "Advanced field of view (5.x sensors only)" on page 69) only -WT sensors, Teach-In function (see "Teach-In function (-WT sensors only)" on page 53) only for S202A-MC sensors, cuboid shape (see "Cuboid shape (only for S202A-MC sensors)" on page 71)
	S203A	-W	
	S201A	-WT	
	S203A	-WT	
	S202A	-M	
	S202A	-MC	

3.5.3 Functions

The sensors perform the following functions:


- Detect motion in their field of view.
- Send the motion detection signal to the control unit through CAN bus.
- Signal to the control unit through CAN bus the failures or faults detected on the sensor during diagnostics.

3.5.4 2-axis bracket



Part	Description
A	Sensor
B	Status LED
C	Tamper-proof screws to position the sensor at a specific angle around x-axis (tilt 10° steps)
D	Mounting bracket
E	Screw to position the sensor at a specific angle around y-axis (pan 10° steps)
F	Connectors for connecting the sensors in a chain and to the control unit

3.5.5 3-axis bracket



Part	Description
A	Sensor
B	Status LED
C	Tamper-proof screws to position the sensor at a specific angle around x-axis (tilt 10° steps)
D	Mounting bracket
E	Tamper-proof screw to position the sensor at a specific angle around y-axis (pan 10° steps)
F	Connectors for connecting the sensors in a chain and to the control unit
G	Tamper-proof screw to position the sensor at a specific angle around z-axis (roll 10° steps)

3.5.6 Status LED

Status	Meaning
Steady blue	Sensor is working. No motion detected.
Flashing blue	Sensor is detecting motion*. Not available if the sensor is in muting. For restart prevention function, the LED keeps flashing for about 2 seconds after the end of a detection
Purple	Firmware update conditions (see "Sensor LED" on page 106)
Red	Error conditions (see "Sensor LED" on page 106)

Note*: the detection signal overrides the masking signal if they are present at the same time. Only for S202A sensors, the masking signal overrides the detection signal.

3.6 System applications

3.6.1 Introduction

Two system applications are available:

- Inxpect Safety
- Inxpect Safety 3D

A system that includes at least one S202A sensor must be configured with Inxpect Safety 3D application. For other systems, the two applications are equally available.

If you configure a control unit with Inxpect Safety application you can then continue the configuration with Inxpect Safety 3D application, conversely, if you use Inxpect Safety 3D application you can not continue with Inxpect Safety application.

3.6.2 Functions

The application permits the following main functions to be performed:

- Configure the system.
- Create the configuration report.
- Check system functioning.
- Download system log.

3.6.3 Inxpect Safety application usage

To use the application, the control unit must be connected to a computer with a data USB cable or, if the Ethernet port is available, an Ethernet cable. The USB cable allows to configure the system locally, whereas the Ethernet cable allows to do it remotely.

The Ethernet communication between the control unit and the Inxpect Safety application is secured by the most advanced security protocols (TLS).

3.6.4 Authentication

The application can be downloaded free of charge at <https://tools.inxpect.com>.

Different user levels are available. The Admin user is in charge of user management. All the passwords can be set through the application and then saved on the control unit.

3.6.5 User levels

These are the functions available for each user level:

	Observer	Expert	Engineer	Admin	Service*
Read system configuration	x	x	x	x	x
Validation	-	x	x	x	x
Download log files	-	x	x	x	x
Sensor setup (e.g., Node ID) and configuration	-	-	x	x	-
Apply changes	-	-	x	x	-
Digital I/O configuration	-	-	x	x	-

	Observer	Expert	Engineer	Admin	Service*
Backup configuration	-	X	X	X	-
Restore configuration	-	-	X	X	-
Network and Fieldbus settings and System labels	-	-	-	X	-
Control unit firmware upgrade	-	-	-	X	-
User management	-	-	-	X	-
SD Backup and SD Restore (if available)	-	-	-	X	-
Technical support and maintenance	-	-	-	-	X
Debug and statistical information	-	-	-	-	X

Note*: Service user can be enabled/disabled by the administrator. Since only Inxpect technicians are allowed to access as Service, the Service user is protected by an activation code.

3.6.6 Main menu

Page	Function
Dashboard	Display main information on the configured system. Note: the messages show the same information in the log files. For the meanings of the messages, see the chapters on logs in "Troubleshooting" on page 104.
Configuration	Define the monitored area. Configure the sensors, their shape (for 5.x sensors), and the detection fields. Configure the sensors and the detection fields. Define the dynamic configurations. Choose the safety working mode. Enable the static object detection option. Set the restart timeout.
Settings	Configure the sensor groups. Choose the detection fields dependency. Enable the anti-tampering functions. Synchronize more control units. Configure the inputs and outputs function. Perform the configuration backup and load a configuration. Download the log. Perform the sensor Node ID assignment. Set and perform the Teach-In function. Other general functions.
Admin	Configure and manage the users. Enable the SD Backup and the SD Restore. Perform a factory reset. Configure, show, and change the Network parameters (if available). Configure, show and change the MODBUS parameters (if available). Configure, show and change the Fieldbus parameters (if available). Set labels for control units and sensors.
Validation	Start the validation procedure. Note: the messages shown are those in the log file. To know the meaning of the messages, see the chapters on logs in "Troubleshooting" on page 104.

Page	Function
 REFRESH CONFIGURATION	Refresh configuration or ignore unsaved changes.
User	Change user profile. Modify account settings.
Control unit	Retrieve control unit information. Close the connection with the control unit and allow it to connect to another control unit.
	Change the language.

3.7 System configuration

3.7.1 System configuration

The control unit parameters have their own default values that can be modified via the Inxpect Safety application (see "Configuration application parameters" on page 138).

When a new configuration is saved, the system generates the configuration report.

Note: after a physical change of the system (e.g., new sensor installed), the system configuration must be updated and a new configuration report must be generated, too.

3.7.2 Dynamic system configuration

Inxpect SRE 200 Series allows a real-time adjustment of the most important system parameters, providing the means to switch dynamically among different preset configurations. Via the Inxpect Safety application, once the first system configuration (default configuration) has been set, it is possible to set alternative presets to allow a dynamic real-time reconfiguration of the monitored area. The alternative presets are 7 through digital input and 31 through Fieldbus (if available).

3.7.3 Dynamic system configuration parameters

These are the programmable parameters for each sensor:

- detection field (from 1 to 4)

These are the programmable parameters for each detection field:

- horizontal angular coverage
- only for S202A sensors, vertical angular coverage
- detection distance
- safety working mode (**Access detection and restart prevention** or **Always-on access detection**) (see "Safety working modes and safety functions" on page 47)
- only for 5.x sensors: classic and corridor shapes (see "Advanced field of view (5.x sensors only)" on page 69)
- static object detection option (see "Restart prevention function: static object detection option" on page 49)
- restart timeout

All the remaining system parameters cannot be changed dynamically and are considered static.

3.7.4 Dynamic system configuration switch

One of the preset configurations can be activated dynamically either through the digital inputs (**Dynamic configuration switch**) or through the safety Fieldbus (if available).

 **WARNING!** If one or more digital inputs are configured as "Dynamic configuration switch", a switch through the safety Fieldbus is not considered.

Note: only for S202A sensors, if the application type is set as **Stationary** and the next configuration has at least one detection field with safety working mode set as **Access detection and restart prevention**, the configuration change leads to an alarm on that/those detection field/s for at least as long as the time set in the **Restart timeout** parameter.

3.7.5 Dynamic configuration through the digital inputs

To activate one of the preset configurations dynamically, one or both the digital inputs of the control unit can be used. The result is the following:

If...	Then it is possible to switch dynamically between...
only one digital input is configured as Dynamic configuration switch	two preset configurations (see "Case 1" below and "Case 2" below)
both digital inputs are configured as Dynamic configuration switch and the encoded channel option is disabled	four preset configurations (see "Case 3" below)
both digital inputs are configured as Dynamic configuration switch and the encoded channel option is enabled	eight preset configurations (see "Case 4" on the next page)

Note: the configuration change is safe because two-channel inputs are used.

Note: if the encoded channel option is enabled, any invalid combination that lasts more than 33 ms results in a fault on the inputs that brings the system to a safe state.

Case 1

The first digital input has been configured as **Dynamic configuration switch**.

Dynamic configuration number	Input 1 (CH1 and CH2)	Input 2
#1	0	-
#2	1	-

0 = signal deactivated; 1 = signal activated

Case 2

The second digital input has been configured as **Dynamic configuration switch**.

Dynamic configuration number	Input 1	Input 2 (CH1 and CH2)
#1	-	0
#2	-	1

0 = signal deactivated; 1 = signal activated

Case 3

Both digital inputs have been configured as **Dynamic configuration switch**, and the encoded channel option is disabled.

Dynamic configuration number	Input 1 (CH1 and CH2)	Input 2 (CH1 and CH2)
#1	0	0
#2	1	0
#3	0	1
#4	1	1

0 = signal deactivated; 1 = signal activated

Case 4

Both digital inputs have been configured as **Dynamic configuration switch**, and the encoded channel option is enabled.

The valid combinations are only those that differ at least by two values, and they are listed below:

Dynamic configuration number	Input 1		Input 2	
	CH1	CH2	CH1	CH2
#1	1	0	0	0
#2	0	1	0	0
#3	0	0	1	0
#4	0	0	0	1
#5	1	1	1	0
#6	1	1	0	1
#7	1	0	1	1
#8	0	1	1	1

0 = signal deactivated; 1 = signal activated

3.7.6 Dynamic configuration through the safety Fieldbus

To activate one of the preset configurations dynamically, connect an external safety PLC that communicates through the safety Fieldbus to the control unit. This makes it possible to dynamically switch between all the preset configurations, therefore up to 32 different configurations. For all the parameters used for each configuration, see "Dynamic system configuration" on page 33.

Note: only for S202A sensors, the maximum number of dynamic configurations is 16.

For details about the supported protocol, please refer to the Fieldbus manual.

 **WARNING!** Before activating one of the preset configurations through the safety Fieldbus, ensure that none of the digital inputs is configured as Dynamic configuration switch; otherwise, the Inxpect SRE 200 Series ignores all the switches made through the safety Fieldbus.

3.7.7 Safe configuration change

The change of the configuration takes place safely both on stationary and moving machinery. The sensor always monitors the entire monitored area and when it receives a request to change to a configuration with a longer detection field, it immediately reverts to safe state if people are present in such a field.

4. System communication

Contents

This section includes the following topics:

4.1 Fieldbus communication (PROFIsafe)	36
4.2 Fieldbus communication (Safety over EtherCAT® - FS0E)	37
4.3 Fieldbus communication (CIP Safety™ on Ethernet/IT™)	39
4.4 MODBUS communication	40

4.1 Fieldbus communication (PROFIsafe)

4.1.1 PROFIsafe support

The safety communication using PROFIsafe is available on all the control units provided with the PROFIsafe interface. For details, see "Control units" on page 16.

4.1.2 Communication with the machinery

The Fieldbus makes the following actions possible:

- Choose from 1 to 32 preset configurations dynamically.
- Read the status of the inputs.
- Control the outputs.
- Read the target data.
- Mute the sensors.
- Enable the restart signal.
- Enable the system recondition signal.

For details, see the PROFIsafe communication Reference guide.

4.1.3 Input data coming from the PLC

If neither digital input nor OSSD is configured as **Fieldbus controlled**, the behavior of the input data coming from the PLC is as described below:

Condition	Input data coming from the PLC	System behavior
IOPS (PLC provider status) = bad	the last valid value of the input variable is retained	the system keeps working in its normal operating state
Connection loss	the last valid value of the input variable is retained	the system keeps working in its normal operating state
After power-up	the initial values (set to 0) are used for the input variables	the system keeps working in its normal operating state

If at least one digital input or OSSD is configured as **Fieldbus controlled**, the behavior of the input data coming from the PLC is as described below:

Condition	Input data coming from the PLC	System behavior
IOPS (PLC provider status) = bad	the last valid value of the input variable is retained	the system keeps working in its normal operating state
Connection loss	the last valid value of the input variable is retained	the system transits to safe state, deactivating the OSSDs, until the connection is re-established.
After power-up	the initial values (set to 0) are used for the input variables	the system remains in a safe state with the OSSDs deactivated, until the input data are passivated.

4.1.4 Data exchanged through PROFIsafe

The following table details the data exchanged through the Fieldbus communication:

WARNING! The system is in the safe state if the control unit status byte of the System configuration and status module PS2v6 or PS2v4 is different from "0xFF".

Data type	Description	Communication direction
Safe	<p>SYSTEM STATUS DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> internal status status of each of the four OSSDs status of each single channel and dual channel input <p>Sensor:</p> <ul style="list-style-type: none"> status of each detection field (target detected or not) or error status status of static object detection option muting status 	from the control unit
Safe	<p>SYSTEM SETTING COMMAND</p> <p>Control unit:</p> <ul style="list-style-type: none"> set the ID of the dynamic configuration that shall be activated set the status of each of the four OSSDs save the reference for the anti-rotation around axes enable the restart signal enable the system recondition signal <p>Sensor:</p> <ul style="list-style-type: none"> set the muting status 	to the control unit
Safe	<p>DYNAMIC CONFIGURATION STATUS</p> <ul style="list-style-type: none"> ID of the dynamic configuration currently active signature (CRC32) of the dynamic configuration ID currently active 	from the control unit
Safe	<p>TARGET DATA</p> <ul style="list-style-type: none"> Current distance and angle of the targets detected by each sensor. For each detection field of each sensor, only the closest target to the sensor is considered. 	from the control unit
Unsafe	<p>DIAGNOSTIC DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> internal status with an extended description of the error condition <p>Sensor:</p> <ul style="list-style-type: none"> internal status with an extended description of the error condition 	from the control unit
Unsafe	SYSTEM STATUS AND TARGET DATA	from the control unit
Unsafe	TEACH-IN FUNCTION	from the control unit

4.2 Fieldbus communication (Safety over EtherCAT® - FSoE)

4.2.1 FSoE support

The safety communication using FSoE is available on all the control units provided with the FSoE interface. For details, see "Control units" on page 16.

4.2.2 Communication with the machinery

The Fieldbus makes the following actions possible:

- Choose dynamically from 1 to 32 preset configurations.
- Read the status of the inputs.
- Control the outputs.
- Mute the sensors.
- Enable the restart signal.
- Enable the system recondition signal.

For details, see the FSoE communication Reference guide.

4.2.3 Data exchanged through FSoE

The following table details the data exchanged through the Fieldbus communication:

 **WARNING! The system is in the safe state if Byte 0 of the selected TxPDO has at least one of its bits equal to 0, except for bit 4, which can assume any value.**

Data type	Description	Communication direction
Safe	<p>SYSTEM STATUS DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> • internal status • status of each of the four OSSDs • status of each of single channel inputs and dual channel inputs <p>Sensor:</p> <ul style="list-style-type: none"> • status of each detection field (target detected or not) or error status • status of Static object detection for each detection field • muting status 	from the control unit
Safe	<p>SYSTEM SETTING COMMAND</p> <p>Control unit:</p> <ul style="list-style-type: none"> • set the ID of the dynamic configuration that shall be activated • set the status of each of the four OSSDs • enable the system recondition signal • enable the restart signal <p>Sensor:</p> <ul style="list-style-type: none"> • set the muting status 	to the control unit
Safe	<p>DYNAMIC CONFIGURATION STATUS</p> <ul style="list-style-type: none"> • ID of the dynamic configuration currently active • signature (CRC32) of the dynamic configuration ID currently active 	from the control unit
Unsafe	<p>DIAGNOSTIC DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> • internal status with an extended description of the error condition <p>Sensor:</p> <ul style="list-style-type: none"> • internal status with an extended description of the error condition 	from the control unit
Unsafe	SYSTEM STATUS	from the control unit

4.3 Fieldbus communication (CIP Safety™ on Ethernet/IT™)

4.3.1 CIP Safety support

The safety communication using CIP Safety on Ethernet/IP is available on all the control units provided with the CIP Safety interface. For details, see "Control units" on page 16.

4.3.2 Communication with the machinery

The Fieldbus makes the following actions possible:

- Choose dynamically from 1 to 32 preset configurations.
- Read the status of the inputs.
- Control the outputs.
- Mute the sensors.
- Enable the restart signal.
- Enable the system recondition signal.

For details, see the CIP Safety communication Reference guide.

4.3.3 Data exchanged through CIP Safety

 **WARNING!** The system is in the safe state if Byte 0 of the selected safety input connection (T20) has at least one of its bits equal to 0, except for bit 4, which can assume any value.

The following table details the data exchanged through the Fieldbus communication:

Data type	Description	Communication direction
Safe	<p>SYSTEM STATUS DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> • internal status • status of each of the four OSSDs • status of each of single channel inputs and dual channel inputs <p>Sensor:</p> <ul style="list-style-type: none"> • status of each detection field (target detected or not) or error status • status of Static object detection for each detection field • muting status 	from the control unit
Safe	<p>SYSTEM SETTING COMMAND</p> <p>Control unit:</p> <ul style="list-style-type: none"> • set the ID of the dynamic configuration that shall be activated • set the status of each of the four OSSDs • enable the system recondition signal • enable the restart signal <p>Sensor:</p> <ul style="list-style-type: none"> • set the muting status 	to the control unit
Safe	<p>DYNAMIC CONFIGURATION STATUS</p> <ul style="list-style-type: none"> • ID of the dynamic configuration currently active • signature (CRC32) of the dynamic configuration ID currently active 	from the control unit
Unsafe	<p>DIAGNOSTIC DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> • internal status with an extended description of the error condition <p>Sensor:</p> <ul style="list-style-type: none"> • internal status with an extended description of the error condition 	from the control unit

Data type	Description	Communication direction
Unsafe	SYSTEM STATUS	from the control unit
Unsafe	TEACH-IN FUNCTION	from the control unit

4.4 MODBUS communication

4.4.1 MODBUS support

The communication using MODBUS is available on all the control units provided with the MODBUS interface. For details, see "Control units" on page 16.

4.4.2 MODBUS communication enabling

In the Inspect Safety application, click on **Admin > MODBUS Parameters** and check that the feature is enabled (ON).

Within the Ethernet network, the control unit acts like a server. The client must send requests to the IP address of the server on the MODBUS listening port (default port is 502).

To show and change the address and the port, click on **Admin > Network Parameters** and **Admin > MODBUS Parameters**.

4.4.3 Data exchanged through MODBUS

The following table details the data exchanged through the MODBUS communication:

Data type	Description	Communication direction
Unsafe	SYSTEM STATUS DATA Control unit: <ul style="list-style-type: none">internal statusstatus of each of the four OSSDsstatus of each single channel and dual channel inputrevision information Sensor: <ul style="list-style-type: none">status of each detection field (target detected or not) or error statusmuting statusrevision information	from the control unit
Unsafe	DYNAMIC CONFIGURATION STATUS <ul style="list-style-type: none">ID of the dynamic configuration currently activesignature (CRC32) of the dynamic configuration ID currently active	from the control unit
Unsafe	TARGET DATA <ul style="list-style-type: none">Current distance and angle of the targets detected by each sensor. For each detection field of each sensor, only the closest target to the sensor is considered.	from the control unit
Unsafe	DIAGNOSTIC DATA Control unit: <ul style="list-style-type: none">internal status with an extended description of the error condition Sensor: <ul style="list-style-type: none">internal status with an extended description of the error condition	from the control unit
Unsafe	TEACH-IN FUNCTION	from the control unit

5. Functioning principles

Contents

This section includes the following topics:

5.1 Sensor functioning principles	41
5.2 Detection fields	41

5.1 Sensor functioning principles

5.1.1 Introduction

The sensor is an FMCW (Frequency Modulated Continuous Wave) radar device based on a proprietary detection algorithm. It is also a multi-target sensor that sends pulses and receives information, analyzing the reflection of the nearest moving target that it encounters within each detection field.

The sensor can detect the current distance and the angle of each target.

Each sensor has its own fieldset. The fieldset corresponds to the structure of the field of view, which is composed of detection fields (see "Detection fields" below).

5.1.2 Factors that influence the sensor field of view and object detection

 **WARNING!** The presence of conductive material on the sensor could affect its field of view and, thus, object detection. For proper and safe system operation, validate the system under this condition.

5.1.3 Factors that influence the reflected signal

The signal reflected by the object depends on several characteristics of the same object:

- Metallic objects have a very high reflection coefficient, while paper and plastic reflect only a small portion of the signal
- The greater the surface exposed to the radar, the greater the reflected signal
- All other factors being equal, objects positioned directly in front of the radar generate a more significant signal than objects to the side
- Motion speed
- Inclination

All these factors have been analyzed for a human body during the safety validation of Inxpect SRE 200 Series and cannot lead to a dangerous situation. These factors may occasionally influence the behavior of the system causing spurious activation of the safety function.

5.1.4 Detected and missed objects

The signal analysis algorithm considers only those objects that move within the field of view, ignoring completely static objects (if the static object detection option is disabled).

Furthermore, a *falling objects* algorithm allows ignoring undesired alarms generated by small work waste products that fall in the first part of the sensor's field of view.

5.1.5 Interference with pacemakers or other medical devices

Radiation from Inxpect SRE 200 Series does not interfere with pacemakers or other medical devices.

5.2 Detection fields

5.2.1 Introduction

The field of view of each sensor can be composed of up to four detection fields. Each of the four detection fields has a dedicated detection signal.

⚠ WARNING! Configure the detection fields and associate them with the dual channel safety outputs according to the risk assessment requirements.

Note: for information about the cuboid detection fields, see "Cuboid shape (only for S202A-MC sensors)" on page 71.

5.2.2 Detection field parameters



These are the programmable parameters for each detection field:

- horizontal angular coverage
- only for S202A sensors, vertical angular coverage
- detection distance
- safety working mode (**Access detection and restart prevention** or **Always-on access detection**) (see "Safety working modes and safety functions" on page 47)
- restart timeout
- static object detection option
- only for 5.x sensors, Advanced field of view shape

5.2.3 Horizontal angular coverage

The horizontal angular coverage is in a range from 10° to 100° for the entire field of view.


The horizontal angular coverage of the detection field must be wider than, or equal to, the horizontal angular coverage of the following detection fields.



5.2.4 Vertical angular coverage (only for S202A sensors)


The vertical angular coverage is in a range from 30° to 90° for the entire field of view.

The vertical angular coverage of the detection field must be wider than, or equal to, the vertical angular coverage of the following detection fields.




5.2.5 Detection distance

The detection distance of the first detection field starts from the sensor. The detection distance of one field starts where the one of the previous field ends.



5. Functioning principles

The detection distance of one or more fields can be 0 (e.g., detection field 3). The first detection field with a detection distance other than 0 (e.g., detection field 1) must have a minimum detection distance of 500 mm (19.7 in) (for 3.x sensors) or 200 mm (7.9 in) (for 5.x sensors).



5.2.6 Detection fields dependency and detection signal generation


Note: the cuboid detection fields are independent and the dependency mode can not be set.

If a sensor detects motion within a detection field, its detection signal changes status and, when configured, the related safety output is deactivated. The behavior of the outputs related to the following detection fields depends on the detection field dependency set:


If...	Then...
the Dependent mode is set and thus detection fields are dependent on each other	<p>if a sensor detects motion within a detection field, all the outputs related to its following detection fields are deactivated too.</p> <p>Example</p> <p>Detection field configured: 1, 2, 3</p> <p>Detection field with target detected: 2</p> <p>Detection field in alarm status: 2, 3</p>
the Independent mode is set and thus detection fields are independent from each other	<p>if a sensor detects motion within a detection field, only the output related to that detection field is deactivated.</p> <p>Example</p> <p>Detection field configured: 1, 2, 3</p> <p>Detection field with target detected: 2</p> <p>Detection field in alarm status: 2</p>

⚠ WARNING! If detection fields are independent, an evaluation of the safety of the monitored area must be performed during the risk assessment. The blind area generated by a target can prevent the sensor from detecting targets in the following detection fields.

In this example, both detection field 1 and 2 generate a detection signal, for target **[A]** and **[B]** respectively.




In this example, detection field 1 generates a detection signal for target **[A]** but target **[B]** could not be detected.



In the **Inxpect Safety** application, click on **Settings > Advanced > Detection field dependency** to set the dependency mode of the detection fields.

5.2.7 Independent detection fields: a use case

It can be useful to set the detection fields as independent, for example, if there is a scheduled temporary motion of an object in a detection field. An example can be a robotic arm moving from right to left within the detection field 1 only during a specific phase of the operative cycle.



In this case, it is possible to ignore the detection signal in the detection field 1, thus avoiding unnecessary downtime.

⚠ WARNING! Evaluate the safety of the monitored area during risk assessment before deciding to ignore the detection signal of the detection field 1.

⚠ WARNING! The blind area generated by the moving robotic arm can prevent the sensor from detecting targets in the following other detection fields for a time interval. This time must be considered when defining the detection distance for detection field 2.

6. Safety functions

Contents

This section includes the following topics:

6.1 Safety working modes and safety functions	47
6.2 Safety working mode: Access detection and restart prevention (default)	48
6.3 Safety working mode: Always-on access detection	48
6.4 Restart prevention function: static object detection option	49
6.5 Features of the restart prevention function	49

6.1 Safety working modes and safety functions

6.1.1 Introduction

Each detection field of each sensor can perform the following safety working modes:

- **Access detection and restart prevention**
- **Always-on access detection**

Each safety working mode is composed of one or both of the following safety functions:

Function	Description
Access detection	The machinery is reverted into a safe status when one or more persons enter the dangerous area.
Restart prevention	The machinery is prevented from restarting if people are in the dangerous area.

6.1.2 Safety working modes

Via the Inxpect Safety application, you can select which safety working mode each sensor will employ for each of its detection fields:

- **Access detection and restart prevention** (default):
 - The sensor performs the access detection function when it is in normal operation (**No alarm** status).
 - The sensor performs the restart prevention function when it is in alarm status (**Alarm** status).
- **Always-on access detection**:
 - The sensor always performs the access detection function (**No alarm** status + **Alarm** status).

6.1.3 Access detection speed limits

The speed limits of the movements detected by the access detection function are reported below:

Application type	Minimum speed	Maximum speed
Stationary	0.1 m/s (0.33 ft/s)	1.6 m/s (5.25 ft/s)
Mobile	0.1 m/s (0.33 ft/s)	<ul style="list-style-type: none">• for detection distance less than or equal to 4 m (13.12 ft): 3 m/s (9.84 ft/s)• for detection distance greater than 4 m (13.12 ft): 2 m/s (6.56 ft/s) <p>Only for S202A sensors: always 1.6 m/s (5.25 ft/s)</p>

6.1.4 Recommendations for the access detection function

When one or more S203A sensors are installed at a height above 2 m (6.56 ft) from the reference plan and with a downward inclination in the range [60°, 120°], the sensors should be configured so that their field of view intersect the reference plan.

6.2 Safety working mode: Access detection and restart prevention (default)

6.2.1 Introduction

This safety working mode is composed of the following safety functions:

- access detection
- restart prevention

6.2.2 Safety function: access detection

Access detection allows what follows:

When...	Then...
no motion is detected in the detection field	the safety outputs remain active
motion is detected in the detection field (see "Access detection speed limits" on the previous page)	<ul style="list-style-type: none"> • the safety outputs are deactivated • the restart prevention function is activated

6.2.3 Safety function: restart prevention

The restart prevention function remains active and the safety outputs deactivated as long as motion is detected in the detection field, or, with the static object detection option enabled (see "Restart prevention function: static object detection option" on the next page), as long as a static object is detected in the detection field.

The sensor can detect micro-movements of just a few millimeters, such as breathing movements (with normal breathing or a short apnea) or the movements necessary for a person to remain in balance in an upright or squatting position.

The system sensitivity is higher than the sensitivity that characterizes the access detection function. For this reason, the system reaction to vibrating and moving parts is different.

The sensor guarantees the detection of people moving at any speed from 0 up to 1.6 m/s (5.25 ft/s)*, provided that the guidelines described in "Sensor positioning guidelines" on the next page are fulfilled.

Note*: a stationary person still has static residual movements that the radar can detect.

 **WARNING!** When the restart prevention function is active the monitored area may be affected by the position and inclination of the sensors, as well as by their installation height and angular coverage (see "Sensor position" on page 62).

6.2.4 Restart timeout parameter

When the system does not detect motion anymore or, with static object detection option enabled, no static object is detected, the OSSD outputs remain in OFF-state for the time set in the **Restart timeout** parameter. The **Restart timeout** parameter's minimum value is 0.1 s.

 **WARNING!** If the **Restart timeout** is set to a value less than 4 s, the sensor is no longer able to detect breathing movement or the movements necessary for a person to remain in balance in an upright or a squatting position. Set a value less than 4 s only for areas where people have no access.

6.3 Safety working mode: Always-on access detection

6.3.1 Safety function: access detection

This is the only safety function available for the **Always-on access detection**. Access detection allows what follows:

When...	Then...
no motion is detected in the detection field	the safety outputs remain active
motion is detected in the detection field	<ul style="list-style-type: none"> • the access detection function remains active • the safety outputs are deactivated • the sensitivity remains as it was before the motion detection

 **WARNING!** If the Always-on access detection is selected, additional safety measures must be introduced to ensure the restart prevention function.

6.3.2 T_{OFF} parameter

If the safety working mode is **Always-on access detection**, when the system does not detect motion anymore, the OSSD outputs remain in OFF-state for the time set in the T_{OFF} parameter.

The T_{OFF} value can be set from 0.1 s to 60 s.

6.4 Restart prevention function: static object detection option

6.4.1 Introduction

The static object detection option allows the restart prevention function also to detect static objects in the dangerous area.

NOTICE: the ability to detect an object depends on the RCS of the object. The static object detection option does not guarantee 100% detection of static objects.

6.4.2 Availability

The static object detection option is available for:

- control unit firmware version 1.5.0 or later, and
- sensor firmware version 3.0 or later.

6.4.3 Possible applications

This option can be useful if the sensor is installed on moving elements (see "Installations on moving elements (Mobile application)" on page 81) or to prevent the restart of a robot that could bump into a static object in the area temporarily.

6.4.4 Operation

The option can be enabled for each detection field of each sensor with the safety working mode set to **Access detection and restart prevention**. Enable the option only if the detection field is free of static objects; otherwise, the system would never reactivate the detection signals after a motion is detected in the area.

6.4.5 Settings

It is possible to increase or decrease the sensitivity of the static object detection of the sensors through the Inxpect Safety application (**Settings > Advanced > Static object detection sensitivity**)

6.5 Features of the restart prevention function

6.5.1 Sensor positioning guidelines

The restart prevention function is effective if the sensor can detect a person's movements or their static residual movements. To detect people who are not standing or squatting, it is important that the sensor can clearly detect the person's chest.

Particular attention should be paid to the following situations:

- There are objects that limit or prevent the sensor from detecting motion.
- The risk assessment requires the detection of a lying person and the sensor is installed at a height below 2.5 m (8.2 ft) or with an inclination lower than 60° downward.
- The sensor does not detect a sufficient portion of the body or does not properly detect the person's chest.

A validation procedure (see "Validate the safety functions" on page 96) must be performed when one or more of the above conditions are met.

If the conditions described above limit the performance of the sensor, take the following steps to reach an appropriate level of performance:


- Increase the **Restart timeout** parameter.
- Change the position of the sensors.

6. Safety functions

- Add more sensors.

If one or more of the above actions are taken, it is recommended to perform a validation procedure (see "Validate the safety functions" on page 96).

Below are some examples of situations where the above conditions are not met (X) and how to properly position the sensor (✓). These examples are not meant to be exhaustive.



6.5.2 Types of managed restart

NOTICE: it is the responsibility of the machinery manufacturer to assess if automatic restart can guarantee the same level of safety as manual restart (as defined in standard EN ISO 13849-1, section 5.2.2).

For each detection field independently, the system manages three types of restart:

Type	Conditions for enabling machinery restart	Safety working mode allowed
Automatic	The time interval set through the Inxpect Safety application (Restart timeout) has passed since the last motion detection*.	All
Manual	The Restart signal was received correctly** (see "Restart signal (dual channel, redundancy mode coherent)" on page 149).	Always-on access detection
Safe manual	<ul style="list-style-type: none"> The time interval set through the Inxpect Safety application (Restart timeout) has passed since the last motion detection* and The Restart signal was received correctly** (see "Restart signal + System recondition (dual channel, redundancy mode coherent)" on page 152). 	Access detection and restart prevention

⚠ WARNING! If the Automatic restart is set with the Safety working mode Always-on access detection, the restart prevention safety function is not performed, and consequently, the system does not guarantee the detection of a person within the monitored area.

Note*: machinery restart is enabled if no motion is detected up to 35 cm (13.8 in) beyond the detection field.

Note:** (for all types of restart) other dangerous system statuses may prevent the restart of the machinery (e.g., diagnostic fault, sensor masking, etc.).

6.5.3 Precautions for preventing unexpected restarting

To prevent unexpected restarting, if the sensor is installed at a height of less than 15 cm (5.9 in) from the ground to its center, a minimum distance of 50 cm (20 in) from the sensor must be guaranteed.

Note: if the sensor is installed at a height of less than 15 cm (5.9 in) from the ground to its center, an option is to enable the masking function to generate a system error if a person stands in front of the sensor.

6.5.4 Configure the restart function

 **WARNING!** If the Restart signal function has been enabled both through the safety Fieldbus and the digital inputs, the functionality can be activated from both of them.

Type	Procedure
Automatic	<ol style="list-style-type: none"> 1. In the Inxpect Safety application in Settings > Restart function, select Automatic. 2. In the Inxpect Safety application, in Configuration for each detection field in use with automatic restart, select the desired Safety working mode and set the Restart timeout (or the T_{OFF} parameter, if present).
Manual	<ol style="list-style-type: none"> 1. In the Inxpect Safety application in Settings > Restart function, select Manual. 2. If there is a digital input configured as Restart signal (Settings > Digital Input-Output), connect the machinery button for the restart signal as convenient (see "Electrical connections" on page 131). 3. To use the Fieldbus communication for the restart signal, make sure that no digital input is configured as Restart signal (Settings > Digital Input-Output). See the Fieldbus protocol for details. 4. In the Inxpect Safety application, in Configuration for each detection field in use with manual restart, set the T_{OFF} parameter value. <p>Note: the Safety working mode is automatically set to Always-on access detection for all the detection fields in use with manual restart.</p>
Safe manual	<ol style="list-style-type: none"> 1. In the Inxpect Safety application in Settings > Restart function, select Safe manual. 2. If there is a digital input configured as Restart signal (Settings > Digital Input-Output), connect the machinery button for the restart signal as convenient (see "Electrical connections" on page 131). 3. To use the Fieldbus communication for the restart signal, make sure that no digital input is configured as Restart signal (Settings > Digital Input-Output). See the Fieldbus protocol for details. 4. In the Inxpect Safety application, in Configuration for each detection field in use with safe manual restart, select the Safety working mode among those allowed and set the Restart timeout parameter value.

7. Other functions

Contents

This section includes the following topics:

7.1 Muting	52
7.2 Teach-In function (-WT sensors only)	53
7.3 Anti-tampering functions: anti-rotation around axes	57
7.4 Anti-tampering functions: anti-masking	59
7.5 Auto-resume (5.x sensors only)	60
7.6 Electromagnetic Robustness	61

7.1 Muting

7.1.1 Description

The muting function is an additional safety-related function that inhibits the sensing capability of the sensor on which it is activated. It can be activated for a specific sensor or for a group of sensors. This results in keeping the ON-state of the OSSD or the safety Fieldbus even when the muted sensors detect motion.

When the muting function is enabled, its effective activation on one or more sensors occurs only as soon as the conditions permit (see "Muting activation conditions" below).

7.1.2 Muting enabling

The muting function can be enabled through digital input (see "Enable muting signal characteristics" on the next page) or safety Fieldbus (if available).

 **WARNING! If the muting function has been enabled through the safety Fieldbus and the digital inputs, only the digital inputs enabling is considered for the function.**

 **WARNING! When the sensor is in muting, no sensor error is available (see "ERROR events (sensor)" on page 117).**

Through the safety Fieldbus (if available) the muting function can be enabled for each sensor individually.

Through digital inputs the muting function can be enabled for all the sensors simultaneously or only for a group of sensors. Up to two groups can be configured, each associated with a digital input.

Through the Inxpect Safety application, the following must be defined:

- for each input, the group of managed sensors
- for each group, the sensors that belong to it
- for each sensor, whether it belongs to a group or not

Note: if the muting function is enabled for one sensor, it is enabled for all the detection fields of the sensor, regardless if the detection fields are dependent or independent and the anti-tampering functions are disabled for that sensor.

See "Configure the inputs and outputs" on page 95.

7.1.3 Muting activation conditions

The muting function is activated on a specific sensor only in the following conditions:

- All the detection fields involved have no active detection signal, no active static object detection signal, and the restart timeout has expired for all of them.
- There is no tampering signal or fault signal for that sensor.


When the muting is enabled for a group of sensors, the function is activated as soon as there is no detection in the monitored area of all sensors.

WARNING! Enable the muting signal on sensors monitoring the same dangerous area once the whole area is safe and nobody can access it. If the muting is enabled on single sensors through Fieldbus and sensors monitoring the same dangerous area are still detecting a movement, a person could move to a space monitored by a muted sensor, compromising the safety of the whole area.

7.1.4 Enable muting signal characteristics

The muting function is enabled only if both logic signals of the dedicated input meet certain characteristics.

Below is a graphic representation of the signal characteristics.



In the **Inspect Safety** application, in **Settings > Digital Input-Output** it is necessary to set the parameters that define the signal characteristics.

Note: with pulse duration = 0, it is sufficient that the input signals are at high logic level (1) to enable muting.

7.1.5 Muting status

Any output dedicated to the muting status (Muting enable feedback signal) is activated if at least one of the groups of sensors is in muting.

NOTICE: it is the responsibility of the machinery manufacturer to assess whether the indication of the muting status is necessary (as defined in section 5.2.5 of EN ISO 13849-1 standard).

7.2 Teach-In function (-WT sensors only)

7.2.1 Availability

The Teach-In function is available for:

- S201A-WT and S203A-WT sensors (firmware version 5.0 or later), and
- control unit firmware version 2.1 or later

7.2.2 Introduction

For all the connected -WT sensors, the Teach-In function searches for moving or static objects (monitoring phase) within the Teach-In monitoring area (configurable area). The function adjusts automatically the detection distance of the last detection field of each sensor according to the position of the nearest target and an offset distance set.

The function affects the last configured detection field (with detection distance > 0) of each sensors as set in the first dynamic configuration. The function affects the first dynamic configuration regardless of how many dynamic configurations are configured and which of them is active.


The function can be activated through digital input or safety Fieldbus.

WARNING! The Teach-In function is a non-safe function which changes the configuration of the detection fields and consequently the safety of the area. Validate the configuration set by the function (see relevant step in the procedure "Execute the Teach-In function" on page 57).

7.2.3 Monitoring area

The default Teach-In monitoring area is as follows:

- horizontal angular coverage: 40°
- detection distance : from 300 mm (0.98 ft) to 5000 mm (16.4 ft).




The monitoring area can be customized: horizontal angular coverage (β parameter) and corridor width (c parameter), see "Configuration application parameters" on page 138.


Note: the Teach-In monitoring area (shared between the -WT sensors and set in **Settings > Advanced > Teach-In** function) is different from the field of view of each sensor (set in **Configuration**).

7.2.4 Operation

If during the monitoring phase, the function finds at least a target inside the monitoring area, it adjusts the detection distance of the last detection field [D_{DF}] according to the target distance [R] and the offset distance [o] set (default 200 mm (0.65 ft).).



If no target is found, the detection distance of the last detection field [D_{DF}] of each -WT sensors is set up such as the total detection distance of the sensor [D_{TOT}] is the maximum detection distance (5000 mm (16.4 ft)).



The function does not modify any configuration parameters except for the detection distance of the last detection field, which can be either reduced or increased according to the target distance.

A manual validation of the new configuration is required to confirm the distance set by the function.

7.2.5 Detection distance calculation

Legend

R = target distance

o = offset distance (**o** parameter, default 200 mm)

b = beginning of the last detection field, if there is only one detection field it is 0.

d = minimum detection distance of the detection field = 200 mm

D_{DF} = detection distance of the detection field set by the function


D_{TOT} = total detection distance of the sensor (**D_{DF}** + **b**)

D_{MAX} = maximum detection distance of the sensor (5000 mm (16.4 ft))

Case 1 (target detected)

If $R - o > b + d$


Result: $D_{DF} = R - o - b$



Case 2 (target detected)

If $R - o < b + d$


Result: $D_{DF} = d$



WARNING! To avoid misconfiguring the detection fields, set the start of the last detection field with a correct margin towards the target you expect to detect. See "Calculation examples" on the next page.

Case 3 (target not detected)


Result: $D_{DF} = D_{MAX} - b$.



Case 4 (target detected)

If $R < b$

Result: D_{DF} = not calculated, function fault



7.2.6 Calculation examples

Example 1: case 1

R: 1900 mm

o: 150 mm

d: 200 mm

b: 1500 mm

R - o = 1750

b + d = 1700

R - o > b + d

Then $D_{DF} = R - o - b = 1900 - 150 - 1500 = 250$ mm

$D_{TOT} = D_{DF} + b = 1750$ mm

Example 2: field of view of the sensor pre-configured in an non optimal way by the user

R: 1600 mm

o: 150 mm

d: 200 mm

b: 1500 mm

R - o = 1450 mm

b + d = 1750

R - o < b + d

Then **D_{DF}** = **d** = 200 mm

D_{TOT} = **D_{DF}** + **b** = 1700 mm

The total detection distance of the sensor (**D_{TOT}**) is greater then the target distance (**R**). If the sensor generates false alarms, adjust the beginning of the last detection field (**b**) properly.

7.2.7 Execute the Teach-In function

1. Check that the field of view configuration of the sensor is compatible with the Teach-In function by means of the Inxpect Safetyapplication. See "Example 2: field of view of the sensor pre-configured in an non optimal way by the user" above and See "Define the area to be monitored" on page 95.
2. Activate the Teach-In function through digital input or safety Fieldbus. During the monitoring time, the following actions are performed:
 - the detection signals outputs switch to OFF-state.
 - the **Teach-In feedback signal** output switches to ON-state.
 - the monitoring phase begins.
 - for each -WT sensor, the detection distance of the last detection field is adjusted according to the position of the nearest target detected, if any, and an APPLY CHANGES operation is performed to save the new configuration on the control unit.

Note: to activate the Teach-In function through digital input, a digital input must be set as **Teach-In**.

Note: the monitoring time of the Teach-In function is about 7 seconds.

3. At the end of the monitoring phase, read the status of the **Teach-In feedback signal** (via digital output or safety Fieldbus) to verify that the Teach-in feedback signal flashes slowly (500 ms ON-state followed by 1500 ms OFF-state).


Note: in case of fault condition given by the Teach-in function the **Teach-In feedback signal** flashes faster (500 ms ON-state followed by 500 ms OFF-state) and the detection signal outputs go in OFF-state. Restart the procedure or open the Inxpect Safetyapplication to have details about the error.
4. Validate the correctness of the system configuration set by the function (see "Validate the safety functions" on page 96).
5. If the set system configuration is ok, confirm the end of the validation through digital input or safety Fieldbus (same signal used for the function activation). The output set as **Teach-In feedback signal** switches to OFF-state.
6. If the set system configuration is not ok, confirm the end of the validation (step 5) then go back to step 1.

7.3 Anti-tampering functions: anti-rotation around axes

7.3.1 Anti-rotation around axes

The sensor detects rotation around its axes.

Note: the axes are those represented in the figure below, regardless of the installation position of the sensor.



When the system configuration is saved, the sensor also saves its position. Later, if the sensor detects changes in rotation around these axes, it sends a tamper alert to the control unit. Upon reception of a tampering signal, the control unit deactivates the safety outputs.

Note: when the position is modified with respect to the saved references (i.e., when a sensor is rotated) and the anti-rotation around axes function is enabled, the Inxpect SRE 200 Series detects the tampering and sends the message within 5 s.

The sensor can detect changes in rotation around the x-axis and the z-axis even if it is switched off. The tamper alert is sent to the control unit at the following switch on.

A change in rotation around the y-axis is detected only if it is faster than 5° every 10 s and if the system is on.

⚠️ WARNING! The tamper alert due to a rotation around the y-axis is reset at the next switch on. For proper and safe operation of the system, validate the system again.

7.3.2 Enable the anti-rotation around axes function

The anti-rotation around axes function is disabled by default.

⚠️ WARNING! If the function is disabled, the system cannot signal a change in the rotation of the sensor around the axes and, therefore, any changes in the monitored area. See "Checks when the anti-rotation around axes function is disabled" below.

⚠️ WARNING! Take precautions to prevent tampering, if the function is disabled for at least one axis of one sensor and if the rotation around that axis is not protected with tamper-proof screws.

The function can be enabled and configured for each axis of each sensor individually. In the Inxpect Safety application, in **Settings > Anti-tampering**, click on the specific option to enable the function for a sensor.

7.3.3 When to enable

Enable the anti-rotation around axes function only if it is necessary to detect a change in the rotation of a sensor around a specific axis.

It is strongly suggested not to enable the function if the sensor is installed on a moving element (e.g., carriage, vehicle) whose motion could change the sensor inclination (e.g., motion on a slope or in a curve).

7.3.4 Checks when the anti-rotation around axes function is disabled

When the anti-rotation around axes function is disabled, perform the following checks.

Safety function	Schedule	Action
Access detection function	Before each machinery restart	Check that the sensor is positioned as defined in the configuration.
Restart prevention function	Each time the safety outputs are deactivated	Check that the monitored area is the same as defined by the configuration. See "Validate the safety functions" on page 96.

7.4 Anti-tampering functions: anti-masking

7.4.1 Masking signal

The sensor detects the presence of objects that could obstruct the field of view. When the system configuration is saved, the sensor memorizes the surrounding environment. If the sensor subsequently detects variations in the environment that could influence the field of view, it sends a masking signal to the control unit. The sensor monitors from -50° to 50° on the horizontal plane regardless of the horizontal angular coverage set. Upon receiving a masking signal, the control unit deactivates the safety outputs.

Note: the masking signal is not guaranteed in the presence of objects which cause reflection effects that bring their RCS below the minimum detectable threshold.

Note: when the position is modified with respect to the saved references (i.e., when a sensor is masked) and the anti-rotation around axes function is enabled, the Inxpect SRE 200 Series detects the tampering and notifies it within 5 s.

7.4.2 Environment memorization process

The sensor starts the surrounding environment memorization process when the Inxpect Safety application configuration is saved. From that moment, it waits for the system to exit the alarm status and for the scene to be static up to 20 seconds, then scans and memorizes the environment.

NOTICE: if the scene is not static during the 20 seconds interval, the system remains in a fault status (SIGNAL ERROR) and the system configuration must be saved again.



It is recommended to start the memorization process after at least 3 minutes from turning on the system to guarantee that the sensor has reached the operating temperature.

Only at the conclusion of the memorization process it is possible for the sensor to send masking signals.

7.4.3 Causes of masking

Possible causes of masking signals are the following:

- An object that obstructs the field of view of the sensor has been placed in the detection field.
- The environment in the detection field changes significantly, for example, if the sensor is installed on moving parts or if there are moving parts inside of the detection field.
- The configuration was saved with sensors installed in an environment that is different from the working environment.
- There were temperature fluctuations.

7.4.4 Masking signal when the system is turned on

If the system was off for several hours and there were temperature fluctuations, the sensor might send a false masking signal when it is turned on. The safety outputs activate automatically within 3 minutes when the sensor reaches its working temperature. This does not happen if this temperature is still very far from the reference temperature.

7.4.5 Settings

For each sensor, the anti-masking settings are the following:

- maximum distance from the sensor (range [20 cm/7.87 in, 100 cm/3.28 ft*], 10 cm/3.94 in steps) in which the function is active
- sensitivity

Note*: only for S202A sensors, the maximum detection distance value is 50 cm/1.64 ft.

These are the four levels of sensitivity:

Note: the function has a tolerance area where the actual detection of a masking object depends on the RCS of the object and on the sensitivity level set. The high sensitivity level has the largest area, about 10-20 cm (3.94-7.87 in).

Level	Description	Example application
High	The sensor has the highest sensitivity to changes in the environment. (Suggested level when the field of view is empty up to the set masking distance)	Installations with an empty environment and a height of less than one meter, where objects could occlude the sensor.
Medium	The sensor has low sensitivity to changes in the environment. Occlusion must be evident (deliberate tampering).	Installations with a height of more than one meter, where masking is likely to occur only if voluntary.
Low	The sensor detects masking only if the sensor occlusion is complete and the objects are highly reflective (e.g., metal, water) near the sensor.	Installations on moving parts, where the environment is changing continuously, but where static objects may be near the sensor (obstacles on the route).
Disabled	<p>The sensor does not detect changes in the environment.</p> <p> WARNING! If the function is disabled the system cannot signal the presence of objects that might impede normal detection (see "Checks when the anti-masking function is disabled" below).</p>	See "When to disable" below.

To change the sensitivity level or disable the function, in the Inxpect Safety application, click **Settings > Anti-tampering** and search for **Anti-masking sensitivity**.

To set the distance, in the Inxpect Safety application, click **Settings > Anti-tampering** and search for **Anti-masking distance**.

7.4.6 Checks when the anti-masking function is disabled

When the anti-masking function is disabled, perform the following checks.

Safety function	Schedule	Action
Access detection function	Before each machinery restart	Remove any objects that obstruct the field of view of the sensor.
Restart prevention function	Each time the safety outputs are deactivated	Reposition the sensor according to the initial installation.

7.4.7 When to disable

The anti-masking function should be disabled under the following conditions:

- (With restart prevention function) The monitored area includes moving parts that stop in different and unpredictable positions.
- The monitored area includes moving parts that vary their position while the sensors are in muting.
- The sensor is positioned on a part that can be moved.
- The presence of static objects is tolerated in the monitored area (e.g., loading/unloading area).

7.5 Auto-resume (5.x sensors only)

7.5.1 Introduction

Some transient faults cause a permanent lock-out condition that prevents normal operation from being restored. While the safe state is maintained, this behavior represents a limitation, especially for remote systems that are not easily accessible.

The Auto-resume function tries to restore the normal functioning of the sensor for five consecutive attempts: if the fault condition persists, the block condition is preserved. Otherwise, the normal functioning condition is automatically restored.

7.5.2 Function limitations

The following faults are not subjected to auto-resume:

- POWER ERROR
- SIGNAL ERROR
- TAMPER ERROR
- TEMPERATURE ERROR

The function is not performed when the sensor is muted.

7.6 Electromagnetic Robustness

7.6.1 Electromagnetic robustness parameter

With the **Electromagnetic robustness** parameter, it is possible to increase the robustness of the system to electromagnetic interference (e.g., due to sensors of different systems installed too close to each other or problems on the CAN bus).

In the Inxpect Safety application in **Settings > Advanced**, the following levels of robustness can be set:

- **Standard** (default)
- **High**
- **Very High**

 **WARNING!** The parameter impacts the system response time for the access detection safety function. According to the chosen level, the maximum guaranteed response time is 100 ms (Standard), 150 ms (High), or 200 ms (Very High).

8. Sensor position

Contents

This section includes the following topics:

8.1 Basic concepts	62
8.2 Sensor field of view	63
8.3 Advanced field of view (5.x sensors only)	69
8.4 Cuboid shape (only for S202A-MC sensors)	71
8.5 Separation distance calculation	72
8.6 Calculation of range of distances	78
8.7 Sensor position recommendations	80
8.8 Installations on moving elements (Mobile application)	81
8.9 Outdoor installations	83


8.1 Basic concepts

8.1.1 Determining factors

The sensor installation height and inclination should be decided together with the angular coverage and the detection distances in order to have optimal coverage of the dangerous area.

8.1.2 Sensor installation height

The installation height (h) is the distance between the center of the sensor and the ground or reference plane of the sensor.



8.1.3 Sensor inclination

Sensor inclination is the rotation of the sensor around its x-axis. Inclination is defined as the angle between a line perpendicular to the sensor and a line parallel to the ground. Three examples are presented as follows:

- sensor tilted upwards: α positive
- straight sensor: $\alpha = 0$
- sensor tilted downwards: α negative



8.2 Sensor field of view

8.2.1 Types of field of view

During the configuration phase, for each sensor it is possible to select the horizontal angular coverage (see "Horizontal angular coverage" on page 42).

The actual detection field of the sensor also depends on the sensor installation height and inclination (see "Calculation of range of distances" on page 78).

The standard shapes of the field of view are described below. For 5.x sensors, the Classic and Corridor shapes are available (see "Advanced field of view (5.x sensors only)" on page 69).

8.2.2 Areas and dimensions of the field of view

The sensor field of view is composed of two areas:


- detection field: where detection of objects similar to humans in any position is guaranteed
- tolerance area: where the actual detection of a moving object/person depends on the characteristics of the object itself (see "Factors that influence the reflected signal" on page 41).

8.2.3 Dimensions for the access detection function


Below are reported the maximum field of view dimensions **[A]** and the relative tolerance area **[B]**.

The tolerance area dimensions are the same for maximum angular coverage (as described in the following figures) and for smaller coverages.


Note: the tolerance area dimensions described are related to the detection of humans. It dimensions




Top view



Side view S201A model



Side view S203A model



Side view S202A model


8.2.4 Dimensions for the restart prevention function

Below are reported the maximum field of view dimensions **[A]** and the relative tolerance area **[B]**.


The tolerance area dimensions are the same for maximum angular coverage (as described in the following figures) and for smaller coverages.

Note: the tolerance area dimensions described are related to the detection of humans. It dimensions


8. Sensor position




Top view



Side view S201A model



Side view S203A model



Side view S202A model

8.2.5 Position of the field of view



The field of view is tilted of the following degrees:

- 2.5° for S201A model
- 5° for S202A model
- 1° for S203A model



To understand the actual position of the sensor field of view consider the LED position:

- left with sensor LED on the right (with respect to the sensor center, facing the sensor)
- right with sensor LED on the left (with respect to the sensor center, facing the sensor)
- downward with sensor LED up



Offset 2.5°



Top view with sensor inclination 0°.




Top view with sensor inclination 0°.




Side view with sensor inclination 0°.

8. Sensor position


Offset 5°



Top view with sensor inclination 0°.




Top view with sensor inclination 0°.




Side view with sensor inclination 0°.


Offset 1°



Top view with sensor inclination 0°.



Top view with sensor inclination 0°.



Side view with sensor inclination 0°.

8.3 Advanced field of view (5.x sensors only)

8.3.1 Introduction

For each sensor, two field of view shapes are available:


- Classic
- Corridor

Only for S202A-MC sensors, the cuboid shape is also available, see .


8.3.2 Classic field of view

The classic shape allows you to choose the standard shape of the field of view and, if desired, to make it asymmetric. Each detection field can have its own symmetric/asymmetric angular coverage.

Only for S202A sensors, it is possible to customize also the field of view height.



Examples of asymmetric horizontal angular coverage.



Examples of asymmetric vertical angular coverage.

8. Sensor position


Conditions:

- The sensor axis must always be included in all the detection fields.
- The horizontal/angular coverage of each detection field must be wider than, or equal to, the horizontal/angular coverage of the following detection fields.
- The minimum field of view width is 10°. Only for S202A sensors the minimum value is 20°.
- The minimum field of view height is 30°.


8.3.3 Corridor field of view

The corridor shape allows to customize the shape of the field of view. Starting from the standard shape with maximum angular coverage, it is possible to crop it on the side with two flat surfaces parallel to the axis of the sensor. Each detection field can have its own corridor width.

Only for S202A sensors, it is possible to customize also the corridor height of each detection field.



Examples of corridor width.



Examples of corridor height.

Conditions:

- The sensor axis must always be included in all the detection fields.
- The corridor width/height of each detection field must be wider than, or equal to, the corridor width/height of the following detection fields.
- The minimum corridor width is 20 cm. Only for S202A sensors the minimum value is 30 cm.
- The minimum corridor height is 30 cm.


8.4 Cuboid shape (only for S202A-MC sensors)

8.4.1 Availability

The cuboid shape is available only for S202A-MC sensors.

8.4.2 Introduction

The cuboid shape allows you to shape each detection field as a cuboid. Starting from the standard shape of the field of view with maximum angular coverages, the cuboid is defined by its own dimensions and it can be positioned anywhere within the field of view of the sensor.



⚠️ WARNING! Position the cuboid away from the limits of the field of view to avoid irregular cuboid shapes and tolerance area effects.

8.4.3 Cuboid detection fields

The four detection fields available for each sensors are independent from each other and there are no constraints on the positions of the cuboids, which can also be overlapped and/or included within each other. An area in common with two detection fields (e.g. detection field 1 and detection field 2), belongs to the detection field with lower numbering (detection field 1 in the previous example).

The detection field is numbered to be identified in the system and matched with the relative detection signal.


8.4.4 Cuboid detection field parameters

These are the programmable parameters for each detection field:

- cuboid dimensions
- safety working mode (**Access detection and restart prevention** or **Always-on access detection**) (see "Safety working modes and safety functions" on page 47)
- restart timeout
- static object detection option

8.4.5 Dimensions

The x, y and z dimensions of the cuboid can be set. The minimum value for each dimension is 500 mm.





⚠️ WARNING! At the limits of the cuboid there is a tolerance area where the actual detection of a moving object/person depends on the characteristics of the object itself. Validate the system thoroughly to check the influence of the tolerance area.

8.4.6 Cuboid tail

The area of the field of view from the sensor to the vertexes of the front face of the cuboid (*tail*) can be included or excluded from the detection field, for all the detection fields of the sensor and for a specific dynamic configuration. When included, the tail belongs to detection field 1.

By default the tail is included. If the tail is excluded, graphically it is not visible in the application and the sensor will not trigger an alarm if a movement is detected in the tail area.



Example of cuboid detection field with the tail included and excluded.

8.5 Separation distance calculation

8.5.1 Introduction

The formula the Inxpect SRE 200 Series uses to calculate the separation distance is based on the ISO 13855:2024 standard and is described in the following sections. The standard was used as a guideline to define the separation distance for volumetric devices that can be approached from different directions.

8.5.2 Formula for stationary application

To calculate the separation distance (S) for stationary applications, use the following formula:

$$S = K * T + D_{DS} + Z$$

Where:

Variable	Description	Value	Measurement unit	Notes
K	Maximum approach speed	1600	mm/s	The maximum approach speed is considered to be 1600 mm/s because RPDs are body protection devices. This is in accordance with the definition of approach speed of ISO 13855:2024.
T	Overall system response	See ISO 13855	s	The overall system response time T includes portions of time that vary according to machine type, safeguard(s) applied, and elements of the SRP/CS involved in the safety function.

Variable	Description	Value	Measurement unit	Notes
D_{DS}	Reaching distance	<ul style="list-style-type: none"> If $H_{DT} \leq 1000$, $D_{DS} = 1200$ If $1000 < H_{DT} < 1400$, $D_{DS} = 1200 - [(H_{DT} - 1000) * 0.875]$ If $H_{DT} \geq 1400$, $D_{DS} = 850$ 	mm	For the definition of H_{DT} , see ISO 13855:2024. For more details about H_{DT} , see "Reaching distance calculation assumptions" below.
z	Supplemental distance factor	See ISO 13855:2024.	mm	The tolerance zone as expressed in IEC TS 61496-5 is already considered in the provided detection distance. No corrective values for the tolerance zone need to be added in the calculation of the separation distance.


Note: when using Fieldbus, the computation of the overall response time should consider the cycle time.

8.5.3 Reaching distance calculation assumptions


The reaching distance D_{DS} can be calculated starting from the height of detection zone H_{DT} , based on the following assumptions:

- for H_{DT} higher than 1400 mm, the person could just introduce one arm (see "Example of HDT \geq 1400 mm (parallel approach)" on the next page).
- for H_{DT} lower than 1000 mm, the person could introduce one arm and part of the upper body (see "Example of HDT \leq 1000 mm (parallel approach)" on the next page).


The formula for the calculation of D_{DS} is defined using a conservative approach derived from the values extracted from Table 2 of ISO 13855:2024.



Line	Description
-----	Reaching distance over a vertical zone according to Table 2 of ISO 13855
=====	Reaching distance according to the formula $1200 - [(H_{DT} - 1000) * 0.875]$

Example of $H_{DT} \geq 1400$ mm (parallel approach)

Part	Description
A	Reference place
B	RPD
C	Hazard zone
D	Obstacle

Example of $H_{DT} \leq 1000$ mm (parallel approach)


Part	Description
A	Reference place
B	RPD
C	Hazard zone

8.5.4 Height of detection zone calculation and sensor position

The height of detection zone H_{DT} should be calculated using the guideline of ISO 13855:2024, both for parallel and orthogonal approach.


For cuboid detection fields use the parallel approach to calculate the height of detection zone H_{DT} .

The sensor must be installed to avoid reaching under (see ISO 13855:2024). If the vertical distance of the detection zone from reference plane H_D is greater than 200 mm, there is a risk of inadvertent undetected access beneath the detection zone. This must be taken into account in the risk assessment and additional protective measures applied, if necessary.

Example of H_{DT} for orthogonal approach (top view)

Part	Description
A	RPD
B	Protective structure
C	Hazard zone
D	Protective structure


Example of H_{DT} for orthogonal approach (front view)




Part	Description
A	Reference plane
B	Protective structure
C	RPD
D	Protective structure

8.5.5 Examples


Below is an additional example of identification of H_{DT} for parallel approach [A], and examples of identification of H_{DT} for orthogonal approach [B], [C], [D] and [E].




[A]




[B]



[C]




[D]



[E]

8.5.6 Example of calculation of the separation distance - parallel approach

Below is an example of an operator approaching a hazardous area where a RPD is used to safeguard the area.



Example

- Overall stopping time $T = 0.2 \text{ s}$
- $H_{DT} = 1200 \text{ mm}$
- $Z_P = 100 \text{ mm}$
- $Z_M = 100 \text{ mm}$

According to the formula for the calculation of the reaching distance:


$$D_{DS} = 1200 - [(H_{DT} - 1000) * 0.875] = 1200 - 175 = 1025 \text{ mm}$$

According to these values, the overall separation distance is:

$$S = 1600 \times 0.2 + 1025 + 200 = 1545 \text{ mm}$$

8.5.7 Example of calculation of the separation distance - orthogonal approach

Below is an example of an operator approaching a hazardous area where an RPD is used to safeguard the area.



Example

- Overall stopping time $T = 0.1 \text{ s}$
- $H_{DT} = 2200 \text{ mm}$
- $Z = 0 \text{ mm}$

According to the formula for the calculation of the reaching distance:

$$D_{DS} = 850 \text{ mm}$$

According to these values, the overall separation distance is:

$$S = 1600 \times 0.1 + 850 + 0 = 1010 \text{ mm}$$

8.5.8 Formula for mobile application

To calculate the depth of the separation distance (S) for mobile applications, use the following formula:

$$S = K * T + C$$

Where:

Variable	Description	Value	Measurement unit
K	Maximum vehicle/part of machinery speed *.	For detection distance \leq 4 m (13.12 ft): K \leq 3000	mm/s
		For detection distance $>$ 4 m (13.12 ft): K \leq 2000	
T	Overall system response time	See ISO 13855**	s
C	Corrective value	200	mm

Note*: only the speed of the vehicle or of the part of machinery is considered. This is based on the assumption that the person recognizes the hazard and stands still.

Note**: the overall system response time T includes portions of time that vary by machine type, the safeguard(s) applied, and the elements of the SRP/CS involved in the safety function.

Note: when using Fieldbus, the cycle time should be considered in the computation of the overall response time.

Example 1

- maximum vehicle speed = 2000 mm/s
- machinery stopping time = 0.5 s

$$T = 0.1 \text{ s} + 0.5 \text{ s} = 0.6 \text{ s}$$

$$S = 2000 * 0.6 + 200 = 1400 \text{ mm}$$

8.6 Calculation of range of distances

8.6.1 Introduction

Note: the following calculation instructions are not valid for cuboid detection fields.

The range of detection distances for a sensor depends on the inclination (**α**) and the installation heights (**h**) of the sensor. The detection distance of each detection field (**Dalarm**) depends on a distance **d** that must be within the range of distances allowed.

The formulas for calculating the distances are reported as follows.

 **WARNING!** Define the optimum sensor position according to the risk assessment requirements.

8.6.2 Legend

Element	Description	Measurement unit
α	Sensor inclination	degrees
h	Sensor installation height	m
d	Detection distance (linear) Must be within the range of distances allowed (see "Installation configurations" on the next page).	m
Dalarm	Detection distance (real)	m
D₁	Start detection distance (for configuration 2 and 3); end detection distance (for configuration 1)	m
D₂	End detection distance (for configuration 3)	m

8.6.3 Installation configurations

For the S201A model, three configurations are possible based on the inclination of the sensor (α):

- $\alpha \geq +13^\circ$: configuration 1, the field of view of the sensor never intersects the ground
- $-7^\circ \leq \alpha \leq +12^\circ$: configuration 2, the upper portion of the field of view of the sensor never intersects the ground
- $\alpha \leq -8^\circ$: configuration 3, the upper portion and the bottom portion of the field of view always intersect the ground

For the S203A model, three configurations are possible based on the inclination of the sensor (α):

- $\alpha \geq +8^\circ$: configuration 1, the field of view of the sensor never intersects the ground
- $-5^\circ \leq \alpha \leq +7^\circ$: configuration 2, the upper portion of the field of view of the sensor never intersects the ground
- $\alpha \leq -6^\circ$: configuration 3, the upper portion and the bottom portion of the field of view always intersect the ground

Note: the positive sign (+) indicates the tilt up, while the negative sign (-) the downward tilt.

8.6.4 Calculate the range of distances

The range of detection distances for a sensor depends on the configuration:

Configuration	Range of distances
1	From 0 m to D_1
2	From D_1 to 5 m
3	From D_1 to D_2

For S201A model:

$$D_1 = \frac{h-0.2}{\tan((-\alpha)+2.5^\circ+10^\circ)}$$


$$D_2 = \frac{h-0.6}{\tan((-\alpha)+2.5^\circ-10^\circ)}$$

For S203A model:


$$D_1 = \frac{h-0.2}{\tan((-\alpha)+1^\circ+6^\circ)}$$

$$D_2 = \frac{h-0.6}{\tan((-\alpha)+1^\circ-6^\circ)}$$

Below is an example for configuration 3, with $D_1 = 0.9$ m and $D_2 = 1.6$ m.



S201A model




S203A model

8.6.5 Calculate the real detection distance

The actual detection distance **Dalarm** is the value to be entered on the **Configuration** page of the Inxpect Safety application.

Dalarm indicates the maximum distance between the sensor and the object to be detected.



$$Dalarm = \sqrt{d^2 + (h - 0.2)^2}$$

8.7 Sensor position recommendations

8.7.1 For access detection function

Below are some recommendations for the sensor positioning for the access detection function:

- If the distance between the ground and the bottom portion of the field of view is greater than 20 cm (7.9 in), take precautions to make sure that even a person entering the dangerous area below the volume monitored by the field of view is still detected.
- If the height above the ground is less than 20 cm (7.9 in), install the sensor with an inclination of minimum 10° upwards.
- The installation height (from the ground to the center of the sensor) must be greater than or equal to 15 cm (5.9 in).


8.7.2 For access control of an entrance

⚠️ WARNING! Take all necessary precautions to avoid any attempt to climb over whenever there is that risk.


Below are some recommendations for the sensor positioning if it is installed for controlling an entrance:

- The installation height (from the ground to the center of the sensor) must be greater than or equal to 20 cm (7.9 in).
- The horizontal angular coverage must be 90°.
- The inclination must be 40° upwards.
- The rotation around the z-axis must be 90°.

Below is an example:



⚠ WARNING! The horizontal angular coverage in the first 800 mm (31.5 in) of the field of view must be at least 60°. If this specification cannot be respected, take precautions to avoid the access of a human in the first 800 mm (31.5 in) of the field of view.



8.7.3 For restart prevention function

Below are some recommendations for the sensor positioning for the restart prevention function:

- The installation height (from the ground to the center of the sensor) must be greater than or equal to 15 cm (5.9 in).

8.8 Installations on moving elements (Mobile application)

8.8.1 Introduction

The sensors can be mounted on moving vehicles or moving machinery parts.

The characteristics of the detection field and the response time are the same as in stationary installations.

8.8.2 Speed limits

The detection is guaranteed only if the speed of the vehicle or part of the machinery is:

- for detection distance less than or equal to 4 m (13.12 ft), from 0.1 m/s (0.33 ft/s) to 3 m/s (9.84 ft/s)
- for detection distance greater than 4 m (13.12 ft), from 0.1 m/s (0.33 ft/s) to 2 m/s (6.56 ft/s)

Note: only the speed of the vehicle or of the part of machinery is considered. This is based on the assumption that the person recognizes the hazard and stands still.

8.8.3 Detection signal generation conditions

When the sensor is mounted on moving parts, it will detect static objects as moving objects.

The sensor will trigger a detection signal if the following conditions are met:

- The RCS (Radar Cross-Section) of static objects is greater than or equal to the RCS of a human body.
- The relative speed between the objects and the sensor is greater than the minimum speed necessary for detection.

8.8.4 Prevention of unexpected restart

As for stationary installations, when the moving part where the sensor is installed is arrested because of detection, the system will switch to restart prevention safety function (if **Safety working mode** is not **Always-on access detection**), and the sensor will detect the presence of a human body (see "Sensor positioning guidelines" on page 49). Static objects are then automatically filtered out and no longer detected.


The restart of the moving vehicle or moving part of the machinery in the presence of static objects can be prevented using the following methods:

- Static object detection option enabled (see "Restart prevention function: static object detection option" on page 49).
- Anti-masking function: if the function is enabled, an error will occur when the static object will be close enough to limit the detection of the sensor.
Note: if the anti-masking function is active when the sensor is moving also, this could generate false alarms since the environment change during movement could be detected as tampering.
- Manual restart: the restart is triggered externally and only once the static object is removed from the trajectory of the moving vehicle or moving part.
- Application logic on PLC/control unit that permanently stops the moving part if multiple stops occur immediately after the restart of the part. If the vehicle or the part stops very quickly after the restart, this probably means that there is a static obstacle. Once the moving part is stopped, the sensor does not detect the object anymore and therefore the part moves but it stops again as soon as it detects the object again.

8.8.5 Recommendations for positioning the sensor

In mobile applications, the sensor moves with the vehicle or moving machinery parts. Position the sensor so the floor is excluded from its detection field to avoid undesired alarms.

For driverless industrial trucks in indoor environments, it is recommended to use a S203A model sensor and install it so that the center of the sensor is positioned at a height of 15 cm (5.9 in) from the ground, with an inclination of no more than 7° upward.



8.9 Outdoor installations

8.9.1 Position exposed to precipitation

If the sensor installation position might be exposed to precipitation that can cause undesired alarms, it is recommended to take the following precautions:


- Make a cover to protect the sensor from rain, hail or snow.
- Position the sensor so that it does not frame the ground where puddles might form.

NOTICE: Weather conditions outside specifications can prematurely age the device.

8.9.2 Recommendations for covering the sensor

Below are some recommendations for creating and installing a sensor cover:

- height from sensor: 15 cm (6 in)
- width: minimum 30 cm (11.8 in), maximum 40 cm (15.7 in)
- protrusion from the sensor: minimum 15 cm (6 in), maximum 20 cm (7.9 in)
- water outflow: at the sides or behind but not in front of the sensor (the cover should be arched and/or tilted backwards)




8.9.3 Recommendations for positioning the sensor

Below are some recommendations for defining the sensor position:

- installation height (from the ground to the center of the sensor): minimum 15 cm (5.9 in)
- suggested inclination: minimum 15° for S201A model, 10° for S203A model

Before installing a sensor facing downwards, make sure there are neither liquids nor radar reflective materials on the floor.

Note: if the above recommendations are followed and the monitored area is free of static objects, the system is robust against a rainfall rate up to 45 mm/h.



8.9.4 Position not exposed to precipitation

If the installation position of the sensor is not exposed to precipitation, no special precautions are required.

9. Installation and use procedures

Contents

This section includes the following topics:

9.1 Before installation	84
9.2 Install Inxpect SRE 200 Series	84
9.3 Set the sensor inclination with a 1° precision	91
9.4 Configure Inxpect SRE 200 Series	94
9.5 Validate the safety functions	96
9.6 Fieldbus network integration	100
9.7 Manage the configuration	100
9.8 Other procedures	101

9.1 Before installation

9.1.1 Materials required

- Two tamper-proof screws (see "Tamper-proof screws specifications" on page 127) to mount each sensor.
- Cables to connect the control unit to the first sensor and the sensors to one another (see "CAN bus cables recommended specifications" on page 127).
- A data USB cable with a micro-USB connector (micro-B type) or, only if the Ethernet port is available, an Ethernet cable to connect the control unit to the computer.
- A bus terminator (product code: 07000003) with resistance of 120 Ω for the last sensor of the CAN bus.
- A screwdriver for tamper-proof screws (see "Tamper-proof screws specifications" on page 127) to be used with the Hex pin security bit supplied in the control unit package.

9.1.2 Operating system required

- Microsoft Windows 10 or later
- Apple OS X 11.0 or later

9.1.3 Install the Inxpect Safety application

Note: if the installation fails, the dependencies needed by the application may be missing. Update your operating system or contact our Technical Support to receive assistance.

1. Download the application from the <https://tools.inxpect.com> website and install it on the computer.
2. With Microsoft Windows operating system, download and install from the same site also the driver for USB connection.

9.1.4 Initiate Inxpect SRE 200 Series

1. Calculate the position of the sensor (see "Sensor position" on page 62) and the depth of the dangerous area (see "Separation distance calculation" on page 72).
2. "Install Inxpect SRE 200 Series".
3. "Configure Inxpect SRE 200 Series".
4. "Validate the safety functions".

9.2 Install Inxpect SRE 200 Series

9.2.1 Install procedure

1. "Install the control unit".
2. Optional. "Mount 3-axis bracket".
3. "Install the sensors".

4. "Connect the sensors to the control unit".

Note: connect the sensors to the control unit off-site if access to the connectors becomes difficult once installed.

9.2.2 Install the control unit

 **WARNING!** To prevent tampering, make sure the control unit is only accessible to authorized personnel (e.g., key-locked electrical panel)

1. Mount the control unit on the DIN rail.
2. Make electrical connections (see "Terminal blocks and connector pin-outs" on page 128 and "Electrical connections" on page 131).

NOTICE: if at least one input is connected, the SNS input "V+ (SNS)" and the GND input "V- (SNS)" must also be connected.

NOTICE: when powered, the system takes about 20 s to start. During that period, the outputs and the diagnostic functions are deactivated, and the green sensor status LEDs of the connected sensors in the control unit flash.

NOTICE: make sure to avoid any EMC interference during the control unit installation.


Note: to correctly connect the digital inputs, see "Voltage and current limits for digital inputs" on page 129.

9.2.3 Mount 3-axis bracket


Note: for an example of sensor installation, see "Examples of sensor installation" on page 89.

The bracket that allows rotation around the z-axis (roll) is an accessory in the package. To mount it:


1. Unscrew the screw at the bottom and remove the bracket with the sensor and the aligning ring.



2. Attach the roll bracket to the base. Use the tamper-proof screw provided with the bracket.



3. Mount the bracket with the sensor and the aligning ring. Use the tamper-proof screw provided with the bracket.



9.2.4 Install the sensors


Note: for an example of sensor installation, see "Examples of sensor installation" on page 89.

Note: the usage of a thread-locking fluid on the threads of fasteners is suggested, especially when the sensor is installed on a moving or vibrating part of the machinery.

Note: if no bracket is used for sensor installation, use tamper-proof screws and threadlocker.


1. Position the sensor as indicated in the configuration report and fasten the bracket with two tamper-proof screws directly onto the floor or another support.

NOTICE: make sure the support does not inhibit machinery commands.




2. With an Allen key, loosen the screw at the bottom to pan the sensor.

Note: to avoid damaging the bracket, loosen the screw completely before panning the sensor.




3. Pan the sensor until it reaches the desired position.

Note: a notch is equal to a 10° of rotation.




4. Tighten the screw.




9. Installation and use procedures

5. Loosen the tamper-proof screws to tilt the sensor.




6. Tilt the sensor to the desired inclination (see "Sensor position" on page 62).

Note: a notch is equal to a 10° of inclination.
For a finer regulation of the sensor inclination with a 1° precision (see "Set the sensor inclination with a 1° precision" on page 91).





7. Tighten the screws.





9.2.5 Examples of sensor installation

NOTICE: refer to the sensor LED position to identify the sensor field of view (see "Position of the field of view" on page 67).




Floor installation



Wall installation (for example for access control of an entrance).

Note: install the sensor so that the field of view is tilted towards the outside of the hazardous area to avoid false alarms (see "Position of the field of view" on page 67).



Installation on the machinery.


9.2.6 Connect the sensors to the control unit

Note: the total maximum length of the CAN bus line is 80 m (262.5 ft).


Note: when replacing a sensor, in the Inxpect Safety application, click **APPLY CHANGES** to confirm the change.

1. With the cable validator tool (downloadable from the site <https://tools.inxpect.com>), decide if the control unit will be positioned at the end of the chain or inside it (see "Chain examples" below).
2. Set the DIP switch of the control unit based on its position in the chain.
3. Connect the desired sensor directly to the control unit.
4. To connect another sensor, connect it to the last sensor in the chain or directly to the control unit to start a second chain.
5. Repeat step 4 for all the sensors to be installed.
6. Insert the bus terminator (product code: 07000003), into the free connector of the last sensor of the chain(s).

9.2.7 Chain examples



Chain with control unit at the end of the chain and a sensor with bus terminator





Chain with control unit inside the chain and two sensors with bus terminator

9.3 Set the sensor inclination with a 1° precision


9.3.1 Procedure

1. Remove the tamper-proof screws and remove the sensor from the bracket.
2. Remove the internal adjustment ring from the bracket.




9. Installation and use procedures


3. Reinsert the adjustment ring in the bracket holes according to the unit value of the desired inclination degrees (see "How to choose the adjustment ring position" on the next page).




4. Insert the sensor and the tamper-proof screws in the bracket (see "How to insert the sensor" on the next page).



5. Tilt the sensor downward or upward the number of notches corresponding to the tens place value of the desired angle (for example, for an inclination angle of +38°, the tens place value is 3: tilt the sensor upward three notches).




6. Tighten the screws.




9.3.2 How to choose the adjustment ring position

On both sides of the bracket, insert the adjustment ring in the hole corresponding to the desired degree unit value (0-9°).

For example, for 8° (upward), +38° (upward) and -18° (downward) the unit value is always 8°:



Side 1



Side 2


9.3.3 How to insert the sensor

To insert the sensor in the bracket, take into account the following rules:


To tilt the sensor...	...then insert the sensor as follows	See
upward	with the rear of the case facing the desired angle	"Example 1 (upward): +62°" below
downward	with the front of the case facing the desired angle	"Example 2 (downward): -37°" on the next page

Example 1 (upward): +62°

In this example, the rear of the case is facing the following angles: 1°, 2°, 3°, 4°, 5°.




Side 1




Side 2

Example 2 (downward): -37°

In this example, the front of the case is facing the following angles: 5°, 6°, 7°, 8°, 9°.




Side 1




Side 2

9.3.4 Example: set the sensor inclination to +62°

1. Insert the adjustment ring in the hole corresponding to 2°.




Side 1



Side 2

2. Insert the sensor in the bracket with the rear of the sensor facing the 2° angle.



3. Tilt the sensor upward of six notches.

9.4 Configure Inxpect SRE 200 Series

9.4.1 Configure procedure

1. "Start the Inxpect Safety application".
2. "Define the area to be monitored".
3. "Configure the inputs and outputs".
4. "Save and print the configuration".
5. Optional. "Assign the Node IDs".
6. Optional. "Synchronize the control units".

9.4.2 Start the Inxpect Safety application

1. Connect the control unit to the computer using a data USB cable with a micro-USB connector or the Ethernet cable (if an Ethernet port is available).
 2. Supply power to the control unit.
 3. Start the Inxpect Safety application.
 4. Choose the connection mode (USB or Ethernet).
- Note:** the default IP address for the Ethernet connection is 192.168.0.20. The computer and the control unit must be connected to the same network.
5. Set a new admin password, memorize it, and provide it only to authorized people.
 6. Select the system Inxpect SRE 200 Series, the sensor model-type (5 meters range sensors or 9 meters range sensors), and the number of sensors.
 7. Optional. Reset and re-assign all Node IDs.
 8. Set the country in which the system is installed.
- Note:** this setting does not have any effect on system performance or safety. The country selection is requested during the first installation of the system to configure the system's radio profile, which must comply with the national regulations of the installation country.
9. Only if the selected country is **United States** or **Canada**, set the installation type in which the system is installed (**Indoor** or **Outdoor**).
 10. Select the application type:
 - for stationary applications, select **Stationary**.
 - for installation on a machine moving gantry, on a truck on rails, on a crane, select **Mobile**.
 - for both automated guided vehicles and vehicles with driver, select **Vehicle**.
- Note:** the algorithms are optimized to minimize the interference between sensors based on the installation conditions. Even though this choice does not affect the performance and the robustness, it is mandatory to select the correct application type.

9.4.3 Define the area to be monitored

 **WARNING!** The system is disabled during configuration. Prepare opportune safety measures in the dangerous area protected by the system before configuring the system.

1. In the Inxpect Safety application click **Configuration**.
 2. Optional. Add the desired number of sensors in the plane.
 3. Define the position and inclination of each sensor.
-  **WARNING!** Set the values of those parameters accurately because the system behavior is optimized following those values.
4. Choose the area shape (only for 5.x sensors).
 5. Define the safety working mode, detection distance, angular coverage, and restart timeout for each detection field of each sensor.
 6. Optional. Enable the **Static object detection** option for each detection field only if needed. For details, see "Restart prevention function: static object detection option" on page 49.

9.4.4 Configure the inputs and outputs

1. In the Inxpect Safety application, click **Settings**.
2. Click **Digital Input-Output** and define the input and output functions.
3. If the muting is managed, click **Settings** > **Muting** and assign the sensors to the groups according to the logic of the digital inputs.
4. **Settings** > **Restart function** and choose the type of managed restart.
5. Click **APPLY CHANGES** to save the configuration.

9.4.5 Save and print the configuration

1. In the application, click **APPLY CHANGES**: the sensors will save the inclination set and the surrounding environment. The application will transfer the configuration to the control unit, and once transfer is complete it will generate a configuration report.
 2. Click  to save and print the report.
- Note:** to save the PDF, a printer must be installed on the computer.
3. Ask the authorized person for a signature.

9.4.6 Assign the Node IDs

Type of assignment

Note: if the connected sensors do not already have a Node ID assigned (e.g., at first startup), the system automatically assigns them a Node ID during the installation procedure.

Three types of assignment are possible:

- Manual: to assign the Node ID to a sensor at a time. Can be performed with all the sensors already connected or after each connection. Useful for adding a sensor or to change Node ID to a sensor.
- Automatic: to assign the Node IDs to all the sensors at once. To be performed when all the sensors are connected.
- Note:** the control unit assigns the Node ID in ascending order of sensor ID (SID).
- Semi-automatic: wizard for connecting the sensors and assign the Node ID one sensor at a time.

Procedure

- Start the application.
- Click **Configuration** and verify that the number of sensors in the configuration is the same as those installed.
- Click **Settings > Node ID Assignment**.
- Proceed according to the type of assignment:

If the assignment is...	Then...
manual	<ol style="list-style-type: none"> Click DISCOVER CONNECTED SENSORS to display the connected sensors. To assign a Node ID, click Assign for the unassigned Node ID in the Configured sensors list. To change a Node ID, click Change for the already assigned Node ID in the Configured sensors list. Select the SID of the sensor and confirm.
automatic	<ol style="list-style-type: none"> Click DISCOVER CONNECTED SENSORS to display the connected sensors. Click ASSIGN NODE IDS > Automatic: the control unit assigns the Node ID in ascending order of sensor ID (SID).
semi-automatic	Click ASSIGN NODE IDS > Semi-automatic and follow the instructions displayed.

9.4.7 Synchronize the control units

If there is more than one control unit in the area, perform the following steps:

- In the Inspect Safety application, click **Settings > Advanced**.
- In **Multi-control unit synchronization**, assign a different **Control unit channel** to each control unit.

Note: if there are more than four control units, the control units with the same channel must have their monitored areas as far from each other as possible.

9.5 Validate the safety functions

9.5.1 Validation

The validation is addressed to the machinery manufacturer and the system installer.

Once the system has been installed and configured, check that the safety functions are activated/deactivated as expected and that the dangerous area is monitored by the system.

The machinery manufacturer must define all the required tests based on the application conditions and the risk assessment.

 **WARNING! The system response time is not guaranteed during the validation procedure.**

 **WARNING! The Inspect Safety application facilitates the installation and configuration of the system. Nevertheless, the validation process described below is still required to complete the installation.**

9.5.2 Validation procedure for the access detection function

The access detection safety function must be operative, and the following requirements must be fulfilled:

- The target (for stationary applications) or the machinery/vehicle on which the sensor is installed (for mobile applications) must move in compliance with the maximum allowed speed. For details, see "Access detection speed limits" on page 47.
- No objects should completely occlude the target.

Starting conditions

- Machinery switched off (Safe condition)
- Inxpect SRE 200 Series configured to fulfill the access detection safety function
- Detection signals monitored via digital outputs or safety Fieldbus

Test setup

The following tests aim to validate the sensor's performance for the access detection safety function.

In stationary applications, all the tests share these parameters:

Target type	Human
Target speed	In the range [0.1, 1.6] m/s ([0.33, 5.25] ft/s), with particular attention to the minimum and the maximum speeds.
Acceptance criteria	The system reaches the safe state via digital outputs or Fieldbus when the target accesses the area during the test.

In mobile applications, all the tests share these parameters:

Target type	Human
Machinery/Vehicle speed	<ul style="list-style-type: none"> • For detection distance less than or equal to 4 m (13.12 ft): in the range [0.1, 3] m/s ([0.33, 9.84] ft/s), with particular attention to the minimum and the maximum speeds. • For detection distance greater than 4 m (13.12 ft): in the range [0.1, 2] m/s ([0.33, 6.56] ft/s), with particular attention to the minimum and the maximum speeds.
Target movement	Stationary
Acceptance criteria	The system reaches the safe state via digital outputs or Fieldbus when, during the movement of the machinery/vehicle, the sensor's field of view reaches the target.

Validation test

The validation procedure of Inxpect SRE 200 Series is reported below:

1. Identify the test positions, including those locations where the operator could access during the production cycle:
 - a. boundaries of the dangerous area
 - b. intermediate points between sensors
 - c. positions that are partially hidden by existing or presumed obstacles during the operating cycle
 - d. positions indicated by the risk assessor
2. Check that the corresponding detection signal is active or wait for its activation.
3. Perform the test according to the test setup previously defined, moving toward one of the test positions.
4. Check that the test acceptance criteria previously defined are fulfilled. If the test acceptance criteria are not fulfilled, see "Troubleshooting validation" on page 100.
5. Repeat steps 2, 3, and 4 for each test position.

9.5.3 Validation procedure for the restart prevention function

The restart prevention safety function must be operative, and the following requirements must be fulfilled:

- The person must breathe normally.
- No objects should completely occlude the person.

Starting conditions

- Machinery switched off (safe condition)
- Inxpect SRE 200 Series configured to fulfill the restart prevention safety function
- Detection signals monitored via digital outputs or safety Fieldbus

Test setup

The following tests aim to validate the performance of the sensor restart prevention safety function.

All the tests share the following parameters:

Configured radar restart timeout	At least 4 s
Target type	Human according to ISO 7250, breathing normally
Target speed	0 m/s (0 ft/s)
Target pose	Standing or crouching (or other poses if requested by specific risk assessment)
Test duration	At least 20 s
Acceptance criteria	The detection signal remains deactivated during the test. When the operator leaves the area; the detection signal is activated.


Validation test


The validation procedure of the Inxpect SRE 200 Series system is reported below:

1. Identify the test positions, including those locations where the operator should normally be located during the production cycle:
 - boundaries of the dangerous area
 - intermediate points between sensors
 - positions that are partially hidden by already present or presumed obstacles during the operating cycle
 - positions indicated by the risk assessor
2. Access the dangerous area and go to one of the test positions: the corresponding detection signal should be deactivated.
3. Perform the test according to the test setup previously defined.
4. Check that the test acceptance criteria previously defined are fulfilled.
5. If the test acceptance criteria are not fulfilled, see "Validate the system with Inxpect Safety" on the next page.
6. Repeat steps 2, 3, and 4 for each test position.

Example of test positions

The following images show examples of positions to be tested and suggestions about identifying other possible positions of interest.





Position 1: position outside the dangerous area

Position 2: position hidden from the operator's viewpoint at "Position 1". Any other similar hidden position should be tested.

Position 3: position at the center distance between two sensors and/or close to the boundaries of the dangerous area (e.g., along safety fences). This position is suggested to verify that the detection fields of different sensors overlap without leaving uncovered areas. Standing close to the fences also allows for verifying that the sensors are rotated correctly, covering both the right and the left side.

Position 4: possible hidden position by elements in the environment that are present or not present during the validation process. Examples: Obstacle 2 precludes detection by Sensor 1 (**S1**). Obstacle 3 is partially present during the Validation process but will likely be present during the normal operating cycle and will preclude the detection of Sensor 4 (**S4**). This position must be covered by additional Sensor 5 (**S5**) and Sensor 6 (**S6**) that should be added within a proper feasibility study.

Position 5: any raised and walkable position indicated by the risk assessor.

Other positions can be indicated by the risk assessor or the machine manufacturer.

9.5.4 Validate the system with Inxpect Safety

WARNING! When the validation function is active, the system response time is not guaranteed.

The Inxpect Safety application is helpful during the safety functions validation phase and allows the actual field of view of the sensors to be checked based on their installation position.

1. Click **Validation**: the validation starts automatically.
2. Move in the monitored area as indicated in "Validation test" on the previous page and "Validation procedure for the restart prevention function" on page 97.
3. Check that the sensor behaves as expected.
4. Check that the distance and the angle where the motion is detected are the expected values.

9.5.5 Additional checks for safety Fieldbus

- Refer to the relevant documentation to integrate the fieldbus properly, see "Fieldbus network integration" on the next page.
- Check safety Fieldbus connection cables and ensure they function as intended.
- Check the safety Fieldbus settings in the configuration.
- Only for CIP Safety™, before entering the configuration signature into the configuration of the PLC of the machinery: check the configuration of the control unit.
- Only for CIP Safety™, check that the assigned SNN numbers for each safety or safety sub-net are unique system-wide.

9.5.6 Troubleshooting validation

Problem	Cause	Solution
The detection signal does not remain deactivated during the restart prevention test, or it does not deactivate during the access detection test	Presence of objects obstructing the field of view	If possible, remove the object. Otherwise, implement additional safety measures in the area where the object is present (e.g., adding new sensors).
	Position of one or more sensors	Position the sensors to ensure that the monitored area is adequate for the dangerous area (see "Sensor position" on page 62).
	Inclination and/or installation height of one or more sensors	<ol style="list-style-type: none"> 1. Change the sensor's inclination and/or installation height to ensure the monitored area is adequate for the dangerous area (see "Sensor position" on page 62). 2. Note or update the inclination and installation height of the sensors in the printed configuration report.
	Inadequate restart timeout (only with the static object detection option enabled)	Change the Restart timeout parameter through the Inxpect Safety application and verify that it is set to at least 4 seconds for each sensor (Configuration > select the affected sensor and detection field)
After that the operator leaves the area, the detection signal does not activate	Presence of moving objects in the sensor's field of view (including vibrations of metal parts where the sensors are installed or vibration of brackets)	Identify the moving objects/brackets and, if possible, tighten all the loose parts
	Reflections of signals	Change the sensor positions or adjust the detection fields reducing the detection distance

9.6 Fieldbus network integration

9.6.1 Integration procedure

The integration into the Fieldbus network may differ depending on the control unit model and type. Refer to the relevant additional manuals:

- C201A-PNS and C201B-P: PROFIsafe communication Reference guide (Inxpect 100S_200S PROFIsafe RG_7_00067_en)
- C201A-F and C201B-F: FS0E communication Reference guide (Inxpect 100S_200S FS0E RG_7_00237_en)
- C201A-C and C201B-C: CIP Safety communication Reference guide (Inxpect 100S_200S CIP RG_7_00326_en)

9.7 Manage the configuration

9.7.1 Configuration checksums

In the Inxpect Safety application in **Settings > Configuration checksums**, it is possible to consult:

- the configuration report hash, a unique alphanumeric code associated with a report. It is computed considering the entire configuration, plus the time of the **APPLY CHANGES** operation, and the name of the computer which did it
- dynamic configuration checksum, associated with a specific dynamic configuration. It considers both common and dynamic parameters

9.7.2 Configuration reports

After changing the configuration, the system generates a configuration report with the following information:

- configuration data
- unique hash
- date and time of configuration change
- name of the computer used for the configuration

The reports are documents that cannot be changed and can only be printed and signed by the machinery safety manager.

Note: to save the PDF, a printer must be installed on the computer.

9.7.3 Change the configuration

 **WARNING!** The system is disabled during configuration. Prepare opportune safety measures in the dangerous area protected by the system before configuring the system.

1. Start the Inxpect Safety application.
2. Click **User** and enter the admin password.
Note: after five wrong password entries, application authentication is blocked for one minute.
3. Depending on what you want to change, follow the instructions below:

To change...	Then...
Monitored area and sensors configuration	Click Configuration
Node ID	Click Settings > Node ID Assignment
Function of inputs and outputs	Click Settings > Digital Input-Output
Detection field groups configuration	Click Settings > Detection field groups and select the group for each detection field of each connected sensor. Then click Settings > Digital Input-Output and set a digital output as Detection signal group 1 or Detection signal group 2 function
Muting	Click Settings > Muting
Sensor number and positioning	Click Configuration

4. Click **APPLY CHANGES**.
5. Upon conclusion of transfer of the configuration to the control unit, click  to print the report.
Note: to save the PDF, a printer must be installed on the computer.

9.7.4 Display previous configurations

In **Settings**, click **Activity History** and then click **Configuration reports page**: the reports archive opens.

9.8 Other procedures

9.8.1 Change language

1. Click .
2. Select the desired language. The language changes automatically.

9.8.2 Restore factory default settings

 **WARNING!** The system is provided without any valid configuration. Therefore the system maintains the safe state at the first start-up until a valid configuration is applied through the Inxpect Safety application by clicking **APPLY CHANGES**.

 **WARNING!** The procedure resets both the configuration and the password of all the users.

To restore the configuration parameters to the default settings, follow the procedures reported below:


Procedure using the Inxpect Safety application

1. Log in to the Inxpect Safety application as the Admin user.
2. In **Admin > FACTORY RESET**.

Procedure using the reset button on the control unit

1. Press and hold the button **[A]** for longer than 10 seconds: all the system status LEDs **[B]** turn on (steady orange), and the system is ready to be reset.
2. Release the button **[A]**: all the system status LEDs **[B]** turn on (flashing green), and the reset procedure starts. The procedure can last up to 30 seconds. Do not switch off the system during the reset.

Note: if the button is pressed for longer than 30 seconds, the status of the LEDs switches to red, and the reset is not performed even after the button is released.



For the default values of the parameters, see "Configuration application parameters" on page 138.


9.8.3 Reset the control unit Ethernet parameters

1. Ensure the control unit is turned on.
2. Press the Network parameter reset button and hold it down during steps 3 and 4.
3. Wait for five seconds.
4. Wait until all the six LEDs on the control unit turns steady green: the Ethernet parameters are set to their default values (see "Ethernet connection (if available)" on page 125).
5. Configure the control unit again.

9.8.4 Restore network parameters

WARNING! After the restore network parameters procedure, the system goes into the safe state. The configuration must be validated and, if necessary, modified through the Inxpect Safety application by clicking **APPLY CHANGES**.

1. To restore the network parameters to the default settings, press and hold the reset button **[A]** on the control unit for 2 to 5 seconds: the first three system status LEDs **[B]** turn on (steady orange) and the network parameters are ready to be reset.
2. Release the button **[A]**: the reset is performed.



For the default values of the parameters, see "Configuration application parameters" on page 138.

9.8.5 Identify a sensor

In **Settings > Node ID Assignment** or **Configuration**, click **Identify by LED** near the desired sensor Node ID: the LED on the sensor flashes for 5 seconds.

9.8.6 Set network parameters

In **Admin > Network Parameters** set the IP address, the netmask and the gateway of the control unit as desired.

9.8.7 Set MODBUS parameters

In **Admin > MODBUS Parameters**, enable/disable the MODBUS communication and modify the listening port.

9.8.8 Set Fieldbus parameters

In **Admin > Fieldbus Parameters**, depending on the fieldbus interface, set the following parameters:

- for PROFIsafe interface, the F-addresses and the Fieldbus Endianness
- for Safety over EtherCAT® interface, the Safe address
- for CIP Safety™ interface, the network settings, the host name, the SNN and the Fieldbus Endianness

9.8.9 Set system labels

In **Admin > System labels**, choose the desired labels for the control unit and the sensors.

10. Troubleshooting

Machinery maintenance technician

The machinery maintenance technician is a qualified person with the administrator privileges required to modify the configuration of Inxpect SRE 200 Series through the software and perform maintenance and troubleshooting.

Contents

This section includes the following topics:

10.1 Troubleshooting procedures	104
10.2 Event log management	108
10.3 INFO events	112
10.4 ERROR events (control unit)	115
10.5 ERROR events (sensor)	117
10.6 ERROR events (CAN bus)	119

10.1 Troubleshooting procedures

Note: if requested by Technical Support, in **Settings > Activity History**, click **Download sensor debug info** to download the files and forward them to Inxpect for debugging.

10.1.1 Control unit LED

For more details about the LEDs in the control unit, see "Control units" on page 16 and "System status LEDs" on page 20.

LED	Status	Application messages	Problem	Solution
S1*	Steady red	CONTROL UNIT POWER ERROR	At least one voltage value on the control unit is wrong	If at least one digital input is connected, check that the SNS input and the GND input are connected. Check that the input power supply is the specified type (see "General specifications" on page 124).
S1 + S3	Steady red	BACKUP or RESTORE ERROR	Error during the backup and restore to/from microSD card	Check if the microSD card is inserted. Check if the configuration file on the microSD card is present and not corrupted.
S2	Steady red	CONTROL UNIT TEMPERATURE ERROR	Control unit temperature value is wrong	Check that the system is operating at the correct operating temperature (see "General specifications" on page 124).
S3	Steady red	OSSD ERROR or INPUT ERROR	At least one input or output is in error	If at least one input is used, check that both the channels are connected and that there is no short-circuit on the outputs. If the problem persists, please contact Technical Support.

LED	Status	Application messages	Problem	Solution
S4	Steady red	PERIPHERAL ERROR	At least one of the control unit peripherals is in error	Check the status of the terminal block and connections. If the problem persists, please contact Technical Support.
S5	Steady red	CAN ERROR	Communication error with at least one sensor	Check connections of all sensors in the chain starting from the last sensor in error. Check that all the sensors have an assigned ID (in Inxpect Safety Settings > Node ID Assignment). Check that the firmware of the control unit and sensors are updated to the compatible versions.
S6	Steady red	FEE ERROR, FLASH ERROR or RAM ERROR	Configuration saving error, configuration not performed or memory error	Reconfigure or configure the system (see "Manage the configuration" on page 100). If the error persists, please contact Technical Support.
All LEDs from S1 to S6 together	Steady red	FIELDBUS ERROR	Communication error on the Fieldbus	At least one input or output is configured as Fieldbus controlled . Check that the cable is correctly connected, communication with the host is correctly established, watchdog timeout is configured correctly, and exchanged data are not maintained passivated.
All LEDs from S1 to S5 together	Steady red	DYNAMIC CONFIGURATION ERROR	Error in the selection of the dynamic configuration: invalid ID	Check the preset configurations within the Inxpect Safety application.
All LEDs from S1 to S4 together	Steady red	SENSOR CONFIGURATION ERROR	Error during the configuration of the sensors	Check the sensors connected and try again to perform the configuration of the system via the Inxpect Safety application. Check that the firmware of the control unit and sensors are updated to compatible versions.
At least one LED	Flashing red	See "Sensor LED" on the next page	Sensor corresponding to the flashing LED in error ** (see "Sensor LED" on the next page)	Check the problem through the LED on the sensor.
At least one LED	Flashing green	See "Sensor LED" on the next page	Sensor corresponding to the flashing LED in error ** (see "Sensor LED" on the next page)	If the issue persists longer than one minute, please contact Technical Support.
All LEDs	Steady orange	-	The system is starting up.	Wait for a few seconds.

LED	Status	Application messages	Problem	Solution
All LEDs	Flashing green one after the other in sequence	-	The control unit is in boot state.	Open the latest available version of the Inxpect Safety application, connect to the device and proceed with the automatic recovery procedure. If the issue persists, please contact Technical Support.
All LEDs	Off	In Dashboard > System status  icons	Configuration not yet applied to the control unit.	Configure the system.
All LEDs	Off	Progress icon	Configuration transfer to the control unit in progress.	Wait for the transfer to be completed.

Note: fault signal on the control unit (steady LED) takes priority over a faulty sensor signal. For the status of the single sensor, check the sensor LED.

Note*: S1 is the first from the top.

Note:** S1 corresponds to the sensor with ID 1, S2 corresponds to the sensor with ID 2 and so on.

10.1.2 Sensor LED

Status	Application messages	Problem	Solution
Steady purple	-	Sensor in boot state	Contact Technical Support.
Flashing purple *	-	Sensor receiving a firmware update	Wait for the update to be completed without disconnecting the sensor.
Flashing red. Two flashes followed by a pause **	CAN ERROR	Sensor without a valid identifier assigned	Assign a Node ID to the sensor (see "Connect the sensors to the control unit" on page 90).
Flashing red. Three flashes followed by a pause **	CAN ERROR	Sensor does not receive valid messages from the control unit	Verify the connection of all the sensors in the chain and check that the number of sensors configured in the Inxpect Safety application is equal to the number of the sensors physically connected
Flashing red. Four flashes followed by a pause **	SENSOR TEMPERATURE ERROR or SENSOR POWER ERROR	Sensor in temperature error or is receiving an incorrect supply voltage	Check the sensor connection and that the cable length is within the maximum limits. Verify that the temperature of the environment in which the system is operating conforms to the operating temperatures listed in the technical data in this manual.

Status	Application messages	Problem	Solution
Flashing red. Five flashes followed by a pause **	MASKING, SIGNAL PATTERN ERROR ***	Sensor detected a masking (tampering) or there are radar signal errors	Not available if the sensor is in muting. Check that the sensor is installed correctly and that the area is clear of objects that obstruct the sensor's field of view.
	MASKING REFERENCE MISSING	Sensor is not able to save the monitored area reference for occlusion	Repeat the system configuration making sure no movement is present inside the monitored area
	MSS ERROR/DSS ERROR	Error detected by diagnostics relative to the internal micro-controllers (MSS and DSS), their internal peripherals or memories	If the issue persists, please contact Technical Support.
Flashing red. Six flashes followed by a pause **	TAMPER ERROR	Sensor detected a variation in rotation around the axes (tampering)	Not available if the sensor is in muting. Check if the sensor has been tampered with or if the side or mounting screws have loosened.

Note *: flashes at 100 ms intervals without pause

Note **: flashes at 200 ms intervals and then with a 2 s pause.

Note*:** the detection signal overrides the masking signal if they are present at the same time. Only for S202A sensors, the masking signal overrides the detection signal.

10.1.3 Other problems

Problem	Cause	Solution
Undesired detections	Transit of people or objects in close proximity to the detection field	Change the configuration (see "Change the configuration" on page 101).
Machinery in safe status without motion in the detection field	No power supply	Check electrical connection. Contact Technical Support if necessary.
	Failure of the control unit or one or more sensors	Check the status of the LEDs on the control unit (see "Control unit LED" on page 104). Access the Inxpect Safety application, on the Dashboard page, mouse-over on  in correspondence with the control unit or the sensor.
The voltage value detected on the SNS input is zero	The chip that detects inputs is faulty	Contact Technical Support.
The system does not function correctly	Control unit error	Check the status of the LEDs on the control unit (see "Control unit LED" on page 104). Access the Inxpect Safety application, on the Dashboard page, mouse-over on  in correspondence with the control unit or the sensor.
	Sensor error	Check the status of the LEDs on the sensor (see "Sensor LED" on the previous page). Access the Inxpect Safety application, on the Dashboard page, mouse-over on  in correspondence with the control unit or the sensor.

10.2 Event log management

10.2.1 Introduction

The event log recorded by the system can be downloaded from the Inxpect Safety application in a PDF file. The system saves up to 4500 events, divided in two sections. In each section the events are displayed from the most recent to the least recent. Above this limit, the oldest events are overwritten.

10.2.2 Download the system log

 **WARNING! The system response time is not guaranteed while downloading the log file.**

1. Start the Inxpect Safety application.
2. Click **Settings** and then **Activity History**.
3. Click **DOWNLOAD LOG**.

Note: to save the PDF, a printer must be installed on the computer.

10.2.3 Log file sections

The first line of the file reports the NID (Network ID) of the device and the date of the download.

The rest of the file log is divided in two sections:

Section	Description	Content	Size	Reset
1	Event log	Information events	3500	At every firmware update or on demand using the Inxpect Safety application
		Error events		
2	Diagnostic event log	Error events	1000	Not possible

10.2.4 Log line structure

Each line in the log file reports the following information, separated by tab character:

- Timestamp (seconds counter from the latest boot)
- Timestamp (absolute/relative value)
- Event type:
 - [ERROR] = diagnostic event
 - [INFO] = information event
- Source
 - CONTROL UNIT = if the event is generated by the control unit
 - SENSOR ID = if the event is generated by a sensor. In this case, the Node ID of the sensor is also provided
- Event description

10.2.5 Timestamp (seconds counter from the latest boot)

An indication of the instant when the event occurred is provided as relative time from the latest boot, in seconds.

Example: 92

Meaning: the event occurred 92 seconds after the latest boot

10.2.6 Timestamp (absolute/relative value)

An indication of the instant when the event occurred is provided.

- After a new system configuration, it is provided as absolute time.

Format: YYYY/MM/DD hh:mm:ss

Example: 2020/06/05 23:53:44

- After a reboot of the device, it is provided as relative time from the latest boot.

Format: Rel. x d hh:mm:ss

Example: Rel. 0 d 00:01:32

Note: when a new system configuration is performed, even the older timestamps are updated in absolute time format.

Note: during system configuration, the control unit is receiving the local time of the machine where the software is running.

10.2.7 Event description

A complete description of the event is reported. Whenever possible, depending on the event, additional parameters are reported.

In case of a diagnostic event, an internal error code is also added, useful for the purpose of debug. If the diagnostic event disappears, the label “(Disappearing)” is reported as an additional parameter.

Examples

Detection access (field #3, 1300 mm/40°)

System configuration #15

CAN ERROR (Code: 0x0010) COMMUNICATION LOST

CAN ERROR (Disappearing)

10.2.8 Log file example

Event logs of ISC NID UP304 updated 2020/11/18 16:59:56

[Section 1 - Event logs]

```

380 2020/11/18 16:53:49 [ERROR] SENSOR#1 CAN ERROR (Disappearing)
375 2020/11/18 16:53:44 [ERROR] SENSOR#1 CAN ERROR (Code: 0x0010) COMMUNICATION LOST
356 2020/11/18 16:53:25 [INFO] CONTROL UNIT System configuration #16
30 2020/11/18 16:53:52 [ERROR] SENSOR#1 ACCELEROMETER ERROR (Disappearing)
27 2020/11/18 16:47:56 [ERROR] SENSOR#1 ACCELEROMETER ERROR (Code: 0x0010) TILT ANGLE ERROR
5 2020/11/18 16:47:30 [ERROR] SENSOR#1 SIGNAL ERROR (Code: 0x0012) MASKING
0 2020/11/18 16:47:25 [INFO] CONTROL UNIT Dynamic configuration #1
0 2020/11/18 16:47:25 [INFO] CONTROL UNIT System Boot #60
92 Rel. 0 d 00:01:32 [INFO] CONTROL UNIT Detection exit (field #2)
90 Rel. 0 d 00:01:30 [INFO] CONTROL UNIT Detection exit (field #1)
70 Rel. 0 d 00:01:10 [INFO] SENSOR#1 Detection access (field #2, 3100 mm/20°)
61 Rel. 0 d 00:01:01 [INFO] SENSOR#1 Detection access (field #1, 1200 mm/30°)
0 Rel. 0 d 00:00:00 [INFO] CONTROL UNIT Dynamic configuration #1
0 0 d 00:00:00 [INFO] CONTROL UNIT System Boot #61

```

[Section 2 - Diagnostic events log]

```

380 Rel. 0 d 00:06:20 [ERROR] SENSOR #1 CAN ERROR (Disappearing)
375 Rel. 0 d 00:06:15 [ERROR] SENSOR #1 CAN ERROR (Code: 0x0010) COMMUNICATION LOST
356 Rel. 0 d 00:05:56 [INFO] CONTROL UNIT System configuration #16
30 Rel. 0 d 00:00:30 [ERROR] SENSOR #1 ACCELEROMETER ERROR (Disappearing)
27 Rel. 0 d 00:00:27 [ERROR] SENSOR #1 ACCELEROMETER ERROR (Code: 0x0012) TILT ANGLE ERROR
5 Rel. 0 d 00:00:05 [ERROR] SENSOR #1 SIGNAL ERROR (Code: 0x0014) MASKING

```

10.2.9 Event list

The event logs are listed below:

Event	Type
Diagnostic errors	ERROR
System Boot	INFO
System configuration	INFO
Factory reset	INFO
Stop signal	INFO
Restart signal	INFO
Detection access	INFO
Detection exit	INFO
Dynamic configuration in use	INFO
Muting status	INFO
Fieldbus connection	INFO

Event	Type
MODBUS connection	INFO
Session authentication	INFO
Validation	INFO
Log download	INFO
Teach-In	INFO

For further information about the events, see "INFO events" on the next page and "ERROR events (control unit)" on page 115.

10.2.10 Verbosity level

There are six verbosity levels for the log. The verbosity can be set during the configuration of the system via the Inxpect Safety application (**Settings > Activity History > Log verbosity level**).

Depending on the selected verbosity level, the events are logged in accordance to the following table:

Event	Level 0 (default)	Level 1	Level 2	Level 3	Level 4	Level 5
Diagnostic errors	x	x	x	x	x	x
System Boot	x	x	x	x	x	x
System configuration	x	x	x	x	x	x
Factory reset	x	x	x	x	x	x
Stop signal	x	x	x	x	x	x
Restart signal	x	x	x	x	x	x
Teach-In	x	x	x	x	x	x
Detection access	-	See "Verbosity level for detection access and exit events" below				
Detection exit	-	See "Verbosity level for detection access and exit events" below				
Dynamic configuration in use	-	-	-	-	x	x
Muting status	-	-	-	-	-	x

10.2.11 Verbosity level for detection access and exit events

Depending on the selected verbosity level, the detection access and exit events are logged as follows:

- LEVEL 0: no detection info is logged
- LEVEL 1: the events are logged at the control unit level, and the additional information is the detection distance (in mm) and the detection angle (in °)* in detection access

Format:

CONTROL UNIT Detection access (distance mm/azimuth°)

CONTROL UNIT Detection exit

- LEVEL 2: the events are logged in a single field at the control unit level, and the additional information is: detection field, detection distance (in mm) and detection angle (in °)* in access, and detection field at exit

Format:

CONTROL UNIT Detection access (field #n, distance mm/azimuth°)

CONTROL UNIT Detection exit (field #n)

- LEVEL 3 / LEVEL 4 / LEVEL 5 The events are logged:

- in a single field at the control unit level, and the additional information is: detection field, detection distance (in mm) and detection angle (in °)* in access, and detection field at exit
- at the sensor level and the additional information read by the sensor is: detection distance (in mm) and detection angle (in °)* in access, and detection field at exit

Format:

CONTROL UNIT #k Detection access (field #n, distance mm/azimuth°)

SENSOR #k Detection access (distance mm/azimuth°)

CONTROL UNIT Detection exit (field #n)

SENSOR #k Detection exit

Note*: see "Target position angle conventions" on page 129.

10.3 INFO events

10.3.1 System Boot

Every time the system is powered up, the event is logged reporting the incremental count of the boot from the beginning of the life of the device.

Format: *System Boot #n*

Example:

```
0 2020/11/18 16:47:25 [INFO] CONTROL UNIT SYSTEM BOOT #60
```

10.3.2 System configuration

Every time the system is configured, the event is logged reporting the incremental count of the configuration from the beginning of the life of the device.

Format: *System configuration #3*

Example:

```
20 2020/11/18 16:47:25 [INFO] CONTROL UNIT System configuration #3
```

10.3.3 Factory reset

Every time a factory reset is required, the event is logged.

Format: *Factory reset*

Example:

```
20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Factory reset
```

10.3.4 Stop signal

If configured, every change of the Stop Signal is logged as ACTIVATION or DEACTIVATION.

Format: *Stop signal ACTIVATION/DEACTIVATION*

Example:

```
20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Stop signal ACTIVATION
```

10.3.5 Restart signal

If configured, every time the system is waiting for the restart signal or the restart signal is received, the event is logged as WAITING or RECEIVED.

Format: *Restart signal WAITING/RECEIVED*

Example:

```
20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Restart signal RECEIVED
```

10.3.6 Detection access

Every time motion is detected, a detection access is logged with additional parameters depending on the selected verbosity level: the detection field number, the sensor which detected the motion, the detection distance (in mm) and the detection angle (°)* (see "Verbosity level for detection access and exit events" on page 111).

Format: *Detection access (field #n, distance mm/azimuth°)*

Note*: see "Target position angle conventions" on page 129.

Example:

20 2020/11/18 16:47:25 [INFO] SENSOR #1 Detection access (field #1, 1200 mm/30°)

10.3.7 Detection exit

After at least one detection access event, a detection exit event related to the same field is logged when the detection signal returns to its default no-motion status.

Depending on the selected verbosity level additional parameters are logged: the detection field number, the sensor which detected the motion.

Format: *Detection exit (field #n)*

Example:

20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Detection exit (field #1)

10.3.8 Dynamic configuration in use

At every change of the dynamic configuration, the new ID of the dynamic configuration selected is logged.

Format: *Dynamic configuration #1*

Example:

20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Dynamic configuration #1

10.3.9 Muting status

Every change of the muting status of each sensor is logged as disabled or enabled.

Note: the event indicates a change of the muting status of the system. It does not correspond to the muting request.

Format: *Muting disabled/enabled*

Example:

20 2020/11/18 16:47:25 [INFO] SENSOR#1 Muting enabled

10.3.10 Fieldbus connection

The Fieldbus communication status is logged as CONNECTED, DISCONNECTED or FAULT.

Format: *Fieldbus connection CONNECTED/DISCONNECTED/FAULT*

Example:

20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Fieldbus connection CONNECTED

10.3.11 MODBUS connection

The MODBUS communication status is logged as CONNECTED or DISCONNECTED.

Format: *MODBUS connection CONNECTED/DISCONNECTED*

Example:

20 2020/11/18 16:47:25 [INFO] CONTROL UNIT MODBUS connection CONNECTED

10.3.12 Session authentication

The status of the session authentication and the interface used (USB/ETH) are logged.

Format: *Session OPEN/CLOSE/WRONG PASSWORD/UNSET PASSWORD/TIMEOUT/CHANGE PASSWORD via USB/ETH*

Example:

```
20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Session OPEN via USB
```

10.3.13 Validation

Every time a validation activity starts or ends on the device, it is logged. The interface used (USB/ETH) is logged as well.

Format: *Validation STARTED/ENDED via USB/ETH*

Example:

```
20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Validation STARTED via USB
```

10.3.14 Log download

Every time a log download is performed on the device, it is logged. The interface used (USB/ETH) is logged as well.

Format: *Log download via USB/ETH*

Example:

```
20 2020/11/18 16:47:25 [INFO] CONTROL UNIT Log download via USB
```

10.3.15 Teach-In function

Every time the teach-in function is used, a few events are logged.

Format: *Teach-In REQUESTED*

Example:

```
286 2024/03/07 17:03:15 [INFO] CONTROL UNIT Teach-In REQUESTED
```

Format: *Teach-in READ DISTANCE(dm) n*

Example:

```
217 2024/03/07 17:03:18 [INFO] SENSOR#1 Teach-in READ DISTANCE(dm) 19
```

```
218 2024/03/07 17:03:18 [INFO] SENSOR#2 Teach-in READ DISTANCE(dm) 23
```

Format: *Teach-in WAITING FOR VALIDATION n*

Example:

```
228 2024/03/07 17:03:20 [INFO] CONTROL UNIT Teach-in WAITING FOR VALIDATION
```

Format: *Teach-in VALIDATED n*

Example:

```
232 2024/03/07 17:03:23 [INFO] CONTROL UNIT Teach-in VALIDATED
```

Format: *Teach-in SET DISTANCE(dm) n*

Example:

```
234 2024/03/07 17:02:23 [INFO] SENSOR#1 Teach-in SET DISTANCE(dm) 17
234 2024/03/07 17:02:23 [INFO] SENSOR#2 Teach-in SET DISTANCE(dm) 21
```

Format: *Teach-in EXCEPTION message (see "EXCEPTION messages" below)*

Example:

```
104 2024/03/07 16:46:12 [INFO] Teach-in EXCEPTION Sensor #1 detection under min
```

10.3.16 EXCEPTION messages

- System fault
- System configuration
- No teach-in sensor available
- Sensor #n detection under min
- Generic fault (Code: xxx)

10.4 ERROR events (control unit)

10.4.1 Introduction

A diagnostic error is logged every time the periodic diagnostic functions detect a coming or going fault on the control unit.

10.4.2 Temperature errors (TEMPERATURE ERROR)

Error	Meaning
BOARD TEMPERATURE TOO LOW	Board temperature below minimum
BOARD TEMPERATURE TOO HIGH	Board temperature above maximum

10.4.3 Control unit voltage errors (POWER ERROR)

Error	Meaning
Control unit voltage UNDERVOLTAGE	Undervoltage error for the indicated voltage
Control unit voltage OVERVOLTAGE	Ovvoltage error for the indicated voltage
ADC CONVERSION ERROR	ADC conversion error in the micro-controller

The following table describes the control unit voltage:

Screen printing	Description
VIN	Power supply voltage (+24 V DC)
V12	Internal supply voltage
V12 sensors	Sensors power supply voltage
VUSB	USB port voltage
VREF	Inputs reference voltage (VSNS Error)
ADC	Analog-digital converter

10.4.4 Peripheral error (PERIPHERAL ERROR)

Error detected by diagnostics relative to the micro-controller, its internal peripherals or memories.

10.4.5 Configuration errors (FEE ERROR)

Indicates that the system must still be configured. This message can appear when the system is first turned on or after reset to default values. It can also represent another error on the FEE (internal memory).

10.4.6 Output errors (OSSD ERROR)

Error	Meaning
OSSD 1 SHORT-CIRCUIT	Short-circuit error on MOS output 1
OSSD 2 SHORT-CIRCUIT	Short-circuit error on MOS output 2
OSSD 3 SHORT-CIRCUIT	Short-circuit error on MOS output 3
OSSD 4 SHORT-CIRCUIT	Short-circuit error on MOS output 4
OSSD 1 NO LOAD	No load on OSSD 1
OSSD 2 NO LOAD	No load on OSSD 2
OSSD 3 NO LOAD	No load on OSSD 3
OSSD 4 NO LOAD	No load on OSSD 4

10.4.7 Flash errors (FLASH ERROR)

A flash error represents an error on the external flash.

10.4.8 Dynamic configuration error (DYNAMIC CONFIGURATION ERROR)

A dynamic configuration error indicates an invalid dynamic configuration ID.

10.4.9 Internal communication error (INTERNAL COMMUNICATION ERROR)

Indicates that there is an internal communication error.

10.4.10 Input error (INPUT ERROR)

Error	Meaning
INPUT 1 REDUNDANCY	Error in the redundancy on Input 1
INPUT 2 REDUNDANCY	Error in the redundancy on Input 2
ENCODING	Invalid encoding when the encoded channel option is enabled
PLAUSIBILITY	0->1->0 transition not compliant with input functionality specification

10.4.11 Fieldbus error (FIELDBUS ERROR)

At least one of the inputs and outputs has been configured as **Fieldbus controlled**, but the Fieldbus communication is not established or not valid.

Error	Meaning
NOT VALID COMMUNICATION	Error on the Fieldbus

10.4.12 RAM error (RAM ERROR)

Error	Meaning
INTEGRITY ERROR	Wrong integrity check on the RAM

10.4.13 SD Backup or restore error (SD BACKUP OR RESTORE ERROR)

Error	Meaning
GENERIC FAIL	Unknown fault
TIMEOUT	Writing and reading internal operation timeout

Error	Meaning
NO_SD	microSD not present
WRITE OPERATION FAILED	Writing error on the microSD card
CHECK OPERATION FAILED	File corrupted or no file during restore from microSD card

10.4.14 Sensor configuration errors (SENSOR CONFIGURATION ERROR)

Error occurred on the sensors during the configuration process or at the system power up. At least one of the connected sensors did not get the correct configuration.

As details, the list of sensors not configured is reported.

10.5 ERROR events (sensor)

10.5.1 Introduction

A diagnostic error is logged every time the periodic diagnostic functions detect a coming or going fault on the sensor.

 **WARNING! No sensor errors are available if the sensor is in muting.**

Note: if requested by Technical Support, in **Settings > Activity History**, click **Download sensor debug info** to download the files and forward them to Inxpect for debugging.

10.5.2 Sensor configuration error (SENSOR CONFIGURATION ERROR)

Error occurred on the sensors during the configuration process or at the system power up. At least one of the connected sensors is not correctly configured.

The list of sensor configuration errors is the following:

Error	Meaning
UNKNOWN MODEL-TYPE	Unknown model-type
WRONG MODEL-TYPE	Model-type different from the one set during system configuration
RADIO BANDWIDTH n.a.	Selected radio bandwidth not supported
STATIC OBJECT DETECTION n.a.	Static object detection not supported
CUSTOM TARGET DETECTION n.a.	Custom target detection not supported
ADVANCED FOV n.a.	Advanced field of view not supported
ANTI-MASKING REF	Error occurred during the anti-masking reference grabbing
ANTI-ROTATION REF	Error occurred during the anti-rotation around axes reference grabbing
TIMEOUT	Timeout error occurred during the system recondition
ASSIGN NODE ID ERROR	Error occurred during the Node ID setting of the system recondition
SEQUENCE, STREAM SEQUENCE, STREAM END, STREAM CRC	Sequence error occurred during the sensor configuration
MISSING SENSORS	Too many sensors are missing during the system recondition

10.5.3 Misconfiguration error (MISCONFIGURATION ERROR)

The misconfiguration error occurs when the sensor does not have a valid configuration or it has received an invalid configuration from the control unit.

10.5.4 Status error and fault (STATUS ERROR/FAULT ERROR)

The status error occurs when the sensor is in an internal invalid status or it has reached an internal fault condition.

10.5.5 Protocol error (PROTOCOL ERROR)

The protocol error occurs when the sensor receives commands with an unknown format.

10.5.6 Sensor voltage errors (POWER ERROR)

Error	Meaning
Sensor voltage UNDERVOLTAGE	Undervoltage error for the indicated voltage
Sensor voltage OVERVOLTAGE	Ovvoltage error for the indicated voltage

The following table describes the sensor voltage:

Screen printing	Description
VIN	Power supply voltage (+12 V DC)
V3.3	Internal chip power supply voltage
V1.2	Micro-controller power supply voltage
V1.8	Internal chip power supply voltage (1.8 V)
V1	Internal chip power supply voltage (1 V)

10.5.7 Anti-tampering sensor (TAMPER ERROR)

Error	Meaning
TILT ANGLE ERROR	Sensor rotation around the x-axis
ROLL ANGLE ERROR	Sensor rotation around the z-axis
PAN ANGLE ERROR	Sensor rotation around the y-axis

Note: the information of the angle (in degrees) is reported.

10.5.8 Signal error (SIGNAL ERROR)

The signal error occurs when the sensor detected an error in the RF signals part, in particular:

Error	Meaning
MASKING	The sensor is obstructed
MASKING REFERENCE MISSING	During the configuration process, it was not possible to get the masking reference
SIGNAL PATTERN ERROR	Radar internal fault or unexpected signal pattern

10.5.9 Temperature errors (TEMPERATURE ERROR)

Error	Meaning
BOARD TEMPERATURE TOO LOW	Board temperature below minimum
BOARD TEMPERATURE TOO HIGH	Board temperature above maximum
CHIP TEMPERATURE TOO LOW	Internal chip below minimum
CHIP TEMPERATURE TOO HIGH	Internal chip above maximum
IMU TEMPERATURE TOO LOW	IMU below minimum
IMU TEMPERATURE TOO HIGH	IMU above maximum

10.5.10 MSS error and DSS error (MSS ERROR/DSS ERROR)

Error detected by diagnostics relative to the internal micro-controllers (MSS and DSS), their internal peripherals or memories

10.6 ERROR events (CAN bus)

10.6.1 Introduction

A diagnostic error is logged every time the periodic diagnostic functions detect a coming or going fault on the CAN bus communication.

Depending on the communication bus side, the logged source can be the control unit or a single sensor.

10.6.2 CAN errors (CAN ERROR)

Error	Meaning
TIMEOUT	Timeout on message to sensor/control unit
CROSS CHECK	Two redundant messages do not coincide
SEQUENCE NUMBER	Message with sequence number different from the expected number
CRC CHECK	Packet control code does not match
COMMUNICATION LOST	Impossible to communicate with the sensor
PROTOCOL ERROR	Control unit and sensors have different and incompatible firmware versions
POLLING TIMEOUT	Timeout on data polling

NOTICE: A shielded cable between the control unit and the first sensor, and between the sensors is strongly recommended. Nevertheless, route the CAN cables separately from high-potential power lines or through an exclusive conduit.

11. Maintenance

Contents

This section includes the following topics:

11.1 Planned maintenance	120
11.2 Extraordinary maintenance	120

11.1 Planned maintenance

Generic maintenance technician

The generic maintenance technician is a person qualified only to perform basic maintenance without the administrator privileges required to modify the configuration of Inxpect SRE 200 Series through the application.

11.1.1 Cleaning

Keep the sensor clean and free of any work residues and conductive material to prevent masking and/or poor system operation.

11.1.2 Spare parts

See Inxpect SRE 200 Series Spare Parts document.

11.2 Extraordinary maintenance

11.2.1 Machinery maintenance technician

The machinery maintenance technician is a qualified person with the administrator privileges required to modify the configuration of Inxpect SRE 200 Series through the Inxpect Safety application and perform maintenance and troubleshooting.

11.2.2 Control unit firmware update

1. Download the latest Inxpect Safety application version from the <https://tools.inxpect.com> website and install it on your computer.
2. Connect to the control unit via Ethernet and log in as Admin user.
Note: update via USB is available only for C203A and C203B.
3. In **Settings > General**, check if a new update is available.
4. Update without disconnecting from or turning off the device.

11.2.3 Replace a sensor: System recondition function

The system recondition function is useful for replacing an existing sensor without changing current settings. The function can be enabled through digital inputs (**System recondition** or **Restart signal + System recondition**) or via Fieldbus (**System recondition** only).

 **WARNING! If the system recondition function has been configured through the safety Fieldbus and the digital inputs, the function can be used from both.**

Note: keep the scene static while running the system recondition function so that the anti-tampering functions can save their references.

Note: while running the system recondition function, the system goes to the safe state, deactivating the OSSDs, until the process is completed.

1. Configure the digital inputs or Fieldbus to perform the system recondition function.
2. Connect a sensor without Node ID in the same position of the CAN bus line as the replaced sensor.

Note: only one sensor at a time must be connected to complete the procedure correctly.

3. Activate the function (via digital inputs or Fieldbus) and wait for the operation to be performed. See "Control unit LED" on page 104 to know which is the system status.

The following actions are performed:

- The first available Node ID is assigned to the new sensor.
- The previous configuration of the system is applied (**APPLY CHANGES** operation). The operation is saved in the event log as a standard **System configuration** event.
- The event is logged in the reports archive (**Settings > Activity History > Configuration reports page**) with the following strings in the **User, PC** column:
 - "sys-recondition-i" when the function is performed via digital input
 - "sys-recondition-f" when Fieldbus is used

Note: for more details, see "Digital input signals" on page 143.

11.2.4 Back up the configuration to a PC

The current configuration can be backed up, including the input/output settings. The configuration is saved in a .cfg file, which can be used to restore the configuration or to facilitate configuration of several Inxpect SRE 200 Series.

1. In **Settings > General**, click **BACKUP**.
2. Select the file destination and save.

Note: user login credentials are not saved using this backup mode.

11.2.5 Back up the configuration to a microSD card

If the control unit is provided with a microSD slot, a backup file of the system settings, and (optionally) the login credentials of all the users, can be stored on the microSD card. The SD Backup function can be enabled/disabled through the Inxpect Safety application, as well as the backup of the login credentials of all the users. By default, both options are disabled.

1. To enable the SD Backup function, in **Admin > SD Card** select **Automatic backup creation**.
 2. To enable the saving of all users' login credentials, select **Users data included**.
 3. To perform the backup, insert a microSD card into the control unit memory card slot.
- Note:** the microSD card is not supplied with the control unit. For details about the microSD card specifications, see "microSD card specifications" on the next page
4. In the Inxpect Safety application, click **APPLY CHANGES**: the backup is automatically performed.

11.2.6 Load a configuration from a PC

1. In **Settings > General**, click **RESTORE**.
2. Select the previously saved .cfg file (see "Back up the configuration to a PC" above) and open it.

Note: a re-imported configuration requires new downloading onto the control unit and approval according to the safety plan.

11.2.7 Load a configuration from a microSD card

If the control unit is provided with a microSD slot, the administrator can restore both the system settings and (if any) the login credentials of all the users. This requires a valid backup file saved on a microSD. The SD Restore function can be enabled/disabled through the Inxpect Safety application. By default the option is enabled.

Note: this SD Restore function also includes a System recondition operation, see "Replace a sensor: System recondition function" on the previous page.

1. To perform the restore, insert the microSD card with the saved configuration into the memory card slot of the new control unit.
- Note:** the microSD card is not supplied with the control unit. For details about the microSD card specifications, see "microSD card specifications" on the next page
2. Press the SD Restore button on the control unit for at least 5 seconds: the system status LEDs turn off and, when the reset is performed, the LEDs return to the previous state.

Note: to disable the SD Restore function, in **Admin > SD Card** deselect **Enable restore by button**

The following actions are performed:

- The system configuration is applied (**APPLY CHANGES** operation).
- The event is logged in the reports archive (**Settings > Activity History > Configuration reports page**) with the string **Restore-via-sdcard**.

11.2.8 microSD card specifications

Type	microSD
File system	FAT32
Recommended capacity	32 GB or less

12. Technical references

Contents

This section includes the following topics:

12.1 Technical data	124
12.2 Terminal blocks and connector pin-outs	128
12.3 Target position angle conventions	129
12.4 Electrical connections	131
12.5 Configuration application parameters	138
12.6 Digital input signals	143

12.1 Technical data

12.1.1 General specifications

Detection method	Inxpect motion detection algorithm based on FMCW radar
Frequency	<p>Working band:</p> <ul style="list-style-type: none"> for S201A model: 60.6-62.8 GHz for S202A model: 60.7-62.9 GHz for S203A model: 61.2-63.4 GHz <p>Maximum radiated power: see National configuration addendum</p> <p>Modulation: FMCW</p>
Detection interval	From 0 to 5 m (from 0 to 16.4 ft)
Detectable target RCS (Human detection)	0.17 m ²
Field of view	<p>Horizontal angular coverage:</p> <ul style="list-style-type: none"> S201A and S203A models: programmable from 10° to 100° S202A model: programmable from 20° to 100° <p>Vertical angular coverage:</p> <ul style="list-style-type: none"> S201A model: 20° S202A model: programmable from 30° to 90° S203A model: 12°
Decision probability	> 1-(2.5E-07)
CRT (Certified Restart Timeout)	4 s
Guaranteed response time	<p>Access detection: < 100 ms *</p> <p>Restart prevention: 4000 ms</p> <p>WARNING! During the real-time validation and the download of the log file, the response time is not guaranteed.</p>
Total consumption	Max. 26.5 W (control unit and sensors)
Electrical protections	<p>Polarity inversion</p> <p>Overcurrent through resettable integrated fuse (max. 5 s @ 8 A)</p>
Overvoltage category	II
Altitude	Max. 1500 m ASL
Air humidity	Max. 95%
Noise emission	Negligible**

Note*: the value depends on the Electromagnetic robustness level set through the Inxpect Safety application, see "Electromagnetic Robustness" on page 61.

Note:** the A-weighted emission sound pressure level does not exceed 70 dB(A).

12.1.2 Safety parameters

SIL (Safety Integrity Level)	2
HFT	0
SC*	2
TYPE	B
PL (Performance Level)	d
ESPE Type (EN 61496-1)	3
Category (EN ISO 13849)	3 equivalent
Class (IEC TS 62998-1)	D
Communication protocol (sensors-control unit)	CAN complies with standard EN 50325-5
Mission time	20 years
MTTF_D	42 years
PFH_D	<p>With Fieldbus communication:</p> <ul style="list-style-type: none"> Access detection: 1.40E-08 [1/h] Restart prevention: 1.40E-08 [1/h] Muting: 6.37E-09 [1/h] Stop signal: 6.45E-09 [1/h] Restart signal: 6.45E-09 [1/h] Dynamic Configuration Switch: 6.37E-09 [1/h] Fieldbus controlled: 6.45E-09 [1/h] <p>Without Fieldbus communication:</p> <ul style="list-style-type: none"> Access detection: 1.30E-08 [1/h] Restart prevention: 1.30E-08 [1/h] Muting: 5.37E-09 [1/h] Stop signal: 5.45E-09 [1/h] Restart signal: 5.45E-09 [1/h] Dynamic Configuration Switch: 5.37E-09 [1/h] Fieldbus controlled: 5.45E-09 [1/h]
SFF	≥ 99.89%
DCavg	≥ 99.46%
MRT**	< 10 min
Safe state when a fault occurs	At least one channel for each safety output is in OFF-state. Stop message sent on Fieldbus (if available) or communication interrupted

Note*: the systematic capability is guaranteed only if the user uses the product according to the instructions of this manual and uses the product in the appropriate environment.

Note:** the MRT considered is the Technical Mean Repair Time, i.e., it takes in consideration availability of skilled personnel, adequate tools and spare parts. Considering the type of device, the MRT corresponds to the time necessary for the device replacement.

12.1.3 Ethernet connection (if available)

Default IP address	192.168.0.20
Default TCP port	80
Default netmask	255.255.255.0
Default gateway	192.168.0.1


12.1.4 Control unit features

Outputs	Configurable as follows: <ul style="list-style-type: none"> 4 Output Signal Switching Devices (OSSDs) (used as single channels) 2 dual channel safety outputs 1 dual channel safety output and 2 Output Signal Switching Devices (OSSDs)
OSSD characteristic	<ul style="list-style-type: none"> Maximum resistive load: 100 KΩ Minimum resistive load: 70 Ω Maximum capacitive load: 1000 nF Minimum capacitive load: 10 nF
Safety outputs	<p>High-side outputs (with extended protection function)</p> <ul style="list-style-type: none"> Maximum current: 0.4 A Maximum power: 11.2 W <p>The OSSDs provide what follows:</p> <ul style="list-style-type: none"> ON-state: from U_v-1V to U_v (U_v = 24V +/- 4V) OFF-state: from 0 V to 2.5 V r.m.s.
Inputs	<p>Configurable as follows:</p> <ul style="list-style-type: none"> 4 single channel (cat. 2) type 3 digital inputs with common GND 2 dual channel (cat. 3) type 3 digital inputs with common GND 1 dual channel (cat. 3) and 2 single channels (cat. 2) type 3 digital inputs with common GND <p>See "Voltage and current limits for digital inputs" on page 129.</p>
Fieldbus interface (if available)	Ethernet based interface with different standard Fieldbus
Power supply	24 V DC (20–28 V DC) * Maximum current: 1.2 A
Consumption	Max. 5 W
Assembly	On DIN rail
Weight	For Type A: with cover: 170 g (6 oz) For Type B: with cover: 160 g (5.7 oz)
Degree of protection	IP20
Terminals	Section: 1 mm ² (16 AWG) max. Maximum current: 4 A with 1 mm ² cables (16 AWG)
Impact test	For Type A: 0.5 J, 0.25 kg ball from a 20 cm height For Type B: 1 J, 0.25 kg ball from a 40 cm height


Shock/Bump	For Type A: in accordance with IEC/EN 61496-1:2013 sec. 5.4.4.2 (IEC 60068-2-27) For Type B: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.2 class 5M3 (IEC 60068-2-27)
Vibration	For Type A: in accordance with IEC/EN 61496-1:2013 sec. 5.4.4.1 (IEC 60068-2-6) For Type B: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.1 class 5M3 (IEC 60068-2-6 and IEC 60068-2-64)
Pollution degree	2
Outdoor use	No
Operating temperature	From -30 to +60 °C (from -22 to +140 °F)
Storage temperature	From -40 to +80 °C (from -40 to +176 °F)

Note*: the unit shall be supplied by an isolated power source which complies with the standard IEC/EN 60204-1 and fulfils the requirements of:

- Limited-Energy Circuit in accordance with IEC/UL/CSA 61010-1/ IEC/UL/CSA 61010-2-201 or*
- Limited Power Source (LPS) in accordance with IEC/UL/CSA 60950-1 or*
- (For North America and/or Canada only) a Class 2 supply source which complies with the National Electrical Code (NEC), NFPA 70, Clause 725.121 and Canadian Electrical Code (CEC), Part I, C22.1. (typical examples are a Class 2 transformer or a Class 2 power sources in compliance with, UL 5085-3/CSA-C22.2 No. 66.3 or UL 1310/CSA-C22.2 No. 223).*




Type A




Type B 12.1.5 Sensor features

Connectors	2 5-pin M12 connectors (1 male and 1 female)
CAN bus termination resistance	120 Ω (not supplied, to be installed with a bus terminator)
Power supply	12 V DC ± 20%, through control unit
Consumption	For S201A and S203A model: <ul style="list-style-type: none"> Average 2.2 W Peak 3.4 W For S202A model: <ul style="list-style-type: none"> Average 2.6 W Peak 4.3 W
Degree of protection	Type 3 enclosure, according to UL 50E, in addition to IP 67 rating
Material	Sensor: PA66 Bracket: PA66 and glass fiber (GF)
Frame rate	62 fps
Weight	With 2-axis bracket: 300 g (10.6 oz) With 3-axis bracket: 355 g (12.5 oz)
Shock/Bump	For S201A model: in accordance with IEC/EN 61496-1:2013 sec. 5.4.4.2 (IEC 60068-2-27) For S202A model: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.2 class 5M3 (IEC 60068-2-27) For S203A model: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.2 class 5M3 (IEC 60068-2-27)
Vibration	For S201A model: in accordance with IEC/EN 61496-1:2013 sec. 5.4.4.1 (IEC 60068-2-6) For S202A model: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.1 class 5M3 (IEC 60068-2-6 and IEC 60068-2-64) For S203A model: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.1 class 5M3 (IEC 60068-2-6 and IEC 60068-2-64)
Pollution degree	4
Outdoor use	Yes
Operating temperature	From -30 to +60 °C (from -22 to +140 °F)*
Storage temperature	From -40 to +80 °C (from -40 to +176 °F)

Note*: in environmental conditions where the operating temperature can reach values higher than the supported range, install a cover to shield the sensor from sun rays.






12.1.6 CAN bus cables recommended specifications

Section	2 x 0.50 mm ² (21 AWG) power supply 2 x 0.22 mm ² (24 AWG) data line
Type	Two twisted pairs (power supply and data) and one drain wire (or shield)
Connectors	5-pole M12 (see "Connectors M12 CAN bus" on page 129) Connectors shall be type 3 (raintight)
Impedance	120 Ω ±12 Ω (f = 1 MHz)
Shield	Shield with twisted wires in tin-plated copper. To be connected to ground circuit on the power supply terminal block of the control unit.
Standards	Cables shall be listed in accordance with application as described in the National Electrical Code, NFPA 70, and in the Canadian Electrical Code, C22.1. Total maximum length of the CAN bus line: 80 m (262.5 ft)

12.1.7 Tamper-proof screws specifications


Pin Hex button head security screw



d_1	M4
l	10 mm (0.39 in)
d_2	7.6 mm (0.30 in)
k	2.2 mm (0.09 in)
t	min 1.3 mm (0.05 in)
s	2.5 mm (0.10 in)
d_3	max. 1.1 mm (0.04 in)

12.1.8 Non tamper-proof screws specifications

Hex button head screw




d₁	M4
l₁	19 mm (0.74 in)
l₂	6 mm (0.23 in)
l₃	2 mm (0.07 in)
d₂	7.6 mm (0.30 in)
k	3 mm (0.11 in)
s	2.5 mm (0.10 in)
d₃	4 mm (0.15 in)

12.1.9 Bottom screws specifications

The bottom screws can be:


- cheese head
- button head

Note: avoid using countersunk head screws.



12.2 Terminal blocks and connector pin-outs

12.2.1 Digital inputs and outputs terminal block



Note: facing the control unit so that the terminal block is on the top left, number 12 is the closest to the control unit corner.

Terminal block	Symbol	Description	Pin
Digital In	4	Input 2, Channel 2, 24 V DC type 3 - INPUT #2-2	1
	3	Input 2, Channel 1, 24 V DC type 3 - INPUT #2-1	2
	2	Input 1, Channel 2, 24 V DC type 3 - INPUT #1-2	3
	1	Input 1, Channel 1, 24 V DC type 3 - INPUT #1-1	4
	V+	V+ (SNS), 24 V DC for diagnostics of the digital inputs (mandatory if at least one input is used)	5
	V-	V- (SNS), common reference for all digital inputs (mandatory if at least one input is used)	6
Digital Out	-	GND, common reference for all digital outputs	7
	4	Output 4 (OSSD4)	8
	3	Output 3 (OSSD3)	9
	2	Output 2 (OSSD2)	10
	1	Output 1 (OSSD1)	11
	-	GND, common reference for all digital outputs	12

Note: the cables used must have a maximum length of 30 m (98.4 ft) and the maximum operating temperature must be at least 80 °C.

Note: use only copper wires with a minimum gauge of 18 AWG and a torque of 0.62 Nm (5.5 lbs in).

12.2.2 Voltage and current limits for digital inputs

The digital inputs (input voltage 24 V DC) adhere to the following voltage and current limits, in accordance with standard IEC/EN 61131-2:2003.

Type 3


Voltage limits

0	from - 3 to 11 V
1	from 11 to 30 V

Current limits

0	15 mA
1	from 2 to 15 mA

12.2.3 Power supply terminal block




Note: connector front view.

Symbol	Description
V-	GND
	Earth
V+	+ 24 V DC

Note: the maximum operating temperature of the cables must be at least 70 °C.

Note: use only copper wires with a minimum gauge of 18 AWG and a torque of 0.62 Nm (5.5 lbs in).


12.2.4 CAN bus terminal block




Symbol	Description
+	+ 12 V DC output
H	CAN H
L	CAN L
-	GND

Note: the maximum operating temperature of the cables must be at least 70 °C.

12.2.5 Connectors M12 CAN bus



Male connector



Female connector


Pin	Function
1	Shield to be connected to the functional earth on the power supply terminal block of the control unit.
2	+12 V dc
3	GND
4	CAN H
5	CAN L

12.3 Target position angle conventions

12.3.1 Horizontal angle

The horizontal angle of the target position is reported according the following convention:

- the angle has a plus (+) sign when the target is on the left of the sensor.
- the angle has minus sign (-) when the target is on the right of the sensor.




12.3.2 Vertical angle

The vertical angle of the target position is reported according the following convention:


- the angle has a plus (+) sign when the target is above the center of the sensor.
- the angle has minus sign (-) when the target is below the center of the sensor.

12. Technical references



12.4 Electrical connections


12.4.1 Connection of safety outputs to the Programmable Logic Controller



Digital I/O settings (through the Inxpect Safety application)

- Digital input #1 Not configured
- Digital input #2 Not configured
- Digital output #1 Detection signal 1
- Digital output #2 Detection signal 1
- Digital output #3 Not configured
- Digital output #4 Not configured


12.4.2 Connection of safety outputs to an external safety relay



Digital I/O settings (through the Inxpect Safety application)

- Digital input #1 Not configured
- Digital input #2 Not configured
- Digital output #1 Detection signal 1
- Digital output #2 Detection signal 1
- Digital output #3 Not configured
- Digital output #4 Not configured

12.4.3 Connection of stop signal (Emergency button)



Note: the indicated emergency button opens the contact when pressed.

Note: the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

Digital I/O settings (through the Inxpect Safety application)

Digital input #1 Not configured

Digital input #2 Stop signal


Digital output #1 Not configured

Digital output #2 Not configured

Digital output #3 Not configured

Digital output #4 Not configured

12.4.4 Connection of restart signal (dual channel)



Note: the button indicated for the restart signal closes the contact when pressed.

Note: the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

Digital I/O settings (through the Inxpect Safety application)

Digital input #1 Not configured

Digital input #2 Restart signal


Digital output #1 Not configured

Digital output #2 Not configured

Digital output #3 Not configured

Digital output #4 Not configured

12.4.5 Connection of the muting input and output (one group of sensors)




Note: the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

Digital I/O settings (through the Inxpect Safety application)

- Digital input #1 Muting group 1
- Digital input #2 Not configured
- Digital output #1 Not configured
- Digital output #2 Not configured
- Digital output #3 Muting enable feedback signal
- Digital output #4 Not configured

12.4.6 Connection of the muting input and output (two groups of sensors)



Note: the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

Digital I/O settings (through the Inxpect Safety application)

Digital input #1 Muting group 1

Digital input #2 Muting group 2


Digital output #1 Not configured

Digital output #2 Not configured

Digital output #3 Muting enable feedback signal

Digital output #4 Not configured


12.4.7 Detection signal 1 and 2 connection



Digital I/O settings (through the Inxpect Safety application)

- Digital input #1 Not configured
- Digital input #2 Not configured
- Digital output #1 Detection signal 1
- Digital output #2 Detection signal 1
- Digital output #3 Detection signal 2
- Digital output #4 Detection signal 2

12.4.8 Diagnostic output connection



Note: the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

Digital I/O settings (through the Inxpect Safety application)

- Digital input #1 Not configured
- Digital input #2 Not configured
- Digital output #1 Not configured
- Digital output #2 Not configured
- Digital output #3 System diagnostic signal
- Digital output #4 Not configured

12.5 Configuration application parameters

12.5.1 Parameter list

Parameter	Min	Max	Default value
Settings > Account			
Password	-	-	Not available

Parameter	Min	Max	Default value
Settings > General			
System	Inxpect SRE 100 Series, Inxpect SRE 200 Series		Inxpect SRE 100 Series
Sensors model and type	5 meters range sensors, 9 meters range sensors		5 meters range sensors
Country	Europe, Rest of the certified countries or list of countries		Europe, Rest of the certified countries
Application type selection	Stationary, Mobile, Vehicle		Stationary
Configuration			
Number of installed sensors	1	6	1
Plane	Dim. X: 1000 mm Dim. Y: 1000 mm	Dim. X: 65000 mm Dim. Y: 65000 mm	Dim. X: 10000 mm Dim. Y: 7000 mm
Position (for each sensor)	X: 0 mm Y: 0 mm	X: 65000 mm Y: 65000 mm	Default position of sensor #1: X: 2000 mm Y: 3000 mm
Rotation 1 (for each sensor)	0°, 90°, 180°, 270°		0°
Rotation 2 (for each sensor)	0°	359°	180°
Rotation 3 (for each sensor)	-90°	90°	0°
Sensor installation height (for each sensor)	0 mm	10000 mm	0 mm
Detection Distance 1, Detection Distance 2 (for each sensor)	0 mm <i>Note: the minimum value for the first detection field with distance > 0 is 500 mm for 3.x sensors and 200 mm for 5.x sensors.</i>	5000 mm <i>Note: the sum of all the detection distances (for each sensor) cannot exceed 5000 mm.</i>	1000 mm
Detection Distance 3, Detection Distance 4 (for each sensor)	0 mm <i>Note: the minimum value for the first detection field with distance > 0 is 500 mm for 3.x sensors and 200 mm for 5.x sensors.</i>	5000 mm <i>Note: the sum of all the detection distances (for each sensor) cannot exceed 5000 mm.</i>	0 mm
For 5.x sensors - Detection area shape	Classic, Corridor		Classic
Horizontal angular coverage left (Classic shape)	0° <i>Note: the minimum horizontal angular coverage (left + right) is 10°. Only for S202A sensors the minimum value is 20°.</i>	50°	45°
Horizontal angular coverage right (Classic shape)	0° <i>Note: the minimum horizontal angular coverage (left + right) is 10°. Only for S202A sensors the minimum value is 20°.</i>	50°	45°

Parameter	Min	Max	Default value
For S202A sensors - Vertical angular coverage top (Classic shape)	0° Note: the minimum vertical angular coverage (up + down) is 30°	50°	
For S202A sensors - Vertical angular coverage bottom (Classic shape)	0° Note: the minimum vertical angular coverage (up + down) is 30°	40°	
For 5.x sensors (Corridor shape) – Left side	0 mm Note: the minimum corridor width (left + right) is 200 mm. Only for S202A sensors the minimum values is 300 mm.	4000 mm	500 mm
For 5.x sensors (Corridor shape) – Right side	0 mm Note: the minimum corridor width (left + right) is 200 mm. Only for S202A sensors the minimum values is 300 mm.	4000 mm	500 mm
For S202A sensors (Corridor shape) - Top side	0 mm Note: the minimum corridor height (top + bottom) is 300 mm.	4000 mm	500 mm
For S202A sensors (Corridor shape) - Bottom side	0 mm Note: the minimum corridor height (top + bottom) is 300 mm.	4000 mm	500 mm
X size (Cuboid shape)			
Y size (Cuboid shape)			
Z size (Cuboid shape)			
Cuboid tail(Cuboid shape)	Enabled/Disabled		Enabled
Cuboid enable	Enabled/Disabled		Enabled
Show/hide full FOV	Show/Hide		Show
Safety working mode (for each detection field of each sensor)	Access detection and restart prevention, Always-on access detection		Access detection and restart prevention
Static object detection (for each detection field of each sensor)	Enabled, Disabled		Disabled
Restart timeout (for each detection field of each sensor)	100 ms	60000 ms	4000 ms
T _{OFF}	100 ms	60000 ms	100 ms
Settings > Advanced			
Detection field dependency (only for Inxpect Safety 3D application, for each sensor)	Enabled, Disabled		Enabled*
Electromagnetic robustness	Standard, High, Very High		Standard
Static object detection sensitivity	-20 dB	+20 dB	0 dB
Stop signal debounce filter	Enabled, Disabled		Disabled

Parameter	Min	Max	Default value
Settings > Advanced > Teach-In function			
Corridor width (c)	300 mm	5000 mm	0 mm (Disabled)
Horizontal angular coverage (β)	10°	40°	40°
Offset (o)	100 mm	1000 mm	200 mm
Settings > Advanced > Multi-control unit synchronization			
Control unit channel	0	3	0
Settings > Anti-tampering			
Anti-masking sensitivity (for each sensor)	Disabled, Low, Medium, High		Low
Anti-masking distance (for each sensor)	200 mm	1000 mm Note: for S202A sensors, 500 mm	1000 mm Note: for S202A sensors, 500 mm
Anti-rotation around axes (for each sensor)	Disabled, Enabled		Disabled
Anti-rotation around axes - Enable specific axis - Tilt (for each sensor)	Disabled, Enabled		Disabled
Anti-rotation around axes - Enable specific axis - Roll (for each sensor)	Disabled, Enabled		Disabled
Anti-rotation around axes - Enable specific axis - Pan (for each sensor)	Disabled, Enabled		Disabled
Settings > Digital Input-Output			
Digital input (for each input)	Not configured, Stop signal, Restart signal, Muting group "N", Dynamic configuration switch, Fieldbus controlled, System recondition, Teach-In, Restart signal + System recondition, Single channel (Category 2)		Not configured
Digital input channel (for each channel of each input)	Not configured, Restart signal, Fieldbus controlled, System recondition, Restart signal + System recondition, Teach-In function		Not configured
Redundancy mode	Coherent, Inverted		Coherent
Encoded channel	Enabled, Disabled Note: available only when both the digital inputs are configured as Dynamic configuration switch		Disabled
Digital output (for each output)	Not configured, System diagnostic signal, Muting enable feedback signal, Fieldbus controlled, Restart feedback signal, Detection signal "N", Detection signal "N" (non-safe), Static object detection feedback signal, Detection signal group 1, Detection signal group 2, Detection signal group 1 (non-safe), Detection signal group 2 (non-safe), Teach-In feedback signal		Not configured
OSSD Pulse width	Short (300 µs), Long (2 ms)		Short (300 µs)
Short-circuit/Open circuit diagnostics	Enabled, Disabled		Disabled
Settings > Muting			
Group for muting (for each sensor)	None, Group 1, Group 2, both		Group 1
Pulse width (for each input)	0 µs (= Period and Phase shift disabled) 200 µs	2000 µs	0 µs
Period (for each input)	200 ms	2000 ms	200 ms
Phase shift (for each input)	0.4 ms	1000 ms	0.4 ms


Parameter	Min	Max	Default value
Settings > Restart function			
Detection field 1, 2, 3, 4	Automatic, Manual, Safe manual		Automatic
Settings > Activity History			
Log verbosity level	0	5	0
Settings > Detection field groups			
Detection field 1, 2, 3, 4 (for each sensor)	None, Group 1, Group 2, Both		None
Admin > Network Parameters			
IP Address	-		192.168.0.20
Netmask	-		255.255.255.0
Gateway	-		192.168.0.1
TCP port	1	65534	80
Admin > Fieldbus Parameters			
PROFINET/PROFIsafe			
System configuration and status PS2v6	1	65535	145
Sensors information PS2v6	1	65535	147
Sensor 1 detection status PS2v6	1	65535	149
Sensor 2 detection status PS2v6	1	65535	151
Sensor 3 detection status PS2v6	1	65535	153
Sensor 4 detection status PS2v6	1	65535	155
Sensor 5 detection status PS2v6	1	65535	157
Sensor 6 detection status PS2v6	1	65535	159
System configuration and status PS2v4	1	65535	146
Sensors information PS2v4	1	65535	148
Sensor 1 detection status PS2v4	1	65535	150
Sensor 2 detection status PS2v4	1	65535	152
Sensor 3 detection status PS2v4	1	65535	154
Sensor 4 detection status PS2v4	1	65535	156
Sensor 5 detection status PS2v4	1	65535	158
Sensor 6 detection status PS2v4	1	65535	160
Fieldbus endianness	Big Endian, Little Endian		Big Endian
FSoE			
FSoE Safe Address	1	65535	145
Ethernet/IP™ - CIP Safety™			
IP Address	-		DHCP
Network mask	-		DHCP
Gateway	-		DHCP
Host name	-		[empty]
Safety Network Number (SNN)	-		0xFFFFFFFFFFFF
Fieldbus endianness (only for non-safe connections)	Big Endian, Little Endian		Big Endian
Admin > MODBUS Parameters			
MODBUS Enable	Enabled, Disabled		Enabled
Listening port	1	65534	502
Admin > System labels			
Control unit	-		-
Sensor 1	-		-
Sensor 2	-		-
Sensor 3	-		-

Parameter	Min	Max	Default value
Sensor 4	-	-	-
Sensor 5	-	-	-
Sensor 6	-	-	-
Admin > Users management			
User name	-	-	-
Access level	Admin, Engineer, Expert, Observer, Service	Observer	Observer
Admin > SD Card			
Automatic backup creation	Enabled, Disabled	Disabled	Disabled
Users data included	Enabled, Disabled	Disabled	Disabled
Enable restore by button	Enabled, Disabled	Enabled	Enabled

Note*: for S202A-MC sensors with cuboid shape of the detection fields, the detection field dependency is disabled and can not be enabled.

12.6 Digital input signals


12.6.1 Stop signal



Part	Description
OSSDx: Detection signal "N"/Detection signal group "N"	Detection signal outputs deactivate on the falling edge of, at least, one of the two input channels of the input signal. They remain in OFF-state as long as one of the two input channels remains to the low logic status (0).
Stop signal CH1	Interchangeable channel. As soon as one channel goes to the low logic level (0), Detection signal 1 and Detection signal 2 are set to OFF-state.
Stop signal CH2	
Diff	Less than 50 ms. If the value is greater than 50 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
Dt	Activation delay. If the Stop signal debounce filter is disabled, less than 5 ms. If the Stop signal debounce filter is enabled, less than 50 ms.


12.6.2 Muting (with/without pulse)

Without pulse (redundancy mode coherent)






Part	Description
Diff	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
Muting signal (group n) CH 1	Interchangeable channel.
Muting signal (group n) CH 2	
Muting status	They are enabled as long as both channels are at a high logic level (1) and deactivated when both channels go to a low logic level (0).
Dt	Activation/deactivation delay. Less than 50 ms.

Without pulse (redundancy mode inverted)




Part	Description
Diff	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
Muting status	They are enabled as long as channel 1 of the Muting signal is at a high logic level (1) and channel 2 is at a low logic level (0). Disabled as long as channel 1 is at a low logic level (0) and channel 2 is at a high logic level (1).

Part	Description
Dt	Activation/deactivation delay. Less than 50 ms.
With pulse	
Muting signal (group n) CH1	
Muting signal (group n) CH2	
Muting status	


Part	Description
Diff	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
Muting signal (group n) CH 1	Interchangeable channel.
Muting signal (group n) CH 2	
Muting status	They are enabled as long as both the input signals follow the configured muting parameters (pulse width, period, and phase shift).
Dt	Activation/deactivation delay. Less than three times the period.

12.6.3 Teach-In function (dual channel, redundancy mode coherent)




Part	Description
Teach-In CH1	Interchangeable channel. Both channels of Teach-In must have a transition of logical level $0 \rightarrow 1 \rightarrow 0$. The time they stay at a high logical level (t) must be at least 200 ms and less than 5 s.
Teach-In CH2	
Dt	Activation delay. Less than 50 ms.
OSSDx: Detection signal "N"/Detection signal group "N"	The output goes to OFF-state as soon as the last channel has correctly completed the transition $0 \rightarrow 1 \rightarrow 0$, then it goes back to ON-state as soon as the monitoring phase is completed.
Teach-In function feedback	It goes to ON-state during the monitoring phase, then it starts flashing (500 ms ON-state followed by 1500 ms OFF-state) waiting for the confirmation (of completed validation) to be received. <i>Note: in case of fault condition, it flashes faster (500 ms ON-state followed by 500 ms OFF-state) as long as the fault is present.</i>
Diff	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

12.6.4 Teach-In function (dual channel, redundancy mode inverted)




Part	Description
Teach-In CH1	Channel 1 of the Teach-In must have a transition of logical level 0 -> 1 ->0. Channel 2 of the Teach-In must have a transition of logical level 1 -> 0 ->1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) must be at least 200 ms and less than 5 s.
Teach-In CH2	The output goes to OFF-state ass soon as the last channel has correctly completed the transition 0 -> 1 ->0, then it goes back to ON-state as soon as the monitoring phase is completed.
Dt	Activation delay. Less than 50 ms.
OSSDx: Detection signal "N"/Detection signal group "N"	The output goes to OFF-state ass soon as the last channel has correctly completed the transition 0 -> 1 ->0, then it goes back to ON-state as soon as the monitoring phase is completed.
Teach-In function feedback	It goes to ON-state during the monitoring phase, then it starts flashing (500 ms ON-state followed by 1500 ms OFF-state) waiting for the confirmation (of completed validation) to be received. <i>Note: in case of fault condition, it flashes faster (500 ms ON-state followed by 500 ms OFF-state) as long as the fault is present.</i>
Diff	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

12.6.5 Teach-In function (single channel)




Part	Description
Teach-In	The channel must have a transition of logical level 0 \rightarrow 1 \rightarrow 0. The time it stays at a high logical level (t) must be at least 200 ms and less than 5 s.
Dt	Activation delay. Less than 50 ms.
OSSDx: Detection signal "N"/Detection signal group "N"	The output goes to OFF-state as soon as the last channel has correctly completed the transition 0 \rightarrow 1 \rightarrow 0, then it goes back to ON-state as soon as the monitoring phase is completed.
Teach-In function feedback	It goes to ON-state during the monitoring phase, then it starts flashing (500 ms ON-state followed by 1500 ms OFF-state) waiting for the confirmation (of completed validation) to be received. <i>Note: in case of fault condition, it flashes faster (500 ms ON-state followed by 500 ms OFF-state) as long as the fault is present.</i>

12.6.6 Restart signal (dual channel, redundancy mode coherent)




Part	Description
OSSDx: Detection signal "N"/Detection signal group "N"	Detection signal outputs go to ON-state as soon as the last channel has correctly completed the transition 0 -> 1 -> 0.
Restart signal CH1	Interchangeable channel. Both channels of Restart signal must have a transition of logical level 0 -> 1 -> 0. The time they stay at a high logical level (t) must be at least 200 ms and less than 5 s.
Restart signal CH2	
Dt	Activation delay. Less than 50 ms.
Diff	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

12.6.7 Restart signal (dual channel, redundancy mode inverted)




Part	Description
OSSDx: Detection signal "N"/Detection signal group "N"	Detection signal outputs go to ON-state as soon as the last channel has correctly completed the transition.
Restart signal CH1 Restart signal CH2	Channel 1 of the Restart signal must have a transition of logical level 0 -> 1 -> 0. Channel 2 of Restart signal must have a transition of logical level 1 -> 0 -> 1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) must be at least 200 ms and less than 5 s.
Dt	Activation delay. Less than 50 ms.
Diff	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

12.6.8 Restart signal (single channel)




Part	Description
OSSDx: Detection signal "N"/Detection signal group "N"	Detection signal outputs go to ON-state as soon as the Restart signal has correctly completed the transition 0 -> 1 -> 0.
Restart signal	The channel must have a transition of logical level 0 -> 1 -> 0. The time they stay at a high logical level (t) must be at least 200 ms and less than 5 s.
Dt	Activation delay. Less than 50 ms.

12.6.9 System recondition (dual channel, redundancy mode coherent)




Part	Description
System recondition CH1	Interchangeable channel. Both channels of System recondition must have a transition of logical level 0 -> 1 -> 0. They must stay at a high logical level (t) for at least 10 s and less than 30 s.
System recondition CH2	
Diff	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

12.6.10 System recondition (dual channel, redundancy mode inverted)




Part	Description
System recondition CH1	Channel 1 of System recondition must have a transition of logical level 0 -> 1 -> 0.
System recondition CH2	Channel 2 of System recondition must have a transition of logical level 1 -> 0 -> 1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) for at least 10 s and less than 30 s.
Diff	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

12.6.11 System recondition (single channel)




Part	Description
System recondition	The channel must have a transition of logical level 0 -> 1 -> 0. The time it stays at a high logical level (t) must be at least 10 s and less than 30 s.

12.6.12 Restart signal + System recondition (dual channel, redundancy mode coherent)



Part	Description
CH1 CH2 (Restart signal)	Interchangeable channel. Both channels must have a transition of logical level 0 -> 1 ->0. The time they stay at a high logical level (t) must be at least 200 ms and less than 5 s.
	For details about the behavior of Detection signal 1 and 2 outputs and the deactivation delay, see "Restart signal (dual channel, redundancy mode coherent)" on page 149.
CH1 CH2 (System recondition)	Interchangeable channel. Both channels must have a transition of logical level 0 -> 1 ->0. They must stay at a high logical level (t) for at least 10 s and less than 30 s.
Diff	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

12.6.13 Restart signal + System recondition (dual channel, redundancy mode inverted)



Part	Description
CH1 CH2 (Restart signal)	Channel 1 of the Restart signal must have a transition of logical level 0 -> 1 -> 0. Channel 2 of Restart signal must have a transition of logical level 1 -> 0 -> 1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) must be at least 200 ms and less than 5 s.
	For details about the behavior of Detection signal 1 and 2 outputs and the deactivation delay, see "Restart signal (dual channel, redundancy mode inverted)" on page 150.
CH1 CH2 (System recondition)	Channel 1 of System recondition must have a transition of logical level 0 -> 1 -> 0. Channel 2 of System recondition must have a transition of logical level 1 -> 0 -> 1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) for at least 10 s and less than 30 s.
Diff	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.


12.6.14 Restart signal + System recondition (single channel)




Part	Description
Restart signal	The channel must have a transition of logical level 0 -> 1 ->0. The time it stays at a high logical level (t) must be at least 200 ms and less than 5 s. For details about the behavior of Detection signal 1 and 2 outputs and the deactivation delay, see "Restart signal (single channel)" on page 150.
System recondition	The channel must have a transition of logical level 0 -> 1 ->0. The time it stays at a high logical level (t) must be at least 10 s and less than 30 s.

12.6.15 Dynamic configuration switch (redundancy mode coherent)

With one input




With two inputs (encoded channels disabled)




Part	Description
Diff	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
Dynamic configuration number	For details about the dynamic configuration number and the encoded channel option, see "Dynamic configuration through the digital inputs" on page 34.
Dt	Activation/deactivation delay. Less than 50 ms.

12.6.16 Dynamic configuration switch (redundancy mode inverted)

With one input



With two inputs



Part	Description
Diff	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
Dynamic configuration number	For details about the dynamic configuration number and the encoded channels option, see "Dynamic configuration through the digital inputs" on page 34.
Dt	Activation/deactivation delay. Less than 50 ms.

13. Appendix

Contents

This section includes the following topics:

13.1 System software	156
13.2 Disposal	157
13.3 Service and warranty	157
13.4 Intellectual property	157
13.5 Checklist for installing ESPE	157

13.1 System software

13.1.1 Introduction

The aim of this appendix is to provide and clarify the information related to the system software. It includes the information necessary for the integrator during the installation and integration in accordance with IEC 61508-3 Annex D.

Considering that Inxpect SRE 200 Series is an embedded system provided with a firmware already deployed on board, no software integration is required by the system installer or by the end user. The following paragraphs analyzes all the information required in IEC 61508-3 Annex D.

13.1.2 Configuration

The system configuration can be performed by means of a PC-based configuration tool, called the Inxpect Safety application.

The system configuration is described in "Installation and use procedures" on page 84.

13.1.3 Competence

Although no competence is required for software integration, a skilled person is required for system installation and configuration, as described in "Installation and use procedures" on page 84.

13.1.4 Installation instructions

The firmware is already deployed on the hardware, the PC-based configuration tool includes a self-explanatory setup installer.

13.1.5 Outstanding anomalies

At the moment of the issue of this document, no software/firmware anomalies or bugs are known.

13.1.6 Backward compatibility

Backward compatibility is guaranteed.

13.1.7 Change control

Any change proposal suggested by the integrator or the end user should be forwarded to Inxpect and evaluated by the Product Owner.

13.1.8 Implemented security measures

Firmware upgrade packages are managed by the Inxpect Technical Support and are signed to prevent the use of unverified binary files.

13.2 Disposal



Inxpect SRE 200 Series contains electrical parts. As set forth in European Directive 2012/19/EU, do not dispose of the product with unsorted urban waste materials.



It is the responsibility of the owner/distributor to dispose of these products, as well as other electrical and electronic equipment, through specific waste collection facilities indicated by the waste disposal services.

Correct disposal and recycling will contribute to the prevention of potentially harmful consequences to the environment and human health.

For more detailed information about disposal, contact the waste disposal services or the representative from whom you purchased the product.

13.3 Service and warranty

13.3.1 Technical Support

Inxpect SpA
 Via Serpente, 91
 25131 Brescia (BS) - Italy
 Tel: +39 030 5785105
 email: safety-support@inxpect.com
 website: www.inxpect.com

13.3.2 How to return the product

If necessary, complete the request with information about the return on the website www.inxpect.com/industrial/rma. Then, return the product to the local distributor or exclusive distributor. **Use the original packaging. Shipping costs are at the customer's expense.**

Area distributor	Manufacturer
<i>Note distributor information here:</i>	Inxpect SpA Via Serpente, 91 25131 Brescia (BS) Italy www.inxpect.com

13.3.3 Service and warranty

Refer to www.inxpect.com for the following information:

- terms, exclusions and cancellation of the warranty
- general conditions of the Return Merchandise Authorization (RMA)

13.4 Intellectual property

13.4.1 Trademarks

EtherCAT® and Safety over EtherCAT® are registered trademarks and patented technologies licensed by Beckhoff Automation GmbH, Germany.

13.5 Checklist for installing ESPE

13.5.1 Introduction


Collecting the details relating to the following items is mandatory no later than when the system is commissioned for the first time.

This checklist should be kept with the machine documentation to serve as a reference during periodic tests.

This checklist does not replace the initial commissioning or regular inspection by qualified safety personnel.

13.5.2 Checklist

Question	Yes	No
Have the safety rules and regulations been observed in compliance with the directives and standards applicable to the machine?		
Are the applied directives and standards listed in the declaration of conformity?		
Does the ESPE comply with the required PL/SIL claim limit and PFHd in accordance with EN ISO 13849-1/EN 62061 and the required type in accordance with EN 61496-1?		
Is access to the dangerous area only possible through the detection field of the ESPE?		
Have appropriate measures been taken to detect any persons in the dangerous area?		
Have the safety devices been secured or locked to prevent their removal?		
Are additional mechanical protective measures fitted and secured against manipulation which prevent reaching below, above, or around the ESPE?		
Has the maximum stopping time of the machine been measured, specified, and documented?		
Has the ESPE been mounted such that the required minimum distance from the nearest hazardous point has been achieved?		
Are the ESPE devices properly mounted and secured against manipulation after adjustment?		
Are the required protective measures against electric shock in effect (protection class)?		
Is the control switch for resetting the protective devices (ESPE) or restarting the machine present and correctly installed?		
Are the outputs of the ESPE integrated according to the required PL/SIL in accordance with EN ISO 13849-1/EN 62061, and does the integration correspond to the circuit diagrams?		
Has the protective function been checked in compliance with the test notes of this documentation?		
Are the specified protective functions effective at every operating mode that can be set?		
Does the ESPE activate the switching elements?		
Is the ESPE effective over the entire period of the dangerous state?		
Once initiated, will a dangerous state be stopped when switching the ESPE on or off, when changing the operating mode, or when switching to another protective device?		



Inxpect SpA

Via Serpente, 91

25131 Brescia (BS)

Italy

www.inxpect.com

safety-support@inxpect.com

+39 030 5785105

Inxpect SRE 200 Series

Instruction manual v1.7

SEP 2024

Inxpect SAF-IM-200S_5m_Teach-In_7_00335_en_

v1.7

Copyright © 2021-2024 Inxpect SpA