


尺寸: 114.3\*114.3mm  
说明书做成小册子, 铜版纸彩色印刷  
红色文字用Pantone - 485C Red




## Package •

### Contents



DUO TWS  
Stereo Earbuds



USB  
Charging Cable



Charging  
Case

## Safety •

### Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This product is not a toy.
- Long or repeated exposure to sound at high volume levels can cause hearing loss.

## Care & Maintenance •

Read the following recommendations before using the Bluetooth Earbuds.

- Do not expose the Bluetooth Earbuds to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Do not use abrasive cleaning solvents to clean the device.
- Do not expose the device to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Do not dispose of the device in a fire as it will result in an explosion.
- Do not expose the device to contact with sharp objects as this will cause scratches and damage.
- Do not let the device fall on the floor. The internal circuit might get damaged.
- Do not attempt to disassemble the device as it may get damaged if you are not professional.

## FCC •

### Instructions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.


Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## Controls •

### Description



- ① Charging Port
- ② Digital Display
- ③ Built-in Mic
- ④ Right Earbud Touch Pad (Multi-function)
- ⑤ LED Light Indicators
- ⑥ Left Earbud Touch Pad (Multi-function)
- ⑦ Charging Slots

### RF warning statement:

The device has been evaluated to meet general RF exposure requirement.  
The device can be used in portable exposure condition without restriction.

## Instruction For Use

### LED Information



While charging, the LED light indicator on the Earbuds turns on green and the digital display on the Charging Case shows battery charge levels. When the battery of Earbuds is fully charged, the green LED light will turn off.

### ON / OFF Device


Press and hold the Touch Pad (Multi-function) of the Earbud for 3 seconds to turn ON / OFF (The earbuds will automatically go to sleep mode while in the charging case and will awaken when removed).




5

## Instruction For Use

### Pairing



After Turning On the Device  
Wait for Green Flashing Light on one Earbud  
(and no Light on the other Earbud)



Bluetooth Device  
Connected

Search "DUO"  
in your Bluetooth Settings

**Note:** The Bluetooth Earbuds will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, disconnect / forget from your current connected device and please follow the steps outlined above. Once the Bluetooth Earbuds is paired with your device the music will transmit through the Bluetooth Earbuds. Please refer to your device's user manual for further information.

6

## Instruction For Use

### Control Functions

▶ Volume Up	Press and hold the Touch Pad of left Earbud for 2 seconds
◀ Volume Down	Press and hold the Touch Pad of right Earbud for 2 seconds
II Pause	Short press the Touch Pad of one Earbud will pause the music
▶ Play	Short press the Touch Pad of one Earbud will resume the music
◀ Previous track	Short press the Touch Pad of left Earbud three times
▶ Next track	Short press the Touch Pad of right Earbud three times

Note: An indication tone will alert you when the volume is adjusted to maximum level.

### Call Functions

📞 Answer a call	Short press the Touch Pad of one Earbud to answer an incoming call.
📞 Reject a call	Press and hold the Touch Pad of one Earbud for 2 second and release
📞 End a call	After your phone conversation, short press the Touch Pad of one Earbud

### Voice Assistant Operation



Voice Assistant is a built-in interactive feature that allows you to Start Conversation with Your Siri or Google Assistant, with short press the Touch Pad two times on your device. This feature enables you to ask questions and seek assistance on a number of things from your Voice Assistant, even when you're several feet away from your phone. Below are some of the many examples listed below.

While the earbuds is paired using Bluetooth. Short press the Touch Pad two times to start conversation with your Siri or Google Assistant. An indication tone would be heard before you speak into the earbuds.

**Example 1:** Short press the Touch Pad two times and then speak into the earbuds, how's the weather today?

Voice Assistant will reply with something like: *mainly cloudy with a few showers.*

**Example 2:** Short press the Touch Pad two times, and then speak into the earbuds, what's the time now?

Voice Assistant will reply with something like: *it is 8pm now.*

## Troubleshooting

Symptom	Solution
No Sound	<ul style="list-style-type: none"><li>Power On the earbuds and charge the battery</li><li>Increase the volume on your earbuds, your mobile device and music source</li><li>Move your mobile device closer to the earbuds and away from any interference or obstructions</li><li>User a different music source</li><li>Connect another mobile device</li></ul>
Poor Sound Quality	<ul style="list-style-type: none"><li>User a different music source</li><li>Connect another mobile device</li><li>Move your mobile device closer to the earbuds and away from any interference or obstructions</li></ul>
Battery Won't Charge	<ul style="list-style-type: none"><li>Secure the ends of the USB charging cable</li><li>Try another charging source</li></ul>
Your Google Assistant not responding	<ul style="list-style-type: none"><li>This is only available for Android Mobile Devices</li><li>Make sure Google Assistant is downloaded on your mobile device and set to default voice assistant</li><li>Make sure your Android Mobile Device is Bluetooth paired with earbuds</li><li>Make sure you are in a country where Google Assistant is available</li><li>For additional support, visit <a href="http://www.support.google.com/assistant">www.support.google.com/assistant</a></li></ul>
Loud Dial Tone Noise When Activating Google Assistant	<ul style="list-style-type: none"><li>Make sure you have latest version of Google Assistant App</li><li>On your Android mobile device, go to Settings &gt; Apps &gt; Google App &gt; Disable. After that, tap Enable (If you have uninstalled Google App, please uninstall and reinstall the App).</li></ul>

#### **Product Specifications:**

Bluetooth version: 5.0  
Bluetooth range: Up to 33 feet  
Input voltage: DC 5V  
Charging time: less than 2 hours  
Play time: Up to 4 hours per charge (case adds up to an additional 16 hours)  
Built-In battery: Charging Case - 250mAh, Bluetooth Earbud - 30mAh (each)  
Size: Charging Case - 2.12" L x 2.13" D x 0.87" H, Bluetooth Earbud - 0.75" L x 0.73" D x 1.51" H (each)  
Weight: Charging Case - 1.3 oz, Bluetooth Earbud - 0.1 oz (each)

(Note: Battery life & charging time may vary based on usage & types of devices used.)

#### **Warranty** •


**WARRANTY COVERAGE:** This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse; neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to; LCD Screens, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

**WARRANTY DISCLAIMERS:** This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer's/ Distributor's maximum liability exceed the retail value of the product.

**WARRANTY PERFORMANCE:** During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

**SERVICE AND REPAIR:** If service is required for this product, you should first contact Midwest Trading Group Customer Service at [info@mtradinggroup.com](mailto:info@mtradinggroup.com) or by calling **1 (866) 815-4714**, Monday to Friday 10am to 6pm EST.

**NOTE:** Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.



™ and © ITV Studios Netherlands Content BV. Licensed by ITV Studios.