



90x25 Inch LED SEG Tower

USER MANUAL



SKU: LEDSEG90HW

V1.0

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes/modifications to this equipment not approved by the party responsible for compliance could void the user's authority to operate the equipment.



Thank you for purchasing this product from Displays2go.

It's our mission to help you connect with the world and build your brand with products that are personalized to your needs.

Your product has been manufactured with great care using only the finest quality materials and expert workmanship. Our Quality Assurance team inspects all electronics during assembly process to assure reliable operation. This product comes with a 12-month warranty. Scan the QR code to visit the product page and learn more about your warranty.

Need assistance? We are available for expert advice and all of your customer service needs.

 **Chat Us**
DISPLAYS2GO.COM

 **Email Us**
INFO@DISPLAYS2GO.COM

 **Call Us**
1-844-221-3388

TABLE OF CONTENTS

BEFORE USE

Safety and Warnings	4
Packing List	6
Parts Description	7
Assembly	8
SEG Fabric Installation	9

OPERATION

Power On/Off	10
IP Address	10
Display Media with ViPlex Express	11
Unit Connection Methods	15

REFERENCE

Technical Specifications	16
Cleaning and Maintenance	17
Troubleshooting Guide	18
Names and Contents of Toxic and Hazardous Substances or Elements in the Product	20
FCC Compliance Notice	21

BEFORE USE

Safety Warnings and Precautions

Thank you for purchasing the high-performance digital signage from Displays2go. We have considered the factors to ensure personal safety in product design and have tested rigorously at the factory. However, improper installation and use may result in electric shock and fire.

In order to safely use, maximize performance of the unit and extend the life of the product, please read and follow all instructions carefully before using the product. Keep the instructions for future reference.

We strongly recommend using a surge protector or a power strip with internal circuit breaker to prevent damages to the digital signage.

	Warning: May cause personal injury or death
	The operation is prohibited
	Caution: May cause damage or property loss



If any of the following occurs:

- Power outage or instable voltage.
- Abnormal sound or smell from the unit.
- AC power cord is damaged.
- Digital Signage is damaged due to drop, knock or impact.
- Any liquid or foreign matters fall into the enclosure.



Turn off the Digital Signage immediately, pull out the plug from the power outlet, and ask the authorized personnel for maintenance quickly.



If coal gas or other flammable gas leaks, do not pull out the plug of the digital signage or other electrical appliances; instead, turn off the gas valve immediately, and open the doors and windows quickly.



WARNING



- Cut off the power supply before connecting or disconnecting any cables.
- Do not place the Digital Signage on any instable positions, or else it may be damaged or cause fire.
- Do not place the Digital Signage in the positions such as:
 - The environment subject to direct strong sunlight, moisture, extreme temperature or too much dust,
 - The environment with flammable or explosive materials,
 - The environment with flammable or corrosive gases,
- Do not use damaged or inappropriate power outlets, and ensure that the plugs and outlets contact properly.
- Do not let dust or metal deposits adhere to the plugs and outlets.
- Do not damage the power cords:
- Do not modify the power cords,
- Do not place heavy objects on the power cords,
 - Keep the power cords away from heat source,
 - Do not pull the cord to remove the plug.
- Do not connect too many plugs to one outlet in parallel, or else it may cause fire due to excessive power consumption.
- Do not approach the Digital Signage with open flame (e.g. a lighted candle), or else it may cause electric shock or fire.
- Do not put any sharp objects, metal or liquid into the vents or let them touch the signal terminals to avoid short circuit, product damage, and electric shock.
- The openings in the enclosure are designed for ventilation and cooling, to ensure long time reliable running of components inside the enclosure and prevent overheating. Do not block the openings when place the unit.



Do not touch the plugs with wet fingers, or else it will cause electric shock.



Do not use the Digital Signage in stormy weather, especially when there is lightning, instead, please disconnect the power and antenna plugs to avoid lightning strike.



Do not disassemble the Digital Signage without permission, or else it may cause electric shock or fire. Please ask qualified technician for repair.



CAUTION

- Do not let children climb onto the Digital Signage.
- Keep the small parts away from children to prevent them from swallowing.
- If the Digital Signage won't be used for a long time, please turn it off and pull out the power plug.
- To adjust the position of the Digital Signage, please disconnect all power cords and move slowly to avoid tip over.
- Do not scratch or knock the digital signage with hard object, or twist and squeeze the digital signage.
- Do not turn on the unit immediately when it is moved from a place with low temperature to high temperature, or else it will cause condensation and malfunction.
- Before cleaning the Digital Signage, please pull out the power plug, wipe with soft cloth, do not use industrial chemicals, prevent foreign matters from entering the machine. Improper cleaning (such as cleaning solution, water) may damage the product, erase the printed information, and even cause damage of the components if fluid flows in, resulting in machine failure.
- If the unit displays the same screen for a long time or the moving picture has fixed text or icon, it will leave ghosting on the screen and won't disappear when the unit is turned off, it is normal and isn't covered by the warranty.
- The power of the Digital Signage can be cut off by pulling out the plug.
- To carry the Digital Signage with hands, please grab and hold the edges, do not apply pressure on the panel.
- Use the Digital Signage properly: Use in proper lighting conditions, insufficient lighting or long time watching will impair your eyesight.
- Unplug device to disconnect from power.
- Insert the plug into the outlet properly, or else it may cause sparks and fire.

The technical specifications printed herein and on the packaging are subject to change without prior notice. The Manual may be slightly different from actual operation, and the latter is applicable.


Packing List

Description	Qty.
Top SEG Light Box & LED Screen	1
Bottom SEG Light Box	1
Base & Caster Wheels	1
Bracket	2
Hardware Kit	1

Description	Qty.
AC Power Cord	1
Maintenance Tool	1
User Manual	1

If you have any questions regarding our products, please visit us at www.displays2go.com or contact Displays2go customer service at 844-221-3388.

Parts Description




Assembly

! NOTE: Two people recommended for the safe assembly of the product.




2 PEOPLE REQUIRED
FOR UNPACKING




1

Tighten the base and the bottom SEG light box with 8pcs M6*16 screws;



2


Use 12pcs M6*8 screws to the two rear brackets to the base and the back panel;



3

Fix the lower body and the upper body with 8pcs M6*12 screws;

! NOTE: Casters can be locked for safety.



4

As shown in the figure, connect the male and female connectors on the left and right sides, and then plug in the AC power cord.


SEG Fabric Installation

Bend the silicone edges of the SEG fabric to form a right angle. Press into the channels along the frame, starting with the corners. Press all edges firmly into the channels until the graphic lies flat.

Top SEG Slot Dimension:
642mm W x 498mm H

Bottom SEG Slot Dimension:
642mm W x 1105mm H

Looking for more details on installing the SEG graphics? **Scan the QR code** to view our SEG video tutorial!




OPERATION

Power On/Off

Insert the power cable into the power cord input on the unit. Then turn the unit ON using the On/Off switch. After a few seconds, the LEDs light up and the unit's IP address becomes active.

! **NOTE:** We recommend the use of a surge protector or power strip with an internal circuit breaker to prevent damages to the product.



IP Address

The IP address of the unit is active after the unit is powered on. The IP address is "AP" followed by the product ID number, which can be found on the information sticker on the inside of the access door.

WiFi ID: AP-xxxxxxxx

Password: SN2008@+

Display Media with ViPlex Express

To display content, you first need to create and publish a content playlist, known as a 'solution' in ViPlex Express software. ViPlex Express is a program for creating, editing, and displaying content on your LED unit.




! **NOTE:** The ViPlex software appearance may vary from the screenshots included in this manual. [Refer to the official ViPlex user manual in the software for the most up-to-date visuals and instructions.](#)

DOWNLOAD VIPLEX EXPRESS

INSTALL VIPLEX EXPRESS FROM USB

1. Insert the included USB into your PC and download ViPlex Express software.
2. Once installed, the software shortcut appears on your desktop. Click to open the software.



DOWNLOAD VIPLEX EXPRESS ONLINE

If your USB is not readily available, you can also download the software on its official website:

www.novastar.tech/downloads

Click the Nova Cloud tab, then, scroll to ViPlex Express. Download and install either the ViPlex Express x32 or x64 software. You may also download the Studio Mode User Manual here or in the ViPlex software.

A screenshot of the Nova Cloud Software download page. The top navigation bar includes tabs for COEX, LED Control System, Processors, **Nova Cloud** (which is highlighted with a red box), Software, and Calibrations. Below the tabs, there are two main download sections: 'ViPlex Handy' and 'ViPlex Express'. The 'ViPlex Express' section is also highlighted with a red box. Both sections show download links for 'ViPlex Handy User Manual', 'Software QR code', and 'ViPlex Express (x64)' and 'ViPlex Express (x32)'. There are also links for 'Async Mode User Manual', 'Studio Mode User Manual', and 'Release Notes'.

! **NOTE:** Most modern computers are compatible with x64 software. Check your PC device specifications to determine your processor's compatibility with either the x32 or x64 software.

After downloading, you'll be asked to choose **Async** mode or **Studio** mode. Please refer to the Studio Mode and Async Mode user manuals on the product page as the mode selected will effect the available actions and user interface.


Studio Mode	Async Mode
Synchronously Play Content from a Connected Computer	Play Content from a Multimedia Player, Connected USB, or Wireless Playback.

LOG INTO VIPLEX EXPRESS

1. Open ViPlex Express application after powering the LED signage on. The IP addresses of all units appear listed in the Screen Management tab. Choose an available unit from the list, then click **Connect**.
2. Enter the username and password then click **OK**.

Initial Username: **admin**

Initial Password: **SN2008@+**





CREATE NEW SOLUTION

1. In the Solutions tab, click **New** in the top left corner, then click **Regular Screen**.
2. Name the playlist and select the unit from the terminal list: **AP-xxxxxxxx**
3. Click **OK**. The Solution Information dialog box appears.
4. Enter the dimensions for the solution and then click **OK**.


Width: **256 px**

Height: **256 px**

You can also set a resolution by clicking **Specify Terminal** and the resolution will be the same as the resolution of the terminal you select.




After clicking **OK**, the Solution Editing page opens. From here, you can add content, edit settings, and personalize the solution with widgets and customizations. With the page selected, add content from the **+** drop down menu in the **Window** menu in the sidebar, or use the tools in the ribbon, shown on the next page.



1	Save the solution, save a new copy of the solution, or edit solution settings.
2	Customize the page by adding media, text, widgets, and more. Click File to insert images or video on the page. NOTE: Image resolution must match solution resolution.
3	Publish the solution, view the solution in Preview mode, or view the scheduled playback of the solution.
4	Add, copy, delete, or reorder the pages in the solution. Use the down arrow next to Add to create or utilize page templates.
5	Page view. Edit and customize the individual page. Arrange content using the alignment tools in the ribbon.
6	<p>Widget Properties: Widgets are the media added to a page. The properties of different types of media vary. Click a widget to select it before editing its properties.</p> <p>Page Properties: Set the name, play count, validity range, and playback schedule of a page.</p> <ul style="list-style-type: none"> • Play Count: Set the number of times to play a page continuously. • Validity Range: After this option is selected, the Start Date and End Date parameters are displayed. Expired pages will be skipped during solution playback. • Schedule: Allows you to specify the timeslots to play a page and select the days to repeat the playback. If the timeslots of different pages overlap, the pages will be played in order from top to bottom. • Apply Schedule: Allows you to apply the schedule of the current page to other pages. You can select multiple pages and apply a schedule to them at the same time.

PUBLISH SOLUTION

Publish your solution by clicking the green Publish icon. Once published, playlists can be shared to the unit via USB or network connection.




Connect via PC	Connect via Phone
IP Address, Ethernet, or USB	ViPlex Handy mobile app
Create, edit, and publish playlists	Display playlists only

PUBLISH VIA NETWORK CONNECTION

After clicking Publish, the Program Management tab opens.

Select the unit from Terminal Name list. Click Refresh if unit does not appear listed right away. Then, click Publish.

Connect to the unit's network to play solution (see next page for more).



PUBLISH VIA USB


Insert a USB into your PC. In the Program Management tab, select the solution, then click Export to open the USB Playback window. USB Publishing has 2 options: Copy and Play, and Plug and Play.

- **Copy and Play:** Plug USB to copy the playlist to the unit. The playlist will loop play with or without USB in. You must select Overwrite for this option
- **Plug and Play:** Plug USB to play; remove USB to stop.

2. In Path, select your USB in the file browser pop up window. Click OK.

3. In terminal password, enter the unit password.
NOTE: the default password is SN2008@+

4. Click OK to finish publishing to USB.



Unit Connection Methods

CONNECT WIRELESSLY

1. Open Wi-Fi settings on your PC and find the unit IP address. The unit's IP address is "AP-" followed by the product ID number, which can be found on the Wi-Fi information sticker.
2. Enter the default network password: **SN2008@+**



CONNECT VIA ETHERNET


Insert Ethernet cable into Ethernet (RJ45) port of unit, then connect Ethernet to PC.

CONNECT VIA USB

Publish solution to USB in ViPlex Express (see previous page for instructions). Then, insert USB into USB port of unit. The solution plays automatically.

CONNECT VIA MOBILE PHONE

The ViPlexHandy mobile app allows you to display solutions you've created in ViPlex Express. To download the app to your mobile phone, scan the QR code below or search ViPlexHandy in your app store. Or, download from the official website: <https://www.novastar.tech/downloads>.



1. Disconnect PC and other devices before connecting on mobile app.
2. Open your phone's Wi-Fi settings on the phone and connect to the unit's IP address. The unit's IP address is "AP-" followed by the product ID number, which can be found on the Wi-Fi information sticker.
3. Enter the default username (**admin**) and network password: **(SN2008@+)**.

REFERENCE

Technical Specifications

PANEL	LED Size	25.2"H x 25.2"W
	Light Source	LED
	Aspect Ratio	1:1
	Resolution	344 x 344
	Brightness	700 nits
	Contrast	3000: 1
	Response	15ms
	Pixel Pitch	1.86mm
	Refresh Rate	3840Hz
	Viewing Angle	140° / 120°
	Color Saturation	8 bit
	Viewable Area	25.2"H x 25.2"W
POWER SUPPLY	Chromaticness	RGB
	LED Screen Voltage	90-132VAC
	Lightbox Voltage	90-132VAC
	Hertz	60Hz
ENVIRONMENT	Power Consumption	≤350W
	Operating Temperature	32 - 104°F (0~40°C)
	Storage Temperature	14-140°F (-10~60°C)
	Operating Humidity	20~80% RH Non-condensing
	Storage Humidity	10~60% RH Non-condensing
FUNCTIONS	Maximum Operating Time	18 hours /7 days
	Operating System	NovaStar TCC 160
	Processor	Nova Star TCC 160
	RAM	1GB
	ROM	32GB
	Decoding Resolution	1080P UHD Compatible
	Touch Support	No touch
	Supported Video Files	MPEG2, MPEG4, H.264, RMVB, AVI, MPEG1, MP4, MKV, FLV, WMV, MOV
	Supported Image Files	JPEG, BMP, PNG, GIF
	Supported Audio Files	MP3
	Speakers	2x 8W

I/O INTERFACES	Wi-Fi	Internal x1 (Internal Antenna)
	Ethernet (RJ45)	x1
	HDMI IN	N/A
	VGA	N/A
	Headset	N/A
	USB	USB 2.0 x 1
	TF	N/A
	SIM	N/A
STRUCTURE	Net Weight	161.82 lbs
	Gross Weight	261.91 lbs
	Unit Dimensions	25.39" L x 25.39" D x 93.11" H
	Package Dimensions	47.24" L x 15.55" W x 35.04" H
	Shell Material	Steel/Plastic
LANGUAGE	Shell Color	Black
LANGUAGE	OSD	English

Cleaning and Maintenance

- Avoid strong vibration or impact on the product.
- Keep the product dry to avoid possible damage by moisture.
- Do not place the product under direct sunlight which may shorten the service life of the screen.
- If the product will not be used for a long time, unplug the power cord to prevent the internal short circuit or other potential dangers.

I/O INTERFACES	Wi-Fi	Internal x1 (Internal Antenna)
	Ethernet (RJ45)	x1
	HDMI IN	N/A
	VGA	N/A
	Headset	N/A
	USB	USB 2.0 x 1
	TF	N/A
	SIM	N/A
STRUCTURE	Net Weight	161.82 lbs
	Gross Weight	261.91 lbs
	Unit Dimensions	25.39" L x 25.39" D x 93.11" H
	Package Dimensions	47.24" L x 15.55" W x 35.04" H
	Shell Material	Steel/Plastic
LANGUAGE	Shell Color	Black
LANGUAGE	OSD	English

Cleaning and Maintenance

- Avoid strong vibration or impact on the product.
- Keep the product dry to avoid possible damage by moisture.
- Do not place the product under direct sunlight which may shorten the service life of the screen.
- If the product will not be used for a long time, unplug the power cord to prevent the internal short circuit or other potential dangers.

I/O INTERFACES	Wi-Fi	Internal x1 (Internal Antenna)
	Ethernet (RJ45)	x1
	HDMI IN	N/A
	VGA	N/A
	Headset	N/A
	USB	USB 2.0 x 1
	TF	N/A
	SIM	N/A
STRUCTURE	Net Weight	161.82 lbs
	Gross Weight	261.91 lbs
	Unit Dimensions	25.39" L x 25.39" D x 93.11" H
	Package Dimensions	47.24" L x 15.55" W x 35.04" H
	Shell Material	Steel/Plastic
LANGUAGE	Shell Color	Black
LANGUAGE	OSD	English

Cleaning and Maintenance

- Avoid strong vibration or impact on the product.
- Keep the product dry to avoid possible damage by moisture.
- Do not place the product under direct sunlight which may shorten the service life of the screen.
- If the product will not be used for a long time, unplug the power cord to prevent the internal short circuit or other potential dangers.

Troubleshooting Guide

! **NOTE:** Do not attempt to replace or repair circuitry yourself. Contact customer service to schedule a professional maintenance appointment.

Entire Screen Is Blank	PROBABLE CAUSE
	<ul style="list-style-type: none">• Abnormal electrical power supply of display• Display power not turned on• No video source is switched (synchronous or asynchronous)• Fault on controller or switching power
	SOLUTION
	<ul style="list-style-type: none">• Check Ethernet cable is functioning.• Check power supply and confirm device is powered on.• If problem persists, replace power supply cable.• If problem persists, replace controller.
Blank LED Module	PROBABLE CAUSE
	<ul style="list-style-type: none">• Poor module connection• Faulty module
	SOLUTION
	Contact customer service to schedule a professional maintenance appointment.
Screen is Mostly Blank	PROBABLE CAUSE
	<ul style="list-style-type: none">• Poor connection of board power cable• Board input or output signal faulty
	SOLUTION
	Contact customer service to schedule a professional maintenance appointment.

Screen is Half Blank	PROBABLE CAUSE
	<ul style="list-style-type: none"> • Faulty power cable connection between switching power supply and module • Faulty switching power supply • Cat5 cable loose between receiving card or faulty Cat5 cable • Faulty receiving card or no power to receiving card
	SOLUTION
	<p>Contact customer service to schedule a professional maintenance appointment.</p>
Color Missing on Module	PROBABLE CAUSE
	<ul style="list-style-type: none"> • Faulty module • Signal cable fault
	SOLUTION
	<p>Contact customer service to schedule a professional maintenance appointment.</p>
Disordered or Repeating Images	PROBABLE CAUSE
	<ul style="list-style-type: none"> • Setting error
	SOLUTION
	<ul style="list-style-type: none"> • Reload display configuration files.

If all the potential solutions have been tested for a particular issue and problems have not been resolved, contact a customer service representative for guidance.

844-221-3388 | info@displays2go.com

Names and Contents of Toxic and Hazardous Substances or Elements in the Product

The table shows that the machine contains harmful substances inside. The data is provided by material suppliers and verified by the company according to the material type. Some materials contain harmful substances that can't be replaced in present technology. We are dedicated to improving this.

O: the content of the toxic and hazardous substances or elements in the part is lower than the limit specified in GB/T 26572-2011 standard.

x: the content of the toxic and hazardous substances or elements in the part is higher than the limit specified in GB/T 26572-2011 standard.

PART NAME	TOXIC AND HAZARDOUS SUBSTANCES OR ELEMENTS					
	Pb	Hg	Cd	Cr ⁶⁺	PBB	PBDE
Display		0	0	0	0	0
Shell	0	0	0	0	x	x
Circuit Board Assembly *		0	0	0	0	0
Wires	0	0	0	0	0	0
Metal Parts	0	0	0	0	0	0
Packaging Materials*	0	0	0	0	0	0
Remote Control		0	0	0	0	0
Speakers		0	0	0	0	0
Accessories*	0	0	0	0	0	0

*: Packaging materials include packaging box, styrofoam, etc.;

*: Circuit board assembly includes PCB and the electronic elements thereof;

*: Other accessories include instruction manual.

The EFUP of the product is ten years. The pollution control label is shown right.



The EFUP is valid only when the user operates in the normal conditions specified in the manual herein.

Waste Electrical and Electronic Products Recycling and Disposal Regulations

To protect the earth, if you do not need this product or its service life expires, please abide by your local Waste Electrical and Electronic Products Recycling and Disposal Regulations or send it to qualified local manufacturer for recycling.

FCC Compliance Notice

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 8 inches (20cm) between the radiator and your body.