


Quick Start Guide

M420



English



1. Product Introduction

1.1 Packing List



① The Paper Roll has been installed in the printer. However, if you have purchased a bundled printer package, it does not include a 40*30mm-100pc Paper Roll.

1.2 Printer Parts Instruction



2. Getting Started

2.1 Downloading the App

Method 1: Search for the "Print Master" app on App Store® or Google Play™ to download and install it.

Method 2: Scan the QR code to download the app.



2.2 User Guide

① Remove the protective film.



② Long press the Power Button for 3 seconds until the Indicator Light is on to power up the printer.



③ This step is required for first use.

④ Open the "Print Master" app.



⑤ Tap [Auto Connect].



⑥ Grant permissions.



⑦ Wait for the printer to be connected.



⑧ You can also find manual connection options on [Home]. For more details, see [4. More Connection Methods](#) in this guide.

⑨ Connected.



⑩ Edit your first label, and tap [Print] after you finish editing.




⑪ Remove the existing paper roll in the Paper Compartment.



⑫ Push the Guide Lock towards the Cover Open Lever until you hear a click to unlock the Guides.



⑬ Remove the stopper to one side.




⑭ Remove the Anti-loosening Sticker from the paper roll.




⑮ Place the paper roll in the Paper Compartment.



⑯ Make sure the paper roll is placed in the right direction.




⑰ Tighten both sides of the baffle inward.




① Connected.



② Go to "Home" and tap [Scan].



③ Take out the unused paper roll from the printer.







This QR code is for demonstration only. Please scan the actual QR code on your paper roll.

④ If you have purchased boxed paper rolls separately, or if there is no QR code on the paper roll, please see [4. Identifying Label Sizes](#) in the Online Guide for instructions on how to quickly access the editing page.


⑤ The label size is identified.



⑥ Aim the scanning frame at the QR code on the paper roll's Anti-loosening Sticker.







⑦ Push the Guide Lock towards the Paper Compartment Cover until you hear a click to lock the Guides.



⑧ Pull out the label paper until it is flush with the open button, then close the lid.



⑨ The Paper Exit will auto-calibrate the label and adjust the paper roll to the right position.



6.1 Button Instructions

Button Type	Operation	Function
Power Button	Long press for 3s	Power on/off
	Double press when printer is on	Print a self-test page

6.2 Indicator Light Instructions

Status	Meaning	Advised Action
● Solid Green Light	Functioning normally and fully charged	/
● Flashing Green Light	Charging	/
● Solid Red Light	No paper roll detected/ Faulty	Reinstall paper roll
● Flashing Red Light	Low battery	Charge battery for 1h
No light after long pressing Power Button for 3s	Battery depleted	Charge battery for 4h

① For instructions on reinstalling the paper roll, see [3. Replacing the Paper Roll](#) in this guide; for charging instructions, see [5. Charging Instructions](#) in this guide.

7. FCC INFORMATION (U.S.A.)

FCC Compliance Statement :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorienting or relocating the receiving antenna.
- Increasing the separation between the equipment and receiver.
- Connecting the equipment to an outlet that is on a different circuit than the radio or TV.
- Consulting the dealer or an experienced radio/TV technician for help.

FCC Caution :

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

- This product satisfies FCC regulations when shielded cables and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with electric appliances, such as radios and televisions, use shielded cables and connectors for connections.

8. ISED NOTICE (Canada)

CAN ICES-003(B)/NMB-003(B)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: 1. This device may not cause interference. 2. This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body.

Cet appareil contient un émetteur (S)/ récepteur (S) exempté (S) de licence qui est conforme aux RSS(S) exemptés (S) de licence d'innovation, Science et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes: 1. Cet appareil ne peut pas causer d'interférences. 2. Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un fonctionnement indésirable de l'appareil.

Special Notes

The company takes full responsibility for the revision and explanation of this manual, with utmost care taken to ensure its accuracy. However, please note that any technical improvements to the product may not be separately notified, and that the images of the product, accessories, software interfaces, etc. in this manual are for illustrative purposes and reference only. Due to product updates and upgrades, the actual product may be slightly different from the images. Please rely on the actual product for all details.