




above®





Safety Information

Please read and understand this entire manual before attempting to assemble, operate or install the product.

- Keep away from open flames or heat.
- Avoid allowing metal or foreign objects (such as dust) into the device's USB charging port or any other slot. If a metal object or other foreign object enters the port, remove the debris before using the USB port.
- Only authorized service workers can perform service operations on the device. Do not attempt to disassemble or repair the equipment yourself. Failure to do so may result in equipment damage or personal injury.
- DO NOT strike, throw, step on, apply excessive pressure, or subject the device to severe physical shock.
- DO NOT disassemble the device as this may puncture the battery and cause personal injury or damage to the device.
- This product (including accessories) has magnets. Swallowing the magnet could cause serious injuries such as choking or intestinal damage. If a magnet is accidentally swallowed, seek immediate medical attention. Keep this product out of the reach of children and other people who need to be watched to avoid accidental ingestion.
- You may use the equipment in certain humid or dusty environments but be aware of its IP rating limits, and regular use limits should be met when in use. Conditions that exceed the IP rating limits include excessive humidity, hurricane winds, and dusty environments.
- DO NOT expose it to extreme temperatures. Do not use the equipment in temperatures below 32°F or above +113°F.
- DO NOT remove the LED light cover when in use. It may harm your vision.
- When charging your device with a USB cable, make sure it is not stepped on or tripped over. It may be damaged or severely strained.
- DO NOT attempt to replace the battery yourself; you may risk damaging it, which could lead to overheating, explosion, fire, property damage, or personal injury. Batteries in your device must be repaired and recycled by an Above authorized service partner.
- Please charge the battery at least once every three months. A long period of not charging will reduce battery life.





FCC Compliance

FCC Statement

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help. To ensure continued compliance, any changes or modifications not expressly approved by any party.

Responsible for compliance could void the user's authority to operate the equipment.

(Example - use only shielded interface cables when connecting to computer or peripheral devices.)

This equipment complies with Part 15 of FCC Rules. Operation is subject to the following 2 conditions:

This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment.

Choking Hazard Warning

⚠ WARNING : This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Battery Recycling Warning



Do NOT throw away the battery in a fire



DO NOT throw away the battery into a household garbage or recycling bins.



Lithium-ion (Li-ion) batteries are used in this product. To recycle it, please contact your local waste authority for information on available recycling and/or disposal options.




Table of Content

1. What's in the Box.....	1
2. Symbol Indicators.....	2
3. Assembly	3
3.1 Connect the Solar Panel and Wind Sensor.....	3
3.2 Turn on the Power on the Control Board	4
3.3 Connect the Wind Sensor to the Control Board	4
3.4 Installing the LED Light	5
3.5 Attach The Pole to A Base	6
3.6 Recommend Base Weight for Above Umbrellas.....	6
3.7 Assemble Upper Pole to Bottom Pole.....	7
4. Remote Control	8
4.1 How to Use Remote Control.....	8
4.2 Pairing Your Remote.....	9
4.3 Pairing Your Remote Control to Multiple Umbrellas	9
4.4 Replacing Remote Battery.....	10
5. How to Charge the Umbrella.....	11
5.1 Solar Charging	11
5.2 USB Charging	11
5.3 Low Battery Alert:	12
6. Emergency Release Latch.....	12
7. Setting Wind Sensor Sensitivity.....	13
8. Care and Maintenance	15
9. FAQ.....	17
10. Warranty.....	18
11. Contact Us.....	21

1. What's in the Box

Before beginning to assemble this product, make sure all parts are present. If any parts are missing or damaged, do not attempt to assemble this product. Please contact our customer service department at 1-888-889-8320.





Part	Description
1	Solar Panel
2	Wind Sensor
3	Control Board/ Battery
4	Motor
5	Upper Frame with Canopy
6	LED Light/ USB Port
7	Adjustable Remote Controller Holder
8	Remote Control (Battery Included)
9	Bottom Pole
10	Additional CR2032 Coin Cell Battery



2. Symbol Indicators

Control Board

Symbol	Description
	Turn on/off the power
	Wind Speed Settings
	Micro USB Charging Port
	Unlocked Position
	Locked




LED Light

Symbol	Description
	Micro USB Charging Port


3. Assembly

Fully Assembled Parts



*Motor should come pre-attached to the umbrella

3.1 Connect the Solar Panel and Wind Sensor




1. Align the "V" on the lower side of the "Solar Panel" with the "A" on the upper side of the "Wind Sensor". Turn the solar panel clockwise until "V" on the solar panel is aligned with "A" on the wind sensor.



3. Assembly


3.2 Turn on the Power on the Control Board

Control Board



1. Locate the control board.
2. Pull off the silicone cover in the center of the top of the Control Board.
Turn the power switch on the right side in the red box from off to on.
3. Push the silicone plug back into place.


3.3 Connect the Wind Sensor to the Control Board



*Control board should come pre-attached
to the motor (top part of umbrella)

1. Align the "M" on the lower side of the "Wind Sensor" with the "N" on the upper side of the "Control Board". Turn the wind sensor clockwise until the "M" on the wind sensor aligns with the "N" on the control board.

3.4 Installing the LED Light



1. Insert the LED fixture through the pole with the umbrella. Align "M" on the lower side of the runner hub with "N" on the upper side of the LED Light. Turn the LED light clockwise until "M" is aligned with "N".




3. Assembly

3.5 Attach The Pole to A Base

- Put the bottom pole in to the base.
- Screw and lock the bottom pole to the base. (Umbrella bases may vary.)

*Please make sure to set the base on a flat surface




3.6 Recommend Base Weight for Above Umbrellas

Umbrella Size	Base Weight
9ft/10ft	90 LBS
11ft	120 LBS

TIP : A heavier weight is better for keeping an umbrella steady in windy conditions.

3. Assembly

3.7 Assemble Upper Pole to Bottom Pole




- Press and hold the button located at the end of upper pole.
- Insert the upper pole to the bottom pole until the button clips into the hole.




4. Remote Control

4.1 How to Use Remote Control

The remote control by default should already be paired with your Height umbrella. If you need to re-pair or pair to multiple umbrellas, refer to steps 4.2 and 4.3.




- Press the "Open" button to open the umbrella
- Press the "Close" button to close the umbrella
- Press the "LED Light" button to turn on the LED light



4. Remote Control

4.2 Pairing Your Remote



1. Pull out the silicone plug in the center of the top of the Control Board. Turn the power switch to on.
NOTE :If the switch is already turned on, please turn it off and then back on. The umbrella will be in pairing mode for 30 seconds after turning the switch to on.
2. Press and hold the UP button "▲" on the remote control until the control board beeps. This will indicate that the remote has successfully paired with the control board.
3. Gently press the silicone cover back into place.

4.3 Pairing Your Remote Control to Multiple Umbrellas

1. A remote control can pair with multiple control boards (umbrellas) at the same time. However, an umbrella can only pair with one remote control. If you pair your umbrella with a new remote control, the previous remote will automatically be unpaired.
2. Select a remote that you would like to pair all the umbrellas with.




4. Remote Control

3. Pull off the silicone cover in the center on the top of each Control Board. Turn the power switches to on. (If the switches are already turned on, please turn it off and then back on. The control board will be in pairing mode for 30 seconds after turning the switch from off to on.)
4. Press and hold the Open button "▲" on the remote control until the control boards beep. This will indicate that the remote has successfully paired with the control boards.
5. Gently press the silicone covers back into place.

4.4 Replacing Remote Battery

A CR2032 3 Volt Lithium Coin Cell Battery x 1
(Included in the remote)




1. Unscrew the back cover of the remote control.
2. Remove the silicone button cover.
3. Unscrew the screws from the board and remove it from the cover.
4. Remove battery.
(TIP : Lift the gold clip holding the battery before removing.)
5. Replace with a new battery, make sure the plus sign (+) is facing up.
6. Put the screws and covers back in place.

5. How to Charge the Umbrella


The Height series umbrella has two charging options available: solar or the USB charging ports.

5.1 Solar Charging



1. With the solar panel and control board installed, put the umbrella in direct sunlight. It takes about 12 hours to fully charge depending on the sunlight intensity.
NOTE: the solar panel and control board must both be fully connected as the solar panel will charge the battery in the control board.

5.2 USB Charging



1. Charge using the micro-USB charging port on the LED light or control board and connect the other end to a power outlet. It may take up to 4 hours to fully charge.




5. How to Charge the Umbrella

5.3 Low Battery Alert:

When the battery level is less than 15%, the control board will beep 4 times twice every 30 minutes, and the LED will no longer be available. When this occurs, charge the control board using the solar panel or via the micro-USB charging ports on the control board or LED Light.

6. Emergency Release Latch


When the umbrella cannot be closed due to a dead battery or for any other reason, you can use the emergency release latch to close the umbrella. However, you must attach the latch back on to open the umbrella.




1. Close the umbrella by turning the latch counterclockwise.

7. Setting Wind Sensor Sensitivity

It is not recommended to change the wind sensor settings unless necessary. Changing this setting will cause the umbrella to close when the wind sensor detects that wind speed.



1. Remove the control board by rotating the control board 60° counterclockwise from the motor until "▽" on the lower side of the control board is aligned with "△" on the upper side of the motor. Remove the control board from the motor.




2. Rotate the wind sensor 60° counterclockwise to align the "▽" on the lower side of the wind sensor with the "△" on the upper side of the control board. Remove the wind sensor from the control board.




7. Setting Wind Sensor Sensitivity


Level 1:
13MPH





Level 2:
17MPH



Level 3:
21MPH



OFF



3. Remove the silicon cover at the top of the control board and switch the power to off. Look for the  symbol at the top of the control board. The switches below will indicate the level the wind sensitivity is on. 1 = 13MPH (default), 2 = 17MPH, 3= 21MPH. Follow the diagram above to adjust to your preferred wind sensitivity. When the wind reaches the wind speed you've set, the umbrella will automatically close. Once finished put the silicon cover back on.

8. Care and Maintenance

Cleaning Your Umbrella

Sunbrella® fabrics are exceptionally easy to clean. We recommend spot cleaning the fabric with a mild soap and solution, then rinse thoroughly and air dry.

Storing Your Umbrella

During extreme temperature and weather, it is recommended to bring your umbrella indoors. This will prevent damages to your umbrella as well as preserve the battery life of the control board.

To store the umbrella, first close the umbrella and keep it in a cool and dry location indoors. This will typically be in your garage or a storage compartment.

IMPORTANT: It is recommended to remove the control board from the top of the umbrella and keep it in an area at room temperature. This will keep the battery from being exposed to cold and hot temperatures which may affect the battery life of the control board. To remove the control board at the top of the umbrella, turn it counterclockwise from the motor. Remove the control board and turn the power switch to off.


When you want to put your umbrella back outside, it is best to charge the control board before operating your umbrella. You can charge the control board using the micro-USB port at the top of the control board. Charging will take up to 4 hours from an empty to a full charge. Alternatively, you can charge using solar by control board and solar panel back onto the umbrella. The umbrella may take up to 12 hours for a full charge.




8. Care and Maintenance

How to Remove the Control Board

1. Remove the control board by rotating the control board 60° counterclockwise. Align “” on the lower side of the control board from “” → “” on the upper side of the motor. Remove the control board from the motor.



2. Remove the wind sensor by rotating the wind sensor 60° counterclockwise. Align the “” on the lower side of the wind sensor “” → “” on the upper side of the control board. Remove the wind sensor from the control board. Remove the silicon cover at the top of the control board and switch the power to off.



9. FAQ

How do I open and close the umbrella?

You can open and close the umbrella using the remote control on the remote. Pressing the “” button will open the umbrella. Pressing the “” will close the umbrella.

I pressed the “” button on the remote but it won't close. What do I do?

There is an emergency release latch attaching the lower hub to the upper hub. You can manually close the umbrella by turning the latch counterclockwise.

How do I turn on the LED light?

You can turn on the LED light using the light button on the remote control.

My umbrella will not open or close. What should I do?

If your umbrella has trouble opening, please check the following

1. Leave the umbrella out for at least a few hours during the daytime to recharge the battery in the sun. You may also charge it using the micro-USB power slot located on the LED light fixture to charge the battery for faster charging.
2. Make sure the remote control has power. If it does not have any power, you will need to replace the battery in the remote control with a CR2032 battery.

Can I wash my umbrella?

If you would like to wash your umbrella canvas, we recommend spot cleaning with water or with a mild soap solution and rinse.

Should I close my umbrella when there are high winds?

It is strongly suggested to close your umbrella if there are high winds to avoid damages to your umbrella. If you have a wind sensor installed on your umbrella, this will detect high winds and automatically close the umbrella, so you don't have to worry about going outside to close it.



10. Warranty

ONE YEAR LIMITED WARRANTY

Subject to the terms, conditions and Disclaimers below, Reflection International Inc. (the "Company") hereby warrants to the original retail purchaser of this product that, should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within one year from the date of original purchase, such defect(s) will be repaired or replaced with a reconditioned product (at the Company's option). This limited warranty is the purchaser's exclusive remedy for any such defect(s). To obtain repairs or replacement within the terms of this warranty,

Please visit www.theabove.com or
Contact us at **1-888-889-8320**
Open Mon-Fri 8am-5pm Pacific Time
Proof of warranty coverage (i.e. – dated bill of sale) is required

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). The opinion of the Company with respect to this matter shall be final.

THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT OF THE PRODUCT AS PROVIDED ABOVE, AND, IN NO EVENT, SHALL COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY THE PURCHASER FOR THE PRODUCT. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES OR LIABILITIES. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, MUST BE BROUGHT WITHIN A PERIOD OF 12 MONTHS FROM THE DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY EXPRESS OR IMPLIED WHATSOEVER.

10. Warranty

No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product. Some jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from jurisdiction to jurisdiction.

WIND DISCLAIMER

Above® Umbrellas are tested for endurance and durability, however the Company strongly recommends that no umbrella should be left in the open position when not in use. Although some of our umbrellas have a feature for automatic closure during high winds, the Company suggests that users still monitor their umbrellas and close them during high wind conditions. Doing so will reduce the risk of damage to your umbrella, surrounding objects and properties. Please use a sufficient weighted base to keep your umbrella secure at all times. Read and follow all steps in the instruction manual.

RUST DISCLAIMER:

Rust is a natural part of the aging process of all steel or iron-based materials and therefore is not considered a defect. Above® Umbrellas are designed for minimum maintenance.

DISCLAIMER:

Above® Umbrella warranties DO NOT COVER damage done to the umbrellas due to abuse or misuse of the products. Above® Umbrella warranties DO NOT COVER any damage occurred as a result of contact with the ground or any other foreign objects due to severe weather events or other extreme acts of nature.

SUNBRELLA® UPHOLSTERY FABRICS

Sunbrella® fabric is warranted only by Sunbrella® subject to Sunbrella®'s limited warranty policy. Sunbrella® Upholstery fabrics is covered by Sunbrella®'s 5-year limited warranty from normal usage and exposure conditions including sunlight, mildew, and atmospheric chemicals when used for appropriate applications. These fabrics covers should withstand significant color fades and material rot under stable conditions. Please contact Sunbrella® or visit <https://www.sunbrella.com/warranty> for more details about Sunbrella®'s fabric policy and replacement.



10. Warranty

SCAN
To Register



**Warranty & Parts
Replacements**

11. Contact Us

Our representatives are here to help. If you have any questions, please free to contact us below.

Website: www.theabove.com

Phone: 1-888-889-8320

Email: service@theabove.com



Serie Altura Sombrilla de Patio Inteligente

Manual de Usuario

En instance de brevet

Información de Seguridad

Lea y comprenda este manual en su totalidad antes de intentar montar, utilizar o instalar el producto.

Mantener alejado de las llamas abiertas o el calor.

Evitar que objetos metálicos o extraños (como polvo) entren en el puerto de carga USB del dispositivo o en cualquier otra ranura. Si un objeto metálico u otro objeto extraño entra en el puerto, retirar los residuos antes de usar el puerto USB.

Solo el personal de servicio autorizado puede realizar operaciones de servicio en el dispositivo. No intentar desarmar o reparar el equipo por sí mismo. Si se efectúan dichas reparaciones, se podría provocar daños en el equipo o lesiones personales.

NO golpear, tirar, pisar, aplicar una presión excesiva ni someter el dispositivo a una descarga física grave.

NO desarmar el dispositivo, ya que esto puede perforar la batería y causar lesiones personales o daños al dispositivo.

Este producto (incluidos los accesorios) tiene imanes. Tragar el imán podría causar lesiones graves, como asfixia o daño intestinal. Si un imán se traga accidentalmente, se debe buscar atención médica inmediata. Mantener este producto fuera del alcance de los niños y otras personas que necesitan vigilancia para evitar la ingestión accidental. El equipo puede ser usado en ciertos ambientes húmedos o polvorrientos, pero hay que tener en cuenta sus límites de clasificación IP, y se deben cumplir los límites de uso regular cuando esté en uso. Las condiciones que exceden los límites de clasificación IP incluyen humedad excesiva, vientos huracanados y ambientes polvorrientos.

NO exponer a temperaturas extremas. No utilizar el equipo a temperaturas inferiores a 32°F o superiores a +113°F.

NO retirar la cubierta de la luz LED cuando esté en uso. Podría dañar la visión.

Al cargar el dispositivo con un cable USB, hay que asegurarse de que no se haya pisado o tropezado. Podría estar dañado o seriamente tensado.

NO intentar reemplazar la batería por sí mismo; podría correr el riesgo de dañarla, provocando sobrecalentamiento, explosión, incendio, daños a la propiedad o lesiones personales. Las baterías del dispositivo deben ser reparadas y recicladas por un socio de servicio autorizado.

Cargar la batería al menos una vez cada tres meses. Un largo periodo sin cargar la batería reducirá su vida útil.



Cumplimiento de la FCC

Declaración de la FCC

Este dispositivo cumple con el apartado 15 de la normativa de la FCC.

La utilización de este dispositivo está sujeta a las dos condiciones siguientes: (1) este dispositivo puede no causar interferencias dañinas y (2) este dispositivo debe aceptar cualquier interferencia, incluyendo las que puedan causar un funcionamiento no deseado.

Nota: este equipo ha sido sometido a las pruebas pertinentes y cumple con los límites establecidos para un dispositivo digital de Clase B, conforme al apartado 15 de la normativa de la FCC. Estos límites se establecen con el fin de brindar una protección razonable frente a interferencias nocivas en un ambiente doméstico. Este equipo genera, utiliza y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias perjudiciales en las comunicaciones por radio.

Sin embargo, no se puede garantizar que dicha interferencia no ocurra en un entorno determinado.

Si este equipo causa interferencia perjudicial a una recepción de radio o televisión, que puede ser determinada apagando y encendiendo el equipo, se recomienda al usuario que intente corregir las interferencias mediante una o varias de las siguientes medidas:

- Reorientación o reubicación de la antena receptora.
- Aumento de la distancia entre el dispositivo y el receptor.
- Conexión del dispositivo a una toma de corriente de un circuito distinto al que está conectado el receptor.
- Consulta al distribuidor o a un técnico de radio/TV con experiencia para obtener ayuda. Para garantizar el cumplimiento continuo, cualquier cambio o modificación no aprobada expresamente por ninguna de las partes está prohibido. El responsable del cumplimiento podría anular la autoridad del usuario para operar el equipo. (Ejemplo: usar solo cables de interfaz blindados cuando se conecte a un ordenador o dispositivos periféricos).

Este equipo cumple con el apartado 15 de la normativa de la FCC. El funcionamiento está sujeto a las dos siguientes condiciones:

1. Este dispositivo puede no causar interferencia dañina, y
2. Este dispositivo debe aceptar cualquier interferencia que reciba, incluida aquella que pueda causar un funcionamiento no deseado del dispositivo.

Declaración de Exposición a la Radiación de la FCC

Este equipo cumple con los límites de exposición a la radiación de la FCC establecidos para un entorno no controlado.

Advertencia de Peligro de Asfixia

⚠ ADVERTENCIA

Este producto contiene una pila de botón o del tipo moneda. Si se traga una pila de botón podría provocar quemaduras químicas internas en tan solo dos horas y hasta la muerte. Desechar inmediatamente las pilas usadas. Mantener las pilas nuevas y usadas fuera del alcance de los niños. Si se piensa que las pilas pueden haber sido tragadas o introducidas en alguna parte del cuerpo, se debe buscar atención médica inmediata.

Advertencia sobre el Reciclaje de Baterías



NO tirar la batería al fuego.



NO tirar la batería a la basura ni a los contenedores de reciclaje



Li-ion

Las baterías de iones de litio (Li-ion) son usadas en este producto. Para reciclarlas, hay que comunicarse con la autoridad local de residuos y obtener información sobre las opciones de reciclaje y/o eliminación disponibles.