


正面
(封面封底)

Candy Con™ Gaming Controller

Bluetooth Wireless Gaming Controller | Model: 402221/402222/402223/402253





Home Button/LED Indicator


Left Joystick [Press Down for L3]

Directional Pad

Select Button (-)

Start Button (+)

Screenshot Button (For Nintendo Switch)



Right Bumper (RB)

Right Trigger (RT)

Programmable Button #2 (M2)

Mode Button (M Button)

Reset

Console Mode Toggle Switch

Left Bumper (LB)

Left Trigger (LT)

Programmable Button #1 (M1)

Charging Port

NEED HELP?

Have any questions or comments about troubleshooting, service, or repair?

Contact Us: www.gamstop.com/contact
1 (800) 883-8895

(1) CONSOLE SETUP

CONNECT WITH PC

Wired Connection

Step 1: Make sure the controller mode is in the 'PC' position.

Step 2: Connect the USB cable to the PC and the other end to the controller port. The controller will automatically establish a connection with the PC.

Wireless Connection

Step 1: Make sure the controller mode is in the 'PC' position and powered off.

Step 2: Insert the USB dongle into an available USB port on the PC.

Step 3: Bring the controller within a 2-foot range of the USB dongle for pairing:

- **First-Time Pairing:** On the dongle, short press the button and let go. The dongle LED light will blink rapidly for 30 seconds indicating it has entered pairing mode and ready to connect. On the controller, press & hold the 'Home Button' for 5 seconds until the controller connects to the dongle.
- **Subsequent Connections:** Briefly press the 'Home Button' on the controller to reconnect to the dongle.

The controller will vibrate upon a successful connection with the dongle.

CONNECT WITH NINTENDO SWITCH™

Wired Connection (via Switch Dock)

Step 1: Turn on the 'Pro Controller Wired Communication' within the Switch console. System Settings > Controllers and Sensors > Pro Controller Wired Communication: On

Step 2: Make sure the controller mode is in the 'NS' position.

Step 3: Connect the USB cable to the Switch dock USB port and the other end to the controller port.

The controller will automatically connect and the LED indicator light will blink slowly.

Wireless Connection

Step 1: Make sure the controller mode is in the 'NS' position.

Step 2: Within the Switch menu, go to Change Grip/Order.

Step 3: Press and hold the 'Home Button' for 3 seconds.

Upon a successful connection, the controller will respond with a vibration and the 'Home Button' will remain a solid color.

4 封底

1 封面

反面

Candy Con™ Gaming Controller

Bluetooth Wireless Gaming Controller | Model: 402221/402222/402223/402253



(2) TURBO MODE

Configurable Buttons

The A/B, X/Y, Left Bump, Right Bump, Left Trigger, and Right Trigger.

Turbo Setup

Hold the 'M Button' and then press any of the configurable buttons once to enable the turbo option.

Repeat this operation to cycle through the Turbo options (Manual, Automatic, Off).

Clear all Turbo Buttons

Hold the 'M Button' and the '(-) Select Button' simultaneously for 2 seconds.

Adjust Turbo Speed

There are three speed options:

- Fast: 20 presses per second
- Medium: 12 presses per second (Default)
- Slow: 5 presses per second

Hold the 'M button' and press up or down on the 'Right Joystick' to select the desired turbo speed.

(3) PROGRAMMABLE BUTTONS

Configurable Buttons

All the buttons (except for the Home, Screenshot, and M Button) including joysticks and the D-pad can be programmed. A total of 30 button strokes can be recorded at one time.

Programming Setup

• Step 1: Hold the 'M Button' for 4 seconds to enter Macro recording mode. The 'Home Button' will turn white followed by a vibration response.

• Step 2: Press a desired sequence of button strokes to be programmed. Up to 30 button presses can be recorded.

• Step 3: Press the 'M1' or 'M2' button to assign it the macro program.

Repeat this operation to switch back the A/B and X/Y mapping.

Macro Infinite Loop

Simultaneously press the 'M Button' and 'M1' or 'M2' button to enter an infinite macro loop action. The 'Home Button' indicator light will start to rapidly flash.

Repeat this operation to turn off the macro infinite loop mode.

Deletes Macro Programming

• Step 1: Press and hold the M Button for 4 seconds to enter Macro recording mode.

• Step 2: Press on the desired 'M1' or 'M2' button to delete the programming.

(4) GYROSCOPE JOYSTICK SETUP

Configurable Buttons

The Left or Right Joystick can be mapped for gyroscope.

Gyroscope Setup

Hold L3 or R3, then double-click the 'M Button'. A successful gyroscope setup will be followed by a vibration response.

Repeat this operation to turn off gyroscope.

Adjust Gyroscope Sensitivity (3 sensitivity levels)

To increase or decrease the gyroscope sensitivity, hold the 'M Button' and press up or down on the D-pad.

Gyroscope Calibration

• Step 1: Make sure the controller is on a flat level surface.

• Step 2: Simultaneously press the Screenshot Button, Right Bumper, and Left Bumper buttons together for 2 seconds.

When calibration is complete, the Home Button will flash red.

(5) REMAP A/B AND X/Y

Hold the 'M Button' and the '(-) Start Button' simultaneously for 3 seconds and then release. The buttons have now switched positions.

Repeat this operation to switch back the A/B and X/Y mapping.

(6) VIBRATION ADJUSTMENT

While holding the 'M Button', press up or down on the left joystick to adjust the vibration intensity. A successful adjustment will result in vibration feedback from the controller.

(9) SENSOR CALIBRATION:

Calibrate the gyro sensor and the accelerometer sensor.

• Step 1: Turn off the controller.

• Step 2: Hold the Home Button, '(-) Select Button', and B Button to enter calibration mode until the LED flashes white to enter calibration mode.

Note: If the Start button isn't pressed, the controller will remain in calibration mode.

• Step 3: Place the controller on a flat surface and press the '(-) Start Button' to calibrate. The white LED will quit flashing when calibration is complete.

(10) RESET:

Factory Reset

Press and hold the L3 and R3 buttons simultaneously for 6 seconds.

Default Settings:

- Vibration Rumble: High
- A/B and X/Y: Reset
- M1/M2 Buttons: Reset
- Linear Mode: Enabled
- Joystick Deadzone: Reset

Hard Reset

Find the small hole labeled 'Reset' on the back side of the controller.

Use a straightened paperclip to press the button. The controller will turn off.

Press the 'Home' button to turn the controller back on.

IMPORTANT:

Before using and operating the device, please read and adhere to the following precautions to ensure optimal device performance and to avoid dangerous or illegal situations:

- **Warning:** Do not use this controller within 6in of a cardiac pacemaker. If you have a pacemaker or other implanted medical device, consult a doctor before using this product.
- **Warning:** Do not use this device and its accessories may contain small parts. Keep them out of reach of children. Children might inadvertently damage the device or its accessories, or swallow small parts, leading to choking or other hazards.
- **Use of this device:** This device and its accessories may contain small parts. Keep them out of reach of children. Children might inadvertently damage the device or its accessories, or swallow small parts, leading to choking or other hazards.
- **Low Battery**
- **(11) POWER SETTINGS:**
- **Standby Mode**
- **Wirelessly Connected:** The controller will automatically power off after 10 minutes of inactivity. Press the 'Home Button' for 1 second to wake up the controller.
- **Standby Mode**
- **Wirelessly Connected:** The controller will automatically power off after 10 minutes of inactivity. Press the 'Home Button' for 1 second to wake up the controller.
- **Low Battery**
- **(12) TROUBLESHOOTING:**
- **Pair the Controller to the Dongle:** If the controller lost its pairing session with the dongle, follow the procedure to restore its connection:
- **Step 1:** Insert the dongle into the PC port.
- **Step 2:** On the controller, long press the 'Home Button' until the LED starts flashing.
- **Step 3:** Press the button on the dongle until it flashes rapidly.
- **The controller will vibrate indicating a successful pair.**
- **Controller Will Not Power On:** If the controller will not turn on, it may be out of battery. Allow the controller to charge for 30 min and try again.
- **Controller Keeps Disconnecting:** If the controller keeps disconnecting, make sure you are close enough to the dongle or the Nintendo Switch™. Make sure there is no obstacles in the way that will impede the connection.
- **How to Fix Controller Joystick Drift:** To fix controller joystick drift, turn the controller off and back on.
- **Controller is Unresponsive:** The controller may need a hard reset. With a paperclip, press the 'Reset' button on the back side of the controller.
- **Do not use this product in any way that is not described in the instructions.**