

2. Installation Steps


You can install this receiver as per the following installation steps. If you have some questions regarding installation, please consult your 08008 DOLCE (08008 36523).

2.1 Connecting the Antenna


Connect one end of the antenna cable to the ANT IN on the back of the receiver and the other end to a terrestrial antenna connection or the jack for the public antenna on the wall.

2.2 Connecting Power cable


Connect the Power cable with the receiver as well as the electric socket.



2.3 Connecting Ethernet Cable



2.4 Connecting Telephone Cable



Installation Guide

CG3000BM

Please read the entire manual thoroughly and retain it for future reference.

Important safety instructions

Cautions



Read this manual carefully before using the product. The cautions described below contain important information about safety. The company will not take any responsibility for accidents or damage resulting from careless handling by the user.

FCC Compliance Statement(Part 15.19 (3))

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement(Part 15.105)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure Statement (MPE)

The antenna(s) must be installed such that a minimum separation distance of at least 20 cm is maintained between the radiator (antenna) and all persons at all times. This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Important Safety Instructions


1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. only use the attachments/accessories specified by the manufacturer.
12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. The device is for indoor use only.

1. Introduction

1.1 Front Panel



1	POWER LED	Inform the power status.
2	DOCSIS LED	Inform the DOCSIS status.
3	WIFI LED	Inform the WiFi status.
4	Ethernet LED	Inform the Ethernet status.
5	VOIP LED	Inform the VOIP status.
6	PLUME LED	Inform the PLUME status.

 The front of the product is subject to change without notice.

1.2 Rear Panel



1	RESET	Gateway system reset.
2	USB	Connects to USB Mass storage device for S/W upgrade.
3	ETHERNET	Connects to Ethernet devices using an RJ45 cable.
4	CABLE IN	Connects to cable outlet, or a cable splitter.
5	TEL	Connects to telephones using an RJ11 cable.
6	POWER	To connect your Gateway to the mains power supply.

 The design of the Front/Rear Panel may be changed without any notice in advance.