


Model: TC512



Smart Toilet Installation Manual

Thank you for choosing our product.
Please read the instructions carefully before installation and keep it available for future maintenance or reference.

Radio frequency specification of remote control

Compliance Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. IC Compliance This device has been tested to meet Industry Canada technical specifications. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: 1. This device may not cause interference. 2. This device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d' Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Warning: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For toilet:

This equipment complies with FCC 's and IC 's RF radiation exposure limits set forth for an uncontrolled environment . The antenna(s) used for this transmitter must be installed and operated to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter. Installers must ensure that 20cm separation distance will be maintained between the device and users. Cet appareil est conforme aux limites d ' exposition au rayonnement RF stipulées par la FCC et l ' IC pour une utilisation dans un environnement non contrôlé. Les antennes utilisées pour cet émetteur doivent être installées et doivent fonctionner à au moins 20 cm de distance des utilisateurs et ne doivent pas être placées près d ' autres antennes ou émetteurs ou fonctionner avec ceux-ci. Les installateurs doivent s ' assurer qu ' une distance de 20 cm sépare l ' appareil des utilisateurs.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IMPORTANT SAFEGUARDS

When using electrical products, especially when children are present, basic safety precautions should always be followed, including the following READ ALL INSTRUCTIONS BEFORE USING

DANGER-To reduce the risk of electrocution:

1. Do not use while bathing.
2. Do not place or store product where it can fall or be pulled into a tub or sink.
3. Do not place in or drop into water or other liquid.
4. Do not reach for a product that has fallen into water, Unplug immediately.

WARNING-To reduce the risk of burns, electrocution, fire, or injury to persons.

1. Close supervision is necessary when this product is used by, on, or near children or on, or near children or invalids.
2. Use this product only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
3. Never operate this product if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the product to a service center for examination and repair.
4. Keep the cord away from heated surfaces.
5. Never block the air openings of the product or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
6. Never use while sleeping or drowsy.
7. Never drop or insert any object into any opening or hose.
8. Do not use outdoors or operate where aerosol(spray)products are being used or where oxygen is being administered.
9. Connect this product to a properly grounded outlet only. See Grounding Instructions.
10. Fill reservoir with water only unless otherwise specified by manufacturer.

SAVE THESE INSTRUCTIONS


GROUNDING INSTRUCTIONS

this product should be grounded in the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This product is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

DANGER — Improper use of the grounding plug can result in a risk of electric shock. If repair or replacement of the cord or plug is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire. Check with a qualified electrician or serviceman if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded.

This product is for use on a nominal 120 V circuit, and has a grounding plug that looks like the plug illustrated in sketch A. A temporary adapter, which looks like the adapter illustrated in sketches B and C, may be used to connect this plug to a 2-pole receptacle as shown in sketch B if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (sketch A) can be installed by a qualified electrician. The green colored rigid ear, lug, and the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by the screw.

Grounding methods



AA200

Function

Function		Model	TC512
Wash	Heating mode	FC Instant heating	●
		Thermostatic cleaning	●
		Rear cleaning	●
		Lady cleaning	●
		Self-clean nozzle	●
		Water temp adjustable	●
		Flow rate adjustable	●
		Cold & hot cleaning	●
		Child model	●
		Oscillating Wash	●
Seat		Seat temp adjustable	●
		Anti-bacterial	●
		Sensor	●
S&C open		Remote S&C open	●
		Auto lid open	●
		Foot sensor lid/Seat	●
Light		Night light	●
		Side light	●
Warm air		Wind temp adjustable	●
		Start key	●
Deodorization		catalyst deodorization	●
Flushing		Off seat auto flush	●
		Power off flush	●
		Foot sensor flush	●
Controller		Side knob	●
		Remote control	●
LED display			●

- Standard configuration
- Optional configuration

Catalogue

● Attention	01	Before using
● Packing List	07	
● Product Description	08	
● Precautions Before Installation	10	Installation and use
● Install The Toilet	11	
● Install Remote Control	13	
● Post-installation Inspection	14	
● Function Description	15	
● Instructions For Remote Control	18	
● Cleaning and Maintenance	20	others
● Troubleshootings	21	
● Technical Parameters	23	
● Product Environmental Information	24	
● Service Card	25	
● Maintenance Record	26	

Before using

Installation and use

others

Attention

1. Please read this manual carefully, so that you can use the product correctly. Please do read through all the precautions listed here, which are important content related to safety.
2. After reading, please keep the manual and warranty card together for future reference.
3. Please fill in the purchasing date and place carefully when purchasing.
4. We are not responsible for accidents or injuries caused by failure to install the product in accordance with the method shown in the manual or failure to use the specified components during the installation.

Identifications



Warning

- Warning Misoperation by ignoring the sign may lead to serious injury or death.



Attention

- Misoperation by ignoring the sign may lead to personal injury or property damage.



Prohibiting

- Do not disassemble or modify this product without authorization.



- Do not soak or spray.



- Class I appliances must be grounded



Compulsory

- Operations must be observed.
- Do not touch with wet hands



- High temperature and flammable materials are prohibited.

Precautions for Us

Prevention of low temperature scald

Anyone (including children) that has physical, perception, or intellectual deficiencies or lacks of experience and common sense (including children) are not allowed to use the product without supervision, in consideration of their limited cognitive abilities and/or lack of necessary knowledge, unless they use the product under the supervision or instruction of the person responsible for the use safety of product. Make ensure children are not allowed to use the equipment alone without authorization and that the product is beyond their reach.


Low-temperature burning may happen, if the heated seat ring is in contact with the skin for a long time. Please set the seat ring temperature at [Low gear] or [Off] before using the product, if you are:

Children and the elderly who cannot adjust the temperature to an appropriate level by themselves;
People who cannot move freely, such as the sick and the disabled;
People who are drowsy and overly tired due to hypnotics (such as sleeping pills, cold medicines, etc.).

Warning

Do not disassemble: Absolutely do not disassemble, repair or transform the product by yourself.


- It may cause fire, electric shock and other accidents.



Prohibited remove

Do not spray: Do not pour water or detergent on the product or power plug.


- It may cause fire, electric shock and other accidents.



Prohibited spray

Ground connection: Please check whether the power socket is grounded.


- Ungrounded may pose an electric shock hazard.



Grounded

Do not touch with wet hands: Do not use wet hands to plug or unplug the power.

- It could cause an electric shock.



Do not touch with wet hands

Do not approach products such as lit cigarettes or burning species.


- It could start a fire.



Prohibited fire

Do not stand heavy objects or people on the cover of the toilet seat, and do not hit the product.


- Product fragmentation can result in personal injury



Forbid


⚠ Warning

Please use tap water or potable well water.




Do not use a socket that is too loose or faulty.

- May cause fire or electric shock.




Do not put fingers or other objects into the nozzle outlet.

- May get electric shock or burn out.




Do not twist or break the inlet pipe.

- Otherwise it may cause a leak.




Do not remove power cord by yourself.

- If the power cord is damaged, it must be replaced by the manufacturer or its maintenance department.



Do not flush other things

- it may lead to clogging of the toilet and overflow of sewage.



⚠ Warning

Do not hit the ceramics with gravity to prevent leakage from damage.




Please use kitchen cleaning agent (neutral) during maintenance.

Do not use the following items:
Cleaning agents for toilets, residential
cleaning agents, volatile agents,
banana oil, etc.




Please insert the power plug into the ac AC120V, 60Hz or above 13A (including) socket.



Do not use at 32°F or below.

- Below 32°F, please refer to the instructions on long-term non-use.




Do not flush newsprint, paper urinal pad, feminine sanitary towel and other articles that are easy to jam into the toilet.

- it may lead to clogging of the toilet and overflow of sewage.




Please avoid direct sunlight.

- the product itself may change color and work incorrectly.




⚠ Warning

In case of thunder, disconnect the plug from the socket.




Do not forcibly close the stool cover and seat ring.

- The product may be damaged.




Please do not use cloth cover or cushion in the circle.

- May cause the seat induction is not good.





When the toilet is blocked, the power must be turned off, in case the sewage does not pass the flushing baffle.



Please do not sit on the seat cover when it is closed, and do not lean on the seat cover when it is open.


- Otherwise it may scratch the seat cover and cause a malfunction.



Do not damage the power cord.

1. No damage, no processing, no heating;
2. do not bend, do not curl, do not pull;
3. Do not place heavy objects on the power cord.


Failure to use the product despite damage may result in fire, electric short circuit and other conditions.



Forbid

This product belongs to electrical products, so do not put it in the place of water or high humidity. Please install it when using it in the bathroom A ventilator or a ventilator outlet maintains good ventilation in the bathroom.

- Otherwise it could lead to fire or electric shock.




Coerce

In case of leakage, close the inlet Angle valve.


Prevent damage caused by freezing.

- Freezing will cause water inlet hose and product internal damage, and then cause water leakage.




The product diagram above is for reference only. The real object shall prevail


Packing List



Product Description - External Dimensions



Product Description - Part Name




Attention before Installation

Confirm

The power cord must be plugged into a socket with safety grounding above 120V, 60Hz and 13A (including).



120V
60Hz
13A Above




Notice

- (1) Do not spray water on the toilet.
- (2) If installed in cold environment, please keep it in a warm room for 2 hours before installation.
- (3) In case of accident or failure to use specified parts during installation due to failure to install according to the method shown in the installation instructions In the event of injury, the company is not responsible.


Install Toilet

Installation Steps


1. Lift up the seat cover, remove the tank inlet pipe, shunt valve connector, water pump connector and foot-induction connector.




2. Unscrew the tank fixing bolt.




3. Remove the inlet hose clamp.




4. Remove the water tank upwards.



5. Confirm the drain holes center and place the installation template as shown in below picture. Trace the toilet profile at backside along the hollowed position on template



6. Install the angle valve on the corresponding position of the wall.



Install Toilet

Installation Steps


7. Place the bolt into the flange notch.




8. Align center the flange and putting sealing sludge.




9. Install the ceramic align its contour line.(Note: the fixing block needs to pass through the hole at the bottom of the ceramic.)



10. Install the shims and locking nut, inverse order put the toilet seat back on.



11. Connect the hose to the inlet valve




12. Drainage inspection
Before applying the glue, please flush it several times to see if there is any leakage in the ceramics and make sure that the ceramics are sealed in place.

Install Remote Control

1. Remote control installation

Installation location: The figure shows the recommended installation location for the remote control. The installation location can be selected according to the actual use at home.




Installation steps:

- ① Drill two holes with a diameter of 6mm on the wall with a depth of more than 45mm, the distance between two holes is the same as the distance between the installation holes of the remote control.
- ② Insert the two expansion pipes in the accessory package into the two holes on the wall respectively.
- ③ Tear the double-sided adhesive tape in the accessory bag on one side, and then paste it on the back of the remote control bracket corresponding position.
- ④ Tear open the other side of double-sided adhesive tape, paste the remote control bracket on the wall, pay attention to align the opening hole of the remote control with the hole on the wall.
- ⑤ Fix the remote control bracket with two screws in the accessories package.
- ⑥ Open remote control battery cover, put the batteries in and put back battery cover.
- ⑦ Place the remote control on the bracket.

2. Match remote control

Under normal circumstances, the remote control can be used normally after battery is set inside it. If the product does not move once it is operated, re-pair the remote control as follows:

- ① Unplug the power plug of the toilet.
- ② Long press the stop button of the remote control until the gear light flashes and then release.
- ③ Make the remote control close to the Toilet, and then plug in the power
- ④ The gear light stops flashing and then stays on, which indicates that the pairing is successful.



Testing after Installation


1. Turn on the angle valve

- Open the valve a little bit, observe whether there is leakage in each installation part.
- After confirming, open the valve completely.




2. Connect Power Supply

- Insert the plug of the power cord into the socket, and the power supply means successful if the indicator light of the plug is on.
- Before use, press the leakage test button, the reset switch will bounce, and the product will be powered off, indicating that the leakage protection function is normal.



3. Product self-inspection

- After connect to the power supply, the product will give a "di" sound prompt, knob lamp and key lamp on indicating the completion of self-test.



4. Product test


Washing test

- After being connected to the power supply, turn on the knob directly and the product will continue to self-clean to prevent spillage.
- You must sit on the seat to use washing function.

Flushing test

- Press the middle button of the knob or the remote control flush button to flush the toilet.

Notes: If there is no flushing, there may be residual air in the water pump, and this key needs to be repeatedly pressed to exhaust the water pump. (Repeating keys requires an interval of more than 40 seconds)




Function Description

Power-on Self-check

1. After power-on, all lights will be on, a "beep" sound will give out and all functions will be recovered to factory setting;
2. Water temp at about 95°F; Seat temp. at about 95°F.


Cleaning Function Description

1. Rear/lady cleanse function



- When seated, rotating the knob forward to start lady cleanse, rotating again to oscillating wash. Stop washing after three minutes.
- When seated, rotating the knob backward to start rear cleanse, rotating again to oscillating wash. Stop washing after three minutes.
- Cleaning mode will stop auto after three minutes and then start flush toilet, then start dryer for four minutes.

2. Self-clean nozzle function



- The nozzle will self-clean when start wash function.
- At the mode of rear/lady wash, rotating the knob oppositely, the spray wand will retract to self-clean and then extend for cleaning.

Both washing and dryer mode can be stopped by pressing the middle key of the knob.

Button



1. Dryer function

Short press , to start the dryer function(seated mode), Pressing again or getting up to stop the dryer function.

2. Flushing function

Short press , to start flushing (not seated)

Other Function Description


Other Functions

1. Water temperature protection function
 - (1) If the water temperature exceeds 109.4°F during use, it will automatically switch to continuous self-cleaning mode and give out an alarm;
 - (2) At this time, reconnect power supply before it can be used normally.

2. Low temperature scald prevention function of seat.

After sitting down, the system will enter the low-temperature scald prevention mode automatically.


3. LED display function



It is the current setting seat temp. When the seat heating is off, it will appear two cross bars.

It is the current setting water temp. When water heating is off, it will appear two cross bars.

If the other icon lights up, it means that the function is enabled, if the product enters standby mode, except ECO, all other icon lights are off.



4. Auto lid open function

- (1) When people walk normally near to the toilet and into the sensor area, the lid open automatically when the machine detects human activity.
- (2) The lid will close automatically after people leave the sensor area by about 2 minutes.


5. Microwave leve adjustment (default state microwave in 1st gear)

Long press the "↖" button of the remote control, enter microwave adjustment mode. The display will show the current microwave level. Then you can press "↖" or "↙" to adjust the microwave level. The system will exit the adjustment mode and store the current setting without any action within 10S.

Notes: Sensor area as below:1st level: 0.2-0.4m ,2nd level: 0.2-0.8m,3rd level: 0.2-1.2m

6. Foot sensor lid/seat open and flushing function


- (1)When both the lid and seat are closed, the lid will open automatically once the user touches the foot sensor area.
- (2) When the lid is open and seat is closed, the seat will open automatically once the user touches the foot sensor area.
- (3) When the lid and seat are open, both of them will close and start flushing once the user touches the foot sensor area.



Other function description

7. Power off flush function

When power off, put the lithium battery into the battery box on the toilet, and then short press the knob to flush.




1. Open the battery compartment with a phillips screwdriver.
2. Remove the battery tray.
3. Load 10 pcs size AA batteries into the battery tray.
4. Put the battery tray back into the compartment.

Kindly Reminder

1. This product is designed for water flushing during a power outage. It is recommended to connect to the main unit when the power is off.
2. Strictly follow the "+" and "-" symbols in the battery compartment when inserting batteries. This battery compartment is a series battery pack and must not have reverse-connected cells, as this may cause battery damage, and in severe cases, safety hazards such as explosion or combustion.
3. Only size AA batteries should be used, and old and new batteries must not be mixed. Different models and brands of batteries must not be mixed. When replacing batteries, all of them should be replaced at the same time.
4. Do not disassemble the battery compartment casually. After replacing the batteries, make sure the battery compartment is securely locked and sealed to prevent bathroom moisture from entering the compartment, which could cause battery corrosion and damage.
5. When replacing batteries, disconnect the battery compartment from the main unit.
6. This product is not rechargeable to avoid danger.

Function Description-Remote Control



1. Short Press , to start the flushing. (In order to ensure the flushing effect and save water, it should wait for 40 seconds before reuse.)

2. Short press to enter the energy-saving mode, and adjust the seat temperature to the lowest level (If the seat temperature is closed before starting the energy-saving mode, it will keep the close after the energy-saving mode). At this time, only the flushing function is available. If the user is seated, it will temporarily exit the energy-saving mode. It will automatically return to the energy-saving mode after the user leaves. Press this button again to exit the energy-saving mode.

3. Short Press , to set the light according to the following cycle.



4. After sitting down, press or to turn on the rear wash or lady wash function, and press again to turn on oscillating wash function.

During the washing process:

• Short press , to set the water temperature according to the following cycle.



• Nozzle position can be adjusted by or , with five gears adjustable.

• The washing water volume can be adjusted by or , four levels adjustable.

• Short press "SPA" to change cleaning mode.

• During washing process, press or get up directly to finish washing.

5. After sitting down, short press to turn on the warm air function.

• In drying mode, Press , to set the warm air temperature according to the following cycle.



Function Description-Remote Control

6.Short press  to set the seat ring temperature circularly:



7.Different functions level with different light color, unlight/blue/pink/red is for off/low/middle/high.

8.When the top lid is closed, Press  the top lid will open.

When the top lid is open and the seat ring is closed, press  the seat ring will open. If the person is seated, no action is performed.

When the top lid and seat ring are opened, press this button the top lid/seat ring is closed.

9.Press the  key on the remote control to start the nozzle cleaning. The nozzle start self-clean first and then extend. (Keep 15 minutes, the nozzle will retract automatically.)

10.Short press  to turn on the deodorization function, press this button again to cycle through the gear settings, there are a total of four gears.

Long press  to turn on/off the automatic deodorization function.

11.Children's cleaning function.

Long press  to enter children's cleaning mode, the water temperature, wind temperature, and seat temperature are all in the middle range. The nozzle position is at the front end. The cleaning water volume is at the lowest range. Press  or finish cleaning can exit children's cleaning mode.

12.Description of keys for hidden functions.

Long press , turn on/off Prompt Sound.

Long press , turn on/off Automatic Flip.

Long press , turn on/off Foot Touch Sensing .

Long press , turn on/off Off Seat Automatic Flushing.

Cleaning and Maintenance

1.Maintenance of product surface and ceramics.

The detachable accessories can be removed before maintenance

Note before maintenance:


(1) Make sure the power supply is disconnected.

(2) Do not let water enter the product during the maintenance process.

(3) Be sure to wipe off the detergent after cleaning to avoid its residue at the gap between the main body and the toilet.


● Product surface cleaning

Wet the soft cloth with water, wring it, and then wipe the product. If the product is dirty, you can use a soft cloth dipped a little of diluted neutral detergent to wipe it, and then use a clean damp cloth to wipe it clean.



2.Maintenance of the nozzle

- ① Press the  key on the remote control to start the nozzle cleaning. The nozzle start self-clean first and then extend. (Keep 15 minutes, the nozzle will retract automatically.).
- ② Dip a soft cloth, sponge, or small brush in neutral detergent, then hold the spray wand, wipe it and the nozzle.
- ③ Press any key to exit the mode after cleaning.



3.Maintenance of valve

1. Turn off the angle valve and rotate the filter screen down with a straight screwdriver.
2. Use a small brush to scrub the filter screen, and flush away the internal silt with clean water.
3. Reinstall the filter on to the angle valve and tighten it.



Troubleshootings

Failures	Confirmation	Solution
The product does not work.	<ul style="list-style-type: none"> Confirm whether cloth covers, cushions, etc. are used on the seat sensing area. Confirm whether there is a power outage. Confirm whether the socket is loose or in poor contact Confirm whether there is electricity leakage (the plug indicator light is off) 	<ul style="list-style-type: none"> Please remove cloth covers, cushions and other items. Please wait for the power supply recovery. Please plug in to ensure good power supply. Unplug the power plug first, plug it in again later, and press the reset switch of the leakage protection plug. If it still does not work, please contact after-sales personnel for maintenance.
No water when turning on the knob.	<ul style="list-style-type: none"> Confirm whether the water supply is cut off. Confirm whether the water inlet valve is blocked by dirt. Confirm whether the water supply hose is bent and blocked. 	<ul style="list-style-type: none"> Please wait for the water supply recovery. Open the water inlet angle valve. Straighten the bent part of the water supply hose.
The spray rod does not extend after turning on the knob.	<ul style="list-style-type: none"> No one is sitting on the seat . Someone is sitting on the seat but not in the sensing area. 	<ul style="list-style-type: none"> Sit on the sensing area of the seat (with a beep prompt), and then turn on the knob again to flush normally.
Water drips slowly from the water outlet without an alarm sound when it is not used.	Solenoid valve fails.	<ul style="list-style-type: none"> Contact after-sales personnel for repairing.
The nozzle extends too slowly.	Self-clean before cleaning	<ul style="list-style-type: none"> The nozzle stretches out and starts cleaning in 7s.
No enough water.	The quantity of impurities in the water is so significant that it has blocked filter.	<ul style="list-style-type: none"> Clean the filtermesh; a filter is recommended.
While someone sitting on and washing, there is continuously alarm and dripping. The remote buttons are invalid at the same time.	Trigger safety protection or hardware failure.	<ul style="list-style-type: none"> Stop using and reconnect to the power supply. If fault still remains, please contact after-sales personnel for replacement.
Low water temperature.	The water temperature is set to a lower level.	<ul style="list-style-type: none"> Set water temperature to a higher level.

Troubleshootings

Failures	Confirmation	Solution
The seat is not heated	<ul style="list-style-type: none"> Confirm whether the seat temperature is set in low level or closed state. Confirm whether there is a power outage. 	<ul style="list-style-type: none"> Reset the seat temperature through the seat temperature setting button. Please wait for the power supply recovery
No response when pressing the warm air button.	The Warm air function needs to be activated after sitting down.	<ul style="list-style-type: none"> Start the warm air after sitting down.
No wind temperature after the warm air is turned on.	<ul style="list-style-type: none"> Thermostat is disconnected. Fuse is melted. 	<ul style="list-style-type: none"> Reconnect power supply after disconnection. Contact after-sales personnel for repairing.
Toilet light and knob light don't work.	<ul style="list-style-type: none"> Confirm whether the night light/knob light is turned off. The fault still exists after reconnect power supply. 	<ul style="list-style-type: none"> Long press the knob button to turn on the night light/knob light. Contact after-sales personnel for repairing.
Angle valve is closed.		<ul style="list-style-type: none"> Open the angle valve.
The filter is blocked.		<ul style="list-style-type: none"> Refer to the previous description for cleaning and maintenance.
The toilet does not flush.		<ul style="list-style-type: none"> Drain the air from water pump by repeatedly press the middle button of the knob or the water flush key on remote control (notes: Each operation requires an interval of 40 seconds)
The toilet doesn't flush properly.		<ul style="list-style-type: none"> Refer to the previous description for cleaning and maintenance.
The filter is blocked.		

Product Technical Parameters

Items	SL-613	
Rated Voltage	120V ~ , 60Hz	
Rated Power*	1050W	
Max. Instantaneous Power	1350W	
Power Cord Length	about 1.1m	
Water Supply Pressure	0.1 ~ 0.75MPa (static pressure)	
Water Supply Temperature	41~95°F	
Waterproof Level	IPX4	
Toilet Flush	≤4.8L	
Cleaning Device	Water volume adjustment	4 gears in total
	Water temperature adjustment	4 gears:about 91/95/99°F/off
	Heating method	Instant heating
	Anti-backflow device	Anti-siphon valve
	Safety equipment	Double thermostat + pressure relief valve
Seat Ring Heating	Heater power	50W
	Safety equipment	Thermostat + fuse
	Surface temperature	4 gears:about 91/95/99°F/off
Warm Air	Heater power	300W
	Safety equipment	Thermostat + fuse
	Warm air temperature	4 gears:about 91/99/109°F/off(Test at an ambient temperature of 73±3.6°F)
Deodorization	Deodorization method	Available
Others	Antibacterial material	Seat ring
	Low temperature scald protection	Available
	Prompt for abnormalities	Alarm sound
	Seat sensing	Available
	Lighting control	Available

Rated power: This product is powered on and turned on at an ambient temperature of 73±3.6°F, an inlet water static pressure of 0.18±0.02MPa, and an inlet water temperature of 59±1.8°F.
 Adjust the water temperature and seat temperature to higher levels and turn on hip cleaning function and test according to the maximum flow rate (the reference flow rate is about 600ml/min).
 Measure the average power of the product working for a cleaning cycle (3 min) continuously and stably.

Product Environmental information

Part name	Harmful substances					
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
PCBA	X	O	O	O	O	O
Plastic parts	O	O	O	O	X	X
The motor	X	O	O	X	O	O
Others	X	O	O	O	O	O

This form is prepared according to the provisions of SJ/T11364

O : Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in CB/T26572

X : Indicates that the content of the hazardous substance in all homogeneous materials of the component exceeds the limit specified by CB/T26572



The number in this label indicates that the environmental protection period of the product in normal use is 10 years

Warranty Card

To Dear Customers:

Thank you for choosing our product! If any problem occurs during use, please simply remove and check the problems pursuant to the user's manual. When you cannot remove such problems, contact your local supplier or call the service hotline.

I. Information:

Customer information	Customer name			
	Address			
	TEL			
Dealer information				
	TEL			
Model			Product series number	
Purchase date	Y	M	D	Warranty period One-year free warranty since the purchase date

II. Notes to warranty card:

1. Please complete the warranty card.
2. Warranty cards and invoices are important for the warranty service. If the product failure occurs during warranty period, please show the warranty card and the invoice when the dealer or after-sales service personnel of the Company provide on-site maintenance and repair.
3. The warranty card cannot be reissued, please keep it properly.

III. Rules on free maintenance

During the warranty period, the Company will provide repair free of charge according to the use instructions, precautions for normal use.

IV. Paid maintenance is required in the following circumstances that do not fall within the scope of free maintenance:

1. Out of warranty.
2. The valid invoice and warranty card cannot be provided during the warranty period.
3. Failure or damage caused by transportation, collision after purchase.
4. Product damage during abnormal use, failure and damage during the warranty period caused by human factors or natural disasters, such as fire, earthquake, flood, lightning or environmental pollution, etc.
5. Failure or damage caused by unauthorized disassembly, modification or maintenance due to user's cause or responsibility.
6. Failure or damage caused by violation of maintenance regulations in use, such as improper use of cleaning agent or wiping and maintenance methods not compliant with maintenance requirements.
7. The consumable items (such as sealing rings, etc.) or products have failed or damaged due to sand and impurities.
8. Conduct the secondary transfer according to the customer's requirements.

Maintenance record



