

## [CLI]

Firmware -> info

```
AVS(firmware)#
Help:
  info - Show the current firmware status
  download - Download the firmware file from the configured server
  write - Write the firmware file into image bank
  primary - Set the firmware image as primary
  file - Sub menu to manage the firmware file
  server - Sub menu to configure the firmware file servers
  .. - Navigate up one category
  exit - Exit Command line interface

AVS(firmware)#
Current firmware info:
  Image number  Active  Primary  Version  Size  Checksum  Created time
  1            Inactive  Backup   0.2.0.1658469850  119.0M  f0199c9f484d8b6340d6f170a0b73735  Thu 2022-07-21 23:04:52 PDT
  2            Active   Primary  0.2.0.1660432612  119.6M  feb9b1487fc83929ba359525cbc8462  Sat 2022-08-13 16:17:33 PDT
```

```

AVS(firmware)#
Help:
  info - Show the current firmware status
  download - Download the firmware file from the configured server
    write - Write the firmware file into image bank
  primary - Set the firmware image as primary
    file - Sub menu to manage the firmware file
  server - Sub menu to configure the firmware file servers
    .. - Navigate up one category
  exit - Exit Command line interface

AVS(firmware)# info

Current firmware info:


| Image number | Active   | Primary | Version          | Size   | Checksum                         | Created time                |
|--------------|----------|---------|------------------|--------|----------------------------------|-----------------------------|
| 1            | Inactive | Backup  | 0.2.0.1658469850 | 119.0M | f0199c9f484d8b6340d6f170a0b73735 | Thu 2022-07-21 23:04:52 PDT |
| 2            | Active   | Primary | 0.2.0.1660432612 | 119.6M | feb9b1487fc83929ba359525cbc8462  | Sat 2022-08-13 16:17:33 PDT |



AVS(firmware)# primary 1

```

## Upload/Download the firmware file to the device

There are two mechanisms you can get the firmware image file to be loaded into your WaveTunnel device. You can set up the Http,FTP or TFTP server and put the image file on it. Then, you can download the image file from the server through WEB GUI, Mobile App or CLI to your device. Or you can directly upload the firmware image file from your local laptop through the WEB GUI to the device.

For the download mechanism, you need to put the server address, server port , the file path of the image file, user name(optional),password(optional) before starting the download operation.

### [WEB GUI]

#### Operation -> Firmware Update -> Step 1

Input the server setting and click download button

Step1: Download/Upload the firmware file

Get the firmware from:

HTTP  FTP  TFTP  Local File

Server address:  

Server port:  

File path:  

User name:

User password:

Select the firmware image file from your local laptop and then click “upload” button.

Step1: Download/Upload the firmware file

Get the firmware  HTTP  FTP  TFTP  Local File from:


To upload the firmware file, click [Choose File] to select the file and click [Upload] to confirm.

No file chosen

### [Mobile App]

#### Settings -> Firmware -> Download

Input the server setting and click download button



### [CLI]

#### Firmware -> Server

Input the server configurations in this category.

```
AVS(firmware-server)#
Help:
    ll - List the firmware server setting
    set - Set the attribute of the firmware file servers
    save - Save the changed attributes of the file servers
        .. - Navigate up one category
    exit - Exit Command line interface

AVS(firmware-server)#
Firmware file server settings


| Description               | Attribute Name | Current Value  |
|---------------------------|----------------|----------------|
| Server type               | serverType     | HTTP           |
| HTTP server address       | httpServer     | 192.168.31.252 |
| HTTP server port          | httpPort       | 8080           |
| HTTP remote image path    | httpPath       | /avs_nor0.bin  |
| HTTP server user name     | httpUser       |                |
| HTTP server user password | httpPassword   |                |
| FTP server address        | ftpServer      | 192.168.31.252 |
| FTP server port           | ftpPort        | 21             |
| FTP remote image path     | ftpPath        | /avs_nor0.bin  |
| FTP server user name      | ftpUser        |                |
| FTP server user password  | ftpPassword    |                |
| TFTP server address       | tftpServer     | 192.168.31.252 |
| TFTP server port          | tftpPort       | 69             |
| TFTP remote image path    | tftpPath       | /avs_nor0.bin  |


```

## Firmware -> download

Input the “download” command to download the file

```
AVS(firmware-server)# ..  
AVS(firmware)# ll  
Unknown Command: ll  
  
Help:  
    info - Show the current firmware status  
download - Download the firmware file from the configured server  
    write - Write the firmware file into image bank  
primary - Set the firmware image as primary  
    file - Sub menu to manage the firmware file  
server - Sub menu to configure the firmware file servers  
  
AVS(firmware)# download █
```

## Update the firmware

Once the firmware image file is downloaded or uploaded to the WaveTunnel device. You can see the image file name on the page. Clicking the “Write image” button to update the firmware to the WaveTunnel device. Clicking the “Delete image” button to discard the uploaded image.


There are two options on the update page.

[Set as primary] => The updated image will set to primary after system reboot

[Reboot after update] => The WaveTunnel will be rebooted automatically after the firmware update operation. Un-selected it to delay the reboot if you want to do it later. But the image will only take effect after the system reboot with the primary flag set.

### [WEB GUI]

Operation -> Firmware Update -> Step 2



Step 2: Write the firmware image to device

File Name: avslImage-ls1043ardb.bin (119.6M)


Set as primary

Reboot after update

Write Image Delete Image

### [Mobile App]

Settings -> Firmware -> Update



## [CLI]

### Firmware -> File -> Info

To check if the firmware image file is existed or not.


```
AVS(firmware)#  
Help:  
  info - Show the current firmware status  
  download - Download the firmware file from the configured server  
  write - Write the firmware file into image bank  
  primary - Set the firmware image as primary  
    file - Sub menu to manage the firmware file  
    server - Sub menu to configure the firmware file servers  
    .. - Navigate up one category  
  exit - Exit Command line interface  
  
AVS(firmware)# file  
AVS(firmware-file)  
Help:  
  info - Show information of the downloaded firmware file  
  verify - Verify the the downloaded firmware file  
  delete - Delete the downloaded firmware file  
  .. - Navigate up one category  
  exit - Exit Command line interface  
  
AVS(firmware-file)# info  
Available firmware image file:  


| Name                     | Size   |
|--------------------------|--------|
| avslImage-ls1043ardb.bin | 119.6M |

  
AVS(firmware-file)#
```

## Firmware - > Write

Type “write” command to trigger the firmware update operation.



```
AVS(firmware)#
Help:
    info - Show the current firmware status
    download - Download the firmware file from the configured server
    write - Write the firmware file into image bank
    primary - Set the firmware image as primary
    file - Sub menu to manage the firmware file
    server - Sub menu to configure the firmware file servers
    .. - Navigate up one category
    exit - Exit Command line interface

AVS(firmware)# write
```

## Configure the WaveTunnel device

Once the Wave tunnel connections are established, you should not change the setting in most scenarios. But if you do need to modify the configuration, here are the pages for you to do it.

### Update the WaveTunnel Configurations

#### General WaveTunnel settings

The General Node settings, you can change the label and the antenna direction. For the antenna direction, you will need to adjust the position of the nodes after you make the changes. We suggest you not change it if there is no strong requirement.

#### The Downstream tunnel settings.

You can enable/disable the downstream connection or change the channel value. If you disable the connection, it will cause the connection to be lost in the network. We suggest disable only when there is no downstream node connected. For the channel setting, please ensure the channel setting is not identical to the neighboring device.

#### The Upstream tunnel settings.

You can enable/disable the upstream connection or change the connection name. If you disable the connection, it will cause the connection to be lost in the network. We suggest disable only when there is no upstream node connected or you want to switch the upstream connection to another device.

#### [WEB GUI]

Configuration -> Network -> Wave Tunnel

Wave Tunnel settings

Network Id

newair8 ✓

Node Label

root ✓

Antenna Direction

Default  Flipped

Save  Cancel

Downstream Tunnel settings

Connection

Enabled  Disable

Channel

1

Please set the channel

Save  Cancel

Upstream Tunnel settings

Connection


Enabled  Disable

Connection Name


avb\_newair8\_06 ✓

Save  Cancel


**[Mobile App]**  
**Settings -> Wave Tunnel settings**



**Settings -> Downstream Tunnel settings**



**Settings -> Upstream Tunnel settings**



## [CLI]

### Config -> wavetunnel

```
AVS(config)#  
AVS(config)# wavetunnel  
AVS(config-wavetunnel)#  
Help:  
    device - Sub menu to configure the device settings  
    ethernet - Sub menu to configure the ethernet settings  
    wavetunnel - Sub menu to configure the wave tunnel settings  
        wifi - Sub menu to configure the management WIFI settings  
        persist - Save the running configuration permanently  
        autoSave - Set if persist the running configurations automatically  
        user - Sub menu to configure the User settings  
        .. - Navigate up one category  
    exit - Exit Command line interface  
  
AVS(config-wavetunnel)# downstream  
AVS(config-wavetunnel)# node  
AVS(config-wavetunnel)# upstream  
AVS(config-wavetunnel)# ..  
AVS(config-wavetunnel)# exit
```

## Config -> wavetunnel -> node

```
AVS(config-wavetunnel)# node
Wave tunnel node settings
+-----+-----+-----+
| Description | Attribute Name | Current Value |
+-----+-----+-----+
| Node Type | type | Root Node |
| Network Id | networkId | newair8 |
| Node Id | nodeId | 1 |
| Antenna direction | antennaDirection | Default direction |
| Node label | label | root |
+-----+-----+-----+
AVS(config-wavetunnel-node)# set networkId test
Set networkId to test

Wave tunnel node settings
+-----+-----+-----+-----+
| Description | Attribute Name | Current Value | Modified Value |
+-----+-----+-----+-----+
| Node Type | type | Root Node | |
| Network Id | networkId | newair8 | test |
| Node Id | nodeId | 1 | |
| Antenna direction | antennaDirection | Default direction | |
| Node label | label | root | |
+-----+-----+-----+-----+
AVS(config-wavetunnel-node)# save
```

## Config -> wavetunnel -> downstream