

# SENSE BIKE LIGHT

## USER MANUAL

S500CF

### Package Contents

- ◆ Bike Light
- ◆ Type-C Charger Cable
- ◆ Fixing Mount
- ◆ User Manual

### Features

1. Powered by 21700 rechargeable Li-on battery, 3.7V 4500mAh ;
2. Three brightness levels;
3. Three Mode LED Indicator displays remaining battery capacity;
4. Charging input: Type C 5V2.0A
5. Voltage output: USB 5V2.0A
6. Locate with Apple Find My App
7. The red indicator light will turn on when the power is lower than 20%.
8. When the power is lower than 200mAh, the output will be turned off, and the remaining power is reserved to supply the Find My module.

### Technical Parameters

S500CF	Strong Light Mode	Weak Light Mode	Flashing Mode
Output	500lm	250lm	/
Run Time	4H	8H	/
Waterproof	IPx5		
Net Weight	142g		
Dimensions	40*38*124mm		
Battery	3.7V 4500mAh		

### Operations

- 1.Long press the battery button (2s) to turn on/off the bike light.
- 2.Press the battery button repeatedly to change brightness mode to strong/weak/flashing.
- 3.Press the FM button once to turn it on, it should beep once indicating it is powered on; To power it off, hold the same button for at least 3 seconds, you will hear 2 beeps indicating powered off.

Find My Button

### Battery Capacity Indicator

- ◆ Turn Off state: double press the battery button
- ◆ Red light flashes three times indicate: 61%-100% battery capacity
- ◆ Red light flashes two times indicate: 31%-60% battery capacity
- ◆ Red light flashes one time indicate: 0%-30% battery capacity

Once	Twice	Three times
●	● ●	● ● ●
0~30%	31~60%	61~100%

### Charging

- ◆ Red light: charging
- ◆ No light: fully charged







### Add Your Bike Light

1. Start the App
  - Open Find My app on your supported iPhone or iPad
  - Allow notifications from the app
2. Connect your Bike Light
  - Power on your Bike Light
  - Tap "+" then "Add Other Item"
  - Once your Bike Light is located, tap "Connect"
  - Choose a recognizable name and emoji for your Bike Light and tap "Continue"
  - Find My will ask for confirmation to add your Bike Light to your apple ID - tap "Continue"
  - Tap "Finish" and your Bike Light will be set up

### Locate Your Bike Light

1. Find Bike Light when it is Nearby
  - Open the Find My app and select the "Items" tab or open the Find Items app on your Apple Watch
  - Tap on your Bike Light from the list
  - Tap "Play Sound" to make your Bike Light beep
  - Tap "Stop Sound" to stop the beeps once you find your item
2. Find Bike Light's Last Known Location
  - Open the Find My app and select the "Items" tab or open the Find Items app on your Apple Watch
  - Tap on your Bike Light from the list
  - Our Bike Light's last known location will appear on the map
  - To navigate to that last known location, tap "Directions" to open the Maps app

2

<h3>How to Pair Your Bike Light When Out of Range</h3> <ol style="list-style-type: none"> <li>Enabling "Notify When Left Behind" <ul style="list-style-type: none"> <li>Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch</li> <li>Tap on your Bike Light from the list</li> <li>Under "Notifications", enable the "Notify When Left Behind"</li> <li>You will receive a notification when you leave your Bike Light behind and it's no longer in range of your device</li> </ul> </li> <li>Enabling "Notify When Found" <ul style="list-style-type: none"> <li>Under "Notifications", enable the "Notify When Found"</li> <li>When your Bike Light is seen by another Find My enabled device, you will receive a notification of its updated location</li> <li>Note: "Notify When Found" can only be activated when your Bike Light is out of range</li> </ul> </li> </ol>	<h3>The Fine Print</h3> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>Reorient or relocate the receiving antenna.</li> <li>Increase the separation between the equipment and receiver.</li> <li>Connect the equipment into an outlet on a circuit different from that which the receiver is connected.</li> <li>Consult the dealer or an experienced radio/TV technician for help.</li> </ul> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>
<h3>When Your Bike Light is Lost</h3> <ol style="list-style-type: none"> <li>Enabling Lost Mode <ul style="list-style-type: none"> <li>Open the Find My app and select the "Items" tab or open the Find Items app on your Apple Watch</li> <li>Tap on your Bike Light from the list</li> <li>Under "Lost Mode", tap "Enable"</li> <li>A screen detailing Lost Mode will pop up, tap "Continue"</li> <li>Enter your phone number or email address and tap "Next"</li> <li>You may enter a message that will be shared with the person that finds your item</li> <li>Tap "Activate" to enable "Lost Mode"</li> <li>Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled</li> <li>Note: When "Lost Mode" is enabled, your Bike Light is locked and cannot be paired to a new device</li> </ul> </li> </ol>	<p>Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. ©Apple, Apple Watch, watchOS, iPad, iPadOS, iPod touch, Mac, and macOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.</p>
<h3>Resetting Your Bike Light</h3> <ol style="list-style-type: none"> <li>Remove the Bike Light from the Find My app <ul style="list-style-type: none"> <li>Open Find My app and select the "Items" tab</li> <li>Tap on your Bike Light from the list</li> <li>Please ensure "Lost Mode" is disabled</li> <li>Scroll to the bottom of the screen and tap "Remove Item"</li> <li>A summary will open, tap "Remove" to confirm</li> </ul> </li> <li>Factory Reset your Bike Light <ul style="list-style-type: none"> <li>After successfully removing the Bike Light from Find My app, restart the FM button, then press the FM button four times rapidly, and then hold it a fifth time until you hear a ringing chime.</li> <li>The Bike Light is now reset and ready to be paired with a new device</li> </ul> </li> </ol>	<div> <div>  <p>Company Address: No. 8 Shengding Street, ChangAn Town, Dongguan City, Guangdong, P.R.China</p> </div> <div>  <div>  <div>    </div> </div> </div> </div>

## 风琴折 (2折)