

Q350

User manual

Please read it carefully and keep it properly.



Fast recognition



Various output interface



Suitable for access control scenario



Disclaimer

Before using the product, please read all the contents in this Product Manual carefully to ensure the safe and effective use of the product. Do not disassemble the product or tear up the seal on the device by yourself, or Suzhou CoolCode Technology Co., Ltd. will not be responsible for the warranty or replacement of the product.

The pictures in this manual are for reference only. If any individual pictures do not match the actual product, the actual product shall prevail. For the upgrade and update of this product, Suzhou CoolCode Technology Co., Ltd. reserves the right to modify the document at any time without notice.

Use of this product is at the user's own risk. To the maximum extent permitted by applicable law, damages and risks arising from the use or inability to use this product, including but not limited to direct or indirect personal damage, loss of commercial profits, Suzhou CoolCode Technology Co., Ltd. will not bear any responsibility for trade interruption, loss of business information or any other economic loss.

All rights of interpretation and modification of this manual belong to Suzhou CoolCode Technology Co., Ltd.

Edithistory

Changdate	Version	Description	Responsible
2022.2.24	V1.0	Initialversion	

Catalog

Disclaimer	2
1. Preface	5
1.1. Product introduction	5
1.2. Product features	5
2. Product appearance	6
2.1.1. Overall introduction	6
2.1.2. Product size chart	7
3. Product parameters	8
3.1. General parameters	8
3.2. Recognition parameters	9
3.3. Electric parameters	11
3.4. Working environment	11
4. Interface definition	12
5. Device configuration	18
6. Mounting method	22
7. Attention	23
8. Contact info	24

1. Preface

Thanks for using the Q350 QR code reader, Reading this manual carefully can help you understand the function and features of this device, and quickly master the use and installation of the device.

1.1. Product introduction

Q350 QR code reader was specially designed for access control scenario, which has various output interface, including TTL, Wiegand, RS485, RS232, Ethernet and relay, suitable for gate, access control and other scenes.

1.2. Product feature


- 1, Scan code& swipe card all in one.
- 2, Fast recognition speed, high accuracy, 0.1 second the fastest.
- 3, Easy to operate, humanized configuration tool, more convenient to config the reader.

2. Product appearance

2.1.1. OVERALL INTRODUCTION



2.1.2. PRODUCT SIZE



3. Product parameters

3.1. General parameters

General parameters	
Output interface	RS485, RS232, TTL, Wiegand, Ethernet
Indicating method	Red, green, white light indicator Buzzer
Imaging sensor	300,000 pixel CMOS sensor
Max resolution	640*480
Mounting method	Embedded mounting
Size	75mm*65mm*35.10mm

3.2. Reading parameter

QR code recognition parameter		
Symbologies	QR, PDF417, CODE39, CODE93, CODE128, ISBN10, ITF, EAN13, DATABAR, aztec etc.	
Supported decoding	Mobile QR code and paper QR code	
DOF	0mm~62.4mm(QRCODE 15mil)	
Reading accuracy	≥8mil	
Reading speed	100ms per time(average), support reading continuously	
Reading direction	Ethernet	Tilt ± 62.3 ° Rotation ± 360 ° Deflection ± 65.2 ° (15milQR)
	RS232, RS485, Wiegand, TTL	Tilt ± 52.6 ° Rotation ± 360 ° Deflection ± 48.6 ° (15milQR)
FOV	Ethernet	86.2° (15milQR)
	RS232, RS485, Wiegand, TTL	73.5° (15milQR)
RFID reading parameter		
Supportedcards	ISO 14443A, ISO 14443B protocol cards, ID card (only physical card number)	
Reading method	Read UID, read and write M1 card sector	

Working frequency	13. 56MHz
Distance	<5cm

3.3. Electric parameters

The power input can be provided only when the device is connected properly. If the device is plugged or unplugged while the cable is live (hot plugging), its electronic components will be damaged. Make sure that the power is turned off when plugging and unplugging the cable.


Electric parameters		
Working voltage	RS232, RS485, Wiegand, TTL	DC 5-15V
	Ethernet	DC 12-24V
Working current	RS232, RS485, Wiegand, TTL	156.9mA (5V typical value)
	Ethernet	92mA (5V typical value)
Power consumption	RS232, RS485, Wiegand, TTL	784.5mW (5V typical value)
	Ethernet	1104mW (5V typical value)

3.4. Working environment

Working environment	
ESD protection	±8kV (Air discharge) , ±4kV (Contact discharge)
Working temp	-20° C-70° C
Storage temp	-40° C-80° C
RH	5%-95% (No condensation) (environment temperature30°C)
Ambient light	0-80000Lux (Non direct sunlight)


4. Interface definition

4.1. RS232, RS485 Version




Serial number	Definition	Description	
1	VCC	Positive power supply	
2	GND	Negative power supply	
3	232RX/485A	232Version	Data receiving end of code scanner
		485Version	485 _A cable
4	232TX/485B	232Version	Data sending end of code scanner
		485Version	485 _B cable

4.2. Wiegand&TTL Version



Serial number	Definition	Description	
4	VCC	Positive power supply	
3	GND	Negative power supply	
2	TTLTX/D1	TTL	Data sending end of code scanner
		Wiegand	Wiegand 1
1	TTLRX/D0	TTL	Data receiving end of code scanner
		Wiegand	Wiegand 0


4.3. Ethernet Version



Serial number	Definition	Description
1	COM	Relay common terminal
2	NO	Relay normally open end
3	VCC	Positive power supply
4	GND	Negative power supply
5	TX+	Data transmission positive end (568B network cable pin1 orange and white)
6	TX-	Data transmission negative end (568B network cable pin2-orange)
7	RX+	Data receiving positive end (568B network cable pin3 green and white)
8	RX-	Data receiving negative end (568B network cable

		pin6-green)
--	--	-------------

4.4. Ethernet+Wiegand Version



RJ45 port connect to the network cable, 5pin and 4Pin screws interface descriptions are as follows:

5PIN interface

Serial number	Definition	Description
1	NC	Normally closed end of relay
2	COM	Relay common terminal
3	NO	Relay normally open end
4	VCC	Positive power supply
5	GND	Negative power supply

4PINinterface

Serial number	Definition	Description
1	MC	Door magnetic signal input terminal
2	GND	
3	D0	Wiegand 0
4	D1	Wiegand 1

5. Device configuration


Use the Vguang config tool to configure the device. Open the following configuration tools (available from the download center on the official website)



5.1 config tool

Config the device as the step shows, the example are showing 485 version reader.

Step 1, Select the model number Q350 (Select M350 in the configuration tool) 。



Step 2, Select the output interface, and config the corresponding serial parameters.

The screenshot shows the VguangConfigV2.3.19 software interface. At the top, there is a 'Set Password:' field with the value '1234567887654321' and two buttons: '→ Next' and '→ Main'. Below this is the 'Work mode' section with two radio buttons: '● Ordinary' (selected) and '○ Develop'. The 'Output' section has four radio buttons: '● RS485/232' (selected), '○ TTL', '○ Wigan', and '○ Ethernet'. The 'Serial' section contains four dropdown menus: 'Baudrate:' (showing a list with 115200 selected), 'Databit:' (showing 5), 'CheckDigit:' (showing N), and 'Stopbit:' (showing 1).

VguangConfigV2.3.19

Set Password: 1234567887654321 → Next → Main

Work mode

● Ordinary ○ Develop


Output

● RS485/232 ○ TTL ○ Wigan ○ Ethernet


Serial

Baudrate: 115200 300 2400 4800 9600 19200 38400 57600 Databit: 5 CheckDigit: N Stopbit: 1

Step 3, select the required configuration. For configuration options, please refer to the user manual of Vguangconfig configuration tool on the officialwebsite.



Step 4, After configuring as your needs, click “config code” .



Step 5, Use the scanner to scan the configurations QR code generated by the tool, then restart the reader to finish the new configurations.





For more details about configurations, please refer to the “Vguang configuration tool user manual” .

6. Mounting method

The product using CMOS image sensor, the recognition window should avoid direct sun or other strong light source when install the scanner. The strong light source will cause the contrast in the image too big to decoding, the long term exposure will damage the sensor and cause the device failure.

The recognition window are using tempered glass, which has good transmission of the light, and also a good pressure resistance, but still need to avoid scratching the glass by some hard object, it will affect the QR code recognition performance.

The RFID antenna was in the underside of the recognition window, there should have no metal or magnetic material within 10cm when installing the scanner, or it will affect the card reading performance.

			
Step 1: Open a hole in the mounting plate. 70*60mm	Step 2: Assemble the reader with the holder, and tighten the screws, then plug the cable. M2.5*5 self tapping screw.	Step 3: assemble the holder with the mounting plate, then tighten the screws.	Step 4, installation finished.

7. Attention

- 1, The equipment standard is 12-24V power supply, it can get power from the access control power or power it separately. Excessive voltage may cause the device fail to work normally or even damage the device.
- 2, Do not disassemble the scanner without permission, otherwise the device may be damaged.
- 3, 3, The installation position of the scanner should avoid direct sunlight. Otherwise, the scanning effect may be affected. The panel of the scanner must be clean, otherwise it may affect the normal image capture of the scanner. The metal around the scanner may interfere with the NFC magnetic field and affect card reading.
- 4, The wiring connection of the scanner must be firm. In addition, ensure the insulation between the lines to prevent the equipment from being damaged by a short circuit.

8. Contact info

Company name: Suzhou CoolCode Technology Co., Ltd.

Address: Floor 2, Workshop No.23, Yangshan Science and Technology Industrial Park, No. 8, Jinyan Road, High-tech Zone, Suzhou, China

Hot line: 400-810-2019

FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.