

Grow Light+Duct fan System

GTC42




Scan QR code to download electronic version

USER MANUAL


MANUAL INDEX

Front cover.....	Page 1
Contents.....	Page 2
Product size drawing and interface description.....	Page 3
Product Packing List.....	Page 4
Product connection diagram.....	Page 5
Button function and interface description.....	Page 6
Light control operation.....	Page 7
Device control operations.....	Page 11
Other system setting parameters.....	Page 31

Product size drawing and interface description



size: L153mm*W91.5mm* H30.5mm



Wall hanging hole

Product label



UP date SD



Sensor

Light CH1 out

Light CH1-CH4 out


Device 4 (applicable to some models)

Device 3 (applicable to some models)


Fan 2

Fan 1


Product Packing List




Controller x1




Fixed plate x1




Sensor x1




Wire-RJ12 6p6c x1




Wire-RJ45 8p8c x1



Wire-Type-c x1




Wall mounting positioning stickers x1



Screws and expansion tubes x2



Manual x1



Wire Fixing x1

Packaging Information:

Single packing size: 185*156*73mm


Single weight: 888g

Carton size: 385*325*200mm

Full box weight: 9.42Kg

Full box quantity: 10 Pcs

Product connection diagram



Display instructions

1. LIGHT BUTTON ①

Press the button to display the light control interface. You can switch between 4 channels. You can set the brightness of each channel or select All to set all channels uniformly.

2. DEVICE BUTTON ②

Press the button to display the fan control interface. You can switch between the four devices and set the parameters of each device or select All to set all parameters uniformly.

3. SETTING BUTTON ③

Cycles through the controller settings: DISPLAY, CLOCK, °F/°C
CALIB. T°/H% /kPa
TRANS. T°/H%/kPa
BUFF. T°/H%/kPa/VPD

Only available in device mode;

Over temperature protection/slow rise and slow fall/buffer temperature are **only available in light mode;**

4-5.UP/DOWN BUTTONS ④⑤

Adjusts the value of your current mode. The up button increases and down button decreases the setting. Hold both to reset values to OFF/Default.

6.MODE BUTTON

Cycles through the controller modes:
ON, OFF, AUTO (6 triggers)

TIMER TO ON

TIMER TO OFF

CYCLE (ON and OFF)

SCHEDULE (ON and OFF).



7. Display the level position of each channel ⑦;

8. Control mode ⑧;

9. Display the currently monitored temperature ⑨, and display “--” when no probe is inserted;

When no probe is inserted;

10. Displays the currently monitored VPD ⑩, and displays “--” when no probe is inserted;

11. Displays the currently monitored humidity ⑪, and displays “--” when no probe is inserted;

12. Alert icon bar ⑫ climate alarm, timer alarm, APP connection status, screen lock and over-temperature alarm;

13. Display the current time ⑬. There is a super capacitor inside to maintain the clock. It will not default to 00:00 when the power is cut off;


14. Current equipment operation level ⑭

15. Display time ⑮, timed on or off time, countdown on or off time, cycle on or off time;

16. Display setting value ⑯, display the setting value of the current mode, press the up and down keys to adjust the value;

Interface Operation Instructions

1. Lighting control interface



Press the light key①to enter the light control. The dot before "All" flashes, indicating that the 4 channels CH1-CH4 are set synchronously. At this time, press④or⑤ to set the brightness of the 4 channels at the same time.


Press the light key①again, the dot before "CH1" flashes, and press④or⑤ to adjust the brightness of CH1 alone;

Press the light key①again, the dot before "CH2" flashes, and press④or⑤ to adjust the brightness of CH2 alone;

Press the light key①again, the dot before "CH3" flashes, and press④or⑤ to adjust the brightness of CH3 alone;

Press the light key①again, the dot before "CH4" flashes, and press④or⑤ to adjust the brightness of CH4 alone;


The 4 channels execute their respective set brightness respectively. When the dot before "All" flashes again, the 4 channels all execute the value set by "All" synchronously;



Press ⑥ mode button

Can switch between Normally ON, Normally OFF, SCHEDULE, 3 modes, stay for 5 seconds to automatically confirm;


Normally ON: Run according to the set value; "All": All channels are set synchronously, and the parameters of 1, 2, 3, and 4 can also be set.




Normally OFF: the light will be off in this mode;



SCHEDULE: ON flashes Press the up and down keys to set the on time, press the mode key OFF flashes Press the up and down keys to set the off time; in this mode, the light will turn on or off according to the set time and run automatically every day;



For example:



Press ③ set button

Set over-temperature protection.

Press ④ or ⑤ to adjust parameters.

Over temperature protection setting

Fahrenheit range OFF-33-194

Celsius range OFF-0-90

When the temperature \geq the setting

value, all lights are turned off.

Over-temperature protection prompt

When the monitored temperature is \geq the set value, the lights of all channels will be turned off. The over-temperature

Protection icon lights up as a prompt;

Press the ③ setting key again to set the





buffer value.

Example: BUFF.T° is set to 5 degrees, over-temperature protection is set to 40 degrees, the light goes out when the temperature reaches 40 degrees, and the light turns back on when the temperature drops to \leq 35 degrees.

Fahrenheit range OFF-33-76 degrees

Celsius range OFF-1-10 degrees

For example:




Press the ③ setting key again to set the sun rise and sun set.

Example: The slow rise and slow fall is set to 10 minutes.

The on time is 8:00 and the off time is 8:30. The difference between on and off time is 30 minutes. The maximum slow rise/slow fall time can only be set to 15 minutes (the setting range can only be 0-15 at this time). If the off time is 8:31, the slow rise/slow fall time can still only be set to 15 minutes. If the off time is 8:32, the maximum slow rise/slow fall time can be set to 16 minutes.

That is the slow rise/slow fall time can only be half of the difference between the on and off time.



SUN rise For example: Set the start time to 8:30

SUN rise time to 60 minutes

Then from 8:30, the brightness will rise evenly to the set brightness value within 60 minutes, that is, from 9:30 to the set brightness value

SUN set For example:

Set the end time to 20:00

SUN set time to 60 minutes, then from 19:00, the brightness will fall evenly to the light turning off within 60 minutes, that is, it will start to fall at 19:00 and turn off at 20:00

Setting range: OFF-1-60 minutes

"OFF" means this function is not enabled

Device control



Press key ② to enter device control

Press key ② to enter lighting control. The dot in front of "All" flashes, indicating that the 4 channels CH1-CH4 are set synchronously. At this time, press ④ or ⑤ to set the brightness of the 4 channels at the same time.

Press key ② again. The dot in front of "CH1" flashes. At this time, press ④ or ⑤ to adjust the CH1 level separately; Press key ② again. The dot in front of "CH2" flashes. At this time, press ④ or ⑤ to adjust the CH2 level separately; Press key ② again. The dot in front of "CH3" flashes. At this time, press ④ or ⑤ to adjust the CH3 level separately; Press key ② again. The dot in front of "CH4" flashes. At this time, press ④ or ⑤ to adjust the CH4 level separately; The 4 channels execute their own set levels respectively. When the dot in front of "All" flashes again, the 4 channels will execute the value set by "All" synchronously;

Press the button again to select the device to be controlled, which is All-1-2-3-4 respectively. The scrolling display is as follows

All sets the same parameters for all devices, and different parameters can be set for each of the 4 devices.



After selecting the device to be set, press function key ⑥ to select the operation mode.

They are Normally ON, Normally OFF, AUTO (6 triggers), TIMER ON, TIMER OFF, CYCLE ON/OFF, SCHEDULE mode.

Normally ON: Press ④ or ⑤ to adjust the running level (0-10 levels). The blue box is the setting area. When setting, the number is synchronized to the fan icon; The gear position set in this mode will be used as the maximum gear position for other modes (automatic mode trigger on, countdown TO OFF mode, cycle on mode and schedule on mode). [Please do not set the gear position of this mode to 0, otherwise the gear position will be 0 when triggered in all other modes.](#)



Normally OFF: Press ④ or ⑤ to adjust the running level (0-10 levels). The blue box is the setting area. When setting, the number is synchronized to the fan icon; (This value is the running value when it is turned off. For example, if it is set to 2 level, it will still run at 2 level when it is turned off) This setting will be used for the running level when it is turned off in all modes (automatic mode, timer to on mode, cycle off mode and the lowest running level of schedule off); [If you want the device to be completely turned off when triggered, please set it to "0";](#)

Level description

0-0% 1-23% 2-30%

3-36% 4-45% 5-53%

6-61% 7-69% 8-78%


9-86% 10-100%



AUTO mode (when in this mode, you can select 6 trigger conditions to associate with the device)

AUTO mode (HIGH TEMP TRIGGER)


A white dot will light up in front of the selected item HIGH TEMP The temperature condition for the associated device to start, press the ④ or ⑤ button to adjust the temperature, and it will be automatically saved 5 seconds after setting;the setting range is OFF-33-194 degrees for Fahrenheit and OFF-0-90 degrees for Celsius. "OFF" means the function is not enabled.



If the sensor reading reaches or exceeds this threshold, the device will start, and "HIGH TEMP" will flash Light, up the icon  at the same time;the device will gradually rise to the gear set in the on mode.If the sensor reading falls below this threshold, the device will gradually decelerate to the gear set in stop or off mode;

When in automatic mode, any of the 6 trigger points can activate the device.Even if you select other conditions, if you do not need to enable,then use the ④ or ⑤buttons to set the trigger point to "OFF".If the gear set in the close mode is not 0, the device will run at this gear when the shutdown is triggered.

For example:



AUTO mode (LOW TEMP TRIGGER)

LOW TEMP The temperature conditions for the associated equipment to start,press the ④ or ⑤ button to adjust the temperature.The setting range is OFF-32-194 degrees for Fahrenheit and OFF-0-90 degrees for Celsius;"OFF" means the function is not enabled.



If the sensor reading reaches or falls below this threshold, the device will start, and "LOW TEMP" will flash ,Light up the icon  at the same time;the device will gradually rise to the gear set in the on mode.If the sensor reading falls below this threshold, the device will gradually decelerate to the gear set in stop or off mode;

When in automatic mode, any of the 6 trigger points can activate the device.Even if you select other conditions, if you do not need to enable,then use the ④ or ⑤ buttons to set the trigger point to "OFF".If the gear set in the close mode is not 0, the device will run at this gear when the shutdown is triggered.

For example:



AUTO mode (HIGH HUMID TRIGGER)

HIGH HUMID The humidity conditions for the associated equipment to start, press button ④ or ⑤ to adjust the humidity. The setting range is OFF-0-100%, "OFF" means not enabling this function.



If the sensor reading reaches or exceeds this threshold, the device will start, and "HIGH HUMID" will flash. Light up the icon  at the same time; the device will gradually rise to the gear set in the on mode. If the sensor reading falls below this threshold, the device will gradually decelerate to the gear set in stop or off mode;


When in automatic mode, any of the 6 trigger points can activate the device. Even if you select other conditions, if you do not need to enable, then use the ④ or ⑤ buttons to set the trigger point to "OFF". If the gear set in the close mode is not 0, the device will run at this gear when the shutdown is triggered.

For example:



AUTO mode (LOW HUMID. TRIGGER)


LOW HUMID The humidity conditions for the associated equipment to start,press button ④ or ⑤ to adjust the humidity.The setting range is OFF-0-100%, "OFF" means not enabling this function.



If the sensor reading reaches or falls below this threshold, the device will start, and "LOW HUMID" will flash ,Light up the icon  at the same time;the device will gradually rise to the gear set in the on mode.If the sensor reading falls below this threshold, the device will gradually decelerate to the gear set in stop or off mode;

When in automatic mode, any of the 6 trigger points can activate the device.Even if you select other conditions, if you do not need to enable,then use the ④ or ⑤ buttons to set the trigger point to "OFF".If the gear set in the close mode is not 0, the device will run at this gear when the shutdown is triggered.

For example:



AUTO mode (HIGH VPD TRIGGER)


HIGH VPD VPD conditions for associated equipment startup, press ④ or ⑤ to adjust the saturated water vapor pressure deficit, setting range OFF-0-9.9kPa, "OFF" means not enabling this function.



If the sensor reading reaches or exceeds this threshold, the device will start, and "HIGH VPD" will flash, Light up the icon  at the same time; the device will gradually rise to the gear set in the on mode. If the sensor reading falls below this threshold, the device will gradually decelerate to the gear set in stop or off mode;

When in automatic mode, any of the 6 trigger points can activate the device. Even if you select other conditions, if you do not need to enable, then use the ④ or ⑤ buttons to set the trigger point to "OFF". If the gear set in the close mode is not 0, the device will run at this gear when the shutdown is triggered.

For example:



AUTO mode (LOW VPD TRIGGER)

LOW VPD VPD conditions for associated equipment startup, press ④ or ⑤ to adjust the saturated water vapor pressure deficit, setting range OFF-0-9.9kPa,"OFF" means not enabling this function.



If the sensor reading reaches or falls below this threshold, the device will start, and "LOW VPD" will flash. Light up the icon  at the same time; The device will gradually rise to the gear set in the on mode. If the sensor reading is above this threshold, the device will gradually decelerate to the gear set in stop or off mode;

When in automatic mode, any of the 6 trigger points can activate the device. Even if you select other conditions, if you do not need to enable, then use the ④ or ⑤ buttons to set the trigger point to "OFF". If the gear set in the close mode is not 0, the device will run at this gear when the shutdown is triggered.

For example:



TIMER TO ON (Countdown on mode) Press button ④ or ⑤ to set the countdown time, setting range 0-24 hours. After the timer is up, the device will be triggered to open. If a gear is set in shutdown mode, the device will operate in that gear during the countdown and when shutdown is triggered.

After the setting is completed, if there is no operation for 5 seconds, it will be automatically saved and the countdown will begin. At this time, the remaining time will be displayed above the setting. During the countdown, if you leave this interface, the countdown will be paused, and the countdown will continue until you return to this interface;



Timer to on
Countdown end



TIMER TO OFF (Countdown OFF mode) Press button ④ or ⑤ to set the countdown time. The setting range is 0-24 hours. After the timer ends, the device will be triggered to turn off. The device will run in the ON mode during the countdown and when triggered to turn on.

After the setting is completed, if there is no operation for 5 seconds, it will be automatically saved and the countdown will begin. At this time, the remaining time will be displayed above the setting. During the countdown, if you leave this interface, the countdown will be paused, and the countdown will continue until you return to this interface;



Timer to off
Countdown end



For example:

CYCLE ON/OFF (Cycle On and Off Mode) Press ④ or ⑤ to set the On duration and Off duration. The setting range is 0-24 hours. First set the On duration. After the timing ends, the device will trigger the shutdown. The device will run the ON mode gear during the countdown.

After the setting is completed, if there is no operation for 5 seconds, it will be automatically saved and the countdown will begin. At this time, the remaining time will be displayed above the setting. During the countdown, if you leave this interface, the countdown will be paused, and the countdown will continue until you return to this interface;

Then press the mode key ⑥ to set the shutdown duration. The device will trigger shutdown after the timing ends, and the device will run the gear of the OFF mode during the countdown. If the gear set in the shutdown mode is not 0, the device will run at this gear when the shutdown is triggered.

For example:



ON 2hour



SCHEDULE ON/OFF Press button ④ or ⑤ to set the time for turning on and off every day. The setting range is 0-24 o'clock. First, set the time to turn on the device every day; when the set time is reached, the device will run in the ON mode gear.


After the setting is completed, if there is no operation for 5 seconds, it will be automatically saved. If you leave this interface during the timer operation, it will automatically exit this mode and will continue to operate according to the set schedule until you return to this interface.



Then press the mode key ⑥ SCHEDULE OFF to set the time for each day to shut down. When the set time is reached, the device will be triggered to shut down and will run at the gear of the OFF mode. If the gear set in the shutdown mode is not 0, the device will run at this gear when it is triggered to shut down.



For example:



Controller Settings

Pressing the ③Settings key will cycle through the available settings for the controller: DISPLAY, °F/°C, CLOCK, Calibration Temp/Humidity/VPD, TRANS. Temp/Humidity/VPD, Buffer Temp/Humidity/VPD.

(Available in device mode)

Over temperature protection/sun rise and sun set / buffer temperature (only available in light mode)

DISPLAY is for backlight brightness

adjustment and automatic adjustment. Press button ④ or ⑤ to set. The display will cycle through 1, 2, 3, A2, A3 (1st level 30%, 2nd level 60%, 3rd level 100%, A2 60%, A3 100%; the brightness of A2 and A3 will automatically drop to 30% after 1 minute of no operation);

Long press ③Settings key to lock the screen.

The lock icon will be displayed on the




Long press ③Settings key to lock the screen. The lock icon will be displayed on the screen

Press the ③Settings key again while the screen is locked. The screen will turn off (the program will still run when the screen is off). Press it again to turn the screen back on. Long press the ③Settings key again to unlock the screen, and the lock icon will not be displayed. When the screen is off, the setting program will run normally.



Temperature unit setting

°F/°C Changes the displayed temperature unit to Fahrenheit or Celsius. Press button ④ or ⑤ to cycle through °F/°C. When adjusting this setting, all displayed units automatically switch.



System time setting

CLOCK System time setting, press button ④ or ⑤ to adjust the time, 0:0-23:59, displayed in the upper right corner;



Press the ③Set key again to calibrate sensor parameters.

CALIBRATION TEMPERATURE SETTING

Adjusts the temperature reading the sensor probe is measuring. Press the up or down button to increase or decrease the data figure in 1° increments. The calibration cycle ranges from -18°F to 18°F (or -10°C to 10°C) and will be applied to the sensor probe' s measurements.



CALIBRATION HUMIDITY SETTING

Adjusts the relative humidity reading the sensor probe is measuring. Press the up or down button to increase or decrease the data figure in 1% increments. The calibration cycle ranges from -10% to 10% and will be applied to the sensor probe' s measurements.



CALIBRATION LEAF OFFSET SETTING

Adjusts the VPD reading the sensor probe is measuring. Press the up or down button to increase or decrease the data figure in 0.1 increments. The calibration cycle ranges from -2.5kPa to kPa and will be applied to the sensor probe' s measurements.



TRANSITION TEMPERATURE SETTING


Adjusts how gradually your device will shift between levels when triggered ON by the AUTO Mode's temperature trigger. This will determine how much the probe temperature needs to increase to step up to the next level setting.

The higher the transition setting is, the wider the temperature gap is between levels. The lower the transition setting is, the smaller the temperature gap is between levels. If this figure is set to zero, your device will jump to your maximum level when triggered ON. Press the up or down button to set a transition threshold between 0°F and 18°F (0°C and 10°C). When the sensor temperature first reaches or crosses the temperature trigger point, the level will increase by one (exiting OFF Mode). Each time the threshold level is crossed, the level will ramp up by one until it reaches the level set in ON Mode.

For example:

TRANS. T° is set to 3 degrees, the trigger temperature is 30 degrees, when the temperature reaches 30 degrees, the fan gear is triggered to start at gear 1, when the temperature reaches 33 degrees, the fan becomes gear 2, and so on to the gear set in "ON" mode.

If it is set to 0, the gear set in "ON" mode is directly triggered.



TRANSITION HUMIDITY SETTING


Adjusts how gradually your device will shift between levels when triggered ON by the AUTO Mode's humidity trigger. This will determine how much the probe humidity needs to increase to step up to the next level setting.

The higher the transition setting is, the wider the humidity gap is between levels. The lower the transition setting is, the smaller the humidity gap is between levels. If this figure is set to zero, your device will jump to your maximum level when triggered ON. Press the up or down button to set a transition threshold between 0% and 10%. When the sensor humidity first reaches or crosses the humidity trigger point, the level will increase by one (exiting OFF Mode). Each time the threshold level is crossed, the level will ramp up by one until it reaches the level set.



For example:

TRANS. H% is set to 5%, triggering humidity 60%. When the humidity reaches 55%, the fan gear is triggered to start at gear 1. When the humidity reaches 60%, the fan gear changes to gear 2, and so on to the gear set in "ON" mode. If it is set to 0, the gear set in "ON" mode is directly triggered.



TRANSITION VPD SETTING


Adjusts how gradually your device will shift between levels when triggered ON by the VPD trigger. This will determine how much the probe VPD needs to increase to step up to the next level setting.

The higher the transition setting is, the wider the VPD gap is between levels. The lower the transition setting is, the smaller the VPD gap is between levels. If this figure is set to zero, your device will jump to your maximum level when triggered ON.

Press the up or down button to set a transition threshold between 0.1 kPa and 1.0 kPa. When the sensor VPD first reaches or crosses the VPD trigger point, the level will increase by one (exiting OFF Mode). Each time the threshold level is crossed, the level will ramp up by one.

For example:

TRANS. vpd is set to 0.2kpa, and the atmospheric pressure is set to 0.2kpa. When the atmospheric pressure reaches 0.2kpa, the fan gear is triggered to start at gear 1. When the atmospheric pressure reaches 0.4kpa, the fan gear changes to gear 2, and so on to the gear set in "ON" mode. If it is set to 0, the gear set in "ON" mode is directly triggered.



Buffer temperature setting

The buffer value will create a trigger off point that is lower than the set trigger point to prevent your device from shutting down too quickly or working repeatedly between on and off. Press [④](#) or [⑤](#) buttons to adjust, setting range: 0°F to 9°F for Fahrenheit, 0°C to 5°C for Celsius).


With a HIGH TEMP trigger, your device will turn on and will only turn off when the temperature drops below your buffer setting.

With a LOW TEMP trigger, your device will turn on and will only turn off when the temperature rises above your set buffer setting.



For example:

BUFF. T° is set to 2°C, and the trigger temperature is 40°C. When the temperature reaches 40°C, the device is triggered to turn on, and when the temperature drops to 38°C, the device is triggered to turn off. If it is LOW TEMP, the device will not turn off until the temperature rises to the set buffer value.




Buffer Humidity Setting

The buffer figure will create a trigger-off point below your set trigger point to prevent your device from shutting off too quickly. Press the up or down button to cycle through buffer range from 0% to 10%.


In high humidity triggers, your device will turn on, only turning off when the humidity falls below your buffer setting.

In low humidity triggers, your device will turn on, only turning off when the humidity rises above your set buffer setting.




For example:

BUFF H% is set to 5%, the humidity that triggers the device to turn on is 70%, the device turns on when the humidity reaches 70%, and the device turns off when the humidity drops to 65%;
If it is **LOW HUMID**, the device will turn off only when the humidity rises to the set buffer value.



HIGHT HUMIND: $70\% - 5\% = 65\%$



LOW HUMIND: $70\% + 5\% = 75\%$

BUFFER VPD SETTING

The buffer figure will create a trigger-off point below your set trigger point to prevent your device from shutting off too quickly. Press the up or down button to cycle through buffer range from 0.1 kPa and 1.0 kPa.



In high VPD triggers, your device will turn on, only turning off when the VPD falls below your buffer setting.

In low VPD triggers, your device will turn on, only turning off when the VPD rises above your set buffer setting.



For example:

BUFF. vpd is set to 0.2kpa, the VPD that triggers on is 1kPa, the trigger is on when VPD reaches 1kPa, and the trigger is off when VPD drops to 0.8kPa; If it is LOW VPD, it will be off only when VPD rises to the set buffer value.



Other settings

1. Restore initial settings



Press and hold ③+⑥ button for 5 seconds to reset the controller and clear all user settings.

2. Lock and manually turn off the screen

Long pressing the ③ button for 3 seconds will lock the controller in the current state. After locking, all buttons cannot be adjusted. Press and hold the ③ button again for 3 seconds to unlock;

When the controller is locked, short press the ③ button and the screen will turn off completely. Short press the ③ button again and the screen will light up;

3. Jump to OFF mode with one click

In light mode, press and hold the ⑥ button for 3 seconds. No matter what mode you are in, it will automatically switch to the off mode.

In device mode, press and hold the ⑥ button for 3 seconds. No matter what mode you are in, it will automatically switch to the off mode.

[&After the above operations are successful, there will be a sound prompt](#)

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

