

<h2>User Manual</h2> <h3>BCPR01</h3> <p>1</p>	<p><b>EN~ Instructions for use</b></p> <p>This set includes 2 walkie-talkie units: these are communication devices which operate on mobile radio frequencies. They come with 8/20/22(option) channels as well as a back-lit LCD screen, enabling you to communicate over several kilometres free-of-charge (up to 3 km in open areas)</p> <p><b>NOTE:</b> Please read these user instructions carefully before using the equipment and retain for future consultation!</p> <p><b>SPECIFIC RECOMMENDATIONS</b></p> <ul style="list-style-type: none"> <li>If you carry any kind of personal medical device, consult a doctor before use.</li> <li>To avoid the risk of burns, do not use the device if the aerial is damaged in any way.</li> <li>Do not use the device in a potentially explosive setting (e.g. around petrol pumps, on the lower deck of a boat or around a fuel storage installation or chemical products).</li> <li>If travelling in a car or by bike, stop before using the device. Switch off the device if on an aeroplane or in a hospital.</li> <li>Never use the device in close proximity to a radio to avoid interference.</li> <li>Remove the batteries if the device is not in use for an extended period of time. Never mix used and new batteries.</li> <li>Position the transmitter and antenna at least 5 cm from your face. Direct the antenna upwards and speak normally.</li> <li>Clean the device with a damp cloth. Avoid the use of cleaning agents and solvents.</li> <li>Do not modify the device in any way. In the event of damage occurring, ensure that the device is checked by a qualified professional.</li> <li>The device cannot be used to contact the emergency services.</li> </ul> <p>3</p>	<p><b>ITEM DESCRIPTION (Pic01,02)</b></p> <ol style="list-style-type: none"> <li>Antenna</li> <li>RX icon - Displayed when receiving</li> <li>TX icon - Displayed when transmitting</li> <li>Volume level indicator</li> <li>Adjustorbutton Up (▲)</li> <li>Continued reception(MON)</li> <li>On/off button(⊕)</li> <li>Adjustorbutton Down (▼)</li> <li>Loud speaker</li> <li>Microphone</li> <li>Menu</li> <li>Enter the menu settings</li> <li>Call button(CALL)</li> <li>Keypad lock indicator</li> <li>Battery level indicator</li> <li>Push to talk (TALK)button</li> <li>VOX indication</li> <li>Scanning indication</li> <li>Displayed during scan mode</li> <li>Channel/Menu item indication</li> <li>CTCSS /Menu option -value</li> <li>Lamp Button</li> <li>Scan Button</li> <li>Lamp</li> <li>Belt attachmentclip</li> <li>Belt attachment</li> <li>Batteries (not supplied)</li> <li>Battery compartment</li> </ol> <p>4</p>	<p><b>BEFORE USE (Pic02)</b></p> <p>To insert batteries into the devices, first remove the belt attachment: lift the attachment clip (23) and press the belt attachment upwards (24).</p> <p>Open the battery compartment (26) and insert 4 AA batteries (25) (not supplied), ensuring that the poles are correctly aligned. Then close the lid.</p> <p><b>USING THE TWINTALKER</b></p> <p><b>1. Turning the device on/off:</b> To turn the devices on or off, hold down the on/off button (6) for 3 seconds: a BEEP sound will be played to confirm.</p> <p><b>2. Adjusting the volume:</b> To increase the volume, press the Up adjustor button ▲ (4) and press the Down ▼ (7) button to decrease volume.</p> <p><b>Note:</b> The volume level (3) is displayed on the screen.</p> <p><b>3. Battery Level/Low Battery Indication</b></p> <p>The battery level is indicated by the number of squares presented inside the battery icon on the LCD Screen.</p> <ul style="list-style-type: none"> <li>■ Battery Full</li> <li>■ Battery 2/3 charged</li> <li>■ Battery 1/3 charged</li> <li>■ Battery empty</li> </ul> <p>When the battery level is low, the battery icon will flash and a beep will be heard to indicate that the battery needs to be replaced or recharged.</p> <p>5</p>	<p><b>4. Receiving/transmitting communications:</b></p> <p>The devices are in 'Reception' mode when lit up, i.e. they are ready to receive a call or sound transmitted on the activated frequency.</p> <p>When you press the Call tone button (12), the device switches to 'Transmission' mode. You are then transmitting a sound signal to the other device.</p> <p>To send a voice message, press the TALK button (15) and speak into the microphone (10). Continue to press the button until you have finished transmitting your message. Hold the microphone a minimum of 5 cm from your face.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The other device must be set to the same channel and have set the same CTCSS code (see point 7).</li> <li>When the transmission is complete and the TALK button (15) is no longer held down, the other device will emit a sound (BEEP) to indicate that this device is ready to transmit.</li> </ul> <p><b>7.CTCSS</b></p> <ul style="list-style-type: none"> <li>Press the MENU-button(11) twice : The current CTCSS code flashes on the display.</li> <li>Press the ▲-button(4) or the ▼-button(7) to change to another code.</li> <li>Press the TALK-button(15) to confirm and return to stand-by mode.</li> </ul> <p><b>Note:</b> To disable CTCSS, select code "OF" for CTCSS in the menu. When the entry is confirmed, "OF" will be displayed.</p> <p><b>8.Monitor</b></p> <p>You can use the monitor feature to check for weaker signals in the current channel.</p> <ul style="list-style-type: none"> <li>Press the MON-button to activate channel monitoring.</li> <li>Press the MON-button to stop channel monitoring.</li> </ul> <p><b>Note:</b> During channel monitoring the receiver circuit in the Radio's will not listen to CTCSS codes.</p> <p>6</p>	<p><b>9. VOX Selection</b></p> <p>The Radio's is capable of voice activated VOX transmission. In VOX mode, the radio will transmit a signal when it is activated by your voice or other sound around you. VOX operation is recommended if you plan to use your radio in a noisy or windy environment.</p> <p><b>Note:</b> VOX mode will be override when you press the TALK button "15".</p> <ul style="list-style-type: none"> <li>Press the MENU-button(11) three times, the current VOX setting flashes on the display and the VOX icon is displayed.</li> <li>Press ▲-button(4) to set the VOX sensitivity level between 1 and 3 (level 3 is the most sensitive level).</li> <li>Press ▼-button(7) until "OF" appears on the display, turn VOX OFF.</li> <li>Press the TALK-button(15) to confirm and return to stand-by mode.</li> </ul> <p><b>10. Scanning for an active radio channel</b></p> <ul style="list-style-type: none"> <li>Press the SCAN -button(21) : The 'Scan' function indicator (17) will appear on the screen and the channel (18) will scan continuously from 1 to 22.</li> <li>Press the TALK-button(15) to confirm and return to stand-by mode.</li> </ul> <p><b>Note:</b> If no button is pressed within 15 seconds during setting, the unit will return to standby.</p> <p><b>6.CTCSS (Continuous Tone Coded Squelch System)</b></p> <p>License free radio's operating on the 400-470 MHz frequency band, like the Twintalker , have 8/20/22 available radio channels. If there are many radio's users in your neighborhood, there is a chance that some of these users are operating on the same radio channel. To prevent that you receive signals from other users, sub-channels have been integrated.</p> <p>Two radio's will only be able to communicate with each other when they are operating on the same radio channel and when they have selected exactly the same sub-channel. There are two kind of sub-channels :</p> <ul style="list-style-type: none"> <li>Continuous Tone Coded Squelch System (CTCSS)</li> <li>When using CTCSS, a low frequency tone (between 67 and 250 Hz) will be transmitted along with the voice signal. There are 99 available tones to choose from. You are free to choose one of these 99 available tones. Due to filtering, these tones will generally not be audible so they will not disturb the communication.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The other device must be set to the same channel and have set the same CTCSS code (see point 7).</li> <li>When the transmission is complete and the TALK button (15) is no longer held down, the other device will emit a sound (BEEP) to indicate that this device is ready to transmit.</li> </ul> <p><b>7.CTCSS</b></p> <ul style="list-style-type: none"> <li>Press the MENU-button(11) twice : The current CTCSS code flashes on the display.</li> <li>Press the ▲-button(4) or the ▼-button(7) to change to another code.</li> <li>Press the TALK-button(15) to confirm and return to stand-by mode.</li> </ul> <p><b>Note:</b> To disable CTCSS, select code "OF" for CTCSS in the menu. When the entry is confirmed, "OF" will be displayed.</p> <p><b>8.Monitor</b></p> <p>You can use the monitor feature to check for weaker signals in the current channel.</p> <ul style="list-style-type: none"> <li>Press the MON-button to activate channel monitoring.</li> <li>Press the MON-button to stop channel monitoring.</li> </ul> <p><b>Note:</b> During channel monitoring the receiver circuit in the Radio's will not listen to CTCSS codes.</p> <p>7</p>
---	---	---	--	---	---

<p><b>11. Call Tones</b></p> <p>A call tone alerts others that you want to start talking.</p> <p><b>11.1 Setting the Call Tone</b></p> <p>The Twintalker has 10 call tones.</p> <ul style="list-style-type: none"> <li>Press the MENU-button(11) four times, "CA" is displayed and the current call tone is flashing.</li> <li>Press the ▲-button(4) or the ▼-button(7) to change to another Call Tone.</li> <li>Press the TALK - button(15) to confirm and return to stand-by Mode.</li> </ul> <p><b>11.2 Sending a call Tone</b></p> <p>Press the CALL-button(12) briefly. The call tone will be transmitted on the set channel.</p> <p><b>12. Key-Tone On/Off</b></p> <p>When a button is pressed, the unit will beep briefly.</p> <p>To set the key-tone.</p> <ul style="list-style-type: none"> <li>Press the MENU - button(11) five times. "TO" will be displayed.</li> <li>Press ▲ to enable (ON) or ▼ disable the Key Tones (OF).</li> <li>Press the TALK - button(15) to confirm your selection and return to the standby mode.</li> </ul> <p><b>13. Roger Beep On/Off</b></p> <p>After the TALK-button is released, the unit will send out a roger beep to confirm that you have stopped talking.</p> <p>To set the Roger Beep.</p> <ul style="list-style-type: none"> <li>Press the MENU - button(11) six times. "RO" will be displayed.</li> <li>Press ▲ to enable (ON) or</li></ul>
--