

C086 Operation Manual

FCC 15.19 warning: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

1、Installation method

- ① Install the instrument in the center of the car faucet and fix it with glue.


*Instrument damage caused by excessive torque is not covered by the warranty.

- ② Connect the instrument manual control and motor controller docking connector according to the markings.



2、Display interface

1.1 Boot interface




When starting up, the startup logo interface is displayed for 3 seconds. After the communication connection is established, the instrument enters the main interface display state. The instrument uses the information obtained from the controller communication for actual display. (The displayed data information is executed according to the communication protocol provided by the customer)

1.2 Basic interface and operation buttons



- ① The instrument adopts 3-button form, power button, \searrow , \nwarrow adjustment button
- ② The handle hides the cable outlet method.
- ③ The screen uses a 1.44-inch BOE LCD screen to meet the customization needs of the startup interface.

1.3 Introduction to functional interface



After powering on, the boot logo interface is displayed for 3 seconds. The instrument establishes communication and obtains information normally before entering the normal

riding display interface. The instrument reads the relevant information stored in the controller according to the communication protocol for display, and reads the battery BMS information for display (system instruments without BMS information do not display the battery percentage), and the remaining information is displayed in real time.

1.4 Other functional interfaces

The functional interface mainly displays speed information, including average speed, maximum speed and single mileage. The single mileage information TRIP is the same as the main interface. The speed display value is 3 digits, the maximum value is 99.9KM/H, including one decimal place. The subtotal mileage value is usually 4 digits including one decimal point. If it exceeds 9999.9KM, the decimal point will not be displayed and it will be directly displayed with 5 digits. The maximum value is 99999KM. After exceeding the maximum value, the displayed number is the actual mileage value divided by 100,000. The function interface can clear data through key operations.



1.1 Promote assistance display interface

1.2 Press and hold the \sim adjustment button to enter the push assist mode. The instrument display interface is as follows




1.5 Fault code display interface

After receiving the fault information returned by the controller, the instrument will display the fault code interface on the instrument side to prompt the user with relevant electrical system fault information. The fault code will be displayed in a full-screen pop-up box in numerical form.




1.6 Setting interface

After turning on the phone, quickly click the power button twice to enter the setting interface, and short press the \swarrow and \searrow keys to cycle through the setting interface. In any setting interface, short press the power button to enter the parameter editing state. There are two status modes of picking and interface. The picking status is represented by the side, and the selected state is represented by the display on a yellow background. . in the parameter editing interface, short press the \swarrow , \searrow keys to modify and edit the parameter. In the parameter editing interface, short press the power button to select EXIT to exit the editing state. When returning to the setting interface, select EXIT to return to the main interface.



For the interface operation definition of the above function settings, please refer to Part 7 Setting Function Operation Instructions.

3. Button definition



1.1 Button name definition

Power button: long press to turn on and off, short press to confirm

Adjustment keys (UP key & DOWN key): Adjust the power assist gear during riding and perform setting operations with the function switching key. Press and hold the adjustment key to perform corresponding specific function operations.

1.2 Key operation definition

Operation type	Describe
Short press	Short press refers to pressing the button and then releasing the button immediately. When the button pops up, the corresponding function is triggered.
Long Press	Long press refers to pressing the button and keeping it pressed. When the duration of pressing the button exceeds the long press setting time (usually 2s) to trigger the corresponding function.

4. Basic Function Operation

1.1 Turn on/off

Keep the normal connection between the instrument and the controller, and press and hold when the instrument is turned off.

Press the power button, and then enter the basic interface normally and start working; press and hold the button when the instrument is turned on, and the instrument will display the startup LOGO when it is turned on, and there will be no LOGO when it is turned off. The set shutdown time will automatically turn off if the rider does not perform any operation on the instrument within 5 minutes. The shutdown time can be customized by the user as on or off. As shown below: First, quickly click the power button twice to enter the setting mode, select UNIT, select KM/H, and confirm with the power button.



1.2 Power assist gear switching

In the power-on working state, long press the DOWN button to switch to the power assist position.

* The power assist display has one mode by default. You can indicate the requirements in the order, or you can modify the selection by yourself through the advanced setting function and auxiliary tools of the instrument.

Power assist display mode: WALK mode, long press DOWN key to switch; there are also OFF, ECO, SPORT, BOOST modes, press DOWM/UP key to switch


WALK: walking mode

OFF:No enter boost mode

ECO:Energy saving mode

SPORT:Sport Mode

BOOST:Overclocking mode




1.3 Display information switch

When the phone is powered on, enter the function display interface and switch the display information. Quickly click the power button twice to enter the setting mode.

If the user does not perform any key operations for more than 30 seconds in the setting mode, it will automatically return to the main display interface.

The function display interface displays a single riding time, average speed, maximum speed, single riding mileage, remaining mileage and total mileage.

The switching process of each interface is shown in the figure below:



*If the system does not support the BMS communication function, the instrument cannot obtain accurate RANGE information, and the RANGE item value on the instrument is displayed as ---KM.

1.4 Speed display switching

The instrument provides a speed display function. Under normal conditions, the instrument interface displays real-time speed, average speed AVG and maximum speed MAX. The user can choose to switch through the power button. For details, refer to 6.3 Display Information Switching.

1.5 Battery display and corresponding power output

Battery information indication and remaining percentage indication. When the battery power is normal, it changes according to the battery capacity.

Before establishing communication with the controller during power-on, the percentage is not displayed. If the communication is not successful after 10 seconds of power-on, an 08 fault will be reported.

The corresponding table of battery capacity percentage and power display icon is as follows (BMS or controller is required to provide power

percentage):

Remaining percentage information	Battery bar indicator
SOC = 100%	
$20\% \leq \text{SOC} \leq 100\%$	
$1\% \leq \text{SOC} \leq 20\%$	
SOC = 0%	

5. Basic setting function


Quickly click the power button twice to enter the setting interface, and short press the adjustment button $\curvearrowleft \curvearrowright$ to cycle through the setting interface. In any setting interface, short press the power button to enter the parameter editing state. When entering the parameter editing and setting state, the selected parameter will be displayed with white characters on a red background. as the picture shows:



At this time, short press \wedge , \vee to modify parameters. Short press the power button to confirm parameter selection and edit status. Switch to EXIT again and confirm to exit the current configuration interface and return to the upper menu interface.

After turning on the computer, quickly click the power button twice to enter the setting mode setting interface. The parameter setting interfaces are described in order as follows:

Setup items	Interface content	Parameter value definition	instruction manual
Unit settings		Value=KM/H MPH	default value Value=KM/H KM/H—Metric MPH—imperial
Backlight intensity setting		20%、40%、60%、80%、100%	Default Value= 60%
clear data		Select yes or no	Clear all data except total mileage
hibernate		read only	/

Power-on password setting		Value= OFF and ON; When the parameter value is ON, the user is allowed to set a 4-digit password	默认值为: 4132
Information show		Select yes or no	/
Battery information		/	/
Controller information		/	/
Clear Data		Select YES to confirm, NO to exit	/
bluetooth link		Select YES to confirm, NO to exit	/

6.Data clearing

Data clearing mainly focuses on clearing data information such as single mileage, average speed and maximum speed.

1.In the setting mode, select RESET and then select the YES option. Data clearing is mainly aimed at clearing data information such as single mileage, average speed, maximum speed, and riding time. The password settings will not be cleared. If there is no key operation for 30 seconds, it will return to the main interface.

2. After the data is cleared, the mileage, average speed, maximum speed, and riding time will also be reset to zero; the accumulated mileage TOT value will not be cleared through any operation on the instrument side.



After the data is cleared, the subtotal mileage returns to zero, as does the average speed and maximum speed; the accumulated mileage ODO value is not cleared through any operation on the instrument side and requires professional maintenance tools to clear it.