

**TECHNICAL MANUAL**   **ENGLISH**

**AS-WT-VW**

**Weighing Indicator**

V1.07  
REV:Y1,March,2020



# CONTENTS

1. PRECAUTIONS.....	- 1 -
2. PRODUCT DESCRIPTION.....	- 2 -
2.1 General .....	- 2 -
2.2 Overall view .....	- 2 -
3. INSTALLATION.....	- 3 -
3.1 Unpacking .....	- 3 -
3.2 Installation .....	- 3 -
3.3 Load cell connections.....	- 3 -
3.4 Power Connection .....	- 3 -
3.5 Dry battery operation .....	- 4 -
4. DISPLAY&KEYS FUNTION.....	- 5 -
4.1 Key Board .....	- 5 -
4.2 Indication Description.....	- 6 -
5. OPERATION.....	- 7 -
5.1 Switching on/off.....	- 7 -
5.2 Zeroing .....	- 7 -
5.3 Using Tare .....	- 7 -
5.4 Select Weighing Unit.....	- 8 -
5.5 Check weighing &Check counting.....	- 8 -
5.5.1 Set Check Weighing Mode .....	- 8 -
5.5.2 Limits setting for target weight.....	- 9 -
5.6 Accumulation.....	- 10 -
5.6.1 Accumulation Operation.....	- 10 -
5.6.2 Memory Recall .....	- 10 -
5.6.3 Memory Clear .....	- 10 -
5.7 Hold.....	- 10 -
5.8 Backlight Setting .....	- 11 -
5.9 Auto Power Off Setting .....	- 11 -
5.10 Motion Weighing .....	- 12 -
6. PARAMETERS.....	- 13 -
7. CALIBRATION .....	- 16 -
7.1 Linear Calibration.....	- 16 -
7.2 Normal Calibration.....	- 17 -
8. RS-232 OUTPUT .....	- 19 -
8.1 Specifications .....	- 19 -
8.2 RS-232 (9pin D type connector).....	- 19 -
8.3 Continuously output protocol.....	- 19 -
8.4 Print Formats .....	- 19 -
9. TECHNICAL DATA .....	- 20 -
9.1 General Specification .....	- 20 -
9.2 Overall Dimensions .....	- 20 -
10. ERROR CODES .....	- 21 -
11. EXPLODER DRAWING.....	- 22 -



## 1. PRECAUTIONS

	 <b>WARNING</b>
<p><b>DISCONNECT ALL POWER TO THIS UNIT BEFORE INSTALLING, CLEANING, OR SERVICING. FAILURE TO DO SO COULD RESULT IN BODILY HARM OR DAMAGE THE UNIT.</b></p>	

 <b>CAUTION</b>
<ul style="list-style-type: none"><li>• <b>Permit only qualified persons to service the instrument</b></li><li>• <b>Before connecting or disconnecting any components, remove the power.</b></li><li>• <b>Failure to observe these precautions bodily harm or damage to or destruction of the equipment.</b></li></ul>




- The weighing indicator is a precision electronic instrument, handle it carefully.
- Do not install the scale in direct sunlight.
- Verify the local voltage and receptacle type are correct for the scale.
- Only use original adaptor, other could cause damage to the scale.
- Pluggable equipment must be installed near an easily accessible socket outlet.
- Avoid unstable power sources. Do not use near large users of electricity such as welding equipment or large motors.
- Avoid sudden temperature changes, vibration, wind and water.
- Avoid heavy RF noise.
- Keep the indicator clean

## 2. PRODUCT DESCRIPTION

### 2.1 General

- The AS-WT-VW series weighing indicator that amplifies signals from a load cell, converts it to digital data and displays it as a mass value.
- It is suitable for general weighing or more specialized applications such as check weighing, parts counting, motion weighing and accumulation applications.
- It can connect the indicator to a printer or a PC.
- 22mm high digits LCD display with white LED backlight

### 2.2 Overall view



## 3. INSTALLATION

### 3.1 Unpacking

When you receive the indicator, inspect it to make sure that it is not damaged and that all parts are included:

- Remove the Indicator from the carton.
- Remove the protective covering. Store the packaging and to use if you need to transport the scale later.
- Inspect the indicator for damage.
- Make sure all components are included.
  1. Indicator
  2. Adaptor
  3. Manual
  4. Load cell Output connector
  5. Indicator wall bracket

### 3.2 Installation

- Place the Indicator on a table or use indicator holder to connect with stand.
- Connect the platform load cell cable in to the indicator load cell connector. Load cell connector is locating back side of the indicator.

### 3.3 Load cell connections

Connect the load cell cables to the terminal as shown below.

Pin	Connection
Pin 1	Signal +
Pin 2	Signal -
Pin 3	Shield
Pin 4	Exc -
Pin 5	Exc +

It can connect four 350ohm load cells.

The load cell drive voltage is 3.3V DC  $\pm 5\%$  between Excitation + and Excitation -.

### 3.4 Power Connection

- Connect the adaptor pin in to the indicator adaptor jack. Adaptor jack is locating, back side of the indicator.

- Adaptor connects into your AC power socket. Pluggable equipment must be installed near an easily accessible socket outlet with a protective ground/ earth contact.

### 3.5 Dry battery operation

- The indicator can also be operated with 4x AA batteries.
- If the batteries are empty, display will appear the battery empty symbol. Change batteries. To save battery power, the indicator switches off automatically

	Capacity of batteries exhausted
	Batteries will soon be flat
	Batteries are completely charged


- If the indicator is not used for a longer time, take out the batteries and store them separately. Leaking battery liquid could damage the indicator.

#### 3.5.1 Battery installation

1. Open battery compartment cover at the back side of the indicator.	
2. Insert batteries into battery compartment.	
3. Lock the battery cover again.	


## 4. DISPLAY&KEYS FUNTION

### 4.1 Key Board



Keys	Description
	On/off key, Used to turn the scale on or off
	1) Zero key, used to clear and zero the display 2) Enter key, used to enter the selected menu, sub-menu and setting
	1) Tare key, used to perform a tare function, Subtracts weights 2) Lock key, press and hold the key to lock weighing value 3) Setup menu key, to enter the setup menu 4) To change the menu option in menu setting 5) Value increment key, used to change the selected digit value
	1) Unit key, used to convert the weighing units 2) Accumulation key. Used to enter and show accumulated weights in memory 3) Memory recall key, show the stored values from the memory 4) Left arrow key, used to move the digit to the left 5) ESC key, used to exit the set-up menu. 6) Print key, used to send the data to printer or PC

## 4.2 Indication Description



DISPLAY	FUNCTION
HI OK LOW	Limits indicator. Indicates the high-low limits in weighing and counting.
ZERO	Zero indicator. Indicates the scale is at zero.
GROSS	Indicator for Gross weight
NET	Net indicator. Indicates scale is displaying the net weight.
STABLE	Stable indicator. Indicates the scale weight is stable.
M+	Accumulation indicator. Indicates the scale is in accumulation mode
HOLD	Hold Indicator. Indicates the weighing value is locked
	Battery indicator. Indicates battery is low and needs to be recharged.
ANIMAL	Motion weighing indicator. Indicates the scale is in motion weighing mode.

## 5. OPERATION

### Initial Start-up

Warm-up time of 15 minutes stabilizes the measured values after switching on.

#### 5.1 Switching on/off

- Switch on the indicator by pressing  key. Display will be show the scale version and will be starting self-checking.
- After self-checking, display will be come to normal weighing mode.
- To switched off the scale, press  key again.

#### 5.2 Zeroing

Environmental conditions can lead to the balance exactly zero in spite of the platform not taking any strain. However, you can set the display of your balance to zero

any time by pressing  key and therefore ensure that the weighing starts at zero.

#### 5.3 Using Tare

The weight of any container can be tared by pressing  button so that with subsequent weighing the net weight of the object being weighed is always displayed.

##### Taring a container

- Load weight on the platform.
- Press  key. Zero is displayed, and tare is subtracted. And NET indicator will be on.
- Remove weight on the platform. Tared weight is displayed. It can set only one tare value. It will be shown with a minus value.

##### Muti-tare

- Load weight on the platform.
- Press  key. Zero is displayed, and tare is subtracted. And NET lamb on.
- Load another weight on the platform.



- Press **TARE HOLD** key. Zero is displayed, and tare is subtracted. And NET &stable lamb on.
- Remove weight on the platform. Total tared weight is displayed. It will be shown with a minus value.

### Clearing tare

- To clear the tare value, remove the load from the platform
- Press **TARE HOLD** key. Zero is displayed, the NET lamb off, tare weight is cleared.

## 5.4 Select Weighing Unit



Press the **UNIT M+** key to change the weighing units (kg/g/lb/oz/lb.oz)

## 5.5 Check weighing &Check counting

It can set an upper or lower limit when weighing or counting with the limits range. During the limit controls dividing the unit will indicate whether a value upper or lower limits with an alarm sound.

- When the weight below the low limits, the display will be show LO
- When the weight between the limits, the display will be show OK
- When the weight exceeds the high limits, the display will be show HI

**Note: Check weighing or counting available only when weight more than 20d**

### 5.5.1 Set Check Weighing Mode



Press **TARE HOLD** key during self-checking. Display will appear **F1 CHK**.



Press **ZERO** key to enter display will be show **SET HI**.



Press **TARE HOLD** key until display show **BEEP**.



Press **ZERO** key to select BEEP mode.

BEEP Mode	Description
OK	1. Beeper sounded if the weight is within the limits, OK indicator on 2. Beeper off if the weight is below the lower limits, LO indicator on 3. Beeper off if the weight is exceeding the upper limits, HI indicator on
NG	1. Beeper off if the weight is within the limits, OK indicator on 2. Beeper on if the weight is below the lower limits, LO indicator on 3. Beeper on if the weight is exceeding the upper limits, HI indicator on
OFF	1. Beeper off if the weight is within the limits, OK indicator on 2. Beeper off if the weight is below the lower limits, LO indicator on 3. Beeper off if the weight is exceeding the upper limits, HI indicator on

**Note: Check weighing available only when weight more than 20d**

### 5.5.2 Limits setting for target weight

- Press  key during self-checking. Display will appear **F1 CHK**.
- Press  key to enter display will be show **SET HI**.
- Press  key to enter, display will show **000.000kg**
- Enter the upper limit value, using  keys to move digits to left and using  key to increment the value.
- Press  key to confirm, display will back to setting menu
- Press  key to select **SET LOW**
- Press  key to enter, display will show **000.000kg**
- Enter the lower limit value, using  keys to move digits to left and using  key to increment the value.

- Press  key to confirm, display will back to setting menu,
- Press  key twice to back to normal weighing mode

**Note: To disable the check weighing function, enter zero into both limits.**

## 5.6 Accumulation

The scale can be set to accumulate manually by pressing  key. Before operation scale should be stable and return to zero, accumulation available only when weight more than 20d

### 5.6.1 Accumulation Operation

- Place the load on the platform.
- Press and hold  key, when STABLE indicator on.
- Display will be show ACC 01, and then the total saved value appears. These displays will be shown only two seconds.
- Remove the weight from the pan.
- When display get zero and stable then place the second weight.
- It can continue until the memory gets fully or 99 items.

### 5.6.2 Memory Recall

- To recall the memory press and hold  key in zero point.
- Display will show the total saved value. These displays will be shown only two seconds.

### 5.6.3 Memory Clear

- Press and hold  key in zero point, display will be show the total saved value
- Press  key, all accumulation value will be cleared from the memory and back to normal weighing mode.

## 5.7 Hold

- In the normal weighing mode, load the weight on the platform, when stable

indicator on, press  key, remove the weight, the reading value will be locked and HOLD indicator will be on.

- Press and hold  key again to unlocked and back to normal weighing mode

## 5.8 Backlight Setting

- Press  key during self-checking. Display will be show **F1 CHK**
- Press  key until display show **F6 BK**
- Press  key to enter, the display will be show **BK AU**
- Press  key to select (**BK AUTO/BK OFF/bk on**), After select the back light option press  key to confirm and come to the weighing mode

Display	Description
<b>Bk AUto</b>	Backlight will be turned on, when start to use or when weight is not in zero.
<b>Bk oFf</b>	Backlight function will be turned off
<b>Bk on</b>	Backlight function will be turned on

**Note: If the battery gets low, the backlight function will not be available**

## 5.9 Auto Power Off Setting

- Press  key during self-checking, display will be show **F1 CHK**,
- Press  key until display show **F7 OFF**,
- Press  key to change auto power off time: 0/5/10/20/30.  
(of 0: always on, of xx: auto power off after standby xx minutes)

- Press  key to sure, press  key to escape from the menu, and back to normal weighing mode.

## 5.10 Motion Weighing

It can use for vibrate loads weigh. This function can use for animal weighing.

For settings, select the parameter **F10 ANM » ON**, to enter motion weighing mode animal indicator will be displayed

- Press  key during self-checking. Display will be show **F1 CHK**.
- Press  key until display show **F10 ANM**.
- Press  key to enter, the display will be show **OFF**.
- Press  key to select the option **ON**.
- Press  key to confirm.
- Press  key to back to normal weighing mode
- Make sure platter empty, and scale return to zero
- Bring the load on the platform
- when the load few seconds get stable, the reading will be locked for few seconds
- It can add or remove loads also update the weighing locked values.

To disable the motion weighing function, enter parameter to select **F10 ANM » Off**, scale will be back to normal weighing mode, and animal indicator off

## 6. PARAMETERS

### KEYS OPERATIONS INTO THE MENU

#### Enter the menu

- During self-checking, press  key.

#### Select the menu

- Press  key, it can change the menu block one by one.
- Using increase the digit.

#### Enter the selected menu

- Press  key, it can confirm, which will be shown displayed.

#### Return to weighing mode

- Press  key, exit from the menu.

### PARAMETER BLOCK

Menu	Description			Default
F1 chk	SET HI	Set high limits		0000
	SET LOW	Set low limits		0000
	BEEP	Select beep mode, Options: OFF (turn off the function), OK (beep sound will be active when it's in OK range), NG (beep sound will be active when it's in out of the range)		OFF
F2 com	mode	prt	Send data to PC or printer one time when press and hold <b>UNIT/M+</b> key	CONT
		off	RS232 function disable	
		cont	Send data continuous	

F2 com	baud	1200	To set baud rate	9600
		2400		
		4800		
		9600		
		115200		
	verity	8N1	To set the parity	8N1
		7e1		
		7o1		
	desc	0	To set to use decimal point	
		0.0		
		0.00		
		0.000		
F3 cal	dual	on	Dual interval mode In this mode, need to set division1 and division 2, capacity 1 and capacity 2	
		off	Single interval mode	
	div	1	To set division	
		2		
		5		
		10		
		20		
		50		
	cap		To set capacity	
	cal	kg	Calibration in kg mode	
		lb	Calibration in lb mode	
	L-cal	kg	Linear Calibration in kg mode	
		lb	Linear Calibration in lb mode	
F4inp	To show the Internal counts			
F5 ref	0 auto	2	Initial Zero setting range. When the display is turn on the scale is set to zero	20
		5		
		10		
		20		
		50		
	0 range	2	Manually zero setting range, by pressing ZERO key	5
		5		
		10		
		20		
		50		

F5 ref	Azn 0	0.5d	Auto zero range settings	2d		
		1d				
		2d				
		4d				
F6 bk	Off	To set backlight		AUTO		
	auto					
	on					
F7 off	5 min	Set power automatic turn off the scale		0		
	10 min					
	20 min					
	30 min					
	0					
F8 gra	xxxx	Set the local gravity value				
F9 unt	kg	To set "kg" unit options on/off.		ON		
	g	To set "g" unit options on/off. (lb or kg must be set to .000 to be able to turn on grams) once selected to the main weight, screen change unit to g then enter back into F9 UNIT and you can turn off kg or lb if needed				
	lb	To set "lb" unit options on/off.				
	oz	To set "oz" unit options on/off.				
	lz	To set "lz" unit options on/off.				
F10 anm	on	Animal function		OFF		
	off					

**Com settings****PS: For getting data, minimum weight should be 20d when in prt mode**

## 7. CALIBRATION

### 7.1 Linear Calibration

1. Press  key during self-checking the display will show F1 chk

2. Press  key to select until the display shows F3 cal

3. Enter the function by pressing "ZERO" key, display will show desc

4. Press  key to select until the display shows L-cal

5. Press  key to confirm, the display will show Kg

a. If calibrating in **Kg**, continue step 6

b. If calibrating in **lb**, press  key, **lb** will be show on the display

6. Enter the function by pressing  key, display will be show load 0

Make sure there are no loads on the platform

7. Press  key to confirm when display gets stable, display shows load 1

8. Place test weight 1 on the platform

9. Press  key to confirm when display gets stable, display shows load 2

10. Place test weight 2 on the platform

11. Press  key to confirm when display gets stable, display shows load 3

12. Place test weight 3 (full scale capacity) on the platform

13. Press  key to confirm when display gets stable, display shows load 2

14. After stable and zero indicator on, Remove the third calibration mass weight from the platform

15. Press  key to confirm when display gets stable, display shows load 1

16. After stable and zero indicator on, Remove the second calibration mass weight from the platform

17. Press  key to confirm when display gets stable, display shows  **load 0**


18. After stable and zero indicator on, Remove the last calibration mass weight from the platform  
press  key, display will be shown  **pass**

Display will be self-test and come to the normal weighing mode.

If display will be shown any error or incorrect value, repeat the procedure again.

## 7.2 Normal Calibration

1. Press  key during self-checking the display will show  **F1 chk**

2. Press  key to select until the display show  **F3 cal**

3. Enter the function by pressing  key, display will show  **desc**

4. Press  key to select until the display shows  **cal**

5. Press  key to confirm, the display will show  **Kg**


a. If calibrating in **kg**, continue step 6

b. If calibrating in **lb**, press  key, **lb** will be show on the display

Make sure there are no loads on the platform

**PS: Press  key to choose "kg" or "lb" unit, capacity will be show in kg or lb values.**

6. Enter the function by pressing  key, display will be shown  **unload**  
Currently adjustment, and wait few seconds for stable indicator on.

7. Enter the function by pressing  key, display will be shown  **006.000**



8. If want to change by using the keys, press key and key to change the weight value

9. Press key to enter, display will be show

load

10. Load the calibration mass weight (full scale capacity) on the platform and wait few seconds for display stability.



11. After the stable indicator on press key, display will be shown

pass

Remove the load from platform, Display will be self-test and come to the normal weighing mode.

If display will be shown any error or incorrect value, repeat the procedure again.

*Note: If it's required to calibrate, linear calibration must be operated firstly, then follow to normal calibration*

## 8. RS-232 OUTPUT

AS-WT-WV series indicator can take out data through RS 232 output.

### 8.1 Specifications

RS-232 output of weighing data

Code : ASCII  
 Data bits : 8 data bits  
 Parity : No Parity  
 Baud rate : 1200-115200bps

### 8.2 RS-232 (9pin D type connector)

Pin 2	RXD	Input	Receiving data
Pin 3	TXD	Output	Transmission data
Pin 5	GND	—	Signal ground

#### 9pin D Connector:

Indicator	Computer
Pin 2:	Pin 3
Pin 3:	Pin 2
Pin 5:	Pin 5

### 8.3 Continuously output protocol

HEADER1: ST=STABLE, US=UNSTABLE

HEADER2: NT=NET, GS=GROSS,WEIGHING UNIT:KG

Stable data communication



### 8.4 Print Formats

NO: 1  
 G: 25.0kg  
 N: 25.0kg  
 T: 0.0kg  
 Total: 25.0kg


NO: 2  
 G: 25.0kg  
 N: 25.0kg  
 T: 0.0kg  
 Total: 50.0kg

## 9. TECHNICAL DATA

### 9.1 General Specification

Model	AS-WT-VW
Display	22mm digit LCD display with white LED backlight
Housing	ABS plastic
Operating Temperature	0°C - 40°C / 32°F - 104°F
Resolution	30000d
Key Pad	4 mechanical keys
Power	AC Adaptor (12V/500mA)/ Dry Battery (1.5Vx4 AA )
Units of Measure	kg/g/lb/oz/lb:oz
Calibration	Automatic External
Interface	RS-232 Output standard
Load cell drive Voltage	3.3V/150mA
Load Cells	Up to 4 load cell
ADC	Sigma Delta
ADC Update	≤1/10 second
Stabilization Time	One seconds typical
Gross Weight	1.4kg
Net Weight	0.8kg
Dimensions	43.72(W)x229.7(D)x112.08(H)mm


### 9.2 Overall Dimensions



## 10. ERROR CODES

Error Message	Description	Solution
Err 4	Zero setting error	Zero setting range exceeded due to switching on. Make sure platform empty.
--ol--	Over range	Remove the load. Re calibrate
Err 6	A/D value out of range	Make sure platform empty and check the pan is installed proper. Check the load cell connectors.
BAT LO	Battery low	Re charge battery, check the voltages.

## 11. EXPLoder DRAWING



No.	Name	Spec.
1.	Overlay	1
2.	Top cover	1
3.	Main board	1
4.	+ self thread screw	4;ST3x8
5.	Bottom cover	1
6.	Gasket	2
7.	Nut	2;M6
8.	AC adapter jack	1
9.	Air connector	1
10.	Battery cover	1
11.	Screw	2;M6
12.	+ screw	4;M3*8
13.	Bracket	1
14.	Rubber mat for bracket	2
15.	Cable gland	1;M16
16.	Battery	4;AA
17.	Battery clip	1