



FOLDING DRONE

USER MANUAL

Thank you for choosing our products. Please read this manual carefully before operating. Please keep this manual for future reference. Please refer to the actual object, if the picture does not match the actual object.

SAFETY PRECAUTIONS AND STATEMENTS

1. This product is suitable for people over the age of 14. Please ensure that you operate in a safe environment. Please be sure to use it correctly in strict accordance with safety precautions and the Operation Manual. Please note that any modification, disassembly, or improper use may cause unexpected hazards or accidents.

2. The company is not responsible for improper assembly by users, unsafe environment, unauthorized modification, disassembly, and other illegal operations.

3. This product is a high-tech operational consumable, so any disassembly or modification may cause damage to the components. If any improper operation causes problems with the product, it will not be possible to replace or return the product within the warranty conditions. If there are problems with use, operation, and maintenance, our agent or after-sales service will provide technical guidance and special price parts supply services.

4. Drones are dangerous goods. When flying, be sure to stay away from people and obstacles, and operate within a safe distance (more than 4 meters). Improper assembly, damage to components, poor electronic control equipment, and improper operation can lead to unpredictable damage and accidents caused by uncontrolled flight. Pilots must pay attention to flight safety and understand flight requirements and responsibilities in detail.

5. This product is suitable for indoor and outdoor use. It is strictly prohibited to fly it in areas with dangerous high-voltage electricity and protected by the state.

6. When this product is not used for a long time, please turn off the power supply and take out the battery to prevent danger from battery leakage.

MAINTENANCE

1. Frequently use a clean soft cloth to clean this product.

2. Avoid exposing this product to sunlight or heat.

3. Do not immerse this product in water, otherwise its electronic parts will be damaged.

4. Regularly check the plug and other accessories. If any damage is found, please immediately stop using it until it is completely repaired.

The company reserves the final interpretation right of this manual

CONTENTS

Propeller Replacement Method

1. Please ensure that all propellers are installed in the correct orientation as shown in the following figure. If the installation is incorrect, the aircraft will not be able to fly normally. (Figure 1)

2. Installed. (Figure 2)

INTRODUCTION TO DRONE PARTS AND REMOTE CONTROLLER

REMOTE CONTROLLER CHARGING

1. Connect one end of the USB charging cable to the adapter power port and the other to the battery charging port. When properly charged, the battery light indicator will remain on.

2. The battery indicator light is off, indicating that charging is complete (charging time is about 90 minutes)

CHARGING PRECAUTIONS

Do not place the battery in high temperatures or heated places, such as open flames or electric heating devices, otherwise it may be damaged or explode.

Do not hit the battery or use it to hit the surface of hard objects.

Do not disassemble the battery.

Do not immerse the battery in water. The battery should be stored in a dry place.

Do not charge when the battery is overheated.

Do not charge the battery when it heats up after the drone running.

Please use the original USB charging cable to charge the battery.

DRONE BATTERY INSTALLATION

1. Install the battery module into the battery holder of the drone in the direction shown in the figure to a fixed position. (Figure 1)

2. Installed. (Figure 2)

READY TO FLY

POWER ON

Method 1: Place the drone on a horizontal surface, turn on the drone power switch, and the lights flash. The drone is now in standby mode.

Method 2: When the drone is in flight, press the "One Press Landing" button, and the drone slowly descends to the ground and shut down the drone.

Note: The tail of the aircraft shall face the pilot.

HORIZONTAL CALIBRATION

FLIGHT OPERATION MANUAL

HIGH AND LOW SPEED SWITCHING

During flight, you can press this function key to switch between forward, backward, left, and right flight speeds. The default setting when powering on is in low speed gear. Press this function key once to switch to medium speed gear, and the remote controller beeper emits two "tick" sounds. At the same time, after the buzzer of the remote controller beeps, the horizontal calibration is completed.

360°FLIP

Short press the "360°Flip" button, and the remote controller beeper emits a "tick" sound. Push the right control stick and the drone rolls in the direction of the push. At the same time, the sound disappears, the drone enters the normal mode.

START THE DRONE

Method 1:

Step 1: Move the remote controller's left control stick at 45° to the left and right control stick at 45° to the right, the propellers slowly rotate, and the drone is unlocked.

Step 2: After the drone is unlocked, push the left control stick upward, and the propellers accelerate to rotate and the propellers accelerate to rotate.

Note: When the battery is fully charged, the roll-over effect is best. Unable to roll when under low power.

LOW POWER MODE

During flight the drone indicator light flashes slowly or the remote controller emits "drip" sounds, indicating low battery power and the need to end the flight. Flying with lower power can cause the drone to fall out of control and damage.

CAMERA ANGLE CONTROL

CHARGING PRECAUTIONS

Do not place the battery in high temperatures or heated places, such as open flames or electric heating devices, otherwise it may be damaged or explode.

Do not hit the battery or use it to hit the surface of hard objects.

Do not disassemble the battery.

Do not immerse the battery in water. The battery should be stored in a dry place.

Do not charge when the battery is overheated.

Do not charge the battery when it heats up after the drone running.

Please use the original USB charging cable to charge the battery.

SHUT DOWN THE DRONE

1. After unlocking the drone, press the "One Press Takeoff" button on the remote controller, and the drone will automatically rise to a height of about 2 meters and hover.

2. When the drone is in flight, press the "One Press Landing" button, and the lights flash. The drone is now in standby mode.

Note: The tail of the aircraft shall face the pilot.

FLIGHT OPERATION MANUAL

ONE PRESS TAKEOFF/LANDING

1. After unlocking the drone, press the "One Press Takeoff" button on the remote controller, and the drone will automatically rise to a height of about 2 meters and hover.

2. When the drone is in flight, press the "One Press Landing" button, and the lights flash. The drone is now in standby mode.

Note: The tail of the aircraft shall face the pilot.

HEADLESS MODE

When the drone is taking off, the remote controller must be facing the tail of the drone. After the takeoff is complete, press the remote controller "Headless Mode" button to enter the Headless Mode. The drone lights flash, and the remote controller beeps. During the descent process, you can control the drone to land at a designated location through the right control stick and the propellers will stop rotating.

AUTO RETURN

Long press and hold the "Auto Return" button, and the drone will fly back and parallel to the original takeoff path. Long press and hold the button again to exit the return mode. Manipulate the right control stick forward and backward movements to interrupt the function during the return process.

REMOTE CONTROL PHOTO AND VIDEO RECORDING

1. Short press the remote controller photo button, and the indicator light behind the drone begins to flash.

2. Long press and hold the remote controller photo button, and the indicator light behind the drone flashes quickly, indicating that the drone is recording video. Press and hold the remote controller photo button again, and the indicator light behind the drone will turn on permanently, indicating that the drone has exited the shooting state.

NOTE

1. Item control distance: 80-100 meters. The drone and the distance will be subject to remote control. The drone is not equipped with a GPS and cannot automatically return to the remote control.

2. When the drone is in a stationary state after completing frequency alignment and horizontal calibration, press the "One Press Takeoff" button on the remote controller. The "Auto Return" function of this drone needs to be within the remote control range to be normal.

3. When the transmission distance is 50 meters, the battery will be exhausted.

4. It is recommended to install propeller guards when using it in crowded places to prevent damage to people or property.

READY TO FLY

POWER ON

Method 1: Place the drone on a horizontal surface, turn on the drone power switch, and the lights flash. The drone is now in standby mode.

Method 2: When the drone is in flight, press the "One Press Landing" button, and the drone slowly descends to the ground and shut down the drone.

Note: The tail of the aircraft shall face the pilot.

HORIZONTAL CALIBRATION

FLIGHT OPERATION MANUAL

HIGH AND LOW SPEED SWITCHING

During flight, you can press this function key to switch between forward, backward, left, and right flight speeds. The default setting when powering on is in low speed gear. Press this function key once to switch to medium speed gear, and the remote controller beeper emits two "tick" sounds. At the same time, after the buzzer of the remote controller beeps, the horizontal calibration is completed.

360°FLIP

Short press the "360°Flip" button, and the remote controller beeper emits a "tick" sound. Push the right control stick and the drone rolls in the direction of the push. At the same time, the sound disappears, the drone enters the normal mode.

START THE DRONE

Method 1:

Step 1: Move the remote controller's left control stick at 45° to the left and right control stick at 45° to the right, the propellers slowly rotate, and the drone is unlocked.

Step 2: After the drone is unlocked, push the left control stick upward, and the propellers accelerate to rotate and the propellers accelerate to rotate.

Note: When the battery is fully charged, the roll-over effect is best. Unable to roll when under low power.

LOW POWER MODE

During flight the drone indicator light flashes slowly or the remote controller emits "drip" sounds, indicating low battery power and the need to end the flight. Flying with lower power can cause the drone to fall out of control and damage.

CAMERA ANGLE CONTROL

CHARGING PRECAUTIONS

Do not place the battery in high temperatures or heated places, such as open flames or electric heating devices, otherwise it may be damaged or explode.

Do not hit the battery or use it to hit the surface of hard objects.

Do not disassemble the battery.

Do not immerse the battery in water. The battery should be stored in a dry place.

Do not charge when the battery is overheated.

Do not charge the battery when it heats up after the drone running.

Please use the original USB charging cable to charge the battery.

SHUT DOWN THE DRONE

1. After unlocking the drone, press the "One Press Takeoff" button on the remote controller, and the drone will automatically rise to a height of about 2 meters and hover.

2. When the drone is in flight, press the "One Press Landing" button, and the lights flash. The drone is now in standby mode.

Note: The tail of the aircraft shall face the pilot.

FLIGHT OPERATION MANUAL

ONE PRESS TAKEOFF/LANDING

1. After unlocking the drone, press the "One Press Takeoff" button on the remote controller, and the drone will automatically rise to a height of about 2 meters and hover.

2. When the drone is in flight, press the "One Press Landing" button, and the lights flash. The drone is now in standby mode.

Note: The tail of the aircraft shall face the pilot.

HEADLESS MODE

When the drone is taking off, the remote controller must be facing the tail of the drone. After the takeoff is complete, press the remote controller "Headless Mode" button to enter the Headless Mode. The drone lights flash, and the remote controller beeps. During the descent process, you can control the drone to land at a designated location through the right control stick and the propellers will stop rotating.

AUTO RETURN

Long press and hold the "Auto Return" button, and the drone will fly back and parallel to the original takeoff path. Long press and hold the button again to exit the return mode. Manipulate the right control stick forward and backward movements to interrupt the function during the return process.

REMOTE CONTROL PHOTO AND VIDEO RECORDING

1. Short press the remote controller photo button, and the indicator light behind the drone begins to flash.

2. Long press and hold the remote controller photo button, and the indicator light behind the drone flashes quickly, indicating that the drone is recording video. Press and hold the remote controller photo button again, and the indicator light behind the drone will turn on permanently, indicating that the drone has exited the shooting state.

NOTE

1. Item control distance: 80-100 meters. The drone and the distance will be subject to remote control. The drone is not equipped with a GPS and cannot automatically return to the remote control.

2. When the drone is in a stationary state after completing frequency alignment and horizontal calibration, press the "One Press Takeoff" button on the remote controller. The "Auto Return" function of this drone needs to be within the remote control range to be normal.

3. When the transmission distance is 50 meters, the battery will be exhausted.

4. It is recommended to install propeller guards when using it in crowded places to prevent damage to people or property.

APP OPERATING GUIDE

Scan the QR code below or search "X69 DRONE" in the APP Store or Google Play to download the App.

TECHNICAL SUPPORT

For technical support or 24/7 customer service, please email us. If you receive a defective item, contact us via Amazon for a replacement or refund. We sincerely apologize for any inconvenience and are committed to providing you with full support.

Email: support@maker2service.com

Connect drone and app

In the process of using the app, you will encounter some app permission dialog boxes. Please allow the app to use these permissions, otherwise some functions of the app will not work properly. Such as:

2. Power on the drone.

3. Click the "Settings" menu on the phone to enter the WiFi settings page and turn on the WiFi switch.

4. Find the specified WiFi name "X69DRONE_XXXXXX" in the WiFi list, click the connect button, wait for the connection to succeed, and then exit the "Settings" interface. The WiFi will display "No internet Connection" which is normal and you don't need to worry about it, proceed to the next step as usual.

Control interface function

Function

Gesture Photography/Video Recording

Yeah Gesture Photography

Requirements

1. Software requirements: iOS system 10.0 or above, running memory 1G or above.
2. Hardware requirements: iPhone 6 and above.
3. Requirement: Please allow network connection during use.

1. Turn on the "Control Switch", click the "Trajectory Flight" button, and the interface shown in Figure 1 will pop up. Draw the route trajectory on this interface, and the drone will fly according to the route.

2. After the dialog box depicts the trajectory, the drone will fly according to the displayed trajectory. Note: The "Trajectory Flight" function can only be used normally when the drone is hovering.

OVERHAUL PROCEDURE

Problem	Reason	Solution
The drone doesn't respond.	1. The drone enters the low electric protection mode. 2. Remote controller battery is low, and the power indicator blinks.	1. Change drone. 2. Replace remote controller battery.
The drone is not responsive.	1. The remote controller has low power. 2. Remote controller with the same frequency are transmitting interference.	1. Replace remote controller. 2. Change a place where there is no interference of the same frequency.
Fly sideways while hovering.	1. Horizontal calibration is not performed.	1. Perform horizontal calibration, see page 4 of the manual.
Deviation from straight ahead direction under Headless Mode.	1. Deviation caused by multiple collisions. 2. Atmospheric pressure is unstable under certain weather conditions. 3. Severe collision causes geoprobe data disorder.	1. Reduce the flight distance, see "Headless Mode" on page 7 of the manual. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.
Unstable height setting/ up and down movement.	1. Horizontal calibration is not performed. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.	1. Perform horizontal calibration, see page 4 of the manual. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.

Control interface function

Function

Gesture Photography/Video Recording

Yeah Gesture Photography

Requirements

1. Software requirements: iOS system 10.0 or above, running memory 1G or above.
2. Hardware requirements: iPhone 6 and above.
3. Requirement: Please allow network connection during use.

1. Turn on the "Control Switch", click the "Trajectory Flight" button, and the interface shown in Figure 1 will pop up. Draw the route trajectory on this interface, and the drone will fly according to the route.

2. After the dialog box depicts the trajectory, the drone will fly according to the displayed trajectory. Note: The "Trajectory Flight" function can only be used normally when the drone is hovering.

OVERHAUL PROCEDURE

Problem	Reason	Solution
The drone doesn't respond.	1. The drone enters the low electric protection mode. 2. Remote controller battery is low, and the power indicator blinks.	1. Change drone. 2. Replace remote controller battery.
The drone is not responsive.	1. The remote controller has low power. 2. Remote controller with the same frequency are transmitting interference.	1. Replace remote controller. 2. Change a place where there is no interference of the same frequency.
Fly sideways while hovering.	1. Horizontal calibration is not performed.	1. Perform horizontal calibration, see page 4 of the manual.
Deviation from straight ahead direction under Headless Mode.	1. Deviation caused by multiple collisions. 2. Atmospheric pressure is unstable under certain weather conditions. 3. Severe collision causes geoprobe data disorder.	1. Reduce the flight distance, see "Headless Mode" on page 7 of the manual. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.
Unstable height setting/ up and down movement.	1. Horizontal calibration is not performed. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.	1. Perform horizontal calibration, see page 4 of the manual. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.

Control interface function

Function

Gesture Photography/Video Recording

Yeah Gesture Photography

Requirements

1. Software requirements: iOS system 10.0 or above, running memory 1G or above.
2. Hardware requirements: iPhone 6 and above.
3. Requirement: Please allow network connection during use.

1. Turn on the "Control Switch", click the "Trajectory Flight" button, and the interface shown in Figure 1 will pop up. Draw the route trajectory on this interface, and the drone will fly according to the route.

2. After the dialog box depicts the trajectory, the drone will fly according to the displayed trajectory. Note: The "Trajectory Flight" function can only be used normally when the drone is hovering.

OVERHAUL PROCEDURE

Problem	Reason	Solution
The drone doesn't respond.	1. The drone enters the low electric protection mode. 2. Remote controller battery is low, and the power indicator blinks.	1. Change drone. 2. Replace remote controller battery.
The drone is not responsive.	1. The remote controller has low power. 2. Remote controller with the same frequency are transmitting interference.	1. Replace remote controller. 2. Change a place where there is no interference of the same frequency.
Fly sideways while hovering.	1. Horizontal calibration is not performed.	1. Perform horizontal calibration, see page 4 of the manual.
Deviation from straight ahead direction under Headless Mode.	1. Deviation caused by multiple collisions. 2. Atmospheric pressure is unstable under certain weather conditions. 3. Severe collision causes geoprobe data disorder.	1. Reduce the flight distance, see "Headless Mode" on page 7 of the manual. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.
Unstable height setting/ up and down movement.	1. Horizontal calibration is not performed. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.	1. Perform horizontal calibration, see page 4 of the manual. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.

Control interface function

Function

Gesture Photography/Video Recording

Yeah Gesture Photography

Requirements

1. Software requirements: iOS system 10.0 or above, running memory 1G or above.
2. Hardware requirements: iPhone 6 and above.
3. Requirement: Please allow network connection during use.

1. Turn on the "Control Switch", click the "Trajectory Flight" button, and the interface shown in Figure 1 will pop up. Draw the route trajectory on this interface, and the drone will fly according to the route.

2. After the dialog box depicts the trajectory, the drone will fly according to the displayed trajectory. Note: The "Trajectory Flight" function can only be used normally when the drone is hovering.

OVERHAUL PROCEDURE

Problem	Reason	Solution
The drone doesn't respond.	1. The drone enters the low electric protection mode. 2. Remote controller battery is low, and the power indicator blinks.	1. Change drone. 2. Replace remote controller battery.
The drone is not responsive.	1. The remote controller has low power. 2. Remote controller with the same frequency are transmitting interference.	1. Replace remote controller. 2. Change a place where there is no interference of the same frequency.
Fly sideways while hovering.	1. Horizontal calibration is not performed.	1. Perform horizontal calibration, see page 4 of the manual.
Deviation from straight ahead direction under Headless Mode.	1. Deviation caused by multiple collisions. 2. Atmospheric pressure is unstable under certain weather conditions. 3. Severe collision causes geoprobe data disorder.	1. Reduce the flight distance, see "Headless Mode" on page 7 of the manual. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.
Unstable height setting/ up and down movement.	1. Horizontal calibration is not performed. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.	1. Perform horizontal calibration, see page 4 of the manual. 2. Try to avoid flying under weather conditions. 3. Perform geoprobe calibration, see page 4 of the manual.

Control interface function

Function

Gesture Photography/Video Recording

Yeah Gesture Photography

Requirements

1. Software requirements: iOS system 10.0 or above, running memory 1G or above.
2. Hardware requirements: iPhone 6 and above.
3. Requirement: Please allow network connection during use.

1. Turn on the "Control Switch", click the "Trajectory Flight" button, and the interface shown in Figure 1 will pop up. Draw the route trajectory on this interface, and the