

62mm

92mm




CATALOGUE


- 01 How to wear headphones correctly 3
- 02 Product Introduction 8
- 03 Touch Operation 9
- 04 Item list 18
- 05 Warranty Statement 21

Welcome to MINISO Wireless Earphones


Take out and pair it
When using for the first time, take out the left and right earphones at the same time. When the white light and orange light of the earphones flash alternately, the earphones will enter the automatic pairing mode.



How to wear headphones correctly




1




2



3




4



5

Product Description



6

Specification of Product


Model of Product: BM21
Version: V6.0
Effective Distance: Approx. 10m
Speaker Diameter: ϕ 14.2mm
Impedance: 16 Ω
Frequency Response: 20Hz-20KHz
Microphone Sensitivity: -42dB \pm 3dB
Earphone Input: 5V \pm 35mA

Charging Case Input: 5V \pm 300mA
Charging Case Output: 5V \pm 70mA
Earphone Battery Capacity: 35mAh
Charging Case Battery Capacity: 300mAh
Duration: Approx. 4.5 H (Earphone)
Earphone Charging Time: Approx. 1.5 H
Charging Time of the Charging Case: Approx. 1 H

7


Touch Operation

Connect with Bluetooth device



8


Indicator Light Description



9

Power On


Auto power on: The Earphone is taken out of the charging case, the Earphone will be powered on, with the prompt sound of "Du". Manual power-on: Long press for 3 seconds, the Earphone will be powered on, with the prompt sound of "Du".



10


Power Off

Auto power off: Put the Earphone in the charging case, the Earphone will be powered off, with the prompt sound of "Du". Manual power off: Long press for 5 seconds, the Earphone will be powered off, with the prompt sound of "Du".



11

Once Press




12

Double Press




13

Long Press




14

Triple Press




15

Clear Bluetooth pairing history




16

Wireless pairing mode




17

Switch between game mode and music mode




18

Item list



19

Instruction *1



20

FCC ID: 2BHJR-BM21

FCC Warning:
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.
Company Name: MIBAMONT SOLUTIONS LLC
Address: 34218 HOURGLASS ST, TEMECULA, CA 92592, United States
Contact Name: Wenyi Wang
Telephone No: (951) 401-3633
Email: scotttv668@gmail.com

21

Warranty statement

MINISO product warranty card
Product number: _____ SN number: _____
Name: _____ Purchase date: _____
Telephone: _____
Address: _____
Invoice number: _____
Name: _____ (stamp)
Address: _____
Telephone: _____

22

The above guarantee does not apply to the following situations

- The validity period of the three guarantees has exceeded;
- Altering of the warranty cards and product code do not match the product itself;
- Failure of damages caused by misuse, abuse or improper transportation, use, maintenance or storage;
- Failure of damages caused by force majeure (such as earthquake, war, fire, etc.) or accident;
- Zipper and tower buckles are damaged due to excessive force;
- Offline or tear caused by overloading;
- Any damage caused by sharp objects;
- Products with signs of burn damage or water logging;
- Offline or tear caused by overloading;
- Aging, discoloration, wear, cracking and other losses that occur during normal use of the product.
- The product's original logo or label is changed or damaged; this warranty will be invalid.
- The completeness and appearance of the product and accompanying materials are not covered by the warranty. You should inspect the product on site when receiving it and raise objections to any discrepancies.

23

Warranty Policy

Disclaimer:
This manual does not come with any form of warranty, position expression or other implication. The products, specifications and information mentioned in this manual are for reference only, and the content will be updated on the website at any time without prior notice.
Warranty statement:
The following guarantee is made for the products attached to this document: If the product is damaged due to quality defects under normal use within twelve (12) months from the date of your purchase (the "Warranty Period"), and if it can be repaired, it will be repaired free of charge; If the manufacturer confirms that it cannot be repaired, it will be replaced free of charge; the repaired product will continue to be covered by the warranty for the remaining warranty period; a minimum of not less than 30 days). The purchase date shall be based on the sales invoice date; if the purchase date cannot be determined, the warranty period shall be calculated as thirteen (13) months from the product production date. If you want to apply for warranty, please call the product service hotline first and follow our instructions. When applying for a warranty, you are required to provide a valid sales invoice that is accurate, complete and clearly filled out.

24

Guidelines for safe and effective use

Note: Please read this information first before using your Bluetooth headset. If the user makes modifications or modifications to this Bluetooth headset without permission, the user will lose the right to continue to enjoy the services mentioned in the device.
① Electromagnetic Interference:
Electronic devices: To avoid the effects of electromagnetic interference or configuration incompatibility, please turn off your Bluetooth device in accordance with regulations in places with clear instructions.
Civil Aviation: After boarding the plane, please turn off your Bluetooth headset according to the flight attendant's instructions. It is strictly prohibited to use Bluetooth headsets during flight to avoid interference with the aircraft communication system.
② Safety matters:
Placement: It is recommended that when you are not using the Bluetooth headset, place it in a place where it will not be squeezed. Squeezing may cause damage to the product or personal injury. Children: Do not let children play with Bluetooth headsets. Some of the small parts are detachable and may be swallowed and cause danger.


25

Important safety tips

- Except for the operation methods specifically marked in the manual, please do not attempt to disassemble or replace any parts in the product.
- This product contains a built-in rechargeable battery. It is prohibited to hit, squeeze, puncture, or short-circuit the battery. If there are abnormal phenomena such as excessive temperature, deformation, bulging or leakage, please stop using it. Do not expose the battery to open flames or sunlight. Do not use the battery after it has been immersed in water or in high-temperature or high-pressure environments such as the sun, heaters, or stoves. After using the earphones, do not place the earphones in a humid, dusty, oily smoke, steam, direct sunlight or other high-temperature and high-humidity environment. The battery can be charged and discharged for a limited number of times and will eventually age. If the battery is used abnormally, and discharged properly, there is a risk of explosion. It can only be replaced by an after-sales service provider of the same or equivalent type, battery usage.
- After the product is used and scrapped, do not throw the product into a fire. The waste should be disposed of in strict accordance with the garbage classification. Please use this product reasonably and correctly to avoid causing certain injuries and environmental damage.
- During the use of headphones, due to long distances, obstacles in the middle, or a series of interferences such as other radio signals, Bluetooth signals, WiFi signals, etc., the headphones are used when listening to music, watching videos, playing games, etc., there will be occasional lags, voice out-of-sync or disconnection. If this happens, please reconnect the headphones or stay away from interference.
- When charging, please use a charging device with an output voltage of DC 5V/1A. You must choose a charging device from a regular manufacturer that has obtained CCC safety certification. Do not use a fast-charging charger to avoid excessive battery load, which may cause the battery is damaged. Do not charge continuously for longer than the specified charging time. Do not use it while charging to avoid damage.


26

Enjoy the company of MINISO



27

Creating sound to live with



28