

尺寸:140*210mm



封底

封面

Contents	
1. Safety Instructions	1
2. Introducing Your Cat to the New Litter Box	2
3. Product Package (Accessory Display)	3
4. Components	4
4.1 Control Panel	5
4.2 Clock Panel	5
4.3 Product Dimensions	5
5. How to Use	6
5.1 Let's Setting Up	6
5.2 App Connection and Use	10
5.3 How Does it Work?	11
5.4 Control Panel Functions	13
5.5 App Functions	16
6. Maintenance (Empty Mode)	18
7. Status Indicator & Common Questions	20
8. Product Specifications	22

4. Press the button to open the litter drawer and fill it with cat litter.	5. Connect the power cord to the device and plug the adapter to power outlet. Press the power button to turn on the device.	For cats that urinate vertically	5.2 App Connection and Use	5.3 How Does it Work?	By default, sleep mode is set from 10:00 PM to 6:00 AM. You can enable or disable sleep mode through the control panel of the device. You can also adjust this period in the app. Please note that sleep mode can only be scheduled for future time periods.	5.4 Control Panel Functions	If you do not want to be disturbed by the device's cleaning noise during a specific time period, you can enable sleep mode. You can set the specific time period in the app. Once set, you can enable or disable sleep mode through the app or by tapping this button.
Ensure the litter is filled between the MAX and MIN lines. ▲ Use clumping litter only. Avoid tofu litter that is longer than 7mm.	▲ Only use the official adapter provided.	1. Clean the inner surface of the litter drawer. Push the drawer back into place and ensure it is securely locked.	1. Scan the QR code to download and install.	▲ Cleaning process	Tip: During sleep mode, do not perform any operations, as the device will automatically disable sleep mode.	Power/Clean button	Light ring/ reset button
Ensure the area around the drawer is clean. If the drawer won't lock because the buckle is stuck, contact customer service for assistance.		2. Access the sealing sticker through the safety door, peel off the white backing paper, and press the sticker firmly onto the surface.	2. Open the app, register an account, add the device, and follow the instructions to set up.	▲ Cat protection	▲ Empty mode	Power ON	Light ring is ON
5. Place the litter drawer back into position until you hear a "click" sound, indicating it's securely locked.		▲ Important: There is a pre-installed 3M anti-leakage sticker on each side of the globe. Ensure these stickers are not dislocated when putting the drawer back in place.	3. Ensure you use a 2.4 GHz Wi-Fi network for connection.	During the cleaning, the safety door closes and only reopens once cleaning is complete—keeping curious cats from peeking in. If the door senses any nudges, you'll get an app notification, so you're always up-to-date on your cat's activity. If the cat attempts to enter and forces to open the safety door while it's in cleaning, the rake will pause immediately and open the door for the cat. You will see the light ring in yellow-green, means that the cleaning cycle is interrupted. It will only resume the cleaning 3 seconds after it detects the cat's exit.	After cleaning, press the empty button again to exit empty mode, then press the power button to turn the device back on. Or switch from empty mode to standby mode on the app to turn on the device.	Power OFF	Light ring is OFF
		Tip: Your package includes 4 extra sealing stickers for the front edge and 2 additional 3M anti-leakage stickers for the sides of the globe. Replace them as necessary.	4. Press and hold the Power and Sleep buttons until you hear a beep, then release. Confirm the indicator is flashing.	▲ Sleep mode	▲ UV light	Sleep button	Empty button
			Complete the pairing process within 3 minutes; otherwise, you will need to re-enter pairing mode by pressing the Power + Sleep buttons.	When sleep mode is enabled, the safety door remains open, but the device will not automatically clean after your cat uses the litter box. When sleep mode ends, the device will enter clean mode for a full clean.	▲ Emergency	Sleep mode is ON	
			Follow the instructions on your phone to continue the setup		In case of emergency, manually push open the safety door for immediate access.	Sleep mode is OFF	

• Wi-Fi connection	5.5 App Functions	Abnormal Alerts	6. Maintenance	7. Status Indicator & Common Questions	Common Problems and Solutions	8. Product Specifications
When connecting to Wi-Fi, the Wi-Fi indicator Flash. Once connected, the Wi-Fi indicator Stay on.	Light Ring: Turn the light ring on or off.	1. Daily maintenance	1. Daily maintenance	Color: Status: Reasons	Q1: The rake does not operate after entering clean mode, and the drawer is not cleaned when the safety door is opened.	Rated voltage (V): DC12V
Long press the Power + Sleep buttons together to enter pairing mode.	Cleaning Up: Tap to enable clean mode, and the rake will run twice.	2. Empty Mode	2. Empty Mode	Blue: Standby mode	A1: First, wipe the sensor points with a clean cloth.	Rated frequency (Hz): /
For more flexible control, connect the device to the app. Long press the Power + Sleep buttons to enter pairing mode. Once paired successfully, you can control the device through the app.	Standby Mode: Tap to enter standby mode.	Put the device into empty mode via the app or control panel. After the rake reaches the rear position and stops, unplug the power.	Remove the anti-odor plate.	Flash: The safety door is opening or closing.	Q2: During clean mode, a red light flashes suddenly, and the drawer is pushed out.	Rated power (W): 9.6W
• Time panel settings	Recent Activities: Tap to view recent activities.	Remove the anti-odor plate.	Press both sides of the rake to remove it.	Green: Flash: Cleaning in progress.	A2: Press the button again, push the drawer back, and ensure it is accurately locked.	
1) Long press "+" or "-" for 3 seconds to enter time setting mode.	UV Light Sterilization: Tap to enable UV light sterilization, and tap again to disable it. Set the sterilization time in "More Settings".	Press the anti-leakage sticker.	Peel off the anti-leakage sticker, then pull out and empty the litter drawer.	Yellow-Green: Flash: The safety door is opened during cleaning. When no object is detected inside, the safety door automatically closes.	Q3: During clean mode, the rake stops at the waste bin and does not return to its original position.	
2) When the hour hand is flashing, long press "+" or "-" again for 3 seconds to switch to the minute setting. The minute hand flashes, press "+" to increase by one minute, or press "-" to decrease by one minute.	Mode Switching: Tap to enter standby mode.	Press the anti-leakage sticker.		Purple: Flash: The drawer is not properly installed, and the sensor has not detected the trigger point.	A3: Check if a trash bag is blocking the start and end sensors of the device. Once the obstruction is cleared, the rake will automatically return to its original position.	
3) When the minute hand is flashing, long press "+" or "-" for 3 seconds to exit the time setting mode.	Empty Mode: Tap to enter empty mode.	Press the anti-leakage sticker.		Red: Flash: The rake cannot clean properly due to main motor malfunctions or because it has not reached the correct position for an extended period.	Q4: After plugging in the power, pressing any button only results in a "beep" sound, and the device neither closes the safety door nor starts cleaning.	
	Standby Mode: Tap to enter standby mode.	Press the anti-leakage sticker.		Flash rapidly: Other device malfunctions.	A4: Contact our customer service immediately and send a video of the issue for personal assistance.	

Warranty Exclusions	FCC Warning
The warranty does not cover the following including but not limited to: <ul style="list-style-type: none">• Lack of a valid invoice or expiration of the service period.• Damage caused by non-compliance with the instructions for usage, maintenance, or storage of the product in the user manual.• Damage caused by force majeure events such as fire, lightning, and flood.• Discrepancies between the product model and serial number on the warranty card and the actual product.• Damage from disassembly or repair by unauthorized service providers.• Normal fading, wear, and tear during product usage.• Damage caused by improper use by humans or pets.	This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause unintended operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment uses frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur, which can be determined by whether the equipment causes off and on. The user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/television technician for help. This equipment complies with FCC's radio frequency limits set forth for an unlicensed transmitter. This equipment should be installed and operated with minimum distance 30cm between the radiator & your body.