

# Cover

120mm

COMPAQ

## All-In-One Computer User Manual

QA27R5GW16256W



Please read the product instruction manual carefully before using this product and save it for future reference.  
The pictures in this product's instruction manual are only schematic illustrations.


180mm

Thank you for choosing and using our products; please check whether the outer packaging is intact before unpacking, and after unpacking, check whether the machine in the box is intact and whether the accessories are complete, if you have any questions, please contact your local dealer as soon as possible.

### Packing List

| AIO PC      | Adapter       | Stand | Keyboard |
|-------------|---------------|-------|----------|
| User Manual | Adapter Cable | Base  | Mouse    |

### Schematic diagram of all-in-one computer and its accessories



#### Remark:

- 1. Any changes or modifications not approved by the authorized agency may prevent the user from operating this product.
- 2. Only certified power supply, shielded signal lines and AC power lines must be used.
- 3. The manufacturer is not responsible for radio or electromagnetic interference caused by any unapproved modifications, and the user is responsible for such interference.

#### Warning:

To prevent fire or explosion, do not expose the product to rain or moisture. There are dangers inside the product.  
Do not open the case due to the high voltage. If repairs are needed, please contact professional maintenance personnel.

#### If the following happens

- There is a power outage or unstable voltage.
- There is an unusual noise or smell inside the machine.
- The AC power cable is damaged.
- The unit has been damaged due to falling, knocking or impact.
- Any liquid or foreign objects have fallen into the cabinet.



Immediately turn off the computer and then the power plug. If the power plug is not convenient to connect to, For Class I equipment, a power plug with protective earthing must be used and connected to the grid. When installing in a building, please confirm that the power distribution system should be able to provide circuit breakers with a rated voltage of 120/240V maximum 1.8A.

- For use only with included power adapter

Page 2



### Precautions

- Do not place product near water sources such as bathrooms, dishwashers, kitchens, washing machines, swimming pools, or in wet basements.
- Do not place the product on an unstable car, chair, or table. If the monitor falls, it will injure the user and may cause damage to the equipment.
- For placement on a car or chair, refer to the manufacturer or supplier's recommendations. If the product is fixed on the wall or shelf the fixed installation must be approved by the manufacturer and installed in strict accordance with the procedures.
- There are many narrow openings on the upper and lower parts of the back shell for ventilation. To ensure continued operation of the product without overheating, these openings must not be blocked or covered. Therefore, the product should not be placed on a bed, sofa, blanket or similar surface, nor should it be placed close to a radiator or heat source. Unless ventilation is ensured, it cannot be placed in a bookcase or box.
- The power supply voltage range for product operation is marked on the rear case label. If the supply voltage is about the supplied voltage, please contact the dealer or the local power company.
- This product is equipped with a three-prong grounding plug with one end connected to ground. For safety reasons, plug should into a grounded electrical outlet. If the three-prong plug does not fit into your outlet, have an electrician install one. The safety function of the grounded plug does not alter the safety function of the equipment.
- When the product is not used for a long time, please cut off the power supply. Doing so will prevent electric shock and damage caused by abnormal power supply voltage during thunderstorms.
- Do not overload the socket as this may cause fire or electric shock.
- Do not put foreign objects into the machine as it may cause a short circuit and lead to fire or electric shock.
- The rear case cannot be opened to avoid exposure to high voltage or other dangers. If there is a fault, please contact the after-sales service personnel directly.
- Please connect the power cord into the nearest power outlet as it is more convenient to connect to. For Class I equipment, a power plug with protective earthing must be used and connected to the grid. When installing in a building, please confirm that the power distribution system should be able to provide circuit breakers with a rated voltage of 120/240V maximum 1.8A.


- When the product is not used for a long time, please cut off the power supply. Doing so will prevent electric shock and damage caused by abnormal power supply voltage during thunderstorms.
- Do not overload the socket as this may cause fire or electric shock.
- Do not put foreign objects into the machine as it may cause a short circuit and lead to fire or electric shock.
- The rear case cannot be opened to avoid exposure to high voltage or other dangers. If there is a fault, please contact the after-sales service personnel directly.
- Please connect the power cord into the nearest power outlet as it is more convenient to connect to. For Class I equipment, a power plug with protective earthing must be used and connected to the grid. When installing in a building, please confirm that the power distribution system should be able to provide circuit breakers with a rated voltage of 120/240V maximum 1.8A.

Page 3

### Port Description



### Button Function Description



### Simple Operation

When we need to use the computer:

1. The power cord needs to be connected to the AC power socket.
2. Connect the DC plug on the adapter to the computer's power DC input interface.
3. Press the power switch to turn on the computer.

When you have finished using your computer:

1. We can press the power switch to shut down.
2. Or click the Start menu, then select Shut down computer, and finally click "Shut down (U)." to shut down.

If the computer cannot shut down normally, or we need to shut down in an emergency, we can press the power switch until the system automatically powers down. However, it should be noted that when the computer is accessing or reading and writing data, do not use emergency shutdown to avoid data loss or damage.

### Wall Mounting Instructions

This product can use 100mmx100mm or 75mmx75mm VESA wall mounting bracket. The threaded holes of 4 M4 VESA wall-mounting fixing screws are 8mm deep. (Applicable to models with wall-mounting function) If wall-mounting is required, please be sure to contact the manufacturer.

Page 4

# Back Cover

### Simple Troubleshooting

#### 1.The unit has no display.

If the power supply is not connected properly, please unplug and plug the power cord again to ensure that the power supply is in full contact with the socket.

If you touch the power off button, please press the power button briefly to turn the screen back on.

If determining whether the product is in sleep state, tap the "power button", "REST" button, or move the key/mouse to wake up from sleep and display the screen.

#### 2. There is no sound output from the speaker.

If the volume is too low, please adjust the volume on this machine. Please click the volume icon, increase the volume, and then OK.

If after unplugging the headset, the external speaker sound will automatically switch to silent. After unplugging the headset, the sound will be OK.

3. The running program cannot be ended normally.

If the program is stuck in the memory, causing the machine to freeze. Please press: Ctrl+Alt+Delete at the same time to start any tasks.

Open the task manager, select the program you want to close, and click End Task.

#### 4. The machine does not respond when performing any operations.

If the machine is running too hot, applying heat to the machine to freeze/stuck. Please power off the computer, turn off the power, and then turn it on again.

#### 5. The computer freezes when starting up, or the audio/video freezes.

When turning on the computer, please do not insert a "U" disk or removable hard disk into this product. Virus in the "U" disk or removable hard disk may cause the board to freeze or fail to boot.

If the computer freezes when reading audio/video from an external device, please unplug the external device (containing viruses).

#### 6. USB has no function.

Please check whether your USB device is normal.

Please check whether your USB device is properly connected to this device.

Please check whether your USB device is recognized normally under the operating system.

If the USB external interface cannot be read. Please plug it into the USB interface on the motherboard to be read.

Please confirm whether the USB driver in the operating system is normal.

If the USB still has no function after confirming the above points, please contact your local service center or the manufacturer's customer service department.

#### 7. Unable to access the Internet.

If you are using a wired network, please confirm whether your network cable is connected properly and whether it is normal.

If you are using a wireless network, please check whether the local wireless network is turned on and connected.

Please confirm whether your product is within the wireless network coverage.

Page 6


### Installation Bracket Base and Precautions



1. Take out the monitor, stand base and other accessories.



2. Install the bracket on the host.




3. Attach the base to the stand.




4. After installation is complete, place the all-in-one computer upright.




5. Turn on the computer.



6. Turn on the monitor.



7. Turn on the computer.



8. Turn on the monitor.



9. Turn on the computer.




10. Turn on the monitor.



11. Turn on the computer.



12. Turn on the monitor.



13. Turn on the computer.



14. Turn on the monitor.



15. Turn on the computer.



16. Turn on the monitor.



17. Turn on the computer.



18. Turn on the monitor.



19. Turn on the computer.



20. Turn on the monitor.



21. Turn on the computer.



22. Turn on the monitor.



23. Turn on the computer.



24. Turn on the monitor.



25. Turn on the computer.



26. Turn on the monitor.



27. Turn on the computer.



28. Turn on the monitor.



29. Turn on the computer.



30. Turn on the monitor.



31. Turn on the computer.



32. Turn on the monitor.



33. Turn on the computer.



34. Turn on the monitor.



35. Turn on the computer.



36. Turn on the monitor.



37. Turn on the computer.



38. Turn on the monitor.



39. Turn on the computer.



40. Turn on the monitor.



41. Turn on the computer.



42. Turn on the monitor.



43. Turn on the computer.



44. Turn on the monitor.



45. Turn on the computer.



46. Turn on the monitor.



47. Turn on the computer.



48. Turn on the monitor.



49. Turn on the computer.



50. Turn on the monitor.



51. Turn on the computer.



52. Turn on the monitor.



53. Turn on the computer.



54. Turn on the monitor.



55. Turn on the computer.



56. Turn on the monitor.



57. Turn on the computer.



58. Turn on the monitor.



59. Turn on the computer.



60. Turn on the monitor.



61. Turn on the computer.



62. Turn on the monitor.



63. Turn on the computer.



64. Turn on the monitor.



65. Turn on the computer.



66. Turn on the monitor.



67. Turn on the computer.

